LG
Life's Good

ไทย
ENGLISH

คู่มือการใช้
User Guide

LG-D958

MFL68281301 (1.0)

www.lg.com

ไทย

คู่มือการใช้

- ภาพหน้าจอและภาพประกอบอาจแตกต่างจากที่คุณพบในโทรศัพท์จริง
- ข้อมูลบางอย่างในคู่มือเล่มนี้อาจไม่สามารถใช้ได้กับโทรศัพท์ของคุณ ขึ้นอยู่กับโทรศัพท์ ซอฟต์แวร์ของโทรศัพท์ หรือผู้ให้บริการของคุณ ข้อมูลทั้งหมดในเอกสารนี้เปลี่ยนแปลงได้โดยไม่ต้องแจ้งให้ทราบล่วงหน้า
- โทรศัพท์รุ่นนี้ไม่เหมาะสำหรับผู้พิการทางสายตาเนื่องจากมีแป้นพิมพ์บนหน้าจอสัมผัส
- ลิขสิทธิ์ ©2014 LG Electronics, Inc. สงวนลิขสิทธิ์ LG และโลโก้ LG เป็นเครื่องหมายการค้าจดทะเบียนของ LG Group และหน่วยงานที่เกี่ยวข้อง เครื่องหมายการค้าอื่นๆ ทั้งหมดเป็นสมบัติของเจ้าของนั้นๆ
- Google™, Google Maps™, Gmail™, YouTube™, Hangouts™ และ Play Store™ เป็นเครื่องหมายการค้าของ Google, Inc.

สารบัญ

คำแนะนำเพื่อความปลอดภัยและการใช้งานอย่างมีประสิทธิภาพ.....5

ข้อความประกาศสำคัญ 13

เริ่มทำความรู้จักกับโทรศัพท์ของคุณ..20

ภาพรวมโทรศัพท์ 20

การใส่การ์ด micro-USIM 22

การชาร์จโทรศัพท์ 23

การล็อคและปลดล็อคหน้าจอ.....24

เปิดหน้าจอ.....24

ชุดหูฟังสเตอริโอพร้อมไมโครโฟน .25

Plug & Pop.....26

หน้าจอหลักของคุณ 27

เคล็ดลับสำหรับหน้าจอสัมผัส.....27

หน้าจอหลัก.....28

หน้าจอหลักย่อย 28

การปรับแต่งหน้าจอหลัก.....29

การกลับไปที่แอปพลิเคชันที่เพิ่งใช้ล่าสุด 30

พาเนลการแจ้งเตือน.....30

การเปิดพาเนลการแจ้งเตือน.....31

ไอคอนสัญลักษณ์บนแถบสถานะ...31

แป้นพิมพ์บนหน้าจอ 33

การป้อนตัวอักษรที่ใช้สำหรับเน้นเสียง.33

การตั้งค่าบัญชี Google 34

การเชื่อมต่อกับเครือข่ายและอุปกรณ์.35

Wi-Fi.....35

การเชื่อมต่อกับเครือข่าย Wi-Fi.....35

การเปิด Wi-Fi และการเชื่อมต่อกับเครือข่าย Wi-Fi35

Bluetooth 36

ารแบ่งปันการเชื่อมต่อข้อมูลในโทรศัพท์ 37

Wi-Fi Direct 39

SmartShare 39

เพลิดเพลินกับเนื้อหาจากอุปกรณ์ข้างเคียง 40

การเชื่อมต่อคอมพิวเตอร์ด้วยสายเคเบิล USB 40

การโทร 42

การโทรออก.....42

การโทรออกโดยใช้รายชื่อ 42

การรับสายและการปฏิเสธสายเรียกเข้า 42

การปรับระดับเสียงสนทนา.....43

การใช้สายที่สอง.....43

การดูบันทึกการโทร 43

ตั้งค่าการโทร 44

รายชื่อ.....45

การค้นหารายชื่อ 45

การเพิ่มรายชื่อใหม่.....45

รายชื่อเพื่อนสนิท.....45

การสร้างกลุ่ม 46

ข้อความ.....47

การส่งข้อความ.....47

กล่องเธรด 48

การเปลี่ยนการตั้งค่าข้อความมัลติมีเดีย 48

อีเมล 49
การจัดการแอคเคาท์อีเมล 49
การทำงานกับโฟลเดอร์แอคเคาท์ 49
การเขียนและส่งอีเมล 50

กล้องถ่ายรูป.....51
ทำความรู้จักกับช่องมองภาพ.....51
การใช้การตั้งค่าขั้นสูง 52
การถ่ายภาพด่วน 53
ใช้โหมดถ่ายภาพและล้างภาพ 53
ใช้โหมดกล้องคู่.....54
การใช้โหมด Time catch shot ..54
เมื่อคุณถ่ายภาพแล้ว 55
จากแกลเลอรี่ของคุณ.....56

กล้องวิดีโอ 57
ทำความรู้จักกับช่องมองภาพ.....57
การใช้การตั้งค่าขั้นสูง 58
การบันทึกวิดีโออย่างรวดเร็ว.....59
หลังการบันทึกวิดีโอ 59
จากแกลเลอรี่ของคุณ.....60
การปรับระดับเสียงขณะดูวิดีโอ ...60
การใช้ซูมเสียง 60
การใช้โหมดบันทึกโหมดคู่ 61
การใช้โหมดซูมติดตามวัตถุ 61

ฟังก์ชัน.....62
QuickMemo 62
การใช้ตัวเลือก QuickMemo 63
การดู QuickMemo ที่บันทึกไว้ 63

QuickTranslator.....64
QSlide.....65
QTheater 66
QuickRemote.....66
ซูมแบบติดตาม.....68
VuTalk 69
ลงทะเบียน VuTalk ก่อนใช้.....69
ตั้งค่า VuTalk 69
สื่อสารด้วยภาพผ่าน VuTalk 70
LG SmartWorld.....70
วิธีการเข้าสู่ LG SmartWorld จากโทรศัพท์ของคุณ.....70
วิธีการใช้ LG SmartWorld.....71
On-Screen Phone 72
ไอคอน On-Screen Phone.....72
คุณสมบัติ On-Screen Phone 72
วิธีติดตั้ง On-Screen Phone ในคอมพิวเตอร์.....73

มัลติมีเดีย.....74
แกลเลอรี่ 74
การดูรูปภาพ 74
การเล่นวิดีโอ 74
การแก้ไขภาพถ่าย.....74
การลบภาพถ่าย/วิดีโอ.....75
การตั้งค่าเป็นภาพพื้นหลัง 75
วิดีโอ.....75
การเล่นวิดีโอ 76
เพลง.....77
เพิ่มไฟล์เพลงในโทรศัพท์ของคุณ .77
ถ่ายโอนเพลงโดยใช้ซิงค์มีเดีย (MTP).....77

สารบัญ

การเล่นเพลง 77

ยูทิลิตี 80
ลื่อนไปด้านข้าง (การสลับงานอย่างรวดเร็วด้วยนิ้วสามนิ้ว) 80
หน้าต่างคู่ 80
โหมด Guest.....81
การตั้งเวลาการปลุก 81
การใช้เครื่องคิดเลข 82
การเพิ่มเหตุการณ์ลงในปฏิทิน 82
บันทึกเสียง 83
การบันทึกเสียงหรือเสียงพูด 83
การส่งรายการบันทึกเสียง 83
จัดการแอปฯ 83
การทำงาน 84
POLARIS Viewer 5.....84
Google+ 85
ค้นหาด้วยเสียง.....85
ดาวน์โหลด 85

เว็บไซต์ 86
อินเตอร์เน็ต 86
การใช้แถบเครื่องมือเว็บ 86
การดูเว็บเพจ.....86
การเปิดเพจ 87
การค้นหาเว็บด้วยเสียง.....87
บุ๊คมาร์ก.....87
ประวัติ 87
Chrome.....88
การดูเว็บเพจ.....88
การเปิดเพจ 88
การซิงค์กับอุปกรณ์อื่น 88

ตั้งค่า.....89
เครือข่าย 89
เสียง 92
หน้าจอ 94
ทั่วไป 96

ซอฟต์แวร์คอมพิวเตอร์ (LG PC Suite) 103

อัปเดตซอฟต์แวร์โทรศัพท์.....106
อัปเดตซอฟต์แวร์โทรศัพท์ 106

เกี่ยวกับคู่มือผู้ใช้นี้ 108
เกี่ยวกับคู่มือผู้ใช้นี้.....108
เครื่องหมายการค้า.....109
DivX HD 109
Dolby Digital Plus.....109

อุปกรณ์เสริม 111

การแก้ปัญหา.....112

คำถามที่พบบ่อย 115

คำแนะนำเพื่อความปลอดภัยและการใช้งานอย่างมีประสิทธิภาพ

โปรดอ่านคำแนะนำเบื้องต้นต่อไปนี้ การไม่ปฏิบัติตามคำแนะนำเหล่านี้อาจทำให้เกิดอันตรายหรือผิดกฎหมาย
ในกรณีที่เกิดความผิดพลาด เครื่องมือซอฟต์แวร์ที่อยู่ในอุปกรณ์ของคุณจะเก็บรวบรวมบันทึกความผิดพลาด เครื่องมือนี้รวบรวมเฉพาะข้อมูลเกี่ยวกับความผิดพลาด เช่น ความแรงของสัญญาณ ตำแหน่ง ID เซลล์ในกรณีสายหลุด และแอปพลิเคชันที่โหลด บันทึกจะถูกใช้เพื่อช่วยในการตรวจสอบสาเหตุของความผิดพลาดเท่านั้น บันทึกเหล่านี้จะถูกเข้ารหัสและสามารถเข้าถึงได้โดยศูนย์บริการ LG ที่ได้รับอนุญาตเท่านั้น ในกรณีที่คุณต้องส่งคืนอุปกรณ์เพื่อซ่อมแซม

การรับพลังงานคลื่นความถี่วิทยุ

ข้อมูลเกี่ยวกับการรับพลังงานคลื่นความถี่วิทยุและค่า SAR (Specific Absorption Rate)
โทรศัพท์มือถือรุ่น LG-D958 นี้ ได้รับการออกแบบตรงตามข้อกำหนดเรื่องความปลอดภัยในการใช้งานอันเกี่ยวกับการรับพลังงานคลื่นความถี่วิทยุ ข้อกำหนดนี้ใช้หลักเกณฑ์ทางวิทยาศาสตร์ที่รวมถึงการกำหนดค่าเผื่อไว้ทั้งนี้เพื่อความปลอดภัยของทุกคน โดยไม่ขึ้นกับอายุและสุขภาพ

- ข้อกำหนดเกี่ยวกับการรับพลังงานคลื่นความถี่วิทยุใช้หน่วยวัดที่เรียกว่า Specific Absorption Rate (SAR) การทดสอบ SAR ได้กระทำด้วยการใช้วิธีการที่ได้มาตรฐาน โดยให้เครื่องโทรศัพท์ส่งสัญญาณที่แรงที่สุดและมีการรับรองขนาดสัญญาณแล้ว โดยการส่งสัญญาณดังกล่าวได้กระทำในทุกย่านความถี่ที่โทรศัพท์ใช้อยู่
- แม้ว่าระดับ SAR ของโทรศัพท์ LG แต่ละรุ่นจะแตกต่างกันบ้าง แต่ทุกรุ่นจะได้รับการออกแบบให้อยู่ภายในข้อกำหนดการรับพลังงานคลื่นความถี่วิทยุ
- ข้อจำกัด SAR ที่แนะนำโดย International Commission on Non-Ionizing Radiation Protection (ICNIRP) คือ 2 วัตต์/กก. โดยเฉลี่ยตามเนื้อเยื่อของร่างกายที่หนัก 10 กรัม
- ค่า SAR สูงสุดสำหรับโทรศัพท์รุ่นนี้ ซึ่งทำการทดสอบขณะถือแนบกับหูคือ 0.381 วัตต์/กก. (10 กรัม) และเมื่อพกพาไว้กับตัวคือ 0.405 วัตต์/กก. (10 กรัม)

คำแนะนำเพื่อความปลอดภัยและการใช้งานอย่างมีประสิทธิภาพ

- โทรศัพท์นี้ตรงตามมาตรฐานการดูดกลืนสัญญาณคลื่นความถี่วิทยุ (RF) เมื่อใช้งานตามปกติโดยถือแนบกับหู หรือขณะวางห่างจากร่างกายอย่างน้อย 1.5 ซม. เมื่อใช้กล่องโทรศัพท์สำหรับพกพา คลิปยึดเข็มขัดหรือที่ใส่โทรศัพท์ เพื่อการใช้งานแบบพกติดตัว อุปกรณ์เหล่านั้นไม่ควรเป็นโลหะและควรให้โทรศัพท์อยู่ห่างจากร่างกายอย่างน้อย 1.5 ซม. โทรศัพท์เครื่องนี้ต้องมีการเชื่อมต่อเครือข่ายที่มีคุณภาพสำหรับการส่งไฟล์ข้อมูลหรือข้อความ ในบางครั้งการส่งไฟล์ข้อมูลหรือการส่งข้อความอาจล่าช้าจนกว่าจะเชื่อมต่อเครือข่ายได้ ตรวจสอบให้แน่ใจว่าได้ปฏิบัติตามคำแนะนำเกี่ยวกับระยะห่างดังกล่าวข้างต้น จนกว่าจะส่งข้อมูลเสร็จสิ้น

การดูแลและการบำรุงรักษาผลิตภัณฑ์

⚠ **คำเตือน**
ใช้แบตเตอรี่ อุปกรณ์ชาร์จ และอุปกรณ์เสริมที่ผ่านการรับรองให้ใช้กับโทรศัพท์รุ่นนี้เท่านั้น การใช้อุปกรณ์ประเภทอื่นๆ อาจทำให้การรับรองหรือการรับประกันของเครื่องสิ้นสุดลง หรือก่อให้เกิดอันตรายได้

- ความยืดหยุ่นของผลิตภัณฑ์นี้จำกัดเฉพาะความทนทานในการใช้งานตามปกติทั่วไป โทรศัพท์สามารถงอได้สูงสุด 180 องศาในเวลาที่จำกัด แต่ไม่ควรจะงอเข้า ความเสียหายซึ่งเกิดจากการใช้งานที่ไม่ถูกต้อง รวมถึงแต่ไม่จำกัดเพียง การงอโดยตั้งใจหรือการกระทำรุนแรงกับผลิตภัณฑ์อย่างต่อเนื่อง อาจนำไปสู่ความเสียหายอย่างถาวรของหน้าจอและหรือส่วนและฟังก์ชันอื่นๆ ของโทรศัพท์
- อย่าถอดแยกชิ้นส่วนของเครื่องโทรศัพท์ ควรนำไปให้ช่างเทคนิคผู้มีความรู้เมื่อจำเป็นต้องมีการตรวจซ่อม
- การซ่อมแซมภายใต้การรับประกันเป็นการตัดสินใจของ LG ซึ่งอาจรวมถึงการเปลี่ยนชิ้นส่วนหรือแผงวงจรที่เป็นของใหม่หรือของที่ปรับสภาพโดยมีประสิทธิภาพในการทำงานเทียบเท่าชิ้นส่วนที่ถูกเปลี่ยน
- ควรวางให้ห่างจากอุปกรณ์เครื่องใช้ไฟฟ้า เช่น ทีวี วิทยุ และเครื่องคอมพิวเตอร์

- ควรตั้งเครื่องไว้ห่างจากแหล่งความร้อน เช่น เครื่องระบายความร้อนหรือเตาประกอบอาหาร
- อย่าทำตก
- อย่านำเครื่องนี้ไว้ในที่ที่มีการสั่นสะเทือนหรือการกระแทก
- ปิดเครื่องโทรศัพท์ในบริเวณที่มีข้อบังคับพิเศษว่าห้ามใช้ ตัวอย่างเช่น ห้ามใช้โทรศัพท์ในโรงพยาบาล เนื่องจากอาจมีผลต่อการทำงานของอุปกรณ์ทางการแพทย์ที่ไวต่อสัญญาณรบกวน
- ห้ามสัมผัสโทรศัพท์ด้วยมือเปียก ขณะกำลังชาร์จแบตเตอรี่ เพราะอาจถูกไฟฟ้าดูดและอาจทำให้โทรศัพท์ชำรุดเสียหายได้
- ห้ามชาร์จโทรศัพท์ใกล้วัตถุไวไฟ เนื่องจากโทรศัพท์อาจร้อนและทำให้ติดไฟซึ่งอาจทำให้เกิดเพลิงไหม้
- ใช้ผ้าแห้งเช็ดทำความสะอาดภายนอกเครื่องโทรศัพท์ (อย่าใช้สารละลาย เช่น เบนซิน ทินเนอร์ หรือแอลกอฮอล์)
- อย่าชาร์จโทรศัพท์โดยวางไว้บนพื้นผิวอ่อนนุ่ม
- ควรชาร์จโทรศัพท์ในบริเวณที่มีการถ่ายเทอากาศดี
- อย่านำเครื่องนี้ไว้ในที่ที่มีฝุ่นหรือควันมากเกินไป
- อย่าวางโทรศัพท์ใกล้บัตรเครดิตหรือบัตรโดยสารที่มีแถบแม่เหล็ก เพราะอาจทำความเสียหายต่อข้อมูลในแถบแม่เหล็กได้
- อย่าเคาะหน้าจอด้วยวัตถุมีคม เพราะอาจทำความเสียหายแก่โทรศัพท์ได้
- วางเครื่องโทรศัพท์ให้ห่างจากของเหลวหรือความชื้น
- ใช้อุปกรณ์เสริม เช่น หูฟัง ด้วยความระมัดระวัง อย่าแตะต้องเสาอากาศโดยไม่จำเป็น
- ห้ามใช้ สัมผัส หรือพยายามถอดหรือซ่อมแซมแก้วที่แตก มีรอยแตก หรือร้าว ความเสียหายของหน้าจอแก้วเกิดขึ้นจากการใช้งานโดยไม่ได้รับอนุญาตหรือไม่ถูกต้องจะไม่ครอบคลุมภายใต้การรับประกัน
- โทรศัพท์ของคุณเป็นอุปกรณ์อิเล็กทรอนิกส์ที่มีความร้อนในระหว่างการทำงานปกติ การสัมผัสกับผิวโดยตรงเป็นระยะเวลานานโดยไม่มีการระบายอากาศหรือมีไม่เพียงพออาจทำให้รู้สึกไม่สบายหรือเกิดแผลไหม้เล็กน้อยได้

ดังนั้น ผู้ใช้ต้องระมัดระวังเมื่อถือโทรศัพท์ในระหว่างหรือทันทีหลังจากการใช้การ

- หากโทรศัพท์ของคุณเปียกน้ำ ให้ถอดปลั๊กทันทีเพื่อให้เครื่องแห้งสนิท ห้ามทำให้อุปกรณ์แห้งเร็วขึ้นโดยใช้แหล่งความร้อนภายนอก เช่น เตาอบ เตาไมโครเวฟ หรือเครื่องเป่าผม
- ของเหลวในโทรศัพท์ที่เปียกน้ำจะเปลี่ยนสีของฉลากผลิตภัณฑ์ในโทรศัพท์ ความเสียหายของอุปกรณ์ที่เป็นผลมาจากการสัมผัสกับของเหลวจะไม่ได้รับครอบคลุมภายใต้การรับประกัน

การทำงาน อย่างมีประสิทธิภาพของโทรศัพท์

อุปกรณ์อิเล็กทรอนิกส์

โทรศัพท์เคลื่อนที่ทุกเครื่องอาจได้รับผลจากคลื่นรบกวนได้ ทำให้มีผลต่อการทำงาน

- ห้ามใช้โทรศัพท์เคลื่อนที่ใกล้อุปกรณ์ทางการแพทย์โดยไม่ได้รับอนุญาตเสียก่อน หลีกเลี่ยงการวางโทรศัพท์เหนือเครื่องควบคุมจังหวะการเต้นของหัวใจ เช่น ใส่ในกระเป๋าเสื้อ เป็นต้น
- โทรศัพท์มือถือบางเครื่องอาจก่อให้เกิดสัญญาณคลื่นรบกวนกับเครื่องช่วยฟังได้
- ดังนั้น โทรทัศน์ วิทยุ เครื่องคอมพิวเตอร์ ฯลฯ อาจได้รับการรบกวนบ้างเล็กน้อย
- ใช้โทรศัพท์ของคุณในช่วงอุณหภูมิ 0ºC และ 40ºC หากเป็นไปได้ การปล่อยให้โทรศัพท์อยู่ในอุณหภูมิเย็นจัดหรือร้อนจัดอาจทำให้เกิดความเสียหาย ทำงานผิดพลาด หรือระเบิดได้

ความปลอดภัยบนท้องถนน

ตรวจสอบกฎหมายและระเบียบข้อบังคับว่าด้วยเรื่องการใช้โทรศัพท์เคลื่อนที่ในพื้นที่ที่คุณขับขี่ยานพาหนะ

- ห้ามใช้โทรศัพท์มือถือในขณะขับรถ
- มีสมาธิในการขับขี่ด้วยความระมัดระวังอย่างเต็มที่
- ขับเข้าข้างทาง แล้วจอดรถก่อนโทรออกหรือรับสาย หากสภาพการขับขี่ทำให้จำเป็นต้องดำเนินการดังกล่าว
- พลังงานคลื่นความถี่วิทยุอาจมีผลกระทบต่อระบบอิเล็กทรอนิกส์บางชนิดในรถของคุณ เช่น วิทยุติดรถยนต์ อุปกรณ์เพื่อความปลอดภัย เป็นต้น
- หากรถของคุณติดตั้งถุงลมนิรภัย ห้ามติดตั้งอุปกรณ์พกพาแบบไร้สายซึ่งขัดขวางการทำงานของถุงลม ซึ่งอาจทำให้ถุงลมไม่ทำงาน หรืออาจทำให้คุณได้รับบาดเจ็บรุนแรงเนื่องจากการทำงานผิดปกติของถุงลมนิรภัยได้
- หากคุณกำลังฟังเพลงในขณะอยู่ข้างนอก โปรดตรวจดูว่าระดับเสียงอยู่ที่ระดับที่เหมาะสม เพื่อให้คุณยังสามารถได้ยินเสียงจากรอบข้างได้ โดยเฉพาะอย่างยิ่งเมื่ออยู่ข้างถนน

หลีกเลี่ยงการทำลายความสามารถในการได้ยิน

เพื่อป้องกันการทำลายความสามารถในการได้ยินที่อาจเกิดขึ้นได้ ห้ามฟังเสียงที่ดังมากเป็นเวลานาน

ความสามารถในการได้ยินอาจถูกทำลายได้หากคุณฟังเสียงดังเป็นระยะเวลานาน ดังนั้น เราขอแนะนำว่า คุณไม่ควรเปิดหรือปิดหูฟังใกล้กับหูของคุณ นอกจากนี้ คุณควรตั้งระดับเสียงเพลงและระดับเสียงสายสนทนาไว้ในระดับที่เหมาะสม

- เมื่อใช้หูฟัง ให้ลดระดับเสียงลงหากคุณไม่ได้ยินเสียงพูดของคนข้างๆ หรือคนข้างๆ คุณได้ยินสิ่งที่คุณกำลังฟัง

หมายเหตุ: แรงดันเสียงที่มากเกินไปจากหูฟัง และชุดหูฟังสามารถทำให้สูญเสียการได้ยินได้

ส่วนที่เป็นแก้ว

บางส่วนของโทรศัพท์ของคุณทำมาจากวัสดุแก้ว ซึ่งส่วนที่เป็นแก้วนี้สามารถแตกได้หากโทรศัพท์ตกลงบนพื้นแข็ง หรือถูกกระแทก หากส่วนที่เป็นแก้วนี้แตก อย่าสัมผัส หรือพยายามดึงออก ให้หยุดใช้โทรศัพท์จนกว่าส่วนที่เป็นแก้วนี้จะได้รับการเปลี่ยนโดยผู้ให้บริการที่ได้รับการแต่งตั้ง

บริเวณที่ทำให้เกิดระเบิดได้

ห้ามใช้โทรศัพท์ในพื้นที่ที่อยู่ระหว่างมีการระเบิดต่างๆ ให้ปฏิบัติตามข้อห้ามอย่างเคร่งครัด และทำตามข้อกำหนดหรือกฎเกณฑ์ต่างๆ

บริเวณที่อาจเกิดการระเบิดได้

- ห้ามใช้โทรศัพท์ใกล้จุดเติมน้ำมันเชื้อเพลิง
- ห้ามใช้ใกล้น้ำมันเชื้อเพลิงหรือสารเคมี
- ห้ามขนถ่ายหรือเก็บก๊าซหรือของเหลวที่ติดไฟง่ายหรือระเบิดได้ในห้องโดยสารของรถ ซึ่งคุณใช้เก็บโทรศัพท์หรืออุปกรณ์เสริมต่างๆ ของคุณ

บนเครื่องบิน

อุปกรณ์ไร้สายสามารถก่อให้เกิดคลื่นรบกวนต่อเครื่องบินได้

- ให้ปิดโทรศัพท์มือถือของคุณก่อนขึ้นเครื่องบิน
- อย่าใช้โทรศัพท์เมื่อเครื่องบินจอดที่พื้นก่อนได้รับการอนุญาตจากพนักงานประจำเครื่อง

เด็ก

เก็บโทรศัพท์ในที่ปลอดภัยและห่างจากมือเด็ก รวมทั้งเก็บชิ้นส่วนขนาดเล็กซึ่งอาจทำอันตรายหากเด็กนำใส่ปาก

การโทรฉุกเฉิน

การโทรฉุกเฉินอาจไม่สามารถใช้กับเครือข่ายมือถือบางเครือข่ายได้ จึงไม่ควรใช้โทรศัพท์นี้เพียงอย่างเดียวในกรณีโทรฉุกเฉิน ให้ตรวจสอบกับผู้ให้บริการในพื้นที่ของคุณ

ข้อมูลเกี่ยวกับแบตเตอรี่และการดูแลรักษา

- คุณไม่จำเป็นต้องคายประจุแบตเตอรี่ออกจนหมดก่อนเริ่มการชาร์จ แบตเตอรี่นี้ต่างจากแบตเตอรี่อื่น เนื่องจากไม่มี Memory Effect ประสิทธิภาพของแบตเตอรี่จึงไม่ด้อยลง
- ใช้เฉพาะแบตเตอรี่และเครื่องชาร์จของ LG เท่านั้น เครื่องชาร์จของ LG ได้รับการออกแบบมาเพื่อยืดอายุการใช้งานของแบตเตอรี่ให้นานที่สุด
- อย่าถอดชิ้นส่วนหรือทำให้แบตเตอรี่ลัดวงจร
- เปลี่ยนแบตเตอรี่ก้อนใหม่ทันที เมื่อประสิทธิภาพการใช้งานลดต่ำลงจนถึงระดับที่ไม่อาจใช้งานต่อได้ แบตเตอรี่นี้สามารถชาร์จใหม่ได้หลายร้อยครั้งก่อนที่จะต้องเปลี่ยนก้อนใหม่
- ชาร์จแบตเตอรี่ใหม่อีกครั้ง หากไม่ได้ใช้เป็นเวลานานเพื่อเพิ่มเวลาการใช้งาน
- อย่าให้เครื่องชาร์จแบตเตอรี่โดนแสงแดดโดยตรง หรือใช้ในสภาพที่มีความชื้นสูง เช่น ในห้องน้ำ
- ควรปฏิบัติตามคำแนะนำของผู้ผลิตในการทิ้งแบตเตอรี่ที่ใช้แล้ว โปรดรีไซเคิลเมื่อเป็นไปได้ อย่าทิ้งเป็นขยะในครัวเรือน
- หากคุณต้องการเปลี่ยนแบตเตอรี่ โปรดนำไปที่จุดบริการหรือตัวแทนจำหน่ายที่ได้รับการแต่งตั้งจาก LG Electronics ที่ใกล้ที่สุดเพื่อขอความช่วยเหลือ
- ถอดปลั๊กอุปกรณ์ชาร์จออกจากเต้าเสียบทุกครั้งหลังจากแบตเตอรี่โทรศัพท์เต็มแล้วเพื่อลดการใช้พลังงานสิ้นเปลืองของอุปกรณ์ชาร์จ

คำแนะนำเพื่อความปลอดภัยและการใช้งานอย่างมีประสิทธิภาพ

- อายุการใช้งานแบตเตอรี่จะขึ้นอยู่กับการกำหนดค่าเครือข่าย, การตั้งค่าผลิตภัณฑ์, รูปแบบการใช้, แบตเตอรี่ และสภาพแวดล้อม
- ตรวจสอบให้แน่ใจว่าไม่มีวัตถุที่มีขอบแหลมคม เช่น ฟันหรือเล็บสัตว์ ตะปู สัมผัสกับแบตเตอรี่ ซึ่งอาจก่อให้เกิดไฟไหม้ได้
- เพื่อความปลอดภัยของคุณ ห้ามถอดแบตเตอรี่ที่อยู่ในผลิตภัณฑ์
- อย่าวางโทรศัพท์ทิ้งไว้ในสภาพอากาศที่ร้อนหรือเย็น เนื่องจากประสิทธิภาพของโทรศัพท์อาจด้อยลง
- อย่าเปลี่ยนแบตเตอรี่ด้วยตัวคุณเอง แบตเตอรี่อาจได้รับความเสียหาย ซึ่งอาจเป็นเหตุให้เกิดความร้อนเกินและการบาดเจ็บ แบตเตอรี่ต้องได้รับการเปลี่ยนโดยผู้ให้บริการที่ได้รับการแต่งตั้ง ควรรีไซเคิลและทิ้งแบตเตอรี่โดยแยกจากขยะในครัวเรือน

คำประกาศรับรอง

ดังนั้น **LG Electronics** ขอประกาศว่าผลิตภัณฑ์ **LG-D958** เป็นไปตามข้อกำหนดที่จำเป็น และข้อกำหนดที่เกี่ยวข้องอื่นๆ ของ Directive **1999/5/EC** คุณสามารถดูสำเนาของคำประกาศรับรองได้ที่ **http://www.lg.com/global/declaration**

ประกาศ: ซอฟต์แวร์โอเพ่นซอร์ส

ในการขอรับซอร์สโค้ดที่เกี่ยวข้องตาม GPL, LGPL, MPL และและใบอนุญาตโอเพ่นซอร์สอื่นๆ โปรดไปที่ http://opensource.lge.com/ เงื่อนไขใบอนุญาต การปฏิเสธการรับผิดชอบ และประกาศที่อ้างอิงถึงทั้งหมดสามารถดาวน์โหลดได้พร้อมกับซอร์สโค้ด

ข้อความประกาศสำคัญ

โปรดอ่านข้อความนี้ก่อนที่คุณจะเริ่มใช้งานโทรศัพท์!

โปรดตรวจสอบเพื่อดูว่าปัญหาที่คุณพบในโทรศัพท์ของคุณมีการอธิบายไว้ในส่วนนี้หรือไม่ ก่อนนำโทรศัพท์ไปขอรับการบริการหรือติดต่อตัวแทนฝ่ายบริการ

1. หน่วยความจำโทรศัพท์

เมื่อพื้นที่ว่างในหน่วยความจำโทรศัพท์น้อยกว่า 10% โทรศัพท์จะไม่สามารถรับข้อความใหม่ได้ คุณต้องตรวจสอบหน่วยความจำโทรศัพท์และลบข้อมูลบางอย่าง เช่น แอปพลิเคชันหรือข้อความเพื่อเพิ่มพื้นที่ว่างในหน่วยความจำ

การถอนการติดตั้งแอปพลิเคชัน:

1 แตะ > > แท็บ **แอปฯ** > **ตั้งค่า** > แท็บ **ทั่วไป** > **แอปฯ**
2 เมื่อแอปพลิเคชันทั้งหมดปรากฏขึ้น ให้เลื่อนและเลือกแอปพลิเคชันที่คุณต้องการยกเลิกการติดตั้ง
3 แตะ **ถอนการติดตั้ง**

2. การยืดอายุแบตเตอรี่

ยืดพลังงานแบตเตอรี่โดยการปิดคุณสมบัติที่คุณไม่ได้ให้ทำงานอย่างต่อเนื่องในแบ็คกราวด์ คุณสามารถตรวจสอบวิธีการใช้ไฟแบตเตอรี่ของแอปพลิเคชันและทรัพยากรระบบได้

การยืดอายุแบตเตอรี่ของโทรศัพท์:

- ปิดการสื่อสารทางสัญญาณวิทยุเมื่อคุณไม่ได้ใช้ ปิด Wi-Fi, Bluetooth หรือ GPS หากคุณไม่ได้ใช้งาน
- ลดความสว่างหน้าจอและตั้งค่าไทม์เอาต์หน้าจอให้สั้นลง
- ปิดการซิงค์อัตโนมัติของ Gmail, ปฏิทิน, รายชื่อ และแอปพลิเคชันอื่นๆ
- แอปพลิเคชันที่คุณดาวน์โหลดบางแอปพลิเคชันอาจลดกำลังไฟแบตเตอรี่
- ขณะใช้แอปพลิเคชันที่ดาวน์โหลดมา ให้ตรวจสอบระดับประจุแบตเตอรี่

ข้อความประกาศสำคัญ

หมายเหตุ: หากคุณโดนปุ่มเปิด/ปิด/ล็อค โดยไม่ได้ตั้งใจขณะโทรศัพท์อยู่ในกระเป๋า หน้าจอจะปิดอัตโนมัติเพื่อประหยัดพลังงานแบตเตอรี่

การตรวจสอบระดับกำลังไฟแบตเตอรี่:

- แตะ > >**แท็บ** แอปฯ > **ตั้งค่า** > **แท็บ** ทั่วไป > **เกี่ยวกับโทรศัพท์** > **แบตเตอรี่**

สถานะแบตเตอรี่ (กำลังชาร์จหรือกำลังคายประจุ) และระดับแบตเตอรี่ (เปอร์เซ็นต์ที่ชาร์จ) จะแสดงที่ด้านบนของหน้าจอ

การตรวจสอบและควบคุมการใช้กำลังไฟแบตเตอรี่:

- แตะ > > **แท็บ** แอปฯ > **ตั้งค่า** > **แท็บ** ทั่วไป > **เกี่ยวกับโทรศัพท์** > **แบตเตอรี่** > **การใช้แบตเตอรี่**

เวลาในการใช้แบตเตอรี่จะปรากฏขึ้นบนหน้าจอ โดยแสดงระยะเวลานับจากที่คุณเชื่อมต่อโทรศัพท์กับแหล่งจ่ายไฟครั้งสุดท้าย หรือหากเชื่อมต่ออยู่ในขณะนี้ จะแสดงระยะเวลานับจากที่โทรศัพท์ใช้พลังงานจากแบตเตอรี่ครั้งสุดท้าย หน้าจอจะแสดงรายการแอปพลิเคชันหรือบริการที่ใช้กำลังไฟแบตเตอรี่ โดยเรียงลำดับตามปริมาณที่ใช้จากมากไปน้อย

3. ก่อนการติดตั้งแอปพลิเคชันและ OS โอเพ่นซอร์ส

⚠ **คำเตือน**

หากคุณติดตั้งและใช้ OS อื่นนอกเหนือจากของผู้ผลิต อาจทำให้โทรศัพท์ของคุณทำงานผิดปกติได้ นอกจากนั้น โทรศัพท์ของคุณจะไม่ได้รับความคุ้มครองตามการรับประกัน

⚠ **คำเตือน**

เพื่อปกป้องโทรศัพท์และข้อมูลส่วนตัว ให้ดาวน์โหลดแอปพลิเคชันเฉพาะจากแหล่งที่เชื่อถือได้ เช่น Play Store™ เท่านั้น หากมีการติดตั้งแอปพลิเคชันไม่ถูกต้องในโทรศัพท์ โทรศัพท์อาจทำงานไม่ปกติหรือเกิดข้อผิดพลาดร้ายแรง คุณต้องถอนการติดตั้งแอปพลิเคชันเหล่านั้น และข้อมูลและการตั้งค่าที่เกี่ยวข้องทั้งหมดออกจากโทรศัพท์

4. การใช้แบบปลดล็อค

ตั้งค่าแบบปลดล็อคเพื่อป้องกันโทรศัพท์ของคุณ แตะ > > **แท็บ** แอปฯ > **ตั้งค่า** > แท็บ **หน้าจอ** > **ล็อคหน้าจอ** > **เลือกแบบล็อคหน้าจอ** > **รูปแบบ** ซึ่งจะเปิดหน้าจอที่แนะนำคุณสำหรับวิธีการวาดแบบปลดล็อคหน้าจอ คุณจะต้องสร้างแบ็คอัพ PIN เป็นมาตรการความปลอดภัย ในกรณีที่คุณลืมแบบปลดล็อค

ข้อควรระวัง: สร้างบัญชี Google ก่อนทำการตั้งค่าแบบปลดล็อค และจำแบ็คอัพ PIN ที่คุณได้สร้างไว้เมื่อสร้างล็อคแบบ

⚠ **คำเตือน**

ข้อควรระวังเมื่อใช้ล็อคแบบ

สิ่งสำคัญคือต้องจำแบบปลดล็อคที่คุณตั้งไว้ได้ คุณจะไม่สามารถเข้าใช้โทรศัพท์ของคุณได้หากคุณใช้แบบไม่ถูกต้อง 5 ครั้ง คุณมีโอกาสเพียง 5 ครั้ง ในการป้อนแบบการปลดล็อค PIN หรือรหัสผ่านของคุณ หากคุณทำการป้อนทั้งหมด 5 ครั้งแล้ว คุณสามารถลองใหม่ได้อีกครั้งหลังจากผ่านไป 30 วินาที

ในกรณีที่คุณลืมรูปแบบ, PIN หรือรหัสผ่านการปลดล็อคของคุณ:

< หากคุณลืมแบบของคุณ >

หากคุณล็อกอินบัญชี Google ในโทรศัพท์แต่ป้อนรูปแบบไม่ถูกต้อง 5 ครั้ง ให้แตะ **ลืมแบบ?** ที่ด้านล่างของหน้าจอ จากนั้น คุณจะต้องล็อกอินบัญชี Google ของคุณ หรือคุณต้องป้อนแบ็คอัพ PIN ที่คุณได้ป้อนไว้เมื่อสร้างล็อคแบบ

หากคุณไม่ได้สร้างบัญชี Google บนโทรศัพท์ หรือคุณลืมแบ็คอัพ PIN คุณต้องทำการ Hard Reset

< หากคุณลืม PIN หรือรหัสผ่านของคุณ >

หากคุณลืม PIN หรือรหัสผ่านของคุณ คุณจะต้องทำ Hard Reset

ข้อควรระวัง: หากคุณทำ Hard Reset แอปพลิเคชันผู้ใช้และข้อมูลผู้ใช้ทั้งหมดจะถูกลบ

หมายเหตุ: หากคุณยังไม่ได้ล็อกอินบัญชี Google ของคุณและลืมแบบปลดล็อค คุณจะต้องป้อนแบ็คอัพ PIN ของคุณ

5. การใช้ Hard Reset(รีเซ็ตค่าจากโรงงาน)

หากโทรศัพท์ของคุณไม่สามารถแก้ไขสู่สภาพเดิมได้ ให้ใช้ Hard Reset (รีเซ็ตค่าจากโรงงาน) เพื่อตั้งค่าเริ่มต้นของโทรศัพท์

1 ปิดเครื่อง
2 กด **ปุ่มเปิด/ปิด/ล็อค** + **ปุ่มลดระดับเสียง** ที่ด้านหลังของโทรศัพท์ค้างไว้
3 ปล่อย **ปุ่มเปิด/ปิด/ล็อค** + **ปุ่มลดระดับเสียง** เมื่อเห็นโลโก้ LG แสดงขึ้น จากนั้นกด **ปุ่มลดระดับเสียง** + **ปุ่มเพิ่มระดับเสียง** ค้างไว้อีกครั้ง
4 ปล่อยปุ่มทั้งหมดเมื่อเมื่อหน้าจอ Factory Hard Reset ปรากฏขึ้น
5 ใช้ **ปุ่มเพิ่ม/ลดระดับเสียง** เพื่อเลือก **ใช่** แล้วกด **ปุ่มเปิด/ปิด/ล็อค** เพื่อดำเนินการต่อ หรือใช้ **ปุ่มเพิ่ม/ลดระดับเสียง** เพื่อเลือก **ไม่** แล้วกด **ปุ่มเปิด/ปิด/ล็อค** เพื่อยกเลิก
6 ใช้ **ปุ่มเพิ่ม/ลดระดับเสียง** เพื่อเลือก **ใช่** แล้วกด **ปุ่มเปิด/ปิด/ล็อค** อีกครั้งเพื่อยืนยัน หรือ ใช้ **ปุ่มเพิ่ม/ลดระดับเสียง** เพื่อเลือก **ไม่** แล้วกด **ปุ่มเปิด/ปิด/ล็อค** เพื่อยกเลิก

⚠ **คำเตือน**

หากคุณดำเนินการ Hard Reset แอปพลิเคชันของผู้ใช้, ข้อมูลผู้ใช้ และใบอนุญาต DRM ทั้งหมดจะถูกลบ โปรดอย่าลืมสำรองข้อมูลสำคัญไว้ก่อนดำเนินการ Hard Reset

6. การเปิดและการสลับแอพพลิเคชัน

มัลติทาสกิ้งเป็นเรื่องง่ายใน Android คุณสามารถใช้งานมากกว่าหนึ่งแอปพลิเคชันพร้อมกัน โดยไม่จำเป็นต้องปิดแอปพลิเคชันก่อนเปิดแอปพลิเคชันอื่น การใช้และสลับระหว่างแอปพลิเคชันต่างๆ ที่เปิดอยู่ Android จะจัดการแต่ละแอปพลิเคชัน การหยุดและเริ่มต้นตามที่ต้องการ เพื่อให้แอปพลิเคชันที่ไม่ได้ทำงานไม่ใช้ทรัพยากรโดยไม่จำเป็น

1 แตะ **ปุ่มหน้าหลัก** ค้างไว้ รายการแอปพลิเคชันที่ใช้ล่าสุดจะปรากฏขึ้น

2 แตะแอปพลิเคชันที่คุณต้องการใช้งาน ซึ่งจะไม่เป็นการหยุดการรันของแอปพลิเคชันก่อนหน้าในแบ็คกราวด์ของโทรศัพท์ อย่าลืมแตะ **ปุ่มย้อนกลับ** เพื่อออกจากแอปพลิเคชันหลังการใช้งาน

- ในการหยุดการทำงานของแอปพลิเคชัน ให้แตะ **จัดการแอปฯ** จากรายการแอปพลิเคชันที่ใช้ล่าสุด จากนั้นแตะ **หยุด** หรือ **หยุดทั้งหมด**
- ในการลบแอปพลิเคชันจากรายการแอปพลิเคชันที่ใช้ล่าสุด ให้ลากตัวอย่างแอปพลิเคชันไปทางซ้ายหรือขวา หากต้องการลบแอปพลิเคชันทั้งหมด ให้แตะ **ลบทั้งหมด**

7. การถ่ายโอนเพลง ภาพถ่าย และวิดีโอโดยใช้ซิงค์มีเดีย (MTP)

1 แตะ > > แท็บ **แอปฯ** > **ตั้งค่า** > แท็บ **ทั่วไป** > **ที่เก็บข้อมูล** เพื่อตรวจสอบสื่อเก็บข้อมูล
2 เชื่อมต่อโทรศัพท์กับคอมพิวเตอร์โดยใช้สายเคเบิล USB
3 **การเลือกวิธีการเชื่อมต่อ USB** จะปรากฏขึ้นบนหน้าจอโทรศัพท์ของคุณ เลือกตัวเลือก **ซิงค์มีเดีย (MTP)**
4 เปิดโฟลเดอร์หน่วยความจำบนคอมพิวเตอร์ คุณสามารถดูเนื้อหาในที่เก็บข้อมูลบนคอมพิวเตอร์ของคุณ และโอนไฟล์จากคอมพิวเตอร์ไปยังโฟลเดอร์หน่วยความจำอุปกรณ์ หรือสลับกัน
5 หลังจากโอนไฟล์ ให้เลื่อนแถบสถานะลง และแตะ **เชื่อมต่อ USB แล้ว** และเลือก **ชาร์จโทรศัพท์** จากรายการชนิดการเชื่อมต่อ USB

8. ถือโทรศัพท์ตั้งขึ้น

ถือโทรศัพท์มือถือแนวตั้งเหมือนกับโทรศัพท์ทั่วไป
โทรศัพท์ของคุณมีเสาอากาศภายใน ระมัดระวังอย่าให้เกิดรอยขีดข่วนหรือความเสียหายที่บริเวณด้านหลังเครื่อง เนื่องจากอาจส่งผลต่อประสิทธิภาพการทำงาน
เมื่อทำการโทรออก/รับสาย หรือทำการส่ง/รับข้อมูล ให้หลีกเลี่ยงการถือบริเวณส่วนล่างของโทรศัพท์ซึ่งเป็นตำแหน่งที่มีการติดตั้งเสาอากาศไว้ การทำดังกล่าวส่งผลกับคุณภาพการโทร

9. เมื่อหน้าจอค้าง

หากหน้าจอค้างหรือโทรศัพท์ไม่ตอบสนองเมื่อคุณพยายามใช้งาน:
กดปุ่ม **เปิด/ปิด/ล็อค** ค้างไว้เป็นเวลา 10 วินาทีเพื่อปิดโทรศัพท์ของคุณ หากยังไม่สามารถแก้ไขปัญหาได้ โปรดติดต่อศูนย์บริการ

10. อย่าเชื่อมต่อโทรศัพท์ของคุณในขณะทำการเปิด/ปิดคอมพิวเตอร์

ควรยกเลิกการเชื่อมต่อโทรศัพท์กับคอมพิวเตอร์ขณะเปิดหรือปิดเครื่องคอมพิวเตอร์ เพราะอาจทำให้เครื่องคอมพิวเตอร์อาจเกิดข้อผิดพลาดได้

11. โหมดการควบคุมด้วยปุ่มฮาร์ดแวร์

หากหน้าจอโทรศัพท์ของคุณเสียหายหรือชำรุด คุณสามารถรับสาย วางสาย หรือปิดเสียงเตือนด้วยปุ่มฮาร์ดแวร์ได้

1 ปิดโทรศัพท์ของคุณ

2 กด **ปุ่มเปิด/ปิด/ล็อค** และ **ปุ่มลดระดับเสียง + ปุ่มเพิ่มระดับเสียง** ค้างไว้พร้อมๆ กัน อย่างน้อย 6 วินาทีเพื่อเปิดโหมดการควบคุมด้วยปุ่มฮาร์ดแวร์

3 กด **ปุ่มเพิ่ม/ลดระดับเสียง** เพื่อเลื่อนไปยังตัวเลือกที่ต้องการ แล้วกด **ปุ่มเปิด/ปิด/ล็อค** เพื่อยืนยัน

- **การรับสาย:** กด**ปุ่มลดระดับเสียง + ปุ่มเพิ่มระดับเสียง**พร้อมกัน
- **วางสาย:** กด **ปุ่มเปิด/ปิด/ล็อค** ขณะโทร
- **ปิดเสียงเตือน:** เมื่อเสียงเตือนดัง ให้กด **ปุ่มเพิ่มระดับเสียง** หรือ **ปุ่มลดระดับเสียง** ค้างไว้เพื่อปิดเสียงเตือน

หมายเหตุ: หากคุณยังคงใช้โทรศัพท์ที่กระจกหน้าจอแตก โทรศัพท์อาจเสียหายมากขึ้น หรือคุณอาจได้รับบาดเจ็บ โปรดไปที่ศูนย์บริการที่ได้รับการแต่งตั้งของ LG เพื่อซ่อมแซมโทรศัพท์ของคุณ

เริ่มทำความรู้จักกับโทรศัพท์ของคุณ

ภาพรวมโทรศัพท์

เลนส์กล้องด้านหน้า

เซนเซอร์หน้าจอ

หูฟัง

LED การแจ้งเตือน

หน้าจอสัมผัส

ปุ่มย้อนกลับ

- กลับไปยังหน้าจอก่อนหน้า ออกจากแอปพลิเคชันหลังจากการใช้งาน

ปุ่มหน้าหลัก

- กลับไปยังหน้าจอหลักจากหน้าจอใดๆ

ปุ่มเมนู

- ตรวจสอบว่ามีตัวเลือกอะไรบ้าง

หมายเหตุ: เซนเซอร์หน้าจอ
เมื่อรับสายหรือโทรออก เซนเซอร์หน้าจอจะปิดไฟหน้าจอโดยอัตโนมัติ และล็อคหน้าจอสัมผัสโดยการรับรู้เมื่อโทรศัพท์อยู่ใกล้หู วิธีนี้จะช่วยยืดอายุการใช้งานแบตเตอรี่ และป้องกันไม่ให้คุณเปิดใช้หน้าจอสัมผัสโดยไม่ได้ตั้งใจขณะโทรศัพท์

⚠คำเตือน
การวางวัตถุที่มีน้ำหนักมากบนโทรศัพท์หรือการนั่งทับอาจทำให้จอ LCD และการทำงานของหน้าจอสัมผัสเสียหายได้ อย่าปิดเซนเซอร์หน้าจอ LCD ด้วยฟิล์มป้องกัน เนื่องจากอาจทำให้เซนเซอร์ทำงานผิดปกติได้

ช่องใส่ซิมการ์ด

ช่องปุ่มถอด

ไมโครโฟน

เซ็นเซอร์ QRemote

เลนส์กล้องด้านหลัง

แฟลช

ปุ่มปรับระดับเสียง

- **ในหน้าจอหลัก:** ควบคุมระดับเสียงกริ่ง
- **ระหว่างการใช้สาย:** ควบคุมระดับเสียงหูฟัง
- **ขณะเล่นแทร็ค:** ควบคุมระดับเสียงต่อเนื่อง

ปุ่มเปิด/ปิด/ล็อค

- เปิดหรือปิดโทรศัพท์ของคุณโดยกดปุ่มนี้ค้างไว้
- กดเพื่อล็อค/ปลดล็อคหน้าจอ

ลำโพง

ไมโครโฟน

ช่องเสียบชุดหูฟัง

จุดแตะ NFC

พอร์ตอุปกรณ์ชาร์จ/USB

⚠ **คำเตือน**

- ส่วนนี้จะปิดช่องใส่แบตเตอรี่ โปรดอย่าเปิดฝาครอบด้านหลัง
- ระมัดระวังอย่าให้จุดแตะ NFC บนโทรศัพท์ซึ่งเป็นส่วนหนึ่งของเสาอากาศ NFC เสียหาย

หมายเหตุ: ฝาด้านหลังของผลิตภัณฑ์นี้ใช้เทคโนโลยี "self-healing" ซึ่งสามารถลบรอยขีดข่วนเล็กๆ น้อยๆ ได้ด้วยตนเองในเวลาเพียงไม่กี่นาที รอยขีดข่วนเล็กๆ น้อยๆ คือรอยที่เกิดจากการใช้งานโทรศัพท์แบบทั่วไปในชีวิตประจำวัน รอยขีดข่วนที่เกิดจากพื้นผิวถูกขัดสี การใช้งานไม่ถูกต้อง รวมถึงแต่ไม่จำกัดเพียงรอยขีดข่วนที่เกิดโดยตั้งใจ และความเสียหายที่เกิดจากการร่วงหล่นหรือทำผลิตภัณฑ์ตกหล่น อาจจะไม่หายไป ผลลัพธ์จาก “self-healing” อาจแตกต่างกันไป ขึ้นอยู่กับระดับของความเสียหายรวมถึงสภาพอื่นๆ การรับประกันใดๆ ในที่นี้จะไม่ครอบคลุมถึง “self-healing”

การใส่การ์ด micro-USIM

ก่อนที่คุณจะเริ่มสำรวจโทรศัพท์เครื่องใหม่ของคุณ คุณอาจเลือกใส่การ์ด Micro-USIM
ปุ่มถอดเป็นช่องกลมขนาดเล็กอยู่ที่ด้านล่างของฝาถาด การติดตั้งการ์ด micro-USIM ใหม่:

1 ใส่เครื่องมือถอด Micro-USIM ที่มาพร้อมกับโทรศัพท์ (หรือเข็มหมุดเล็กๆ) ในช่องปุ่มถอด และค่อยๆ ดันอย่างต่อเนื่องจนถาดหลุดออกมา
2 ถอดถาดออกและวางการ์ด micro-USIM ไว้ข้างใน โดยให้หน้าสัมผัสหันออกและมุมตัดอยู่ทางขวา การใส่การ์ดในถาดให้พอดีทำได้เพียงแบบเดียว
3 ใส่ถาดกลับเข้าไปในช่อง และค่อยๆ ดันกลับเข้าไปในโทรศัพท์

หมายเหตุ: โปรดตรวจสอบให้แน่ใจว่าหน้าสัมผัสสีทองของการ์ดคว่ำลง

การชาร์จโทรศัพท์

ชาร์จแบตเตอรี่ก่อนการใช้งานครั้งแรก ชาร์จแบตเตอรี่ด้วยอุปกรณ์ชาร์จ สามารถชาร์จอุปกรณ์ด้วยคอมพิวเตอร์ได้ โดยเชื่อมต่อผ่านสายเคเบิล USB

คำเตือน

ใช้อุปกรณ์ชาร์จ แบตเตอรี่ และสายเคเบิลที่ได้รับการรับรองจาก LG เท่านั้น หากคุณใช้อุปกรณ์ชาร์จ แบตเตอรี่ หรือสายเคเบิลที่ไม่ได้รับการรับรอง อาจทำให้การชาร์จแบตเตอรี่ล่าช้า หรือมีข้อความป๊อปอัพเกี่ยวกับการชาร์จช้าปรากฏขึ้น หรืออาจทำให้แบตเตอรี่ระเบิดหรือทำให้อุปกรณ์ได้รับความเสียหาย ซึ่งจะไม่ได้รับความคุ้มครองตามการรับประกัน

ช่องเสียบอุปกรณ์ชาร์จอยู่ทางด้านล่างของโทรศัพท์ เสียบอุปกรณ์ชาร์จและเสียบปลั๊กไฟเข้ากับเต้าเสียบไฟ

หมายเหตุ:

- แบตเตอรี่ต้องชาร์จจนเต็มเมื่อเริ่มต้นใช้งานเพื่อยืดอายุการใช้งานของแบตเตอรี่
- ห้ามเปิดฝาครอบด้านหลังขณะโทรศัพท์ของคุณกำลังชาร์จ

การล็อคและปลดล็อคหน้าจอ

หากคุณไม่ได้ใช้โทรศัพท์ชั่วขณะหนึ่ง หน้าจอจะปิดและล็อคโดยอัตโนมัติ ซึ่งจะช่วยป้องกันการแตะโดยไม่ตั้งใจและประหยัดพลังงานแบตเตอรี่
ในขณะที่คุณไม่ได้ใช้งานโทรศัพท์ ให้กด **ปุ่มเปิด/ปิด/ล็อค** เพื่อล็อคโทรศัพท์ของคุณ
หากมีโปรแกรมกำลังทำงานอยู่เมื่อคุณล็อคหน้าจอของคุณ โปรแกรมเหล่านั้นอาจจะยังคงทำงานอยู่ในโหมดล็อค ขอแนะนำให้ปิดโปรแกรมทั้งหมดก่อนจะเริ่มใช้งานโหมดล็อค เพื่อป้องกันการเกิดค่าใช้จ่ายที่ไม่จำเป็น (เช่น การโทรเข้า/ออก, การเข้าใช้เว็บ และการสื่อสารข้อมูล)
ในการทำให้โทรศัพท์ของคุณใช้งานได้ ให้กด **ปุ่มเปิด/ปิด/ล็อค** หน้าจอล็อคจะปรากฏขึ้น แตะและเลื่อนล็อคหน้าจอไปในทิศทางใดๆ เพื่อปลดล็อคหน้าจอหลักของคุณ หน้าจอสุดท้ายที่คุณดูจะเปิดขึ้น

เปิดหน้าจอ

คุณสามารถล็อคหรือปลดล็อคหน้าจอได้ เพียงแตะสองครั้ง

ในการเปิดใช้งานคุณสมบัติเปิดหน้าจอ

1 แตะ > > แท็บ **แอปฯ** > **ตั้งค่า** > **แท็บ** ทั่วไป > **Gestures**
2 ทำเครื่องหมายที่ **เปิด/ปิดหน้าจอ**

แตะสองครั้งอย่างรวดเร็วที่กลางหน้าจอเพื่อปลดล็อคหน้าจอ
ในการล็อคหน้าจอ ให้แตะสองครั้งที่แถบสถานะในหน้าจอใดก็ได้ (ยกเว้นช่องมองภาพของกล้องถ่ายรูป) หรือที่พื้นที่ว่างบนหน้าจอหลัก

หมายเหตุ: ในขณะที่กำลังเปิดหน้าจอ ให้แน่ใจว่าคุณไม่ได้บังเซนเซอร์หน้าจออยู่ เนื่องจากหน้าจอจะปิดลงทันทีหลังจากที่เปิด เพื่อป้องกันการเปิดโดยไม่ได้ตั้งใจในขณะที่อยู่ในกระเป๋าเสื้อหรือกระเป๋าสะพาย

ชุดหูฟังสเตอริโอพร้อมไมโครโฟน

เมื่อเชื่อมต่อกับชุดหูฟัง คุณก็สามารถเพลิดเพลินไปกับเพลงหรือวิดีโอด้วยเสียงแบบสเตอริโอ และสามารถสลับสายจากเพลง/วิดีโอเพื่อรับและวางสาย

< ด้านหน้า >

ปุ่มเพิ่มระดับเสียง/ลดระดับเสียง

ปุ่มโทร/วางสาย

- สำหรับสายเรียกเข้า จะกดเพื่อรับหรือวางสาย
- ในขณะที่คุณฟังเพลงอยู่
  จะกดเพื่อหยุดการเล่นหรือเล่นต่อ
  กดสองครั้งเพื่อเล่นเพลงถัดไป

< ด้านหลัง >

ไมโครโฟน

1 เสียบชุดหูฟังตามที่แสดงด้านล่าง

2 พาเนลแอปพลิเคชันจะปรากฏขึ้น และคุณสามารถเลือกแอปพลิเคชันที่จะรันได้

หมายเหตุ: คุณสามารถแก้ไขแอปพลิเคชันที่จะปรากฏบนพาเนล และตั้งค่าให้ไม่แสดงพาเนลแอปพลิเคชันได้ โปรดดู **< อุปกรณ์ >**

3 หากมีสายเรียกเข้าขณะที่ชุดหูฟังเชื่อมต่ออยู่กับโทรศัพท์ ให้กด เพื่อรับสาย

4 ในการวางสาย ให้กด อีกครั้ง

Plug & Pop

Plug & Pop ให้คุณเลือกแอปพลิเคชันได้อย่างรวดเร็วเมื่อเชื่อมต่อหูฟังหรืออุปกรณ์ On-the-Go อื่นๆ เช่น เมาส์ หรือแป้นพิมพ์

1 เชื่อมต่อหูฟังหรืออุปกรณ์ OTG (On-the-Go) (เช่น เมาส์ แป้นพิมพ์ เป็นต้น)

2 พาเนลแอปพลิเคชันจะปรากฏขึ้น และคุณสามารถเลือกแอปพลิเคชันที่จะรันได้

หมายเหตุ: คุณสามารถแก้ไขแอปพลิเคชันที่จะปรากฏบนพาเนล และตั้งค่าให้ไม่แสดงพาเนลแอปพลิเคชันได้

▸ แตะ > > **แท็บ** แอปฯ > **ตั้งค่า** > แท็บ **ทั่วไป** > **อุปกรณ์** > **ที่เก็บข้อมูล USB** หรือ **หูฟัง**

หน้าจอหลักของคุณ

เคล็ดลับสำหรับหน้าจอสัมผัส

เคล็ดลับต่อไปนี้เป็นเคล็ดลับเกี่ยวกับวิธีนาวิเกตโทรศัพท์ของคุณ

แตะหรือสัมผัส – การใช้หนึ่งนิ้วแตะเพื่อเลือกรายการ ลิงค์ ช็อตคัท และตัวอักษรบนแป้นพิมพ์บนหน้าจอ

แตะค้าง – แตะรายการบนหน้าจอค้างไว้ โดยให้แตะโดยไม่ต้องยกนิ้วขึ้นจนกว่าการดำเนินการจะเกิดขึ้น ตัวอย่างเช่น หากต้องการเปิดตัวเลือกที่มีอยู่ของรายชื่อ ให้แตะที่รายชื่อในรายการรายชื่อค้างไว้จนกว่าเมนูลัดจะเปิดขึ้น

ลาก – แตะรายการค้างไว้ชั่วครู่หนึ่ง จากนั้นเลื่อนนิ้วของคุณบนหน้าจอจนกว่าจะไปถึงตำแหน่งเป้าหมาย คุณสามารถลากรายการบนหน้าจอหลักของคุณเพื่อจัดตำแหน่งใหม่ได้

ปัดหรือเลื่อน – ในการปัดหรือเลื่อน ให้เลื่อนนิ้วของคุณผ่านพื้นผิวของหน้าจออย่างรวดเร็ว โดยไม่หยุดพักหลังจากที่แตะครั้งแรก (เพื่อไม่ให้กลายเป็นการลากแทน) ตัวอย่างเช่น คุณสามารถเลื่อนหน้าจอขึ้นหรือลงเพื่อเลื่อนดูรายการ หรือเรียกดูหน้าจอหลักต่างๆ ได้โดยการปัดจากซ้ายไปขวา (และตรงกันข้าม)

แตะสองครั้ง – แตะสองครั้งเพื่อซูมเว็บเพจหรือแผนที่ เช่น แตะสองครั้งอย่างรวดเร็วที่ส่วนหนึ่งของเว็บเพจ เพื่อปรับส่วนนั้นให้พอดีกับความกว้างของหน้าจอ คุณสามารถแตะสองครั้งเพื่อซูมเข้าและออกได้เช่นกันขณะที่ดูภาพ

กางหุบนิ้วเพื่อซูม – ใช้นิ้วชี้และนิ้วโป้งของคุณในการเลื่อนเข้าหากันหรือเลื่อนออกจากกันเพื่อซูมเข้าหรือออกขณะใช้งานบราวเซอร์หรือแผนที่ หรือขณะเรียกดูรูปภาพ

หมุนหน้าจอ – จากหลายๆ แอปพลิเคชันและเมนู การวางแนวของหน้าจอจะเปลี่ยนแปลงไปตามการวางแนวจริงของตัวเครื่องอุปกรณ์

หมายเหตุ:
- ในการเลือกรายการ ให้แตะที่กลางไอคอน
- ไม่ต้องออกแรงกดมาก หน้าจอสัมผัสไวต่อการสัมผัสที่เบาและแน่นอน
- ใช้ปลายนิ้วในการสัมผัสที่ตัวเลือกที่ต้องการ ระวังอย่าแตะโดนปุ่มอื่นๆ

หน้าจอหลักของคุณ

หน้าจอหลัก

หน้าจอหลักเป็นจุดเริ่มต้นในการใช้งานแอปพลิเคชันและฟังก์ชันต่างๆ และให้คุณเพิ่มรายการ เช่น ช็อตคัท หรือ Google Widget ของแอปพลิเคชัน ช่วยให้คุณเข้าใช้ข้อมูลและแอปพลิเคชันต่างๆ ได้ทันที เป็นหน้าจอเริ่มต้นและสามารถเข้าใช้ได้จากทุกเมนูด้วยการแตะ

แถบสถานะ
แสดงข้อมูลสถานะของโทรศัพท์ รวมถึงเวลา ความแรงของสัญญาณ สถานะแบตเตอรี่ และไอคอนการแจ้ง

Widget
Widget เป็นแอปพลิเคชันที่มาพร้อมกับเครื่องซึ่งสามารถเข้าใช้ได้จากหน้าจอแอปพลิเคชันหรือหรือหน้าจอหลักหรือย่อยของคุณ Widget จะปรากฏขึ้นเหมือนกับเป็นแอปพลิเคชันบนหน้าจอ ซึ่งแตกต่างจากช็อตคัท

ไอคอนแอปพลิเคชัน
แตะไอคอน (แอปพลิเคชัน, โฟลเดอร์, ฯลฯ) เพื่อเปิดและใช้งาน

สัญลักษณ์แสดงตำแหน่ง
แสดงว่าคุณกำลังดูหน้าจอหลักใดอยู่

พื้นที่ปุ่มด่วน
ทำให้สามารถเข้าใช้งานฟังก์ชันในทุกหน้าจอหลัก

ปุ่มสัมผัสด้านหน้า

หน้าจอหลักย่อย

ระบบปฏิบัติการจะมีหน้าจอหลักหลายหน้าจอเพื่อให้มีพื้นที่ว่างสำหรับเพิ่มไอคอน, Widgets และอื่นๆ

- เลื่อนนิ้วไปทางด้านซ้ายหรือด้านขวาของหน้าจอหลัก

การปรับแต่งหน้าจอหลัก

คุณสามารถปรับแต่งหน้าจอหลักของคุณโดยเพิ่มแอปพลิเคชัน, Widgets หรือเปลี่ยนพื้นหลัง

การเพิ่มรายการในหน้าจอหลัก

1 แตะค้างไว้บนส่วนที่ว่างของหน้าจอหลัก
2 ในเมนูโหมดเพิ่ม ให้เลือกรายการที่คุณต้องการเพิ่ม จากนั้นคุณจะเห็นรายการที่เพิ่มบนหน้าจอหลัก
3 ลากไปยังตำแหน่งที่คุณต้องการแล้วยกนิ้วขึ้น

เคล็ดลับ! ในการเพิ่มไอคอนแอปพลิเคชันในหน้าจอหลัก จากเมนูแอปฯ ให้แตะค้างไว้ที่แอปพลิเคชันที่คุณต้องการเพิ่ม

การลบรายการจากหน้าจอหลัก

▸ **หน้าจอหลัก** > แตะค้างไว้ที่ไอคอนที่คุณต้องการลบ > ลากไปยัง

ในการเพิ่มแอปพลิเคชันเป็นปุ่มด่วน

▸ จากเมนู แอปฯ หรือบนหน้าจอหลัก ให้แตะไอคอนแอปพลิเคชันค้างไว้ แล้วลากไปยังพื้นที่ปุ่มด่วน สามารถเพิ่มได้สูงสุด 7 แอปฯ

ในการลบแอปพลิเคชันจากพื้นที่ปุ่มด่วน

▸ แตะปุ่มด่วนที่ต้องการค้างไว้ แล้วลากไปยัง

หมายเหตุ: ไม่สามารถลบปุ่ม**แอปฯ** ได้

ในการปรับแต่งไอคอน แอปฯ บนหน้าจอหลัก

1 แตะไอคอนแอปพลิเคชันค้างไว้จนถูกปลดล็อคจากตำแหน่งปัจจุบัน แล้ววางไว้บนหน้าจอ ไอคอนการแก้ไขจะปรากฏขึ้นที่มุมขวาบนของแอปพลิเคชัน
2 แตะไอคอนแอปพลิเคชันอีกครั้งและเลือกการออกแบบและขนาดไอคอนที่ต้องการ
3 แตะ **ตกลง** เพื่อบันทึกการเปลี่ยนแปลง

หน้าจอหลักของคุณ

การกลับไปที่แอปพลิเคชันที่เพิ่งใช้ล่าสุด

1 แตะ ค้างไว้ หน้าจอจะแสดงป๊อปอัปโดยมีไอคอนของแอปพลิเคชันที่คุณเพิ่งใช้ล่าสุด
2 แตะไอคอนเพื่อเปิดแอปพลิเคชัน หรือแตะ เพื่อกลับสู่หน้าจอก่อนหน้า

พาเนลการแจ้งเตือน

การแจ้งเตือนจะแจ้งให้คุณทราบว่ามีข้อความ เหตุการณ์ปฏิทิน และการตั้งปลุกใหม่ รวมถึงเหตุการณ์ต่อเนื่อง เช่น ในขณะที่คุณใช้สาย เมื่อการแจ้งเตือนมาถึง ไอคอนจะปรากฏขึ้นที่ด้านบนของหน้าจอ ไอคอนสำหรับการแจ้งเตือนที่รอดำเนินการจะปรากฏขึ้นทางด้านซ้าย และไอคอนระบบ เช่น Wi-Fi หรือระดับแบตเตอรี่จะแสดงอยู่ทางด้านขวา

หมายเหตุ: ตัวเลือกที่มีอาจแตกต่างกัน โดยขึ้นอยู่กับภูมิภาคหรือผู้ให้บริการ

การเปิดพาเนลการแจ้งเตือน

ลากนิ้วลงจากแถบสถานะเพื่อเปิดพาเนลการแจ้งเตือน

พื้นที่สลับด่วน

แตะปุ่มสลับด่วนแต่ละปุ่มเพื่อเปิด/ปิด แตะปุ่มค้างไว้เพื่อเข้าใช้เมนูตั้งค่าของฟังก์ชัน ในการดูปุ่มสลับเพิ่มเติม ให้ลากนิ้วไปทางซ้ายหรือขวา แตะ เพื่อลบ เพิ่ม หรือจัดเรียงปุ่มสลับ

QSlide แอปพลิเคชัน

แตะแอปพลิเคชัน QSlide เพื่อเปิดหน้าต่างเล็กในหน้าจอของคุณ แตะ เพื่อลบ เพิ่ม หรือจัดเรียงแอปฯ QSlide

แตะเพื่อลบการแจ้งเตือนทั้งหมด

การแจ้งเตือน

แสดงการแจ้งเตือนปัจจุบัน พร้อมคำอธิบายย่อ แตะที่การแจ้งเพื่อดู

ในการปิดพาเนลการแจ้งเตือน ให้แตะแล้วลากแท็บไปที่ด้านบนของหน้าจอ

ไอคอนสัญลักษณ์บนแถบสถานะ

ไอคอนสัญลักษณ์จะปรากฏบนแถบสถานะที่ด้านบนของหน้าจอเพื่อรายงานสายที่ไม่ได้รับ ข้อความใหม่ เหตุการณ์ในปฏิทิน สถานะอุปกรณ์ และอื่นๆ

หน้าจอหลักของคุณ

ไอคอนที่แสดงที่ด้านบนของหน้าจอจะให้ข้อมูลเกี่ยวกับสถานะของอุปกรณ์ ไอคอนที่แสดงในตารางด้านล่างคือบางส่วนของไอคอนที่พบบ่อย

ไอคอน	รายละเอียด
	ไม่ได้ใส่ซิมการ์ด
	ไม่มีสัญญาณเครือข่าย
	เปิดใช้โหมดเครื่องบิน
	เชื่อมต่อกับเครือข่าย Wi-Fi
	เชื่อมต่อชุดหูฟังแบบใช้สายแล้ว
	กำลังใช้สาย
	สายไม่ได้รับ
	เปิด Bluetooth
	เปิด NFC
	คำเตือนระบบ
	ตั้งปลุกแล้ว
	มีข้อความเสียงใหม่
	ข้อความตัวอักษรหรือมัลติมีเดียใหม่

ไอคอน	รายละเอียด
	ปิดเสียงเรียกเข้า
	เปิดใช้โหมดสั่น
	ชาร์จแบตเตอรี่เต็มแล้ว
	กำลังชาร์จแบตเตอรี่
	โทรศัพท์เชื่อมต่อกับคอมพิวเตอร์ผ่านสาย USB
	กำลังดาวน์โหลดข้อมูล
	กำลังอัปโหลดข้อมูล
	เปิด GPS
	กำลังรับข้อมูลตำแหน่งจาก GPS
	กำลังซิงโครไนซ์ข้อมูล
	มีข้อความ Gmail ใหม่
	มีข้อความ Hangouts ใหม่
	เลือกวิธีป้อนข้อมูล

	กำลังเล่นเพลงอยู่		การแบ่งปันเนื้อหา DLNA
	กำลังใช้งาน Mobile Hotspot		กำลังเล่นเพลง DLNA

หมายเหตุ: ตำแหน่งไอคอนในแถบสถานะอาจแตกต่างกันไป โดยขึ้นอยู่กับฟังก์ชันหรือบริการ

แป้นพิมพ์บนหน้าจอ

คุณสามารถป้อนข้อความด้วยแป้นพิมพ์บนหน้าจอได้ แป้นพิมพ์บนหน้าจอจะปรากฏโดยอัตโนมัติบนหน้าจอเมื่อคุณจำเป็นต้องป้อนข้อความ ในการทำให้แป้นพิมพ์ปรากฏขึ้นด้วยตนเอง เพียงแตะฟิลด์ข้อความที่คุณต้องการป้อนข้อความ

การใช้ปุ่มกด และ การป้อนข้อความ

แตะหนึ่งครั้งเพื่อเปลี่ยนตัวอักษรถัดไปที่คุณพิมพ์เป็นตัวพิมพ์ใหญ่ แตะสองครั้งเพื่อเปลี่ยนทุกตัวเป็นตัวพิมพ์ใหญ่

abc #!? แตะเพื่อสลับเป็นแป้นพิมพ์เครื่องหมายและสัญลักษณ์

แตะเพื่อสลับเป็นโหมดเขียนมือ

แตะเพื่อเว้นวรรค

แตะเพื่อลบตัวอักษรก่อนหน้า

การป้อนตัวอักษรที่ใช้สำหรับเน้นเสียง

เมื่อคุณเลือกภาษาฝรั่งเศสหรือสเปนเป็นภาษาที่ใช้ป้อนข้อความ คุณสามารถป้อนตัวอักษรพิเศษของภาษาฝรั่งเศสหรือสเปนได้ (เช่น "á")

ตัวอย่างเช่น ในการป้อน "á" ให้แตะปุ่ม "a" ค้างไว้จนกว่าปุ่มซูมเข้าจะขยายใหญ่ขึ้นและแสดงตัวอักษรจากภาษาอื่นๆ

แล้วเลือกตัวอักษรพิเศษที่คุณต้องการ

การตั้งค่าบัญชี Google

เมื่อคุณเปิดโทรศัพท์เป็นครั้งแรก คุณจะมีโอกาสเปิดการใช้เครือข่ายเพื่อลงชื่อเข้าใช้บัญชี Google และเลือกวิธีการใช้บริการ Google ที่คุณต้องการ

การตั้งค่าบัญชี Google ของคุณ:

- ลงชื่อเข้าใช้บัญชี Google จากหน้าจอตั้งค่าที่แสดง
  หรือ
- แตะ > แท็บ **แอปฯ** > เลือกแอปพลิเคชัน Google เช่น **Gmail** > เลือก **สราง** เพื่อสร้างแอคเคาท์ใหม่

หากคุณมีแอคเคาท์ Google ให้แตะ **ที่มีอยู่** ป้อนอีเมลแอดเดรสและรหัสผ่านของคุณ จากนั้นแตะ

เมื่อคุณตั้งค่าบัญชี Google บนโทรศัพท์ โทรศัพท์ของคุณจะซิงโครไนซ์กับบัญชี Google บนเว็บโดยอัตโนมัติ

รายชื่อ, ข้อความ Gmail, เหตุการณ์ในปฏิทินของคุณ และข้อมูลอื่นๆ จากแอปพลิเคชันเหล่านี้และบริการบนเว็บจะซิงโครไนซ์กับโทรศัพท์ของคุณ (ซึ่งจะขึ้นอยู่กับการตั้งค่าการซิงโครไนซ์ของคุณ)

หลังจากไซน์อิน คุณจะสามารถใช้ Gmail™ และใช้ประโยชน์จากบริการต่างๆ ของ Google บนโทรศัพท์ของคุณ

การเชื่อมต่อกับเครือข่ายและอุปกรณ์

Wi-Fi

ด้วย Wi-Fi คุณสามารถใช้การเข้าถึงอินเตอร์เน็ตความเร็วสูงภายในพื้นที่ครอบคลุมของจุดเชื่อมต่อไร้สาย (AP) สนุกสนานกับอินเตอร์เน็ตไร้สายโดยใช้ Wi-Fi ที่ไม่มีค่าบริการเพิ่มเติม

การเชื่อมต่อกับเครือข่าย Wi-Fi

ในการใช้ Wi-Fi ในโทรศัพท์ คุณจำเป็นต้องเข้าใช้จุดเชื่อมต่อไร้สาย หรือ 'ฮอตสปอต' จุดเชื่อมต่อบางจุดเป็นแบบเปิดและคุณเชื่อมต่อได้ทันที จุดอื่นๆ เป็นแบบซ่อนหรือใช้คุณสมบัติระบบป้องกัน คุณต้องกำหนดค่าโทรศัพท์เพื่อทำการเชื่อมต่อ

ปิด Wi-Fi เมื่อคุณไม่ได้ใช้ เพื่อยืดอายุแบตเตอรี่

หมายเหตุ: ถ้าคุณอยู่นอกพื้นที่ Wi-Fi หรือตั้งค่า Wi-Fi เป็น **ปิด** อาจมีการคิดค่าใช้จ่ายเพิ่มเติมโดยผู้ให้บริการเครือข่ายโทรศัพท์เคลื่อนที่สำหรับการใช้งานข้อมูลโทรศัพท์เคลื่อนที่

การเปิด Wi-Fi และการเชื่อมต่อกับเครือข่าย Wi-Fi

1 แตะ > > **แท็บ** แอปฯ > **ตั้งค่า** > **แท็บ** เครือข่าย > **Wi-Fi**
2 ตั้งค่า **Wi-Fi** เป็น **เปิด** เพื่อเปิดและเริ่มต้นสแกนหาเครือข่าย Wi-Fi ที่มีอยู่
3 แตะเมนู Wi-Fi อีกครั้งเพื่อดูรายการของเครือข่าย Wi-Fi ที่ใช้งานและที่อยู่ในระยะ
   - เครือข่ายที่มีการป้องกันจะระบุด้วยไอคอนแม่กุญแจ
4 แตะเครือข่ายเพื่อเชื่อมต่อ
   - หากเครือข่ายมีการป้องกัน คุณจะได้รับแจ้งให้ป้อนรหัสผ่านหรือรหัสเฉพาะอื่นๆ (ติดต่อผู้ดูแลระบบเครือข่ายสำหรับรายละเอียด)
5 แถบสถานะจะแสดงไอคอนที่ระบุสถานะ Wi-Fi

การเชื่อมต่อกับเครือข่ายและอุปกรณ์

Bluetooth

คุณสามารถใช้ Bluetooth เพื่อส่งข้อมูลได้โดยการเรียกใช้แอปพลิเคชันที่เกี่ยวข้อง ไม่ใช่จากเมนู Bluetooth เหมือนในโทรศัพท์มือถือรุ่นอื่นๆ ส่วนใหญ่

หมายเหตุ:
- LG ไม่มีส่วนรับผิดชอบใดๆ สำหรับการสูญหาย การสกัดกั้น หรือการนำข้อมูลที่ส่งหรือรับผ่านคุณสมบัติไร้สาย Bluetooth ไปใช้ในทางที่ผิด
- คุณต้องแน่ใจเสมอว่าได้แบ่งปันและรับข้อมูลจากอุปกรณ์ที่เชื่อถือได้และปลอดภัย ในกรณีที่มีสิ่งกีดขวางระหว่างอุปกรณ์ ระยะการทำงานอาจลดลง
- อุปกรณ์บางรุ่น โดยเฉพาะรุ่นที่ยังไม่ผ่านการทดสอบหรืออนุญาตโดย Bluetooth SIG อาจไม่สามารถใช้งานร่วมกันกับอุปกรณ์ของคุณได้

การเปิด Bluetooth และการจับคู่โทรศัพท์ของคุณกับอุปกรณ์ Bluetooth

คุณต้องจับคู่อุปกรณ์ของคุณกับอุปกรณ์อื่นก่อนที่จะเชื่อมต่อกับอุปกรณ์นั้น

1 แตะ > > แท็บ **แอปฯ** > **ตั้งค่า** > **แท็บ** เครือข่าย > ตั้งค่า **Bluetooth** เป็น **เปิด**

2 แตะเมนู **Bluetooth** อีกครั้ง คุณจะเห็นตัวเลือกสำหรับทำให้โทรศัพท์ของคุณมองเห็นได้ และตัวเลือกสำหรับการค้นหาอุปกรณ์ ในตอนนี้ให้แตะ **ค้นหาอุปกรณ์** เพื่อดูอุปกรณ์ในระยะ Bluetooth

3 เลือกอุปกรณ์ที่คุณต้องการจับคู่ด้วยจากรายการ เมื่อจับคู่สำเร็จแล้ว อุปกรณ์ของคุณจะเชื่อมต่อกับอุปกรณ์นั้น

หมายเหตุ: อุปกรณ์บางอย่าง โดยเฉพาะชุดหูฟังหรือชุดติดรถยนต์แฮนด์ฟรี อาจมี Bluetooth PIN ที่กำหนดไว้แล้ว เช่น 0000 หากอุปกรณ์เครื่องอื่นมี PIN คุณจะต้องป้อน

ส่งข้อมูลด้วยคุณสมบัติไร้สาย Bluetooth

1 เลือกไฟล์หรือรายการ เช่น รายชื่อ เหตุการณ์ในปฏิทิน หรือไฟล์มีเดีย จากแอปพลิเคชันที่เหมาะสมหรือ **ดาวน์โหลด**

2 เลือกตัวเลือกการส่งด้วย Bluetooth

หมายเหตุ: วิธีการเลือกตัวเลือกอาจแตกต่างกันตามประเภทข้อมูล

3 ค้นหาและจับคู่อุปกรณ์ที่เปิดใช้งาน Bluetooth

รับข้อมูลด้วยคุณสมบัติไร้สาย Bluetooth

1 แตะ > > แท็บ **แอปฯ** > **ตั้งค่า** > **แท็บ** เครือข่าย > ตั้งค่า **Bluetooth** เป็น **เปิด**

2 แตะเมนู **Bluetooth** อีกครั้ง และทำเครื่องหมายที่ช่องทำเครื่องหมายที่ด้านบนของหน้าจอเพื่อให้อุปกรณ์อื่นมองเห็นโทรศัพท์ของคุณ

หมายเหตุ: ในการเลือกระยะเวลาที่จะมองเห็นอุปกรณ์ของคุณได้ ให้แตะ > **เวลาที่สามารถมองเห็น**

3 เลือก **ยอมรับ** เพื่อยืนยันว่าคุณต้องการรับข้อมูลจากอุปกรณ์

ารแบ่งปันการเชื่อมต่อข้อมูลในโทรศัพท์

การปล่อยสัญญาณผ่าน USB และ Portable Wi-Fi Hotspot เป็นคุณสมบัติที่ยอดเยี่ยมในกรณีที่ไม่มีการเชื่อมต่อไร้สายให้ใช้งาน คุณสามารถแบ่งปันการเชื่อมต่อข้อมูลของโทรศัพท์กับคอมพิวเตอร์เครื่องเดียวผ่านสายเคเบิล USB (การปล่อยสัญญาณผ่าน USB) คุณยังสามารถแบ่งปันการเชื่อมต่อข้อมูลของโทรศัพท์กับอุปกรณ์มากกว่าหนึ่งเครื่องพร้อมกัน ด้วยการเปลี่ยนโทรศัพท์ของคุณเป็น Portable Wi-Fi Hotspot

ขณะที่โทรศัพท์กำลังแบ่งปันการเชื่อมต่อข้อมูล
ไอคอนจะปรากฏขึ้นที่แถบสถานะ และแสดงเป็นการแจ้งเตือนขาออกในแถบการแจ้งเตือน

สำหรับข้อมูลล่าสุดเกี่ยวกับการแชร์และฮอตสปอตเคลื่อนที่ รวมถึงระบบปฏิบัติการที่รองรับและรายละเอียดอื่น ให้ไปที่ http://www.android.com/tether

การเชื่อมต่อกับเครือข่ายและอุปกรณ์

การแบ่งปันการเชื่อมต่อข้อมูลของโทรศัพท์โดยเป็น Portble Wi-Fi Hotspot

1 แตะ > > แท็บ **แอปฯ** > **ตั้งค่า** > **แท็บ** เครือข่าย > **การปล่อยสัญญาณ & เครือข่าย** > **Wi-Fi hotspot** สลับเพื่อเปิดใช้งาน

2 ป้อนรหัสผ่านแล้วแตะ **บันทึก**

เคล็ดลับ! หากคอมพิวเตอร์ของคุณใช้งาน Windows 7 หรือระบบปฏิบัติการที่อยู่ในกลุ่ม Linux รุ่นใหม่ๆ (เช่น Ubuntu) โดยปกติแล้วคุณจะไม่จำเป็นต้องเตรียมคอมพิวเตอร์ของคุณสำหรับการปล่อยสัญญาณ แต่ถ้าคุณกำลังใช้งาน Windows เวอร์ชันก่อนหน้า หรือระบบปฏิบัติการอื่น คุณอาจจำเป็นต้องเตรียมคอมพิวเตอร์ของคุณเพื่อสร้างการเชื่อมต่อเครือข่ายผ่าน USB สำหรับข้อมูลล่าสุดเกี่ยวกับระบบปฏิบัติการที่สนับสนุนการปล่อยสัญญาณผ่าน USB และวิธีการปรับแต่ง โปรดไปที่ http://www.android.com/tether

การเปลี่ยนชื่อหรือรักษาความปลอดภัยของ Portable hotspot

คุณสามารถเปลี่ยนชื่อเครือข่าย Wi-Fi (SSID) ของโทรศัพท์ของคุณ รวมทั้งรักษาความปลอดภัยของเครือข่าย Wi-Fi ได้

1 แตะ > > แท็บ **แอปฯ** > **ตั้งค่า** > **แท็บ** เครือข่าย > **การปล่อยสัญญาณ & เครือข่าย** > **Wi-Fi hotspot**

2 แตะ **ตั้งค่า Wi-Fi hotspot**

- กล่องโต้ตอบ **ตั้งค่า Wi-Fi hotspot** จะเปิดขึ้น
- คุณสามารถเปลี่ยน **เครือข่าย SSID** (ชื่อ) ที่จะปรากฏให้อุปกรณ์อื่นเห็นเมื่อทำการสแกนหาเครือข่าย Wi-Fi
- นอกจากนี้ยังสามารถแตะเมนู **ระบบป้องกัน** เพื่อกำหนดค่าเครือข่ายด้วยระบบป้องกัน Wi-Fi Protected Access 2 (WPA2) โดยใช้ Pre-Shared Key (PSK)
- หากคุณแตะที่ตัวเลือกระบบป้องกัน **WPA2 PSK** ฟิลด์รหัสผ่านจะถูกเพิ่มลงในกล่องโต้ตอบ **ตั้งค่า Wi-Fi hotspot** ถ้าคุณป้อนรหัสผ่านไว้ คุณจะต้องป้อนรหัสผ่านดังกล่าวเมื่อทำการเชื่อมต่อ hotspot ของโทรศัพท์กับคอมพิวเตอร์หรืออุปกรณ์อื่น คุณสามารถตั้งค่า **เปิด** ในเมนู

ระบบป้องกัน เพื่อลบระบบป้องกันออกจากเครือข่าย Wi-Fi ของคุณ

3 แตะ **บันทึก**

ข้อควรระวัง! หากคุณตั้งค่าตัวเลือกระบบป้องกันเป็นเปิด คุณจะไม่สามารถป้องกันการใช้บริการออนไลน์โดยไม่ได้รับอนุญาตของบุคคลอื่นและอาจมีค่าใช้จ่ายเพิ่มเติม คุณควรใช้งานตัวเลือกระบบป้องกันเสมอเพื่อหลีกเลี่ยงการใช้โดยไม่ได้รับอนุญาต

Wi-Fi Direct

Wi-Fi Direct สนับสนุนการเชื่อมต่อโดยตรงระหว่างอุปกรณ์ที่เปิดใช้งาน Wi-Fi โดยไม่มีจุดเชื่อมต่อ เนื่องจาก Wi-Fi Direct ใช้พลังงานแบตเตอรี่สูง ขอแนะนำให้คุณเสียบปลั๊กโทรศัพท์ของคุณเข้ากับเต้าเสียบไฟในขณะที่ใช้คุณสมบัติ Wi-Fi Direct ตรวจสอบเครือข่าย Wi-Fi และ Wi-Fi Directed ของคุณล่วงหน้าและตรวจดูว่าผู้ใช้เชื่อมต่อกับเครือข่ายเดียวกัน

การเปิด Wi-Fi Direct:

1 ในหน้าจอหลัก แตะ **ปุ่มเมนู** ▤ **> การตั้งค่าระบบ > Wi-Fi**

2 แตะ **Wi-Fi Direct** ที่ด้านล่างของหน้าจอ

3 เลือกอุปกรณ์ที่ต้องการเชื่อมต่อจากรายการอุปกรณ์ที่สแกน

SmartShare

คุณสามารถใช้คุณสมบัติ SmartShare ได้อย่างง่ายดายในแอปพลิเคชั่นคลังภาพ, เพลง, วิดีโอ ฯลฯ

เพลิดเพลินกับเนื้อหาได้จากอุปกรณ์หลากหลาย

คุณสามารถแบ่งปันเนื้อหากับอุปกรณ์ได้หลากหลาย แตะ ⊞ เพื่อแบ่งปันเนื้อหาในคลังภาพ, เพลง, วิดีโอ, POLARIS Viewer 5

การเล่น/การส่ง

เล่น: คุณสามารถเล่นเนื้อหาผ่านทีวี, ลำโพง Bluetooth ฯลฯ

Beam: คุณสามารถส่งเนื้อหาไปยังอุปกรณ์ Bluetooth ที่รองรับ

SmartShare Beam

- **SmartShare Beam:** ถ่ายโอนคุณสมบัติของเนื้อหาอย่างรวดเร็วผ่าน Wi-Fi Direct

< เล่น >

< Beam >

เพลิดเพลินกับเนื้อหาจากอุปกรณ์ข้างเคียง

คุณจะสามารถเพลิดเพลินกับเนื้อหาจากอุปกรณ์ข้างเคียง (เช่น PC.NAS, โทรศัพท์มือถือ) ได้ที่แอปพลิเคชัน **คลังภาพ, เพลง, วิดีโอ**

การเชื่อมต่ออุปกรณ์

เชื่อมต่ออุปกรณ์ของคุณและอุปกรณ์อื่นๆ ที่รองรับ DLNA ในเครือข่าย Wi-Fi เดียวกัน

การค้นหาอุปกรณ์อื่นๆ

1 แตะ อุปกรณ์ข้างเคียง จากนั้นคุณจะเห็นอุปกรณ์ที่รองรับ DLNA
2 เชื่อมต่อกับอุปกรณ์เพื่อดูเนื้อหา

การเชื่อมต่อคอมพิวเตอร์ด้วยสายเคเบิล USB

เรียนรู้วิธีการเชื่อมต่ออุปกรณ์ของคุณกับคอมพิวเตอร์ด้วยสายเคเบิล USB

ในโหมดการเชื่อมต่อ USB

การถ่ายโอนเพลง รูปถ่าย และวิดีโอโดยใช้โหมดที่เก็บข้อมูล USB

1 เชื่อมต่อโทรศัพท์ของคุณกับคอมพิวเตอร์โดยใช้สายเคเบิล USB
2 หากคุณไม่ได้ติดตั้งไดรเวอร์แพล็ตฟอร์ม LG Android บนคอมพิวเตอร์ คุณจะต้องเปลี่ยนการตั้งค่าด้วยตัวเอง เลือก **การตั้งค่าระบบ > แท็บทั่วไป > การเชื่อมต่อ PC > เลือกวิธีเชื่อมต่อแบบ USB** แล้วเลือก **ซิงค์มีเดีย (MTP)**
3 คุณสามารถดูเนื้อหาในที่เก็บข้อมูลบนคอมพิวเตอร์และโอนไฟล์ได้

ซิงโครไนซ์กับ Windows Media Player

ตรวจสอบว่าติดตั้ง Windows Media Player ใน PC ของคุณแล้ว

1 ใช้สายเคเบิล USB เชื่อมต่อโทรศัพท์กับคอมพิวเตอร์ที่ติดตั้ง Windows Media Player
2 เลือกตัวเลือก **ซิงค์มีเดีย (MTP)** เมื่อเชื่อมต่อแล้ว หน้าต่างป๊อปอัปจะปรากฏขึ้นบนคอมพิวเตอร์
3 เปิด Windows Media Player เพื่อซิงโครไนซ์ไฟล์เพลง
4 แก้ไขหรือป้อนชื่อของอุปกรณ์ของคุณในหน้าต่างป๊อปอัป (ถ้าจำเป็น)
5 เลือกและลากไฟล์เพลงที่คุณต้องการไปยังหน้าต่าง Sync List
6 เริ่มต้นการซิงโครไนซ์

- ต้องตรงตามข้อกำหนดต่อไปนี้เพื่อซิงโครไนซ์กับ Windows Media Player

รายการ	ข้อกำหนด
OS	Microsoft Windows XP SP2, Vista หรือสูงกว่า
เวอร์ชัน Window Media Player	Windows Media Player 10 หรือสูงกว่า

- หากเวอร์ชัน Windows Media Player ต่ำกว่า 10 ให้ติดตั้งเวอร์ชัน 10 หรือสูงกว่า

การโทร

การโทรออก

1 แตะ เพื่อเปิดปุ่มกด
2 ป้อนหมายเลขโดยใช้ปุ่มกด ในการลบตัวเลข ให้แตะ
3 แตะ เพื่อโทรออก
4 ในการวางสาย ให้แตะไอคอน **วางสาย**

เคล็ดลับ! ในการป้อน "+" เพื่อโทรออกต่างประเทศ ให้แตะค้างไว้ที่ 0+

การโทรออกโดยใช้รายชื่อ

1 แตะ เพื่อเปิดรายชื่อ
2 เลื่อนดูรายชื่อหรือป้อนอักษรสองสามตัวแรกของรายชื่อที่คุณต้องการโทร โดยแตะ **ค้นหารายชื่อ**
3 ในรายชื่อ ให้แตะ ที่คุณต้องการโทรออก

การรับสายและการปฏิเสธสายเรียกเข้า

เมื่อมีสายเรียกเข้าในสถานะล็อค ให้ลาก ไปในทิศทางใดก็ได้เพื่อรับสายเรียกเข้า
ลาก ไปในทิศทางใดก็ได้เพื่อปฏิเสธสายเรียกเข้า
ลากไอคอน **ปฏิเสธพร้อมส่งข้อความ** จากด้านล่าง
หากคุณต้องการส่งข้อความ

เคล็ดลับ! ปฏิเสธพร้อมส่งข้อความ
คุณสามารถส่งข้อความได้อย่างรวดเร็วโดยใช้ฟังก์ชันนี้ ตัวเลือกนี้จะเป็นประโยชน์ในกรณีที่คุณต้องการปฏิเสธการรับสายพร้อมส่งข้อความ ในระหว่างการประชุม

การปรับระดับเสียงสนทนา

หากต้องการปรับระดับเสียงระหว่างการใช้สาย ให้ใช้ปุ่มปรับระดับเสียงขึ้นและลงที่ด้านหลังของโทรศัพท์

การใช้สายที่สอง

1 ในระหว่างการโทรสายแรก ให้แตะ **ปุ่มเมนู** > **เพิ่ม สาย** และหมุนหมายเลข คุณสามารถไปยังรายการหมายเลขที่เพิ่งโทรล่าสุดได้โดยการแตะ หรือค้นหารายชื่อได้โดยการแตะ และเลือกรายชื่อที่คุณต้องการโทร

2 แตะ เพื่อโทรออก

3 สายสนทนาทั้งสองสายจะแสดงอยู่ในหน้าจอการโทร สายสนทนาแรกจะล็อคและพักสายไว้

4 แตะหมายเลขที่แสดงเพื่อสลับสลาย หรือแตะที่ **รวมสาย** เพื่อเริ่มต้นการประชุมสาย

5 ในการวางสายที่ใช้ ให้แตะ **วางสาย** หรือแตะ และเลื่อนแถบการแจ้งเตือนลง และเลือกไอคอน **วางสาย**

หมายเหตุ: คุณจะต้องเสียค่าใช้จ่ายในการโทรออกแต่ละสายด้วย

การดูบันทึกการโทร

บนหน้าจอหลัก ให้แตะ และเลือกแท็บ **บันทึกการโทร** ดูรายการสายที่โทรออก, ได้รับ และไม่ได้รับทั้งหมด

เคล็ดลับ!
- แตะที่รายการบันทึกการโทรใดๆ เพื่อดูวันที่, เวลา และระยะเวลาในการโทร
- แตะ **ปุ่มเมนู** แล้วแตะ **ลบทั้งหมด** เพื่อลบรายการที่บันทึกไว้ทั้งหมด

ตั้งค่าการโทร

คุณสามารถกำหนดค่าการตั้งค่าโทรศัพท์ เช่น การส่งต่อสาย และคุณสมบัติพิเศษอื่นๆ จากผู้ให้บริการ

1 บนหน้าจอหลัก ให้แตะ

2 แตะ

3 แตะ **ตั้งค่าการโทร** และเลือกตัวเลือกที่คุณต้องการปรับ

รายชื่อ

เพิ่มรายชื่อในโทรศัพท์และซิงโครไนซ์กับรายชื่อในบัญชี Google หรือแอคเคาท์อื่นที่สนับสนุนการซิงโครไนซ์รายชื่อ

การค้นหารายชื่อ

บนหน้าจอหลัก

1 แตะ เพื่อเปิดรายชื่อ
2 แตะ **ค้นหารายชื่อ** และป้อนชื่อโดยใช้แป้นพิมพ์

การเพิ่มรายชื่อใหม่

1 แตะ ป้อนหมายเลขของรายชื่อใหม่ แล้วแตะ **ปุ่มเมนู** แตะ **เพิ่มในรายชื่อ** > **รายชื่อใหม่**
2 หากคุณต้องการเพิ่มรูปภาพให้กับรายชื่อใหม่ ให้แตะพื้นที่ภาพ เลือกจาก **ถ่ายภาพ** หรือ **เลือกจากแกลเลอรี**
3 เลือกประเภทรายชื่อโดยแตะ
4 แตะชนิดของข้อมูลรายชื่อ และป้อนรายละเอียดเกี่ยวกับรายชื่อ
5 แตะ **บันทึก**

รายชื่อเพื่อนสนิท

คุณสามารถแยกรายชื่อที่โทรหาบ่อยๆ ไว้ในกลุ่มรายการโปรด

การเพิ่มรายชื่อเป็นเพื่อนสนิท

1 แตะ เพื่อเปิดรายชื่อ
2 แตะที่รายชื่อเพื่อดูรายละเอียด
3 แตะดาวทางมุมด้านขวาของชื่อ ดาวจะเปลี่ยนเป็นสีเหลือง

การลบรายชื่อออกจากรายชื่อเพื่อนสนิท

1 แตะ เพื่อเปิดรายชื่อ
2 แตะแท็บ และเลือกรายชื่อเพื่อดูรายละเอียด
3 แตะดาวสีเหลืองทางมุมด้านขวาของชื่อ ดาวจะเปลี่ยนเป็นสีเทา และรายชื่อจะถูกลบออกจากรายการโปรดของคุณ

การสร้างกลุ่ม

1 แตะ เพื่อเปิดรายชื่อ
2 แตะ **กลุ่ม** และแตะ **ปุ่มเมนู** เลือก **กลุ่มใหม่**
3 ป้อนชื่อสำหรับกลุ่มใหม่ คุณยังสามารถตั้งค่าเสียงเรียกเข้าสำหรับกลุ่มที่เพิ่มสร้างขึ้นใหม่
4 แตะ **บันทึก** เพื่อบันทึกกลุ่ม

หมายเหตุ: หากคุณลบกลุ่ม รายชื่อที่ได้รับการกำหนดให้กับกลุ่มนั้นจะไม่หายไป แต่ยังคงอยู่ในรายชื่อ

ข้อความ

โทรศัพท์ของคุณได้ผสมผสาน SMS และ MMS ไว้ในเมนูที่ใช้ง่ายเพียงเมนูเดียว

การส่งข้อความ

1 แตะ บนหน้าจอหลักและแตะ เพื่อเปิดข้อความเปล่า
2 ป้อนรายชื่อหรือหมายเลขของรายชื่อในฟิลด์ **ถึง** ขณะที่คุณป้อนรายชื่อ รายชื่อที่ตรงกันจะปรากฏขึ้น คุณสามารถแตะผู้รับที่แนะนำได้ คุณสามารถเพิ่มได้มากกว่าหนึ่งรายชื่อ

หมายเหตุ: คุณจะต้องเสียค่าใช้จ่ายสำหรับข้อความตัวอักษรในการส่งข้อความให้กับผู้รับทุกคน

3 แตะฟิลด์ **ป้อนข้อความ** และเริ่มต้นเขียนข้อความ
4 แตะ เพื่อเปิดเมนูตัวเลือก เลือกจาก **ข้อความด่วน, แทรกสไมลีย์, ตั้งเวลาการส่ง, เพิ่มชื่อเรื่อง** และ **ยกเลิก**

เคล็ดลับ! คุณสามารถแตะไอคอน เพื่อแนบไฟล์ที่คุณต้องการแบ่งปันไปกับข้อความ

5 แตะที่ **ส่ง** เพื่อส่งข้อความ
6 การตอบกลับจะปรากฏบนหน้าจอ ขณะที่คุณดูและส่งข้อความเพิ่มเติม เธรดข้อความจะถูกสร้างขึ้น

คำเตือน:
- การจำกัดตัวอักษรที่ 160 ตัวอักษรอาจจะแตกต่างกันไปในแต่ละประเทศขึ้นอยู่กับภาษาและวิธีการเข้ารหัส SMS
- หากมีการใส่รูปภาพ, วิดีโอ หรือไฟล์เสียงลงในข้อความ SMS ข้อความดังกล่าวจะถูกแปลงเป็นข้อความ MMS โดยอัตโนมัติ ซึ่งคุณจะเสียค่าใช้จ่ายตามนั้น

กล่องเธรด

ข้อความ (SMS, MMS) ที่แลกเปลี่ยนกับบุคคลอื่นสามารถแสดงเรียงตามลำดับเวลาเพื่อให้คุณสามารถดูภาพรวมของการสนทนาได้อย่างสะดวก

การเปลี่ยนการตั้งค่าข้อความมัลติมีเดีย

การตั้งค่าข้อความของโทรศัพท์ของคุณจะได้รับการกำหนดค่าไว้ล่วงหน้าแล้ว ดังนั้น คุณสามารถส่งข้อความได้ทันที คุณสามารถเปลี่ยนการตั้งค่าตามความต้องการของคุณ

- แตะไอคอน **ข้อความ** บนหน้าจอหลักของคุณ แตะ ☰ จากนั้นแตะ **ตั้งค่า**

อีเมล

คุณสามารถใช้แอปพลิเคชัน อีเมล เพื่ออ่านอีเมลจากบริการอื่นๆ เช่น Gmail ได้ แอปพลิเคชันอีเมลรองรับประเภทแอคเคาท์ต่อไปนี้: POP3, IMAP และ Exchange
ผู้ให้บริการหรือผู้ดูแลระบบของคุณสามารถให้การตั้งค่าแอคเคาท์ที่คุณต้องการได้

การจัดการแอคเคาท์อีเมล

เมื่อเปิดแอปพลิเคชัน **อีเมล** เป็นครั้งแรก วิซาร์ดตั้งค่าจะเปิดขึ้นเพื่อช่วยเหลือคุณในการตั้งค่าแอคเคาท์อีเมล
หลังจากการตั้งค่าครั้งแรก อีเมลจะแสดงเนื้อหาของกล่องขาเข้าของคุณ

การเพิ่มแอคเคาท์อีเมลอื่น:

- แตะ > > แท็บ **แอปฯ** > **อีเมล** > แตะ > **ตั้งค่า** > **เพิ่มแอคเคาท์**

การเปลี่ยนการตั้งค่าของแอคเคาท์อีเมล:

- แตะ > > แท็บ **แอปฯ** > **อีเมล** > แตะ > **ตั้งค่า** > **ตั้งค่าทั่วไป**

การลบแอคเคาท์อีเมล:

- แตะ > > แท็บ **แอปฯ** > **อีเมล** > แตะ > **ตั้งค่า** > แตะ > **ลบแอคเคาท์** > เลือกแอคเคาท์ที่จะลบ > **ลบ** > เลือก **ใช่**

การทำงานกับโฟลเดอร์แอคเคาท์

แตะ > > แท็บ **แอปฯ** > **อีเมล** > แตะ และเลือก **โฟลเดอร์**
แต่ละแอคเคาท์ประกอบด้วยโฟลเดอร์ ถาดเข้า, ถาดออก, ส่งแล้ว และ ร่าง ทั้งนี้คุณอาจมีโฟลเดอร์อื่นนอกเหนือจากนี้ ขึ้นอยู่กับคุณสมบัติที่ผู้ให้บริการแอคเคาท์ของคุณสนับสนุน

การเขียนและส่งอีเมล

การเขียนและส่งข้อความ

1 ในขณะที่อยู่ในแอปพลิเคชัน **อีเมล** ให้แตะ
2 ป้อนแอดเดรสของผู้รับที่ต้องการส่งข้อความ เมื่อคุณป้อนตัวอักษร แอดเดรสที่ตรงกันจากรายชื่อของคุณจะแสดงขึ้น คั่นแอดเดรสแต่ละแอดเคาท์ด้วยเครื่องหมายอัฒภาค
3 แตะ เพื่อเพิ่ม Cc/Bcc และแตะ เพื่อแนบไฟล์ หากต้องการ
4 ป้อนตัวอักษรในข้อความ
5 แตะ

เคล็ดลับ! เมื่อได้รับข้อความอีเมลใหม่ในกล่องขาเข้าของคุณ คุณจะได้รับแจ้งด้วยเสียงหรือการสั่น

กล้องถ่ายรูป

คุณสมบัติ AF (Autofocus) หลายจุดช่วยให้คุณได้ภาพที่คมชัดมากขึ้นและเป็นธรรมชาติ แม้ว่าวัตถุนั้นๆ จะไม่ได้อยู่ที่ศูนย์กลาง ในการเปิดแอปพลิเคชันกล้องถ่ายรูป ให้แตะ **กล้องถ่ายรูป** บนหน้าจอหลัก

ทำความรู้จักกับช่องมองภาพ

1. **แฟลช** – เลือกจาก **ปิด**, **เปิด**, **อัตโนมัติ**
2. **สลับกล้อง** – สลับไปมาระหว่างเลนส์กล้องถ่ายรูปที่ด้านหลังและเลนส์กล้องถ่ายรูปที่ด้านหน้า
3. **โหมดช็อต** – เลือกจาก **ปกติ, ถ่ายภาพและล้างภาพ**, **Dynamic tone (HDR)**, **พาโนรามา**, **VR พาโนรามา**, **ถ่ายภาพต่อเนื่อง**, **ช็อตสวยงาม**, **กล้องคู่**, **Time catch shot**, **ระบบอัตโนมัติอัจฉริยะ**, **กีฬา** หรือ **กลางคืน**
4. **ตั้งค่า** – แตะที่ไอคอนนี้เพื่อเปิดเมนูการตั้งค่า
5. **โหมดวิดีโอ** – แตะและเลื่อนไอคอนนี้ลงเพื่อสลับไปยังโหมดวิดีโอ
6. **ปุ่มถ่ายภาพ**
7. **แกลเลอรี่** – แตะเพื่อดูภาพถ่ายล่าสุดที่คุณถ่าย คุณสามารถเข้าดูแกลเลอรี่และดูภาพถ่ายที่บันทึกไว้ขณะอยู่ในโหมดกล้องถ่ายรูป

หมายเหตุ: โปรดตรวจสอบให้แน่ใจว่าได้ทำความสะอาดเลนส์กล้องถ่ายรูปก่อนถ่ายภาพ

การใช้การตั้งค่าขั้นสูง

ในช่องมองภาพ ให้แตะ ⚙ เพื่อเปิดตัวเลือกขั้นสูง คุณสามารถเปลี่ยนการตั้งค่ากล้องถ่ายรูปได้โดยเลื่อนรายการ หลังจากเลือกตัวเลือก ให้แตะ ↩

	ในการถ่ายภาพ ให้พูดหนึ่งในคำต่อไปนี้: Cheese (ชีส), Smile (สไมล์), Whisky (วิสกี้), Kimchi (กิมจิ) หรือ LG (แอลจี)
	กำหนดและควบคุมปริมาณแสงแดดที่เข้าในรูป
	แตะเพื่อเลือกโหมดโฟกัส
W10M	เลือกความละเอียดภาพถ่าย หากคุณเลือกความละเอียดสูง ขนาดไฟล์จะเพิ่มขึ้น ซึ่งหมายความว่าคุณจะสามารถจัดเก็บภาพถ่ายในหน่วยความจำได้น้อยลง
AUTO	ISO กำหนดความไวของเซนเซอร์แสงในกล้อง ISO ที่มากขึ้นความไวของกล้องก็มากขึ้นเท่านั้น ซึ่งจะเป็นประโยชน์สำหรับสภาพแวดล้อมที่มืดในขณะที่คุณไม่สามารถใช้แฟลชได้
AWB	ปรับปรุงคุณภาพสีในสภาวะแสงที่แตกต่างกัน
	ใช้เอฟเฟกต์งานศิลปะกับรูปภาพของคุณ
	ตั้งเวลาหลังจากกดปุ่มถ่ายภาพ ซึ่งเป็นวิธีการที่ช่วยให้คุณถ่ายรูปตนเองได้
	เปิดฟังก์ชันนี้เพื่อใช้บริการตามพื้นที่ของโทรศัพท์ ถ่ายภาพในที่ที่ต้องการและแท็กรูปภาพด้วยตำแหน่งที่ถ่ายภาพ หากคุณอัปโหลดรูปภาพที่แท็กไปยังบล็อกที่สนับสนุนจีโอแท็ก คุณจะเห็นรูปภาพนั้นแสดงบนแผนที่ **หมายเหตุ:** ฟังก์ชันนี้จะใช้ได้เมื่อเปิดใช้งานฟังก์ชัน GPS เท่านั้น
	เลือกเสียงชัตเตอร์
	ตั้งปุ่มปรับระดับเสียงว่าจะใช้สำหรับจับภาพหรือซูม

?	เปิดวิธีใช้เพื่อดูว่าฟังก์ชันนี้ทำงานอย่างไร
	เรียกคืนการตั้งค่าเริ่มต้นของกล้องถ่ายรูป

เคล็ดลับ!
- เมื่อคุณออกจากกล้อง การตั้งค่าบางส่วนจะกลับสู่ค่าเริ่มต้น เช่น ความสว่าง, โฟกัส, ISO, ความสมดุลแสง เอฟเฟคสี ตัวตั้งเวลา และโหมดช็อต ตรวจสอบค่าเหล่านี้ก่อนที่คุณจะถ่ายภาพครั้งถัดไป
- เมนูการตั้งค่าจะซ้อนทับอยู่บนช่องมองภาพ ดังนั้นเมื่อคุณเปลี่ยนสีภาพถ่ายหรือองค์ประกอบคุณภาพ คุณจะเห็นภาพตัวอย่างของภาพที่เปลี่ยนแปลงอยู่ด้านหลังเมนูตั้งค่า

การถ่ายภาพด่วน

1 เปิดแอปพลิเคชัน **กล้องถ่ายรูป** และหันเลนส์ไปยังวัตถุที่คุณต้องการถ่ายภาพ
2 ช่องโฟกัสจะปรากฏขึ้นที่กลางหน้าจอช่องมองภาพ คุณสามารถแตะตำแหน่งใดก็ได้บนหน้าจอเพื่อโฟกัสจุดนั้นนั้น
3 เมื่อช่องโฟกัสเป็นสีเขียว แสดงว่ากล้องได้จับโฟกัสที่วัตถุแล้ว
4 แตะ เพื่อถ่ายภาพ

ใช้โหมดถ่ายภาพและล้างภาพ

คุณสมบัตินี้ทำให้กล้องสามารถแยกวัตถุที่คุณอาจไม่ต้องการให้อยู่ในภาพหลังจากถ่ายภาพแล้ว แตะวัตถุที่มีกรอบ* เพื่อลบวัตถุนั้นออก จากนั้นบันทึกภาพ

1 เปิดแอปพลิเคชัน **กล้องถ่ายรูป**
2 แตะ โหมด > **ถ่ายภาพและล้างภาพ**
3 แตะ เพื่อถ่ายภาพ

4 แตะวัตถุที่มีกรอบเพื่อลบวัตถุนั้นออกจากภาพ จากนั้นแตะ
* ขณะถ่ายภาพ วัตถุที่เคลื่อนที่จะแสดงเป็นเส้นประ

หมายเหตุ
- ถ่ายภาพหลังจากตั้งกล้องนิ่งสนิทแล้ว
- หากวัตถุที่จะถ่ายมีสีคล้ายพื้นหลังมาก อาจทำให้จับภาพได้เพียงส่วนเดียวหรืออาจลบออกได้ยาก
- หากวัตถุที่เคลื่อนที่มีขนาดเล็กหรือใหญ่เกินไป อาจทำให้ลบออกได้ยาก
- หากวัตถุเคลื่อนที่เล็กน้อย อาจไม่สามารถจับภาพได้

ใช้โหมดกล้องคู่

ให้คุณสามารถถ่ายภาพด้วยกล้องหน้าและกล้องหลังพร้อมๆ กันแล้วรวมกันเป็นภาพเดียวได้

1 เปิดแอปพลิเคชัน **กล้องถ่ายรูป**
2 แตะ โหมด > **กล้องคู่**
3 ช่องมองภาพเล็กๆ จะปรากฏขึ้นบนช่องมองภาพหลัก ตั้งค่าการถ่ายภาพของคุณ
- ลากช่องมองภาพเล็กเพื่อย้ายไปยังตำแหน่งที่คุณต้องการ
- แตะช่องมองภาพเล็กค้างไว้เพื่อปรับขนาดช่องมองภาพ ถ้าจำเป็น
- แตะช่องมองภาพเล็กเพื่อสลับเลนส์ระหว่างช่องมองภาพหลักกับช่องมองภาพเล็ก

4 แตะ เพื่อถ่ายภาพแบบรวมภาพ

การใช้โหมด Time catch shot

ตั้งค่าให้กล้องจับภาพช่วงเวลาที่ขาดหายไปโดยให้ถ่ายภาพห้าภาพต่อเนื่องก่อนแตะ

1 เปิดแอปพลิเคชัน **กล้องถ่ายรูป**

2 แท็บ โหมด > **Time catch shot**
3 แตะ เพื่อถ่ายภาพ
4 ในการดูช่วงเวลาก่อนการถ่ายภาพ ให้แตะภาพขนาดย่อที่ด้านล่างของหน้าจอกล้องถ่ายรูป
5 เลือกรูปภาพที่คุณต้องการเก็บไว้ จากนั้นแตะ ที่ด้านบนสุดของหน้าจอ

เมื่อคุณถ่ายภาพแล้ว

แตะภาพขนาดย่อที่ด้านล่างของหน้าจอกล้องถ่ายรูปเพื่อดูภาพสุดท้ายที่คุณถ่าย

	แตะเพื่อแบ่งปันภาพถ่ายด้วยฟังก์ชัน **SmartShare**
	แตะเพื่อถ่ายภาพอื่นทันที
	แตะเพื่อส่งภาพถ่ายให้กับผู้อื่น หรือแบ่งปันผ่านบริการเครือข่ายสังคม
	แตะเพื่อลบภาพถ่าย

เคล็ดลับ! หากคุณตั้งค่าแอคเคาท์ SNS ไว้บนโทรศัพท์ของคุณ คุณสามารถแบ่งปันภาพถ่ายของคุณกับชุมชน SNS ได้

หมายเหตุ: คุณอาจต้องเสียค่าใช้จ่ายเพิ่มเติมเมื่อดาวน์โหลดข้อความ MMS ขณะโรมมิ่ง

แตะปุ่มเมนู เพื่อเปิดตัวเลือกขั้นสูงทั้งหมด
ตั้งค่าภาพเป็น – แตะเพื่อใช้ภาพถ่ายเป็น ***ภาพของรายชื่อติดต่อ, ภาพหน้าจอหลัก*** หรือ ***ภาพล็อคหน้าจอ***
ย้าย – แตะเพื่อย้ายรูปไปยังตำแหน่งอื่น
คัดลอก – แตะเพื่อคัดลอกภาพถ่ายที่เลือก และบันทึกลงในอัลบั้มอื่น
คัดลอกไปยังถาดคลิป – แตะเพื่อคัดลอกภาพถ่ายและจัดเก็บในถาดคลิป

กล้องถ่ายรูป

แก้ชื่อ – แตะเพื่อแก้ไขชื่อของภาพถ่ายที่เลือก
หมุนซ้าย/ขวา – หมุนไปทางซ้ายหรือขวา
ตัดภาพ – ตัดภาพถ่ายของคุณ เลื่อนนิ้วของคุณบนหน้าจอเพื่อเลือกพื้นที่ที่จะตัดภาพ
แก้ไข – ดูและแก้ไขรูปภาพ
สไลด์โชว์ – แสดงภาพของคุณในโฟลเดอร์ปัจจุบันทีละภาพ
เพิ่มการระบุตำแหน่ง – เพื่อเพิ่มข้อมูลตำแหน่ง
รายละเอียด – ดูข้อมูลเพิ่มเติมเกี่ยวกับไฟล์เหล่านั้น

จากแกลเลอรี่ของคุณ

แตะ **แกลเลอรี่** และเลือก **กล้องถ่ายรูป**

- ในการดูภาพถ่ายเพิ่มเติม ให้เลื่อนไปทางซ้ายหรือขวา
- ในการซูมเข้าหรือออก ให้แตะหน้าจอสองครั้งหรือวางนิ้วสองนิ้วและเลื่อนออกจากกัน (เลื่อนนิ้วเข้าหากันเพื่อซูมออก)

กล้องวิดีโอ

ทำความรู้จักกับช่องมองภาพ

1. **แฟลช** – เลือกจาก **ปิด**, **เปิด**, **อัตโนมัติ**
2. **สลับกล้อง** – สลับไปมาระหว่างเลนส์กล้องถ่ายรูปที่ด้านหลังและเลนส์กล้องถ่ายรูปที่ด้านหน้า
3. **โหมดการบันทึก** – เลือกจาก **ปกติ, เอฟเฟกต์ไลฟ์, บันทึกโหมดคู่** หรือ **ซูมติดตามวัตถุ**
4. **ตั้งค่า** – แตะที่ไอคอนนี้เพื่อเปิดเมนูการตั้งค่า
5. **โหมดกล้องถ่ายรูป** – แตะและเลื่อนไอคอนนี้ขึ้นเพื่อสลับไปยังโหมดกล้องถ่ายรูป
6. **เริ่มการบันทึก**
7. **แกลเลอรี่** – แตะเพื่อดูวิดีโอล่าสุดที่คุณบันทึก คุณสามารถเข้าดูแกลเลอรี่และดูวิดีโอของคุณที่บันทึกไว้ขณะอยู่ในโหมดวิดีโอ

เคล็ดลับ!
เมื่อบันทึกวิดีโอ ให้วางนิ้วสองนิ้วบนหน้าจอและเลื่อนเข้าหากันเพื่อใช้ฟังก์ชันซูม

การใช้การตั้งค่าขั้นสูง

ใช้ช่องมองภาพ แล้วแตะ ⚙ เพื่อเปิดตัวเลือกขั้นสูงทั้งหมด

Audio zoom	แตะเพื่อเปิดคุณสมบัติซูมเสียง คุณสามารถบันทึกเฉพาะเสียงที่คุณต้องการได้อย่างชัดเจนและเสียงดัง หลังจากที่เปิดให้เล็งไปที่วัตถุที่คุณต้องการซูม ที่ด้านในของวงกลมสีน้ำเงินในการซูมเข้าเสียงรวมถึงภาพ ให้เลื่อนนิ้วเข้าหากัน **หมายเหตุ** • ใช้ได้ในมุมมองแนวนอนเท่านั้น • ห้ามบังไมโครโฟนทั้งสองด้าน
FHD	แตะเพื่อตั้งค่าขนาด (พิกเซล) ของวิดีโอที่บันทึก **หมายเหตุ** • เมื่อตั้งค่า UHD ไว้ การบันทึกวิดีโอจะถูกจำกัดไว้ไม่เกิน 5 นาที • การติดตามวัตถุถูกปิดใช้งานใน UHD, QVGA, QCIF • ปุ่มถ่ายภาพถูกปิดใช้งานใน UHD, FHD(60fps), QVGA, QCIF
	กำหนดและควบคุมปริมาณแสงแดดที่เข้าสู่เลนส์ เลื่อนตัวบ่งชี้ความสว่างบนแถบไปทาง "-" เพื่อให้ได้วิดีโอที่มีความสว่างน้อยลง หรือไปทาง "+" เพื่อให้ได้วิดีโอที่มีความสว่างมากขึ้น
	แตะเพื่อเปิดคุณสมบัติป้องกันการสั่น ป้องกันภาพสั่นขณะบันทึกวิดีโอเพื่อให้ได้วิดีโอคุณภาพสูงสุด
AWB	ปรับปรุงคุณภาพสีในสภาวะแสงที่แตกต่างกัน
	เลือกโทนสีเพื่อใช้กับมุมมองใหม่
	เปิดฟังก์ชันนี้เพื่อใช้บริการตามพื้นที่ของโทรศัพท์
	ตั้งปุ่มปรับระดับเสียงว่าจะใช้สำหรับบันทึกภาพหรือซูม
?	เปิดวิธีใช้เพื่อดูว่าฟังก์ชันนี้ทำงานอย่างไร

	เรียกคืนการตั้งค่าเริ่มต้นของกล้องถ่ายรูป

การบันทึกวิดีโออย่างรวดเร็ว

1 เปิดแอปพลิเคชัน **กล้องถ่ายรูป** และเลื่อนปุ่ม **โหมดวิดีโอ**
2 ช่องมองภาพของกล้องวิดีโอจะปรากฏขึ้นบนหน้าจอ
3 ถือโทรศัพท์ แล้วหันเลนส์ไปทางวัตถุที่ต้องการถ่ายวิดีโอ
4 แตะ หนึ่งครั้งเพื่อเริ่มบันทึก
5 ไฟสีแดงจะปรากฏที่มุมด้านซ้ายบนของช่องมองภาพ พร้อมทั้งตัวตั้งเวลาเพื่อแสดงระยะเวลาของวิดีโอ
6 แตะ บนหน้าจอเพื่อหยุดการบันทึก

เคล็ดลับ!
– แตะเพื่อถ่ายภาพขณะบันทึกวิดีโอ
– แตะเพื่อหยุดชั่วคราวขณะบันทึกวิดีโอ

หลังการบันทึกวิดีโอ

ในช่องมองภาพ ให้แตะภาพขนาดย่อของวิดีโอที่ด้านล่างของหน้าจอเพื่อดูภาพสุดท้ายที่คุณถ่าย

	แตะเพื่อแบ่งปันวิดีโอของคุณด้วยฟังก์ชัน **SmartShare**
	แตะเพื่อบันทึกวิดีโออื่นต่อทันที
	แตะเพื่อส่งวิดีโอให้กับผู้อื่น หรือแบ่งปันผ่านบริการเครือข่ายสังคม
	แตะเพื่อลบวิดีโอ

หมายเหตุ: คุณอาจต้องเสียค่าใช้จ่ายเพิ่มเติมเมื่อดาวน์โหลดข้อความ MMS ขณะโรมมิ่ง

กล้องวิดีโอ

จากแกลเลอรี่ของคุณ

แตะ **แกลเลอรี่** และเลือก **กล้องถ่ายรูป** แตะไอคอนเล่นวิดีโอเพื่อเล่นวิดีโอ

การปรับระดับเสียงขณะดูวิดีโอ

ในการปรับระดับเสียงของวิดีโอขณะเล่น ให้ใช้ปุ่มปรับระดับเสียงที่ด้านหลังของโทรศัพท์

การใช้ซูมเสียง

โฟกัสการบันทึกเสียงเฉพาะในบริเวณที่คุณเลือก วิธีนี้จะเพิ่มความไวของไมโครโฟนและลดเสียงรบกวน

1 เปิดแอปพลิเคชัน **กล้องถ่ายรูป** แล้วเปลี่ยนเป็นโหมดวิดีโอ
2 แตะ > **ซูมเสียง** และเลือก **เปิด**
3 แตะพื้นที่ว่างในช่องมองภาพเพื่อปิดหน้าต่างป๊อปอัปตั้งค่า
4 ถือโทรศัพท์ในแนวนอนและแตะ เพื่อเริ่มบันทึก
5 โฟกัสวัตถุที่คุณต้องการซูมให้อยู่ข้างในวงกลมสีน้ำเงิน จากนั้นเลื่อนนิ้วเข้าหากันเพื่อซูมเข้า เพื่อเพิ่มความไวเสียงและลดเสียงรบกวน
6 แตะ เพื่อหยุดการบันทึก

หมายเหตุ
- ห้ามบังไมโครโฟนด้านข้างในขณะใช้คุณสมบัตินี้
- คุณต้องบันทึกในแนวนอนหากต้องการใช้ฟังก์ชันนี้

การใช้โหมดบันทึกโหมดคู่

ให้คุณสามารถบันทึกภาพด้วยกล้องหน้าและกล้องหลังพร้อมๆ กันแล้วรวมกันเป็นไฟล์เดียวได้

1 เปิดแอปพลิเคชัน **กล้องถ่ายรูป** แล้วเปลี่ยนเป็นโหมดวิดีโอ

2 แตะ [โหมด] > **บันทึกโหมดคู่**

3 ช่องมองภาพเล็กๆ จะปรากฏขึ้นบนช่องมองภาพหลัก ตั้งค่าการถ่ายภาพของคุณ

- ลากช่องมองภาพเล็กเพื่อย้ายไปยังตำแหน่งที่คุณต้องการ
- แตะช่องมองภาพเล็กค้างไว้เพื่อปรับขนาดช่องมองภาพ ถ้าจำเป็น
- แตะช่องมองภาพเล็กเพื่อสลับเลนส์ระหว่างช่องมองภาพหลักกับช่องมองภาพเล็ก

4 แตะ ● เพื่อเริ่มการบันทึกโหมดคู่

5 แตะ ■ เพื่อหยุดการบันทึกโหมดคู่

การใช้โหมดซูมติดตามวัตถุ

ให้คุณกำหนดพื้นที่บันทึกเพื่อโฟกัสและขยายได้
คุณสามารถเลือกพื้นที่ก่อนบันทึก แล้วเคลื่อนที่ขณะบันทึกได้ตามต้องการ

1 เปิดแอปพลิเคชัน **กล้องถ่ายรูป** แล้วเปลี่ยนเป็นโหมดวิดีโอ

2 แตะ [โหมด] > **ซูมติดตามวัตถุ**

3 ลากแว่นขยายไปยังพื้นที่ที่คุณต้องการขยาย จอขนาดเล็กจะแสดงโฟกัสที่กำหนดไว้ในมุมมองแบบขยาย

4 แตะ ● เพื่อเริ่มการบันทึก

- ขณะบันทึก คุณสามารถย้ายจอขนาดเล็กได้ แตะและลากจอไปยังบริเวณที่ต้องการ

5 แตะ ■ เพื่อหยุดการบันทึก

QuickMemo

ใช้ **QuickMemo** สร้างบันทึกและถ่ายภาพหน้าจอได้ ให้คุณถ่ายภาพหน้าจอ วาดรูปบนภาพ และแบ่งปันกับครอบครัวหรือเพื่อนๆ ด้วย QuickMemo

1 (ขณะที่ปิดหน้าจอ)
ให้กดปุ่มเพิ่มระดับเสียงค้างไว้

หรือ

หรือ

แตะและเลื่อนแถบสถานะลง และแตะ

2 เลือกตัวเลือกเมนูที่ต้องการจาก **ประเภทปากกา, สี, เครื่องลบ** และสร้างบันทึก

3 แตะ ในเมนู แก้ไข เพื่อจัดเก็บบันทึกพร้อมกับหน้าจอปัจจุบัน ในการออกจาก QuickMemo ให้แตะ

หมายเหตุ: โปรดใช้ปลายนิ้วขณะใช้ QuickMemo อย่าใช้เล็บ

การใช้ตัวเลือก QuickMemo

คุณสามารถใช้ตัวเลือก QuickMenu ได้อย่างง่ายดายในขณะที่ใช้ QuickMemo

	แตะเพื่อจัดเก็บ QuickMemo ปัจจุบันเป็น Text overlay บนหน้าจอและใช้โทรศัพท์ต่อไป
	เลือกว่าจะใช้หน้าจอภาพพื้นหลังหรือไม่
	เลิกทำหรือทำซ้ำ
	เลือกประเภทปากกาและสี
	ลบบันทึกที่คุณสร้าง
	แตะเพื่อแบ่งปันบันทึกกับคนอื่นๆ ผ่านแอปพลิเคชันที่ใช้ได้
	จัดเก็บบันทึกพร้อมกับหน้าจอปัจจุบันใน **แกลเลอรี่** หรือ **โน๊ตบุ๊ค**

การดู QuickMemo ที่บันทึกไว้

แตะ **โน๊ตบุ๊ค/แกลเลอรี่** และเลือกอัลบั้ม QuickMemo

QuickTranslator

เพียงเล็งกล้องถ่ายรูปของสมาร์ทโฟนไปที่ประโยคต่างประเทศที่คุณต้องการทำความเข้าใจ คุณสามารถรับการแปลแบบเรียลไทม์ได้ทุกที่และทุกเวลา

คุณสามารถซื้อพจนานุกรมเพิ่มเติมสำหรับการแปลแบบออฟไลน์ได้จาก Google Play Store

❶ ภาษาต้นทาง
❷ ภาษาปลายทาง
❸ คำแปลคำ
❹ คำแปลประโยค
❺ คำแปลบล็อค
❻ ตั้งค่า

1 แตะ > > แท็บ **แอปฯ** > **QuickTranslator**
2 แตะ **คำ, เส้น** หรือ **บล็อค**
3 แตะและเลือกภาษาที่ต้องการ
4 ถือโทรศัพท์หันไปทางข้อความที่คุณต้องการแปลค้างไว้สองถึงสามวินาที

หมายเหตุ: มีเพียงพจนานุกรมเดียวเท่านั้นที่ใช้ได้ฟรี จะต้องซื้อพจนานุกรมเพิ่มเติม โปรดเลือกพจนานุกรมที่คุณต้องการติดตั้งเป็นพจนานุกรมเสริมจากรายการด้านล่าง

หมายเหตุ: อัตราการแยกแยะคำอาจแตกต่างกันโดยขึ้นอยู่กับขนาด แบบอักษร สี ความสว่าง และองศาของตัวอักษรที่คุณต้องการแปล

QSlide

จากหน้าจอใดๆ เปิดสมุดบันทึก ปฏิทิน และอื่นๆ
เป็นหน้าต่างในหน้าจอของคุณ

1		แตะเพื่อออกจาก QSlide และกลับไปที่หน้าต่างเต็ม
2		แตะเพื่อปรับความโปร่งใส
3		แตะเพื่อสิ้นสุด QSlide
4		แตะเพื่อปรับขนาด

1 แตะและเลื่อนแถบสถานะลงด้านล่าง > แตะแอปพลิเคชัน QSlide หรือ ขณะใช้แอปพลิเคชันที่สนับสนุน QSlide > แตะ ฟังก์ชันจะยังคงแสดงเป็นหน้าต่างขนาดเล็กบนหน้าจอของคุณต่อไป

2 คุณสามารถโทรออก เรียกดูเว็บ หรือเลือกตัวเลือกโทรศัพท์อื่น คุณสามารถใช้และแตะหน้าจอของหน้าต่างเล็กเมื่อแถบโปร่งใสยังไม่เต็ม ได้เช่นกัน

หมายเหตุ: QSlide สามารถสนับสนุนได้สูงสุดสองหน้าต่างพร้อมกัน

QTheater

QTheater ให้คุณสามารถดูภาพสไลด์สำหรับรูปภาพ, วิดีโอ และ YouTube ได้

1 ในหน้าจอล็อค ถือโทรศัพท์ในแนวนอน
2 ดึงหน้าจอด้วยนิ้วหัวแม่มือทั้งสองข้าง
3 คุณสามารถดูภาพสไลด์ของฟังก์ชันที่ต้องการได้

หมายเหตุ: ต้องตั้งโหมดล็อคหน้าจอให้เป็นปัด ก่อนที่คุณจะใช้ฟังก์ชัน QTheater

1 แตะ > **แท็บ แอปฯ** > **ตั้งค่า** > **แท็บ** หน้าจอ > **ล็อคหน้าจอ** > **เลือกแบบล็อคหน้าจอ**
2 เลือก **ปัด**

QuickRemote

QuickRemote เปลี่ยนโทรศัพท์ของคุณเป็นรีโมทคอนโทรลอเนกประสงค์สำหรับ ทีวี เซ็ตท็อปบ็อกซ์ เครื่องเสียง เครื่องเล่น DVD/Blu-ray แอร์ และโปรเจคเตอร์ภายในบ้านของคุณ

1 แตะและเลื่อนแถบสถานะลงด้านล่าง แล้วแตะ > **เพิ่มรีโมท**

หรือ

แตะ > > **แท็บ** แอปฯ > **QuickRemote** > แตะ

2 เลือกประเภทและแบรนด์ของอุปกรณ์ จากนั้นทำตามคำแนะนำบนหน้าจอ เพื่อกำหนดค่าอุปกรณ์

3 แตะและเลื่อนแถบสถานะลงด้านล่าง และใช้ฟังก์ชัน QuickRemote

แตะ **ปุ่มเมนู** เพื่อเลือก **ตั้งค่าเมจิกรีโมท, แก้ไขชื่อรีโมท, เรียนรู้แบบรีโมท, ย้ายรีโมท, ลบรีโมท, แก้ไขห้อง, ตั้งค่า** และ **ช่วยเหลือ**

หมายเหตุ: QuickRemote จะทำงานด้วยวิธีเดียวกับสัญญาณอินฟราเรด (IR) ของรีโมทคอนโทรลทั่วไป ระมัดระวังไม่ให้บังเซนเซอร์อินฟราเรดที่ด้านหลังของโทรศัพท์เมื่อคุณใช้ฟังก์ชัน QuickRemote ฟังก์ชันนี้อาจไม่ได้รับการสนับสนุน ทั้งนี้ขึ้นอยู่กับรุ่น ผู้ผลิต หรือบริษัทที่ให้บริการ

ซูมแบบติดตาม

เมื่อคุณเล่นวิดีโอ คุณสามารถขยายขณะติดตามวัตถุได้

1 เมื่อคุณเล่นวิดีโอ ให้แตะ

2 แตะแว่นขยายและลากแว่นขยายมายังวัตถุที่ต้องการติดตาม

หมายเหตุ:

- ขณะเล่นวิดีโอ ให้เลื่อนด้านซ้ายของหน้าจอขึ้นหรือลงเพื่อปรับความสว่างของหน้าจอ
- ขณะเล่นวิดีโอ ให้เลื่อนหน้าจอไปทางซ้ายหรือขวาเพื่อย้อนกลับหรือไปข้างหน้าอย่างรวดเร็ว
- ไม่ต้องออกแรงกดมาก หน้าจอสัมผัสไวต่อการสัมผัสที่เบาแต่แน่นอน
- ซูมไปยังแทร็กอาจไม่ทำงานหากวัตถุนั้นเคลื่อนที่เร็วเกินไป หรือออกนอกจอ

VuTalk

ด้วยคุณสมบัติ VuTalk คุณสามารถสร้างบันทึกแบบอินเตอร์แอคทีฟและสร้างสรรค์ร่วมกับผู้อื่นได้ การสื่อสารด้วยภาพเป็นไปได้ในขณะแบ่งปันภาพ แผนที่ และตัวอย่างภาพในกล้อง

หมายเหตุ:
- ใช้งานได้ในโทรศัพท์รุ่นที่รองรับคุณสมบัตินี้เท่านั้น
- คุณสามารถใช้คุณสมบัติ VuTalk ขณะโทรได้เช่นกัน
- หน้าจอจะล็อคหากไม่มีการป้อนข้อมูลใดๆ
- ต้องมีการเชื่อมต่อข้อมูล อาจมีค่าใช้จ่ายข้อมูลสำหรับโทรศัพท์ทั้งสองเครื่อง

ลงทะเบียน VuTalk ก่อนใช้

1 แตะ > **รายชื่อ** >
คุณสามารถลงทะเบียนบริการ VuTalk ขณะโทรได้เช่นกัน
2 อ่านข้อกำหนดและเงื่อนไข และนโยบายความเป็นส่วนตัวของแอปพลิเคชัน LG หากคุณยอมรับ ให้แตะช่องทำเครื่องหมาย แล้วแตะ **ยอมรับ**

ตั้งค่า VuTalk

1 แตะ > **รายชื่อ** > > **ตั้งค่า VuTalk**
2 ตั้งค่าตัวเลือกต่อไปนี้ตามที่คุณต้องการ
- **เสียงการแจ้งเตือน:** เลือกเสียงเตือนที่ต้องการ
- **สั่น:** เลือกประเภทการสั่นที่ต้องการ
- **แสดงคำขอ:** เลือกตัวเลือกนี้เพื่อแสดงป๊อปอัปเมื่อมีการรับคำขอ VuTalk
- **ซิงค์รายชื่อ:** เลือกตัวเลือกนี้เพื่อซิงค์รายชื่อ

สื่อสารด้วยภาพผ่าน VuTalk

1 แตะ > **รายชื่อ** > เฉพาะรายชื่อผู้ที่ใช้คุณสมบัติ VuTalk เท่านั้นที่จะปรากฏขึ้น
2 แตะรายชื่อที่ต้องการเพื่อเริ่มใช้งาน VuTalk
3 ในหน้าจอรายละเอียดของรายชื่อ ให้แตะ เมื่ออีกฝ่ายยอมรับคำขอ VuTalk คุณก็สามารถเริ่ม VuTalk กับเขา/เธอได้ทันที
4 ใช้หน้าจอ VuTalk เพื่อแชทและสื่อสารด้วยภาพกับเพื่อนๆ ของคุณ

- แตะ เพื่อแนบรูปถ่าย ถ่ายภาพใหม่ แสดงแผนที่ หรือสติ๊กเกอร์
- แตะไอคอนปากกา และ ไอคอนยางลบ เพื่อเขียนข้อความบนภาพที่คุณแนบไป

5 เมื่อใช้งาน VuTalk เสร็จแล้ว ให้แตะ หรือออกจากคุณสมบัติ VuTalk หน้าจอ VuTalk ที่สร้างขึ้นจะถูกเก็บไว้ในแอปพลิเคชัน **โน๊ตบุ๊ค**

หมายเหตุ: หากคุณแตะ และกลับไปที่หน้าหลัก คุณสมบัติ VuTalk จะยังคงทำงานอยู่ในแบ็คกราวด์

LG SmartWorld

LG SmartWorld นำเสนอเนื้อหาที่น่าตื่นเต้นมากมาย เช่น เกมส์, แอปพลิเคชัน, พื้นหลังและเสียงเรียกเข้า ทำให้ผู้ใช้โทรศัพท์ LG สามารถสัมผัสกับประสบการณ์ "Mobile Life" ได้มากยิ่งขึ้น

วิธีการเข้าสู่ LG SmartWorld จากโทรศัพท์ของคุณ

1 แตะ > > แท็บ **แอปฯ** > แตะไอคอน เพื่อเข้าถึง **LG SmartWorld**
2 แตะ ลงชื่อเข้าใช้ และป้อนข้อมูล ID/PW สำหรับ LG SmartWorld หากคุณยังไม่ได้สมัครสมาชิก ให้แตะรีจิสเตอร์เพื่อรับสถานะสมาชิก LG SmartWorld
3 ดาวน์โหลดเนื้อหาที่คุณต้องการ

หมายเหตุ: หากไม่มีไอคอน
1 ให้ใช้เว็บเบราวเซอร์มือถือ เข้าใช้ LG SmartWorld (www.lgworld.com) และเลือกประเทศของคุณ
2 ดาวน์โหลดแอปพลิเคชัน LG SmartWorld
3 รันและติดตั้งไฟล์ที่ดาวน์โหลด
4 เข้าใช้ LG SmartWorld โดยการแตะไอคอน

วิธีการใช้ LG SmartWorld

- เข้าร่วมการส่งเสริมการขาย LG SmartWorld ทุกเดือน

	ค้นหาเนื้อหา
	ค้นหาเนื้อหาตามประเภท (เช่น เกม การศึกษา ความบันเทิง ฯลฯ)

- ลองใช้ปุ่ม "เมนู" เพื่อค้นหาสิ่งที่คุณต้องการอย่างรวดเร็ว
  ตั้งค่า – ตั้งค่าโปรไฟล์และหน้าจอ
  ลงชื่อเข้าใช้ – ตั้งค่า ID และรหัสผ่านของคุณ
- และลองใช้ฟังก์ชันอื่นๆ ที่มีประโยชน์ (หน้าจอรายละเอียดเนื้อหา)

หมายเหตุ: LG SmartWorld อาจไม่มีให้บริการในบางประเทศหรือจากผู้ให้บริการบางราย

On-Screen Phone

On-Screen Phone ให้คุณสามารถดูหน้าจอโทรศัพท์จากคอมพิวเตอร์ผ่านการเชื่อมต่อ USB หรือ Wi-Fi คุณยังสามารถควบคุมโทรศัพท์มือถือจากคอมพิวเตอร์โดยใช้เมาส์หรือแป้นพิมพ์

ไอคอน On-Screen Phone

	เชื่อมต่อโทรศัพท์มือถือกับคอมพิวเตอร์ หรือยกเลิกการเชื่อมต่อ
	เปลี่ยนแปลงการกำหนดค่า On-Screen Phone
	ออกจากโปรแกรม On-Screen Phone
	ย่อหน้าต่าง On-Screen Phone
	ย่อหน้าต่าง On-Screen Phone

คุณสมบัติ On-Screen Phone

- การถ่ายโอนและการควบคุมแบบเรียลไทม์: แสดงและควบคุมหน้าจอโทรศัพท์เมื่อเชื่อมต่อกับคอมพิวเตอร์
- การควบคุมเมาส์: ให้คุณควบคุมโทรศัพท์ด้วยการใช้เมาส์คลิกและลากบนหน้าจอคอมพิวเตอร์
- ป้อนข้อความด้วยแป้นพิมพ์: ให้คุณสร้างข้อความหรือบันทึกโดยใช้แป้นพิมพ์คอมพิวเตอร์
- ถ่ายโอนไฟล์ (โทรศัพท์ไปยังคอมพิวเตอร์): ส่งไฟล์จากโทรศัพท์ (เช่น ภาพถ่าย วิดีโอ เพลง และไฟล์ POLARIS Viewer 5) ไปยังคอมพิวเตอร์ โดยเพียงคลิกขวาที่ไฟล์ที่คุณต้องการส่งไปยังคอมพิวเตอร์ และคลิก "บันทึกในคอมพิวเตอร์"
- ถ่ายโอนไฟล์ (คอมพิวเตอร์ไปยังโทรศัพท์): ส่งไฟล์จากคอมพิวเตอร์ไปยังโทรศัพท์ เพียงแค่เลือกไฟล์ที่คุณต้องการถ่ายโอน แล้วลากและวางไฟล์ลงในหน้าต่าง On-Screen Phone

ไฟล์ที่ส่งจะถูกจัดเก็บในการ์ด SD ภายใน

- การแจ้งเตือนเหตุการณ์แบบเรียลไทม์: ป๊อปอัปข้อความเพื่อแจ้งคุณเมื่อมีสายเรียกเข้าหรือเมื่อมีข้อความตัวอักษร/ มัลติมีเดียมาถึง

วิธีติดตั้ง On-Screen Phone ในคอมพิวเตอร์

1 เยี่ยมชมหน้าหลัก LG (www.lg.com) และเลือกประเทศที่คุณต้องการ

2 ไปที่ **บริการ** > **บริการโทรศัพท์มือถือ** > เลือกรุ่น (LG-D958) > คลิก **OSP** (On-Screen Phone) เพื่อดาวน์โหลด จากนั้น คุณสามารถติดตั้ง On-Screen Phone ลงในคอมพิวเตอร์ของคุณ

มัลติมีเดีย

แกลเลอรี่

เปิดแอปพลิเคชัน **คลังภาพ** เพื่อดูอัลบั้มรูปภาพและวิดีโอ

1 แตะ > > แท็บ **แอปฯ** > **แกลเลอรี่**
คุณสามารถจัดการและแบ่งปันไฟล์ภาพและวิดีโอทั้งหมดได้ด้วยแกลเลอรี่

หมายเหตุ:
- ไม่สนับสนุนรูปแบบไฟล์บางรูปแบบ โดยขึ้นอยู่กับซอฟต์แวร์ที่ติดตั้งบนอุปกรณ์
- บางไฟล์อาจแสดงผลได้ไม่ถูกต้อง ขึ้นอยู่กับลักษณะการเข้ารหัส

การดูรูปภาพ

การเปิดแกลเลอรี่จะเป็นการแสดงโฟลเดอร์ที่มีของคุณ เมื่อแอปพลิเคชันอื่น เช่น อีเมล จัดเก็บรูปภาพ โฟลเดอร์ Download จะถูกสร้างขึ้นโดยอัตโนมัติ เพื่อเก็บรูปภาพ เช่นเดียวกัน การบันทึกภาพหน้าจอจะเป็นการสร้างโฟลเดอร์ Screenshots โดยอัตโนมัติ เลือกโฟลเดอร์เพื่อเปิด
รูปภาพจะถูกแสดงตามวันที่สร้างในโฟลเดอร์ เลือกรูปภาพเพื่อดูแบบเต็มจอ เลื่อนไปทางซ้ายหรือขวาเพื่อดูภาพถัดไปหรือก่อนหน้า

การซูมเข้าและออก

ใช้หนึ่งในวิธีต่อไปนี้เพื่อซูมเข้าภาพ:
- แตะสองครั้งที่ใดก็ได้เพื่อซูมเข้า
- เลื่อนนิ้วทั้งสองออกจากกันในตำแหน่งใดก็ได้เพื่อซูมเข้า
  เลื่อนนิ้วเข้าหากันเพื่อซูมออก หรือแตะสองครั้งเพื่อย้อนกลับ

การเล่นวิดีโอ

ไฟล์วิดีโอจะแสดงไอคอน ในภาพตัวอย่าง เลือกวิดีโอที่จะดูและแตะ แอปพลิเคชัน วิดีโอ จะเปิดขึ้น

การแก้ไขภาพถ่าย

เมื่อดูภาพถ่าย ให้แตะ **ปุ่มเมนู** > **แก้ไข**

การลบภาพถ่าย/วิดีโอ

ใช้หนึ่งในวิธีต่อไปนี้:

- ในโฟลเดอร์ แตะ และเลือกภาพถ่าย/วิดีโอโดยการทำเครื่องหมายถูก จากนั้นแตะ **ลบ**
- ขณะดูภาพถ่าย/ภาพวิดีโอ ให้แตะ

การตั้งค่าเป็นภาพพื้นหลัง

ขณะดูภาพถ่าย ให้แตะ **ปุ่มเมนู** > **ตั้งค่าภาพเป็น** เพื่อตั้งภาพเป็นภาพพื้นหลัง หรือเพื่อกำหนดให้กับรายชื่อ

หมายเหตุ:

- ไม่สนับสนุนรูปแบบไฟล์บางรูปแบบ โดยขึ้นอยู่กับซอฟต์แวร์อุปกรณ์
- หากขนาดไฟล์ใหญ่เกินกว่าหน่วยความจำที่มีอยู่ อาจเกิดข้อผิดพลาดเมื่อคุณเปิดไฟล์นั้น
- ความละเอียดจะถูกลดขนาดจาก Ultra-HD เป็น Full-HD เมื่อเชื่อมต่อโทรศัพท์กับทีวีผ่านทาง Slimport (หรือ Miracast)

วิดีโอ

โทรศัพท์ของคุณมีเครื่องเล่นวิดีโอภายในตัวที่ให้คุณสามารถเล่นวิดีโอที่คุณชื่นชอบทั้งหมดได้ ในการเข้าใช้งานเครื่องเล่นวิดีโอ ให้แตะ > > แท็บ **แอปฯ** > **วิดีโอ**

การเล่นวิดีโอ

1 แตะ > > แท็บ **แอปฯ** > **วิดีโอ**
2 เลือกวิดีโอที่คุณต้องการเล่น

	แตะทิศทางที่ต้องการสำหรับ Audio zoom
	แตะเพื่อใช้คุณสมบัติซูมไปยังแทร็ก
	แตะเพื่อเข้าสู่ Qslide โหมด
	แตะเพื่อแบ่งปันวิดีโอของคุณผ่านฟังก์ชัน SmartShare
	แตะเพื่อล็อคหน้าจอวิดีโอ
	แตะเพื่อดูรายการวิดีโอ
	แตะเพื่อจับภาพหน้าจอ
	แตะเพื่อหยุดการเล่นวิดีโอชั่วคราว
	แตะเพื่อเล่นวิดีโอต่อ
	แตะเพื่อเดินหน้าไป 10 วินาที
	แตะเพื่อถอยหลังไป 10 วินาที
	แตะเพื่อจัดการระดับเสียงของวิดีโอ
	แตะเพื่อเปลี่ยนอัตราส่วนหน้าจอวิดีโอ

หากต้องการเปลี่ยนระดับเสียงในขณะที่ดูวิดีโอ ให้ใช้ปุ่มปรับระดับเสียงขึ้นและลงที่อยู่ด้านข้างของโทรศัพท์

แตะวิดีโอในรายการค้างไว้ ตัวเลือก **แบ่งปัน**, **ลบ**, **ตัดแต่ง** และ **รายละเอียด** จะปรากฏขึ้น

หมายเหตุ: วิดีโอ UHD(Ultra-HD) ไม่สนับสนุน**ตัวเลือก**ตัดแต่งเมื่อเล่นในแอปพลิเคชัน **คลังภาพ** และ **วิดีโอ**

เพลง

โทรศัพท์ของคุณมีเครื่องเล่นเพลงในตัวซึ่งให้คุณสามารถเล่นเพลงที่คุณชื่นชอบทั้งหมดได้ ในการเข้าใช้งานเครื่องเล่นเพลง ให้แตะ > > แท็บ **แอปฯ** > **เพลง**

เพิ่มไฟล์เพลงในโทรศัพท์ของคุณ

เริ่มต้นจากการถ่ายโอนไฟล์เพลงไปยังโทรศัพท์ของคุณ:

- ถ่ายโอนเพลงโดยใช้ซิงค์มีเดีย (MTP)
- ดาวน์โหลดจากเว็บไร้สาย
- ซิงโครไนซ์โทรศัพท์ของคุณกับคอมพิวเตอร์
- รับไฟล์ผ่าน Bluetooth

ถ่ายโอนเพลงโดยใช้ซิงค์มีเดีย (MTP)

1 เชื่อมต่อโทรศัพท์กับคอมพิวเตอร์โดยใช้สายเคเบิล USB
2 เลือกตัวเลือก **ซิงค์มีเดีย (MTP)** โทรศัพท์ของคุณจะปรากฏเป็นฮาร์ดไดรฟ์ในคอมพิวเตอร์ของคุณ คลิกไดรฟ์เพื่อดู คัดลอกไฟล์จากคอมพิวเตอร์ไปยังโฟลเดอร์ไดรฟ์
3 เมื่อคุณเสร็จสิ้นการถ่ายโอนไฟล์แล้ว ให้ลากนิ้วลงบนแถบสถานะ และแตะ **เชื่อมต่อ USB แล้ว** > **ชาร์จโทรศัพท์** คุณสามารถถอดปลั๊กอุปกรณ์ของคุณได้อย่างปลอดภัย

การเล่นเพลง

1 แตะ > > แท็บ **แอปฯ** > **เพลง**
2 แตะ **เพลง**
3 เลือกเพลงที่คุณต้องการเล่น

	แตะเพื่อหยุดเล่นชั่วคราว
	แตะเพื่อเล่นต่อ
	แตะเพื่อข้ามไปที่แทร็คถัดไปในอัลบั้ม รายการเพลง หรือสับเปลี่ยน แตะค้างไว้เพื่อไปข้างหน้าโดยเร็ว
	แตะเพื่อเริ่มเล่นแทร็คปัจจุบันอีกครั้ง หรือข้ามไปยังแทร็คก่อนหน้าในอัลบั้ม รายการเพลง หรือสับเปลี่ยน แตะค้างไว้เพื่อย้อนกลับ
	แตะเพื่อแสดงแถบเลื่อนระดับเสียง จากนั้นปรับระดับเสียงที่แถบเลื่อน
	แตะเพื่อตั้งค่าเอฟเฟกต์เสียง
	แตะเพื่อค้นหาไฟล์ด้วย YouTube
	แตะเพื่อเปิดรายการเพลงปัจจุบัน
	แตะเพื่อเพิ่มเพลงในรายการโปรดของคุณ
	แตะเพื่อเล่นรายการเพลงปัจจุบันในโหมดสับเปลี่ยน (แทร็คจะเล่นตามลำดับการสุ่ม)
	แตะเพื่อสลับระหว่างโหมดซ้ำ เล่นเพลงทั้งหมดซ้ำ เล่นเพลงปัจจุบันซ้ำ หรือปิดทำซ้ำ
	แตะเพื่อแบ่งปันเพลงของคุณผ่านฟังก์ชัน SmartShare

หากต้องการเปลี่ยนระดับเสียงในขณะที่ฟังเพลง ให้ใช้ปุ่มปรับระดับเสียงขึ้นและลงที่อยู่ด้านหลังโทรศัพท์

แตะเพลงหนึ่งในรายการเพลงค้างไว้ ตัวเลือก **เล่น**, **เพิ่มในรายการเพลง**, **แบ่งปัน**, **ตั้งเป็นเสียงเรียกเข้า**, **ลบ**, **รายละเอียด** และ **ค้นหา** จะปรากฏขึ้น

หมายเหตุ:

- ไม่สนับสนุนรูปแบบไฟล์บางรูปแบบ โดยขึ้นอยู่กับซอฟต์แวร์อุปกรณ์
- หากขนาดไฟล์ใหญ่เกินกว่าหน่วยความจำที่มีอยู่ อาจเกิดข้อผิดพลาดเมื่อคุณเปิดไฟล์นั้น

หมายเหตุ: **ลิขสิทธิ์ของไฟล์เพลงจะได้รับความคุ้มครองตามสนธิสัญญานานาชาติและกฎหมายลิขสิทธิ์ของแต่ละประเทศ**
ดังนั้น อาจจำเป็นที่ต้องได้รับอนุญาตหรือได้สิทธิ์ในการทำซ้ำหรือคัดลอกเพลง ในกฎหมายของบางประเทศมีข้อห้ามในการคัดลอกสื่อที่มีลิขสิทธิ์ด้วยตนเอง ก่อนดาวน์โหลดหรือคัดลอกไฟล์ ให้ตรวจสอบกฎข้อบังคับของประเทศนั้นๆ เกี่ยวกับการใช้สื่อต่างๆ

ลื่อนไปด้านข้าง (การสลับงานอย่างรวดเร็วด้วยนิ้วสามนิ้ว)

คุณสามารถสลับไปยังงานอื่นได้อย่างรวดเร็วด้วยนิ้วสามนิ้ว

1 วางนิ้วสามนิ้วไว้บนหน้าจอที่คุณกำลังใช้งานอยู่แล้วเลื่อนหน้าจอไปทางซ้าย หน้าจอปัจจุบันจะถูกบันทึก และคุณจะสามารถทำงานอื่นได้

- คุณสามารถบันทึกได้ 3 (สาม) แอปฯ ที่ด้านซ้ายของหน้าจอ

2 ในการเปิดหน้าจอที่บันทึกไว้อีกครั้งแล้วใช้แอปพลิเคชันนั้นๆ ต่อ ให้วางสามนิ้วไว้บนหน้าจอแล้วเลื่อนไปทางขวา

หมายเหตุ: โปรดระวังอย่าวางนิ้วอีกนิ้วหรือฝ่ามือบนหน้าจอ

หน้าต่างคู่

สามารถดูสองหน้าจอที่แยกจากกันได้ในเวลาเดียวกัน

1 แตะปุ่มย้อนกลับค้างไว้เพื่อแบ่งหน้าจอ

2 แตะหรือลากไอคอนแอปพลิเคชันที่คุณต้องการใช้

(ไอคอนสวิตช์) : สลับสองหน้าจอ
(ไอคอนการลาก) : ลากเพื่อย่อขนาดหน้าจอที่แยก
(ไอคอนเมนู) : แตะเพื่อดูรายการแอปพลิเคชัน เปลี่ยนเป็นแบบเต็มหน้าจอ หรือปิดแอปพลิเคชันในปัจจุบัน

หมายเหตุ: ควรตั้งค่าหน้าต่างคู่ก่อนใช้งานฟังก์ชัน

1 แตะ > **แท็บ** แอปฯ > **ตั้งค่า** > **แท็บ** ทั่วไป > **มัลติทาสกิ้ง** > **หน้าต่างคู่**
2 ทำเครื่องหมาย**ในช่อง** หน้าต่างคู่

โหมด Guest

คุณสามารถใช้งานโหมด Guest เพื่อป้องกันความเป็นส่วนตัวของคุณหรือจำกัดบางแอปพลิเคชันจากเด็กๆ ได้
เมื่อคุณให้ผู้อื่นยืมโทรศัพท์ คุณสามารถจำกัดแอปพลิเคชันที่จะปรากฏขึ้นได้ ให้ตั้งค่าโหมด Guest และปรับตัวเลือกต่างๆ ไว้ล่วงหน้า

หมายเหตุ: ในการใช้งานโหมด Guest ควรตั้งค่าล็อคแบบไว้ล่วงหน้า

1 แตะ > > **แท็บแอปฯ** > **ตั้งค่า** > แท็บ **ทั่วไป** > **โหมด Guest**
2 แตะเพื่อเปิดใช้โหมด Guest

การตั้งเวลาการปลุก

1 แตะ > > แท็บ **แอปฯ** > **ตั้งปลุก/นาฬิกา** >
2 หลังจากที่คุณตั้งค่านาฬิกาปลุก โทรศัพท์ของคุณจะแจ้งให้คุณทราบว่าเหลือเวลาอีกเท่าไหร่ก่อนที่การปลุกจะทำงาน
3 ตั้งค่า **ซ้ำ**, **ระยะเวลาเลื่อน**, **สั่น**, **เสียงปลุก**, **ระดับเสียงปลุก**, **เริ่มใช้แอปฯ อัตโนมัติ**, **ล็อคปริศนา** และ **บันทึก** แตะ **บันทึก**

หมายเหตุ: ในการเปลี่ยนการตั้งค่าการปลุกในหน้าจอรายการเตือน ให้แตะ **ปุ่มเมนู** และเลือก **ตั้งค่า**

การใช้เครื่องคิดเลข

1 แตะ > > แท็บ **แอปฯ** > **เครื่องคิดเลข**
2 แตะปุ่มตัวเลขเพื่อป้อนตัวเลข
3 สำหรับการคำนวณอย่างง่าย ให้แตะที่ฟังก์ชันที่คุณต้องการ (+, –, x หรือ ÷) แล้วตามด้วย =
4 สำหรับการคำนวณแบบซับซ้อน ให้แตะ > **เครื่องคิดเลขพื้นฐาน**
5 ในการตรวจสอบประวัติ ให้แตะ > **ประวัติการคำนวณ**

การเพิ่มเหตุการณ์ลงในปฏิทิน

1 แตะ > > แท็บ **แอปฯ** > **ปฏิทิน**
2 บนหน้าจอ คุณจะพบกับประเภทมุมมองต่างๆ ของปฏิทิน (วัน สัปดาห์ เดือน ปี นัดหมาย Life Square)
3 แตะวันที่ซึ่งคุณต้องการเพิ่มเหตุการณ์ และแตะ
4 แตะ **ชื่อเหตุการณ์** แล้วป้อนชื่อเหตุการณ์
5 แตะ **ตำแหน่ง** และป้อนตำแหน่ง ตรวจสอบวันที่และป้อนเวลาที่คุณต้องการให้เหตุการณ์เริ่มและเสร็จสิ้น
6 หากคุณต้องการใส่บันทึกลงในเหตุการณ์ของคุณ ให้แตะ **เชื่อมโยงบันทึก** เลือกภาพโน้ตบุ๊คที่บันทึก (ใช้ได้ในปฏิทินโทรศัพท์เท่านั้น)
7 หากคุณต้องการให้ส่งเสียงเตือนซ้ำ ให้ตั้งค่า **ซ้ำ** และตั้งค่า **เตือนความจำ** หากจำเป็น
8 แตะ **บันทึก** เพื่อบันทึกเหตุการณ์ในปฏิทิน

บันทึกเสียง

ใช้บันทึกเสียงเพื่อบันทึกเสียงเตือนความจำหรือไฟล์เสียงอื่นๆ

การบันทึกเสียงหรือเสียงพูด

1 แตะ > > **เครื่องบันทึกเสียง**
2 แตะ เพื่อเริ่มต้นการบันทึก
3 แตะ เพื่อจบการบันทึก
4 แตะ เพื่อฟังการบันทึก

หมายเหตุ: แตะ เพื่อเข้าใช้อัลบั้ม คุณสามารถฟังการบันทึกเสียงที่บันทึกไว้ได้ เวลาการบันทึกที่ใช้อาจแตกต่างจากเวลาการบันทึกจริง

การส่งรายการบันทึกเสียง

1 เมื่อคุณบันทึกเสียงเสร็จแล้ว คุณสามารถส่งคลิปเสียงได้โดยการแตะ
2 เลือกจาก **Bluetooth, อีเมล, Gmail, บันทึก**, **ข้อความ** หรือ **SmartShare Beam**เมื่อคุณเลือก **อีเมล, Gmail, บันทึก** หรือ **ข้อความ** การบันทึกเสียงจะถูกเพิ่มไปยังข้อความ จากนั้นคุณสามารถเขียนและส่งข้อความได้ตามปกติ

จัดการแอปฯ

คุณสามารถจัดการแอปพลิเคชันได้โดยใช้จัดการแอปฯ คุณสามารถตรวจสอบจำนวนแอปพลิเคชันที่กำลังรันและปิดแอปพลิเคชันที่ต้องการได้ง่ายๆ

การทำงาน

งานนี้สามารถสามารถซิงโครไนซ์กับแอคเคาท์ MS Exchange ได้ คุณสามารถสร้าง แก้ไข และลบงานได้ใน MS outlook หรือ MS Office Outlook Web Access

ในการซิงโครไนซ์ MS Exchange

1 จากหน้าจอหลัก ให้แตะ > > แท็บ **แอปฯ** > **ตั้งค่า**
2 แตะแท็บ **ทั่วไป** > **แอคเคาท์และการซิงค์** > **เพิ่มแอคเคาท์**
3 แตะ **Microsoft Exchange** เพื่อสร้างอีเมลแอดเดรสและรหัสผ่าน
4 ตรวจสอบให้แน่ใจว่าคุณได้เลือกงานซิงค์

หมายเหตุ: MS Exchange อาจไม่ได้รับการสนับสนุน โดยขึ้นอยู่กับเซิร์ฟเวอร์อีเมล

POLARIS Viewer 5

POLARIS Viewer 5 คือโซลูชันสำนักงานบนมือถือระดับมืออาชีพที่ให้ผู้ใช้ดูเอกสารประเภทต่างๆ ของ Office รวมถึงไฟล์ Word, Excel และ PowerPoint ได้อย่างสะดวกทุกที่หรือทุกเวลาด้วยอุปกรณ์มือถือของคุณ

แตะ > > แท็บ **แอปฯ** > **POLARIS Viewer 5**

การดูไฟล์

ผู้ใช้มือถือสามารถดูไฟล์ประเภทต่างๆ รวมถึงเอกสาร Microsoft Office และ Adobe PDF ได้ง่ายๆ บนมือถือ เมื่อดูเอกสารโดยใช้ POLARIS Office 5 ออบเจกต์และเลย์เอาต์จะเหมือนกับในเอกสารต้นฉบับ

Google+

ใช้แอปพลิเคชันนี้เพื่อเชื่อมต่อกับบุคคลผ่านบริการเครือข่ายสังคมของ Google

- แตะ > > แท็บ **แอปฯ** > **Google+**

หมายเหตุ: แอปพลิเคชันนี้อาจไม่พร้อมใช้งาน ทั้งนี้ขึ้นอยู่กับภูมิภาคและผู้ให้บริการเครือข่าย

ค้นหาด้วยเสียง

ใช้แอปพลิเคชันนี้เพื่อค้นหาเว็บเพจด้วยเสียง

1 แตะ > > แท็บ **แอปฯ** > **ค้นหาด้วยเสียง**

2 พูดคำหลักหรือวลีเมื่อ **พูดทันที** ปรากฏบนหน้าจอ เลือกคำหลักที่แนะนำคำใดคำหนึ่งที่ปรากฏขึ้น

หมายเหตุ: แอปพลิเคชันนี้อาจไม่พร้อมใช้งาน ทั้งนี้ขึ้นอยู่กับภูมิภาคและผู้ให้บริการเครือข่าย

ดาวน์โหลด

ใช้แอปพลิเคชันนี้เพื่อดูว่ามีไฟล์อะไรบ้างที่ถูกดาวน์โหลดผ่านแอปพลิเคชัน

- แตะ > > แท็บ **แอปฯ** > **ดาวน์โหลด**

หมายเหตุ: แอปพลิเคชันนี้อาจไม่พร้อมใช้งาน ทั้งนี้ขึ้นอยู่กับภูมิภาคและผู้ให้บริการเครือข่าย

เว็บไซต์

อินเตอร์เน็ต

ใช้แอปพลิเคชันนี้เพื่อเรียกดูอินเตอร์เน็ต เบราวเซอร์จะนำคุณเข้าสู่โลกที่เต็มไปด้วยสีสันของเกมส์ เพลง ข่าวสาร กีฬา ความบันเทิงและอื่นๆ อีกมากมายอย่างรวดเร็วที่โทรศัพท์มือถือของคุณโดยตรง ไม่ว่าคุณจะอยู่ที่ใดหรือสนุกกับสิ่งใด

หมายเหตุ: คุณอาจต้องเสียค่าใช้จ่ายเพิ่มเติมเมื่อเชื่อมต่อบริการเหล่านี้และดาวน์โหลดเนื้อหา โปรดสอบถามข้อมูลการคิดค่าใช้จ่ายกับผู้ให้บริการเครือข่ายของคุณ

1 แตะ > > แท็บ **แอปฯ** > **อินเตอร์เน็ต**

การใช้แถบเครื่องมือเว็บ

แตะเลื่อนขึ้นด้านบนด้วยนิ้วมือเพื่อเปิด

	แตะเพื่อย้อนกลับหนึ่งเพจ
	แตะเพื่อไปข้างหน้าหนึ่งเพจไปยังเพจที่ทำการเชื่อมต่อหลังจากเพจปัจจุบัน โดยตรงข้ามกับสิ่งที่เกิดขึ้นเมื่อคุณแตะ ซึ่งจะนำคุณไปยังเพจก่อนหน้า
	แตะเพื่อไปยังโฮมเพจ
	แตะเพื่อเพิ่มหน้าต่างใหม่
	แตะเพื่อเข้าใช้งานบุ๊คมาร์ค

การดูเว็บเพจ

แตะฟิลด์แอดเดรส ป้อนเว็บแอดเดรสแล้วแตะ **ไป**

การเปิดเพจ

ในการไปยังเพจใหม่ ให้แตะ →
ในการไปยังเว็บเพจอื่น ให้แตะ เลื่อนขึ้นหรือลง และแตะเพจเพื่อเลือก

การค้นหาเว็บด้วยเสียง

แตะฟิลด์แอดเดรส แตะ พูดคำหลัก แล้วเลือกหนึ่งในคำหลักที่แนะนำที่ปรากฏขึ้น

หมายเหตุ: คุณสมบัตินี้อาจไม่พร้อมใช้งาน ทั้งนี้ขึ้นอยู่กับภูมิภาคหรือผู้บริการเครือข่าย

บุ๊คมาร์ก

ในการบุ๊คมาร์คเว็บเพจปัจจุบัน ให้แตะ > **บันทึกบุ๊คมาร์ค** > **ตกลง**
ในการเปิดเว็บเพจที่บุ๊คมาร์ค ให้แตะ แล้วเลือก

ประวัติ

แตะ > **ประวัติ** เพื่อเปิดเว็บเพจจากรายการเว็บเพจที่เยี่ยมชมล่าสุด
ในการลบประวัติ ให้แตะ **ปุ่มเมนู** → **ลบประวัติทั้งหมด**

เว็บไซต์

Chrome

ใช้ Chrome ในการค้นหาข้อมูลและเรียกดูเว็บเพจ

1 แตะ > > แท็บ **แอปฯ** > **Chrome**

หมายเหตุ: แอปพลิเคชันนี้อาจไม่พร้อมใช้งาน ทั้งนี้ขึ้นอยู่กับภูมิภาคและผู้บริการเครือข่ายของคุณ

การดูเว็บเพจ

แตะฟิลด์แอดเดรส จากนั้นป้อนเว็บแอดเดรสหรือเกณฑ์การค้นหา

การเปิดเพจ

ในการไปยังเพจใหม่ ให้แตะ → **แท็บใหม่**

ในการไปยังเว็บเพจอื่น ให้แตะ เลื่อนขึ้นหรือลง และแตะเพจเพื่อเลือก

การซิงค์กับอุปกรณ์อื่น

ซิงค์แท็บที่เปิดและบุ๊คมาร์คเพื่อใช้กับ Chrome ในอุปกรณ์อื่นเมื่อคุณล็อกอินด้วยบัญชี Google เดียวกัน

ในการดูแท็บที่เปิดบนอุปกรณ์อื่น ให้แตะ **ปุ่มเมนู** → **อุปกรณ์อื่นๆ** เลือกเว็บเพจเพื่อเปิด

ในการเพิ่มบุ๊คมาร์ค ให้แตะ

ตั้งค่า

ส่วนนี้จะแสดงภาพรวมรายการที่คุณสามารถเปลี่ยนแปลงผ่านเมนูการตั้งค่าระบบของโทรศัพท์ได้

การเปิดเมนูตั้งค่า:

แตะ > > **การตั้งค่าระบบ**

- หรือ -

แตะ > > **แท็บ** แอปฯ > **ตั้งค่า**

เครือข่าย

< Wi-Fi >

Wi-Fi – เปิด Wi-Fi เพื่อเชื่อมต่อเครือข่าย Wi-Fi ที่มีอยู่

เคล็ดลับ! การดู MAC แอดเดรส
ในการเชื่อมต่อกับเครือข่ายไร้สายบางเครือข่ายด้วยฟิลเตอร์ MAC คุณจำเป็นต้องป้อน MAC แอดเดรสของโทรศัพท์ลงในเราเตอร์
คุณสามารถค้นหา MAC แอดเดรสได้ในยูสเซอร์อินเตอร์เฟซต่อไปนี้: แตะ > > **แท็บ** แอปฯ > **ตั้งค่า** > **แท็บ** เครือข่าย > **Wi-Fi** > > **Wi-Fi ขั้นสูง** > **MAC แอดเดรส**

< Bluetooth >

เปิดหรือปิดคุณสมบัติ Bluetooth เพื่อใช้ Bluetooth

< ข้อมูลเครือข่ายโทรศัพท์ >

แสดงการใช้ข้อมูลและตั้งค่าขีดจำกัดการใช้ข้อมูลโทรศัพท์มือถือ

< โทร >

กำหนดค่าการตั้งค่าโทรศัพท์ เช่น การส่งต่อสาย และคุณสมบัติพิเศษอื่นๆ จากผู้ให้บริการ

ข้อความเสียง – ให้คุณเลือกบริการข้อความเสียงของผู้ให้บริการ

จำกัดการโทร – เปิดและรวบรวมรายการหมายเลขที่สามารถโทรออกจากโทรศัพท์ได้ คุณต้องใช้ PIN2 ซึ่งได้จากผู้ให้บริการของคุณ เฉพาะหมายเลขที่อยู่

ในรายการหมายเลขโทรออกที่กำหนดเท่านั้นที่สามารถโทรออกได้
ป๊อบอัพสายโทรเข้า – แสดงป๊อบอัพสายที่โทรเข้าตอนใช้ทีวี กล้อง และวิดีโอ
ปฏิเสธการรับสาย – ตั้งค่าฟังก์ชันปฏิเสธการรับสาย เลือกจาก **โหมดปฏิเสธสาย** หรือ **ไม่รับสายจาก**
ปฏิเสธพร้อมส่งข้อความ – เมื่อคุณต้องการปฏิเสธสาย คุณสามารถส่งข้อความได้อย่างรวดเร็วโดยใช้ฟังก์ชันนี้ ตัวเลือกนี้จะเป็นประโยชน์ในกรณีที่คุณต้องการปฏิเสธการรับสายในระหว่างการประชุม
ระบบป้องกันข้อมูลลับ – ซ่อนชื่อผู้โทรและหมายเลขสำหรับสายเรียกเข้า
การโอนสาย – เลือกว่าจะโอนทุกสาย โอนเมื่อสายไม่ว่าง โอนเมื่อไม่รับสาย หรือโอนเมื่อไม่มีสัญญาณ
รับสายอัตโนมัติ – ตั้งค่าเวลาก่อนอุปกรณ์แฮนด์ฟรีที่เชื่อมต่อจะรับสายเรียกเข้าโดยอัตโนมัติ เลือกจาก ปิด, 1 วินาที, 3 วินาที และ 5 วินาที
การสั่นขณะเชื่อมต่อ – สั่นโทรศัพท์เมื่อคู่สนทนาอื่นๆ รับสาย
ปรับความคมชัดของเสียง – ปรับคุณภาพเสียงเมื่อภายนอกมีเสียงดัง ซึ่งทำให้คุณได้ยินชัดเจนมากขึ้น
บันทึกหมายเลขที่ไม่รู้จัก – เพิ่มหมายเลขที่ไม่รู้จักลงในรายชื่อหลังจากการโทร
ปุ่มวางสาย – ให้คุณเลือกวางสาย
ป้องกันการโทร – ล็อคสายเรียกเข้า สายโทรออก หรือสายโทรออกต่างประเทศ
เวลาโทร – ดูระยะเวลาการโทรทั้งหมด ได้แก่ **โทรครั้งล่าสุด, สายที่โทรออก, สายที่ได้รับ และ ทุกสาย**
ตั้งค่าเพิ่มเติม – ให้คุณเปลี่ยนแปลงการตั้งค่าต่อไปนี้:
- **ข้อมูลผู้โทร:** เลือกว่าคุณจะแสดงหมายเลขของคุณในการโทรออกหรือไม่
- **สายเรียกซ้อน:** หากเปิดใช้สายเรียกซ้อน คุณจะได้รับแจ้งสายเรียกเข้าขณะกำลังใช้สาย (ขึ้นอยู่กับผู้ให้บริการเครือข่ายของคุณ)

< แบ่งปันและเชื่อมต่อ >

NFC – โทรศัพท์ของคุณสามารถใช้ NFC ได้ NFC (Near Field Communication) คือเทคโนโลยีการเชื่อมต่อไร้สายที่ให้การสื่อสารแบบสองทางระหว่างอุปกรณ์อิเล็กทรอนิกส์ โดยจะทำงานในระยะสองสามเซนติเมตร คุณสามารถแบ่งปันเนื้อหาด้วยแท็ก NFC หรืออุปกรณ์อื่นๆ ที่รองรับ NFC ได้ง่ายๆ เพียงการแตะด้วยอุปกรณ์ของคุณ หากคุณแตะแท็ก NFC กับอุปกรณ์ของคุณ จะแสดงเนื้อหาของแท็กในอุปกรณ์ของคุณ

ในการเปิดหรือปิด NFC: จากหน้าจอหลัก ให้แตะและเลื่อนแถบการแจ้งลงด้วยนิ้วของคุณ และเลือกไอคอน NFC เพื่อเปิด

หมายเหตุ: ขณะเปิดใช้งานโหมดเครื่องบินจะสามารถใช้งานแอปพลิเคชัน NFC ได้

การใช้ NFC: ในการใช้ NFC ให้ตรวจสอบให้แน่ใจว่าคุณเปิดอุปกรณ์ของคุณและเปิดใช้งานการตั้งค่า NFC ในกรณีที่ปิดใช้งานเอาไว้

Direct/Android Beam – เมื่อเปิดใช้คุณสมบัตินี้ คุณสามารถบีมเนื้อหาแอปพลิเคชันไปยังอุปกรณ์ที่สามารถใช้ NFC ได้โดยการถืออุปกรณ์ไว้ใกล้ๆ กัน เพียงนำอุปกรณ์เข้าไปใกล้ๆ กัน (หันด้านหลังเข้าหากัน) แล้วแตะหน้าจอของคุณ แอปพลิเคชันจะกำหนดว่าบีมอะไรบ้าง

SmartShare Beam – เปิดเพื่อรับเนื้อหามัลติมีเดียผ่าน **SmartShare Beam** จากโทรศัพท์หรือแท็บเล็ต LG

Miracast – ทำมิเรอร์หน้าจอและระบบเสียงของโทรศัพท์ไปยัง Miracast dongle หรือทีวีแบบไร้สาย

ระบบจัดเก็บข้อมูลไร้สาย – คุณสามารถจัดการไฟล์ในโทรศัพท์ของคุณจากคอมพิวเตอร์ หรือคัดลอกไฟล์ไปยังโทรศัพท์จากคอมพิวเตอร์ได้โดยไม่ต้องเชื่อมต่อ USB หลังจากเปิดระบบจัดเก็บข้อมูลไร้สาย ให้เชื่อมต่อโทรศัพท์และคอมพิวเตอร์กับเครือข่ายเดียวกัน จากนั้น ป้อนเว็บแอดเดรสที่แสดงในโทรศัพท์ของคุณลงในแอดเดรสบาร์ของบราวเซอร์ในคอมพิวเตอร์ของคุณ

< การปล่อยสัญญาณ & เครือข่าย >

Wi-Fi hotspot – คุณยังสามารถใช้โทรศัพท์เพื่อให้การเชื่อมต่อระบบโมไบล์บรอดแบนด์ได้ด้วย สร้างฮอตสปอตและแบ่งปันการเชื่อมต่อของคุณ โปรดอ่าน **"การแบ่งปันการเชื่อมต่อข้อมูลในโทรศัพท์"** สำหรับข้อมูลเพิ่มเติม

การปล่อยสัญญาณบลูทูธ – ให้คุณตั้งค่าโทรศัพท์ว่าจะแบ่งปันการเชื่อมต่ออินเตอร์เน็ตหรือไม่

ช่วยเหลือ – แตะเพื่อดูข้อความความช่วยเหลือเกี่ยวกับฟังก์ชัน Wi-Fi hotspot และการปล่อยสัญญาณบลูทูธ

โหมดเครื่องบิน – หลังจากสลับไปยังโหมดเครื่องบิน การเชื่อมต่อเครือข่ายทั้งหมดจะใช้งานไม่ได้

หมายเหตุ: คุณต้องตั้งค่า PIN หรือรหัสผ่านล็อคหน้าจอก่อนที่จะใช้ระบบจัดเก็บข้อมูลรับรองสิทธิ์

เครือข่ายโทรศัพท์เคลื่อนที่ – ตั้งค่าตัวเลือกสำหรับโรมมิ่งข้อมูล โหมดเครือข่ายและผู้ให้บริการ ชื่อจุดเชื่อมต่อ (APN) และอื่นๆ

VPN – แสดงรายการ Virtual Private Network (VPN) ที่คุณกำหนดค่าก่อนหน้านี้ ให้คุณเพิ่ม VPN ประเภทต่างๆ ได้

เสียง

โปรไฟล์เสียง – เลือก เสียง, เฉพาะสั่น หรือ เงียบ

ระดับเสียง – ปรับการตั้งค่าระดับเสียงของโทรศัพท์ตามความต้องการและสภาพแวดล้อมของคุณ

ความแรงการสั่น – ให้คุณตั้งค่าความแรงการสั่นสำหรับการโทร การแจ้งและการตอบสนองแบบสัมผัส

โหมดเงียบ – ตั้งค่าโหมดเงียบของคุณ แตะสวิตช์ **เปิดโหมดเงียบตอนนี้** เพื่อสลับเปิดหรือปิด คุณสามารถกำหนดเวลาให้โหมดเงียบเปิดใช้โดยอัตโนมัติและกำหนดการยกเว้นให้กับโหมดเงียบได้

ตั้งเวลาเงียบ: แตะสวิตช์เพื่อสลับเปิดหรือปิด คุณยังสามารถตั้งค่าวันและเวลาให้เปิดโหมดเงียบโดยอัตโนมัติได้อีกด้วย

สั่น: เลือกเพื่อใช้การสั่นสำหรับสายหรือการแจ้งเตือนที่อนุญาตเมื่อเปิดใช้โหมดเงียบ

ตั้งค่าสายที่ได้รับ

บล็อกสายโทรเข้า: เลือกเพื่อบล็อคสายโทรเข้าทั้งหมด

อนุญาตให้โทรซ้ำ: เลือกเพื่ออนุญาตการโทรที่โทรซ้ำภายใน 3 นาที

รายชื่อที่อนุญาต: กำหนดว่าสายของรายชื่อใดบ้างที่ได้รับอนุญาต

ตอบรับอัตโนมัติสำหรับเบอร์ที่ถูกบล็อค: ตั้งค่าวิธีที่คุณต้องการตอบกลับสายที่ปิดเสียงโดยอัตโนมัติ

ช่วยเหลือ: ดูการช่วยเหลือสำหรับโหมดเงียบ

เสียงเรียกเข้าโทรศัพท์ – ตั้งค่าเสียงเรียกเข้าสำหรับสายต่างๆ คุณยังสามารถเพิ่มเสียงเรียกเข้าได้โดยการแตะ ⊕ ที่มุมขวาบนของหน้าจอ

สมาร์ทริงโทน – เลือกเพื่อปรับระดับเสียงริงโทนโทรศัพท์อัตโนมัติเมื่อภายนอกมีเสียงดัง

สั่นเมื่อมีสายโทรเข้า – ตั้งค่าตัวเลือกสั่นเมื่อมีสายโทรเข้า

สั่นเบาๆ – เลือกเพื่อค่อยๆ เพิ่มแรงสั่นจนกว่าถึงระดับความแรงที่กำหนดเอาไว้

เสียงพร้อมสั่น – เลือกเพื่อตั้งค่าให้โทรศัพท์สั่นไปพร้อมๆ กับเสียงเรียกเข้าเมื่อมีสายเรียกเข้า

แจ้งเตือนเสียง – แตะสวิตช์ **แจ้งเตือนเสียง** เพื่อสลับเปิดหรือปิด เมื่อเปิดไว้จะทำให้อุปกรณ์แจ้งสายเรียกเข้าและข้อความเข้าโดยอัตโนมัติ

เสียงการแจ้งเตือน – ให้คุณตั้งค่าเสียงของการแจ้งเตือน คุณยังสามารถเพิ่มเสียงได้โดยการแตะ ⊕ ที่มุมขวาบนของหน้าจอ

การตอบสนองแบบสัมผัสและระบบ – ให้คุณตั้งค่าการตอบสนอง (เสียงและ/หรือการสั่น) ขณะกำลังใช้อุปกรณ์

หน้าจอ

< หน้าจอหลัก >

ตั้งค่า **ธีม, พื้นหลัง, เอฟเฟกต์หน้าจอ, ยอมให้วนลูปหน้าจอโฮม** หรือ **มุมมองแนวตั้งเท่านั้น**

แบ็คอัพหน้าหลักและเรียกคืน – คุณสามารถสำรองและเรียกคืนเลย์เอาต์แอปพลิเคชัน/Widget และธีมได้

ช่วยเหลือ – แตะเพื่อดูข้อความช่วยเหลือบนหน้าจอหลัก

< ล็อคหน้าจอ >

เลือกแบบล็อคหน้าจอ – ตั้งค่าประเภทเลือกแบบล็อคหน้าจอเพื่อป้องกันโทรศัพท์ของคุณ เปิดชุดหน้าจอที่แนะนำคุณในการวาดแบบปลดล็อคหน้าจอ ตั้งค่า **ไม่มี, ลาก, ปลดล็อกใบหน้า, รูปแบบ, PIN** หรือ **รหัสผ่าน** หากคุณเปิดใช้งานการประเภทการล็อกรูปแบบเมื่อเปิดโทรศัพท์หรือเรียกหน้าจอ คุณจะต้องวาดแบบปลดล็อคเพื่อปลดล็อคหน้าจอ

หมุนหน้าจอล็อค – เลือกเพื่อให้หน้าจอล็อคขยับขึ้นหรือลงเอง เมื่อคุณเอียงโทรศัพท์ไปในทิศทางนั้น

เอฟเฟกต์หน้าจอ – ตั้งค่าตัวเลือกเอฟเฟกต์หน้าจอ เลือกจาก Ripple, Dewdrop, แสงสีขาว, Particle และ Crystal

หมายเหตุ: เอฟเฟกต์หน้าจอจะกลายเป็นเอฟเฟกต์รูปแบบ หากตั้งค่าการล็อคหน้าจอไว้ที่รูปแบบ

แอนิเมชันสภาพอากาศ – เลือกเพื่อแสดงแอนิเมชันสภาพอากาศสำหรับตำแหน่งปัจจุบันหรือเมืองหลักที่ตั้งค่าในสภาพอากาศตามการอัปเดตข้อมูลอัตโนมัติ

พื้นหลัง – ตั้งค่าภาพล็อคหน้าจอของคุณ เลือกจาก **แกลเลอรี่** หรือ **คลังภาพพื้นหลัง**

ช็อตคัท – ให้คุณเปลี่ยนช็อตคัทบนการล็อคหน้าจอแบบ**ลาก**

ข้อมูลเจ้าของ – เลือกเพื่อตั้งค่าชื่อของเจ้าของอุปกรณ์ให้แสดงบนการล็อคหน้าจอ แตะ ⚙ ป้อนข้อความที่แสดงข้อมูลเจ้าของ

ตั้งเวลาล็อค – ตั้งค่าระยะเวลาก่อนที่หน้าจอจะล็อคโดยอัตโนมัติหลังจากหน้าจอหมดเวลา
ล็อคปุ่มพาวเวอร์ทันที – เลือกเพื่อให้ล็อคหน้าจอทันทีเมื่อปุ่มเปิด/ปิด/ล็อคถูกกด การตั้งค่านี้จะแทนที่การตั้งค่าตัวจับเวลาล็อคการป้องกัน
< ปุ่มสัมผัสด้านหน้า >
ตั้งค่าปุ่มสัมผัสด้านหน้าให้แสดงที่ด้านล่างของทุกหน้าจอ
ตั้งค่าว่าจะให้แสดงอะไร ตำแหน่งของแถบ และลักษณะที่ปรากฏ
เลือกปุ่มและลำดับ ธีม และแบ็คกราวด์
< หน้าจอ >
ความสว่าง – ปรับความสว่างของหน้าจอ เพื่อให้ได้ประสิทธิภาพสูงสุดของแบตเตอรี่ ให้ใช้ความสว่างที่มืดที่สุดเท่าที่จะเห็นได้อย่างสบายตา
ไทม์เอาต์หน้าจอ – ตั้งค่าระยะเวลาก่อนที่หน้าจอจะหมดเวลา
เอฟเฟกต์ปิดหน้าจอ – ตั้งค่าเอฟเฟกต์ปิดหน้าจอ เลือกจาก เฟดออก, Black hole และทีวีย้อนยุค
หมุนจออัตโนมัติ – เลือกเพื่อตั้งค่าโทรศัพท์ให้หมุนหน้าจออัตโนมัติตามแนวของโทรศัพท์ (แนวตั้งหรือแนวนอน)
โหมดหน้าจอ - ตั้งค่าโหมดหน้าจอ เลือกจาก **มาตรฐาน, สดใส,** หรือ **ธรรมชาติ**
Daydream – แตะสวิตช์ Daydream เพื่อสลับเปิดหรือปิด เมื่อเปิดไว้จะทำให้ภาพพักหน้าจอปรากฏขึ้นเมื่อโทรศัพท์กำลังพักขณะวางบนแท่นชาร์จและ/หรือกำลังชาร์จ เลือกได้จาก นาฬิกา การชาร์จ สี เฟรมรูป และตารางรูปภาพ
< ตัวอักษร >
ชนิดแบบอักษร – ตั้งค่าชนิดแบบอักษรที่ใช้สำหรับโทรศัพท์และเมนู
ขนาดแบบอักษร – ตั้งค่าขนาดแบบอักษรที่แสดงในโทรศัพท์และเมนู
< เปิดใช้งานอัจฉริยะ >
จออัจฉริยะ – เลือกเพื่อไม่ให้หน้าจอหมดเวลาเมื่ออุปกรณ์ตรวจเจอดวงตาของคุณที่มองไปยังหน้าจอ
วิดีโออัจฉริยะ – เลือกเพื่อหยุดวิดีโอชั่วคราวเมื่ออุปกรณ์ตรวจไม่พบว่ามี

ดวงตามองไปยังหน้าจอ

< การใช้การตั้งค่าขั้นสูง >

ไฟ LED แจ้งเตือน – แตะสวิตช์เพื่อสลับเปิดหรือปิด เมื่อเปิดไว้จะเปิดใช้ไฟ LED สำหรับการแจ้งเตือนที่คุณเลือกด้วยสีที่คุณตั้งไว้สำหรับการแจ้งเตือนแต่ละรายการ

ปรับโทนหน้าจออัตโนมัติ – เลือกเพื่อประหยัดพลังงานแบตเตอรี่โดยการปรับความสว่างของหน้าจอโดยอัตโนมัติด้วยการวิเคราะห์สีภาพ

พื้นที่จับภาพหน้าจอ – ให้คุณตั้งค่าพื้นที่จับภาพหน้าจอ เลือกจาก **จับภาพหน้าจอเต็ม** หรือ **จับภาพบางส่วนของหน้าจอ**

แก้ไขอัตราส่วนของจอภาพ – ให้คุณเปลี่ยนอัตราส่วนหน้าจอของแอปพลิเคชันที่ดาวน์โหลดเพื่อแก้ไขความผิดเพี้ยนของหน้าจอ

ทั่วไป

< Gestures >

เปิด/ปิดหน้าจอ – เลือกเพื่อเปิดใช้งาน เปิดหน้าจอ เพื่อเปิดและปิดหน้าจอ แตะสองครั้งอย่างรวดเร็วที่ตรงกลางของหน้าจอเพื่อเปิด แตะสองครั้งที่แถบสถานะ พื้นที่ว่างในหน้าจอหลัก หรือล็อคหน้าจอเพื่อปิดหน้าจอเพื่อผลลัพธ์ที่ดีที่สุด ห้ามเคลื่อนย้ายโทรศัพท์ในขณะเปิดใช้งานคุณสมบัติเปิดหน้าจอ อยู่

รับสายโทรเข้า – เลือกเพื่อเปิดใช้งานการรับสายเรียกเข้าโดยอัตโนมัติเมื่อคุณนำโทรศัพท์มาแนบกับหู

หรี่เสียงริงโทน – เลือกเพื่อเปิดใช้การหรี่เสียงเรียกเข้าเพื่อคุณหยิบโทรศัพท์ออกจากพื้นผิวราบ

สายโทรเข้าที่รออยู่ – เลือกเพื่อปิดเสียงสายเรียกเข้าเมื่อคุณพลิกโทรศัพท์

เลื่อนหรือปิดสัญญาณเตือน – เลือกเพื่อเลื่อนหรือปิดสัญญาณเตือนเมื่อคุณพลิกอุปกรณ์

หยุดวิดีโอชั่วคราว – เลือกเพื่อหยุดวิดีโอที่กำลังเล่นอยู่ชั่วคราวเมื่อคุณพลิกอุปกรณ์

ย้ายไอเท็มในจอโฮม – เลือกเพื่อช่วยให้คุณย้ายไอคอนไปยังหน้าจออื่นโดยการเอียงโทรศัพท์ แตะไอคอนค้างไว้และเอียงโทรศัพท์ไปทางซ้ายหรือขวาและปล่อยบนหน้าจอที่คุณต้องการไอคอนดังกล่าว
ช่วยเหลือ – เปิดคู่มือความช่วยเหลือเพื่อดูวิธีการใช้คุณสมบัติ Gestures ของอุปกรณ์ของคุณ
ปรับแต่งเซนเซอร์การเคลื่อนไหว – ให้คุณปรับปรุงความแม่นยำของการเอียงและความเร็วของเซนเซอร์

< ใช้งานมือเดียว >

ปุ่มโทร – เลือกเพื่อให้คุณย้ายปุ่มโทรไปทางด้านซ้ายหรือขวาของอุปกรณ์ เพียงแตะลูกศรเพื่อย้ายไปที่ข้างใดข้างหนึ่ง
LG คีย์บอร์ด – เลือกเพื่อให้คุณย้ายคีย์บอร์ดไปทางด้านซ้ายหรือขวาของอุปกรณ์ เพียงแตะลูกศรเพื่อย้ายไปที่ข้างใดข้างหนึ่ง
ระบบควบคุมท่าทาง – เลือกเพื่อให้คุณปรับตำแหน่งของ LG คีย์บอร์ดได้โดยการลากไปทางซ้ายหรือขวา
ล็อคหน้าจอ – เลือกเพื่อย้ายคีย์แพด PIN ล็อคหน้าจอไปทางด้านซ้ายหรือขวาของอุปกรณ์ เพียงแตะลูกศรเพื่อย้ายไปที่ข้างใดข้างหนึ่ง
ปัดปุ่มสัมผัสด้านหน้า – เลือกเพื่อปัดปุ่มสัมผัสด้านหน้าไปทางด้านซ้ายหรือขวาเพื่อปรับตำแหน่งของปุ่ม เพื่อให้สามารถใช้งานได้ง่ายด้วยมือข้างเดียว
ช่วยเหลือ – แสดงข้อมูลที่เกี่ยวกับการใช้งานด้วยมือเดียว

< ที่เก็บข้อมูล >

ที่เก็บข้อมูลภายใน – ดูการใช้ที่เก็บข้อมูลภายใน

< แบตเตอรี่ >

ข้อมูลแบตเตอรี่

ข้อมูลประจุของแบตเตอรี่จะแสดงบนกราฟิกแบตเตอรี่พร้อมกับเปอร์เซ็นต์ของประจุที่เหลืออยู่และสถานะแตะไอคอนประจุของแบตเตอรี่เพื่อแสดงหน้าจอการใช้แบตเตอรี่เพื่อดูระดับการใช้แบตเตอรี่และรายละเอียดการใช้แบตเตอรี่ หน้าจอนี้จะแสดงส่วนประกอบและแอปพลิเคชันที่กำลังใช้พลังงานแบตเตอรี่มากที่สุด แตะหนึ่งในรายการเพื่อดูข้อมูลอย่างละเอียด

เปอร์เซ็นต์แบตเตอรี่บนแถบสถานะ – เลือกเพื่อแสดงเปอร์เซ็นต์ระดับแบตเตอรี่บนแถบสถานะด้านข้างไอคอนแบตเตอรี่

ประหยัดพลังงาน

แตะสวิตช์ประหยัดพลังงานเพื่อสลับเปิดหรือปิด แตะประหยัดพลังงานเพื่อเข้าถึงการตั้งค่าต่อไปนี้:

ประหยัดพลังงาน – ตั้งค่าระดับเปอร์เซ็นต์ระดับแบตเตอรี่ที่จะให้เปิดประหยัดพลังงานโดยอัตโนมัติ เลือกจาก ทันที, 10% แบตเตอรี่, 20% แบตเตอรี่, 30% แบตเตอรี่ และ 50% แบตเตอรี่

เทคนิคการประหยัดพลังงาน

ซิงค์อัตโนมัติ – เลือกเพื่อปิดซิงค์อัตโนมัติเมื่อเปิดใช้ประหยัดพลังงาน

Wi-Fi – เลือกเพื่อปิด Wi-Fi เมื่อไม่ได้ใช้ข้อมูลในขณะที่เปิดใช้ประหยัดพลังงาน

Bluetooth – เลือกเพื่อปิด Bluetooth เมื่อไม่ได้เชื่อมต่อในขณะที่เปิดใช้ประหยัดพลังงาน

สั่นเมื่อแตะ – เลือกเพื่อปิดการตอบสนองแบบสัมผัสเมื่อเปิดใช้ประหยัดพลังงาน

ความสว่าง – เลือกเพื่อตั้งค่าความสว่างของหน้าจอเมื่อเปิดใช้ประหยัดพลังงาน แตะ เพื่อเปลี่ยนการตั้งค่า

ปรับโทนหน้าจออัตโนมัติ – เลือกเพื่อเปิดการปรับโทนหน้าจออัตโนมัติเมื่อเปิดใช้ประหยัดพลังงาน

ไทม์เอาต์หน้าจอ – เลือกเพื่อตั้งค่าไทม์เอาต์หน้าจอเมื่อเปิดใช้ประหยัดพลังงาน แตะไอคอนตั้งค่าเพื่อเปลี่ยนการตั้งค่า

ไฟ LED แจ้งเตือน – เลือกเพื่อปิดไฟ LED สำหรับการแจ้งเตือนเมื่อเปิดใช้ประหยัดพลังงาน

< แอปฯ >

ดูและจัดการแอปพลิเคชันของคุณ

< มัลติทาสกิ้ง >

เลื่อนไปด้านข้าง – เลือกทำเครื่องหมายที่ช่อง **เลื่อนไปด้านข้าง** เพื่อใช้คุณสมบัติเลื่อนไปด้านข้าง (โปรดดู **เลื่อนไปด้านข้าง**)

หน้าต่างคู่ – เลือกทำเครื่องหมายที่ช่อง**หน้าต่างคู่** เพื่อใช้คุณสมบัติหน้าต่างคู่ (โปรดดู **หน้าต่างคู่**)

มุมมองแบ่งหน้าจอ – เลือกทำเครื่องหมายที่ช่อง **มุมมองแบ่งหน้าจอ** เพื่อแตะที่ลิงค์บนหน้าจอเต็มเพื่อใช้งานหน้าต่างคู่โดยอัตโนมัติ

ช่วยเหลือ – เปิดคู่มือความช่วยเหลือเพื่อดูวิธีการใช้คุณสมบัติมัลติทาสกิ้งของอุปกรณ์ของคุณ

< แอคเคาท์และการซิงค์ >

อนุญาตให้แอปพลิเคชันซิงโครไนซ์ข้อมูลในแบ็คกราวด์ ไม่ว่าคุณจะกำลังใช้งานข้อมูลอยู่หรือไม่ก็ตาม การไม่เลือกการตั้งค่านี้สามารถประหยัดไฟแบตเตอรี่และลด (ไม่ใช่ทั้งหมด) การใช้ข้อมูล

< คลาวด์ >

เพิ่มบัญชีคลาวด์เพื่อใช้บริการคลาวด์ได้รวดเร็วและง่ายดายใน LG แอปพลิเคชัน

< โหมด Guest >

คุณสามารถใช้งานโหมด Guest เพื่อป้องกันความเป็นส่วนตัวของคุณหรือจำกัดบางแอปพลิเคชันจากเด็กๆ ได้

เมื่อคุณให้ผู้อื่นยืมโทรศัพท์ คุณสามารถจำกัดแอปพลิเคชันที่จะปรากฏขึ้นได้ ให้ตั้งค่าโหมด Guest และปรับตัวเลือกต่างๆ ไว้ล่วงหน้า

< เข้าถึงข้อมูลระบุตำแหน่ง >

เข้าถึงข้อมูลระบุตำแหน่งของฉัน – หากคุณเลือกบริการระบุตำแหน่งของ Google โทรศัพท์จะกำหนดตำแหน่งโดยประมาณจากการใช้เครือข่าย Wi-Fi และโทรศัพท์มือถือ เมื่อคุณเลือกตัวเลือกนี้ คุณจะได้รับแจ้งว่าจะยินยอมให้ Google ใช้ตำแหน่งของคุณเมื่อให้บริการเหล่านี้หรือไม่

ดาวเทียม GPS – หากคุณเลือกดาวเทียม GPS โทรศัพท์จะกำหนดตำแหน่งด้วยความแม่นยำระดับถนน

ตำแหน่งเครือข่าย Wi-Fi และโมไบล์ – ให้แอปพลิเคชันใช้ข้อมูลจากแหล่งที่มา เช่น Wi-Fi และเครือข่ายโทรศัพท์มือถือเพื่อระบุพิกัดโดยประมาณ

< ระบบป้องกัน >

เข้ารหัสอุปกรณ์ – ให้คุณเข้ารหัสข้อมูลในโทรศัพท์เพื่อความปลอดภัย คุณจะต้องป้อน PIN หรือรหัสผ่านเพื่อถอดรหัสโทรศัพท์ในแต่ละครั้งที่คุณเปิดใช้การเข้ารหัส

ตั้งค่าล็อคซิมการ์ด – ตั้งค่าล็อคการ์ด Micro-USIM หรือเปลี่ยน PIN ของการ์ด Micro-USIM

ป้อนรหัสผ่านแบบมองเห็น – แสดงตัวอักษรสุดท้ายของรหัสผ่านที่ถูกซ่อนเมื่อคุณพิมพ์

โปรแกรมควบคุมอุปกรณ์ – ดูหรือปิดการใช้งานผู้ดูแลอุปกรณ์

แหล่งที่มาที่ไม่รู้จัก – ตั้งค่าเริ่มต้นเพื่อติดตั้งแอปพลิเคชันที่ไม่ได้มาจาก Play Store

ยืนยันแอปฯ – ไม่อนุญาตหรือเตือนก่อนติดตั้งแอปฯที่อาจก่ออันตราย

การรับรองสิทธิ์ที่ไว้ใจได้ – แสดงการรับรองสิทธิ์ CA ที่เชื่อใจได้

ติดตั้งจากระบบจัดเก็บข้อมูล – เลือกติดตั้งใบรับรองที่เข้ารหัส

ลบจัดเก็บข้อมูล – ลบใบรับรองทั้งหมด

< ภาษาและการป้อนข้อมูล >

ใช้การตั้งค่า ภาษาและการป้อนข้อมูล เพื่อเลือกภาษาสำหรับข้อความในโทรศัพท์ และเพื่อกำหนดค่าแป้นพิมพ์บนหน้าจอ
รวมถึงคำที่คุณเพิ่มในพจนานุกรม

< แบ็คอัพและรีเซ็ท >

เปลี่ยนการตั้งค่าสำหรับการจัดการการตั้งค่าและข้อมูลของคุณ

สำรองข้อมูลของฉัน – ตั้งค่าเพื่อสำรองข้อมูลการตั้งค่าและแอปพลิเคชันของคุณลงบนเซิร์ฟเวอร์ของ Google

บัญชีข้อมูลสำรอง – ตั้งค่าเพื่อสำรองข้อมูลแอคเคาท์ของคุณ

เรียกคืนอัตโนมัติ – ตั้งค่าให้ทำการเรียกคืนข้อมูลการตั้งค่าและแอปพลิเคชันของคุณ เมื่อมีการติดตั้งแอปพลิเคชันซ้ำบนอุปกรณ์ของคุณ

บริการ LG แบ็คอัพ – สำรองข้อมูลทั้งหมดในอุปกรณ์และเรียกคืนข้อมูลในกรณีที่ข้อมูลสูญหายหรือเปลี่ยนเครื่อง
รีเซ็ตข้อมูลจากโรงงาน – รีเซ็ตการตั้งของคุณกลับสู่ค่าเริ่มต้นจากโรงงานและลบข้อมูลทั้งหมดของคุณ หากคุณรีเซ็ตโทรศัพท์ด้วยวิธีการนี้ คุณจะต้องป้อนข้อมูลเช่นเดียวกับเมื่อคุณเริ่มต้น Android ครั้งแรก

< วันที่และเวลา >

ใช้การตั้งค่า **วันที่และเวลา** เพื่อตั้งค่าการแสดงวันที่ คุณยังสามารถใช้การตั้งค่าเหล่านี้เพื่อตั้งค่าเวลาและโซนเวลาของคุณแทนการรับเวลาปัจจุบันจากเครือข่ายโทรศัพท์เคลื่อนที่ได้

< การช่วยสำหรับการเข้าถึง >

ใช้การตั้งค่า **การช่วยสำหรับการเข้าถึง** เพื่อกำหนดค่าปลั๊กอินช่วยเหลือสำหรับการเข้าถึงที่คุณติดตั้งในโทรศัพท์

หมายเหตุ: ต้องใช้พลักอินเพิ่มเติมเพื่อให้สามารถเลือกได้

< การเชื่อมต่อ PC >

เลือกวิธีเชื่อมต่อแบบ USB – ตั้งค่าโหมดที่ต้องการ: **ชาร์จโทรศัพท์, ซิงค์มีเดีย (MTP), การปล่อยสัญญาณ, LG ซอร์ฟแวร์** หรือ **ส่งรูปภาพ (PTP)**
ถามเมื่อทำการเชื่อมต่อ – ถามในโหมดเชื่อมต่อ USB เมื่อโทรศัพท์เชื่อมต่อกับคอมพิวเตอร์
ช่วยเหลือ – ช่วยเหลือในการเชื่อมต่อ USB
PC Suite – เลือกตัวเลือกนี้เพื่อใช้ LG PC Suite กับการเชื่อมต่อ Wi-Fi โปรดอย่าลืมว่าเครือข่าย Wi-Fi ควรเชื่อมต่อกับ LG PC Suite ด้วยการเชื่อมต่อ Wi-Fi
On-Screen Phone – เลือกตัวเลือกนี้เพื่อรับคำขอเชื่อมต่อ Wi-Fi จาก On-Screen Phone
ช่วยเหลือ – ช่วยเหลือเกี่ยวกับ LG ซอร์ฟแวร์

< อุปกรณ์ >

QuickWindow Case – เปิดใช้เพื่อทำให้คุณสมบัติต่างๆ เช่น เพลง สภาพอากาศ และนาฬิกาใช้งานได้ในมุมมองขนาดเล็กเมื่อใช้ QuickWindow Case

ที่เก็บข้อมูล USB – ตั้งค่าคุณสมบัติ Plug & Pop สำหรับที่เก็บข้อมูล USB เลือกตัวเลือก แอปพลิเคชันพาเนล เพื่อแสดงแอปพลิเคชันพาเนลโดยอัตโนมัติเมื่อเชื่อมต่อสายเคเบิล USB แบบ OTG (On-the-Go) แตะ แก้ไขแอปพลิเคชันพาเนล เพื่อเปลี่ยนแอปพลิเคชันที่คุณต้องการให้ใช้ได้

หูฟัง – ตั้งค่าคุณสมบัติ Plug & Pop สำหรับหูฟัง เลือกตัวเลือก แอปพลิเคชันพาเนล เพื่อแสดงแอปพลิเคชันพาเนลโดยอัตโนมัติเมื่อเชื่อมต่อหูฟัง แตะ แก้ไขแอปพลิเคชันพาเนล เพื่อเปลี่ยนแอปพลิเคชันที่คุณต้องการให้ใช้ได้

< เกี่ยวกับโทรศัพท์ >

ดูข้อมูลทางกฎหมาย และตรวจสอบสถานะโทรศัพท์และเวอร์ชันซอฟต์แวร์ของคุณ

ซอฟต์แวร์คอมพิวเตอร์ (LG PC Suite)

ซอฟต์แวร์คอมพิวเตอร์ "LG PC Suite" เป็นโปรแกรมที่จะช่วยเชื่อมต่ออุปกรณ์ของคุณกับคอมพิวเตอร์ ผ่านสายเคเบิลการสื่อสารข้อมูล USB และ Wi-Fi เมื่อเชื่อมต่อแล้ว คุณสามารถใช้ฟังก์ชันของอุปกรณ์ของคุณบนคอมพิวเตอร์ได้

ด้วยซอฟต์แวร์คอมพิวเตอร์ "LG PC Suite" คุณสามารถ...

- จัดการและเล่นเนื้อหามีเดียของคุณ (เพลง ภาพยนตร์ รูปภาพ) บนคอมพิวเตอร์ของคุณ
- ส่งเนื้อหามัลติมีเดียไปยังอุปกรณ์ของคุณ
- ซิงโครไนซ์ข้อมูล (กำหนดการ รายชื่อ บุ๊คมาร์ค) ในอุปกรณ์และคอมพิวเตอร์ของคุณ
- สำรองข้อมูลแอปพลิเคชันต่างๆ ในอุปกรณ์ของคุณ
- อัปเดตซอฟต์แวร์ในอุปกรณ์ของคุณ
- สำรองข้อมูลและเรียกคืนอุปกรณ์ของคุณ
- เล่นเนื้อหามัลติมีเดียในคอมพิวเตอร์ของคุณจากอุปกรณ์ของคุณ
- สำรองและสร้างและแก้ไขบันทึกในอุปกรณ์ของคุณ

หมายเหตุ: คุณสามารถใช้เมนู ช่วยเหลือ จากแอปพลิเคชันเพื่อค้นหาวิธีการใช้งานซอฟต์แวร์คอมพิวเตอร์ "LG PC Suite" ของคุณได้

การติดตั้งซอฟต์แวร์คอมพิวเตอร์ "LG PC Suite"

ซอฟต์แวร์คอมพิวเตอร์ "LG PC Suite" สามารถดาวน์โหลดได้จากเว็บเพจของ LG

1 ไปที่ www.lg.com และเลือกประเทศที่คุณต้องการ
2 ไปที่ **บริการ** > **บริการโทรศัพท์มือถือ** > **โทรศัพท์มือถือ** > **เลือกรุ่น**
3 คลิก **PC SYNC** จาก **คู่มือและการดาวน์โหลด** จากนั้นคลิก ดาวน์โหลด เพื่อดาวน์โหลดซอฟต์แวร์คอมพิวเตอร์ "LG PC Suite"

ซอฟต์แวร์คอมพิวเตอร์ (LG PC Suite)

ข้อกำหนดของระบบสำหรับ "LG PC Suite" PC software

- OS: Windows XP (Service pack 3) 32bit, Windows Vista, Windows 7, Windows 8
- CPU: โปรเซสเซอร์ 1 GHz หรือสูงกว่า
- หน่วยความจำ: 512 MB RAM หรือสูงกว่า
- กราฟิกการ์ด: ความละเอียดหน้าจอ 1024 x 768 สี 32 บิตหรือสูงกว่า
- HDD: พื้นที่ว่าง 500 MB หรือมากกว่า (อาจต้องใช้พื้นที่ว่างบนฮาร์ดดิสก์มากขึ้น โดยขึ้นอยู่กับปริมาณข้อมูลที่จัดเก็บ)
- ซอฟต์แวร์ที่ต้องการ: ไดรเวอร์ในตัวของ LG, Windows Media Player 10 หรือใหม่กว่า

หมายเหตุ: ไดรเวอร์ USB ในตัวของ LG
ไดรเวอร์ USB ในตัวของ LG จำเป็นในการเชื่อมต่ออุปกรณ์ LG และคอมพิวเตอร์ และไดรเวอร์จะถูกติดตั้งโดยอัตโนมัติ เมื่อคุณติดตั้งซอฟต์แวร์คอมพิวเตอร์ "LG PC Suite"

การซิงโครไนซ์อุปกรณ์ของคุณกับคอมพิวเตอร์

ข้อมูลจากอุปกรณ์และคอมพิวเตอร์สามารถซิงโครไนซ์ได้ง่ายๆ ด้วยซอฟต์แวร์ "LG PC Suite" เพื่อความสะดวกของคุณ รายชื่อ กำหนดการ และบุคมาร์คสามารถซิงโครไนซ์ได้
ขั้นตอนจะมีดังต่อไปนี้:

1. เชื่อมต่อเครื่องของคุณเข้ากับเครื่องคอมพิวเตอร์ของคุณ (ใช้สายเคเบิล USB หรือการเชื่อมต่อ Wi-Fi)
2. เลือกวิธีเชื่อมต่อแบบ USB **จะปรากฏขึ้น แล้วเลือก** LG ซอร์ฟแวร์
3. หลังจากการเชื่อมต่อ ให้เรียกใช้โปรแกรมและเลือกส่วนอุปกรณ์จากประเภททางด้านซ้ายของหน้าจอ
4. คลิก **ข้อมูลส่วนตัว** เพื่อเลือก
5. ทำเครื่องหมายที่ช่องเนื้อหาเพื่อซิงโครไนซ์ และคลิกที่ปุ่ม **ซิงค์**

หมายเหตุ: ในการซิงโครไนซ์โทรศัพท์กับคอมพิวเตอร์ คุณต้องติดตั้ง LG PC Suite ในคอมพิวเตอร์ โปรดดูหน้าก่อนหน้านี้สำหรับการติดตั้ง LG PC Suite

การย้ายรายชื่อจากอุปกรณ์เก่าไปยังอุปกรณ์ใหม่

1 เอ็กซ์ปอร์ตรายชื่อของคุณเป็นไฟล์ CSV จากอุปกรณ์เก่าไปยังคอมพิวเตอร์โดยใช้โปรแกรม PC Sync
2 ติดตั้ง "LG PC Suite" ในคอมพิวเตอร์ก่อน เรียกใช้โปรแกรมและเชื่อมต่อโทรศัพท์ของคุณกับคอมพิวเตอร์โดยใช้สายเคเบิล USB
3 ที่เมนูบนสุด เลือก **Device** > **Import to device** > **Import contacts**
4 หน้าต่างป๊อปอัปเพื่อเลือกประเภทไฟล์และไฟล์ที่จะอิมปอร์ตจะปรากฏขึ้น
5 บนป๊อปอัป คลิก **Select a file** แล้ว Windows Explorer จะปรากฏขึ้น
6 เลือกไฟล์รายชื่อที่จะอิมปอร์ตใน Windows Explorer แล้วคลิก **Open**
7 คลิก **OK**
8 ป๊อปอัป **Field mapping** เพื่อลิงค์รายชื่อในอุปกรณ์ของคุณและข้อมูลรายชื่อใหม่จะปรากฏขึ้น
9 หากมีการขัดแย้งระหว่างข้อมูลในรายชื่อ PC และรายชื่ออุปกรณ์ ให้ทำการเลือกหรือแก้ไขที่จำเป็นใน LG PC Suite
10 คลิก **OK**

อัปเดตซอฟต์แวร์โทรศัพท์

อัปเดตซอฟต์แวร์โทรศัพท์

การอัปเดตซอฟต์แวร์โทรศัพท์มือถือ LG จากอินเตอร์เน็ต
สำหรับข้อมูลเพิ่มเติมเกี่ยวกับการใช้ฟังก์ชันนี้ โปรดดูที่ http://www.lg.com/common/index.jsp → เลือกประเทศและภาษาของคุณ
คุณสมบัตินี้ให้คุณอัปเดตเฟิร์มแวร์ของโทรศัพท์เป็นเวอร์ชันใหม่ได้อย่างสะดวกจากอินเตอร์เน็ตโดยไม่ต้องไปที่ศูนย์บริการ คุณสมบัตินี้จะใช้ได้เมื่อ LG มีเฟิร์มแวร์เวอร์ชันใหม่สำหรับอุปกรณ์ของคุณเท่านั้น
เนื่องจากการอัปเดตเฟิร์มแวร์โทรศัพท์มือถือต้องการให้ผู้ใช้ดำเนินการอัปเดตอย่างระมัดระวัง โปรดตรวจสอบคำแนะนำและหมายเหตุที่ปรากฏขึ้นในแต่ละขั้นตอนก่อนดำเนินการต่อไป โปรดทราบว่าการถอดสายข้อมูล USB ระหว่างการอัปเกรดอาจทำให้โทรศัพท์มือถือชำรุดเสียหายได้

หมายเหตุ: LG ขอสงวนสิทธิ์ในการให้บริการอัปเดตเฟิร์มแวร์สำหรับบางรุ่นเท่านั้นตามดุลยพินิจของบริษัทแต่เพียงผู้เดียว และไม่รับประกันว่าจะมีเฟิร์มแวร์เวอร์ชันใหม่สำหรับเครื่องทุกรุ่น

อัปเดตซอฟต์แวร์โทรศัพท์มือถือ LG ผ่าน Over-the-Air (OTA)
คุณสมบัตินี้ให้คุณสามารถอัปเดตซอฟต์แวร์ของโทรศัพท์เป็นเวอร์ชันใหม่อย่างสะดวกผ่าน OTA โดยไม่ต้องเชื่อมต่อโดยใช้สายเคเบิลข้อมูล USB คุณสมบัตินี้จะใช้ได้เมื่อ LG มีเฟิร์มแวร์เวอร์ชันใหม่สำหรับอุปกรณ์ของคุณเท่านั้น
คุณควรตรวจสอบเวอร์ชันของซอฟต์แวร์ในโทรศัพท์มือถือของคุณ
ก่อน: **ตั้งค่า** > แท็บ **ทั่วไป** > **เกี่ยวกับโทรศัพท์** > **ศูนย์กลางอัปเดต > อัปเดตซอร์ฟแวร์ > ตรวจสอบอัปเดตในตอนนี้**

หมายเหตุ: ข้อมูลส่วนตัวของคุณจากพื้นที่การจัดเก็บภายในโทรศัพท์—รวมถึงข้อมูลเกี่ยวกับแอคเคาท์ Google ของคุณและแอคเคาท์อื่นๆ, ข้อมูลระบบหรือแอปพลิเคชันและการตั้งค่าของคุณ, แอปพลิเคชันที่ดาวน์โหลดและใบอนุญาต DRM—อาจสูญหายในกระบวนการอัปเดตซอฟต์แวร์ของโทรศัพท์ ดังนั้น LG ขอแนะนำให้คุณสำรองข้อมูลส่วนตัวก่อนการอัปเดตซอฟต์แวร์ของโทรศัพท์ LG ไม่รับผิดชอบต่อการสูญหายของข้อมูลส่วนตัวใดๆ

หมายเหตุ: คุณสมบัตินี้ขึ้นอยู่กับผู้ให้บริการเครือข่าย ภูมิภาค และประเทศของคุณ

เกี่ยวกับคู่มือผู้ใช้นี้

เกี่ยวกับคู่มือผู้ใช้นี้

- โปรดอ่านคู่มือนี้โดยละเอียดก่อนการใช้งานอุปกรณ์ เพื่อให้มั่นใจว่าคุณใช้โทรศัพท์ของคุณได้อย่างถูกต้องและปลอดภัย
- ภาพและภาพหน้าจอบางภาพที่มีในคู่มือนี้อาจแตกต่างจากที่แสดงบนโทรศัพท์ของคุณ
- เนื้อหาของคุณอาจแตกต่างจากผลิตภัณฑ์ที่วางจำหน่าย หรือจากซอฟต์แวร์ที่มาจากผู้ให้บริการหรือเครือข่าย เนื้อหานี้อาจเปลี่ยนแปลงได้โดยไม่ต้องแจ้งให้ทราบล่วงหน้า สำหรับเวอร์ชันล่าสุดของคู่มือนี้ โปรดดูที่เว็บไซต์ LG ที่ www.lg.com
- แอปพลิเคชันและฟังก์ชันของโทรศัพท์อาจแตกต่างกันตามประเทศ ภูมิภาค หรือข้อมูลจำเพาะของฮาร์ดแวร์ LG ไม่รับผิดชอบต่อปัญหาด้านประสิทธิภาพที่เกิดจากการใช้แอปพลิเคชันที่พัฒนาขึ้นโดยผู้ให้บริการอื่นที่ไม่ใช่ LG
- LG ไม่รับผิดชอบต่อปัญหาด้านประสิทธิภาพหรือการไม่สามารถใช้งานร่วมกันได้ที่เกิดจากการแก้ไขการตั้งค่ารีจิสทรีย์ หรือการแก้ไขซอฟต์แวร์ระบบการปฏิบัติการ ความพยายามในการปรับแต่งระบบปฏิบัติการอาจทำให้อุปกรณ์หรือแอปพลิเคชันของอุปกรณ์ทำงานผิดปกติ
- ซอฟต์แวร์, เสียง, พื้นหลัง, ภาพ และมีเดียที่มีมาให้พร้อมอุปกรณ์ได้รับอนุญาตเพื่อการใช้งานที่จำกัด หากคุณจัดเก็บข้อมูลและใช้ข้อมูลเหล่านี้เพื่อการพาณิชย์หรือวัตถุประสงค์อื่นๆ คุณอาจละเมิดกฎหมายลิขสิทธิ์ ในฐานะผู้ใช้งาน คุณมีส่วนรับผิดชอบอย่างสมบูรณ์สำหรับการใช้มีเดียอย่างผิดกฎหมาย
- อาจมีค่าใช้จ่ายเพิ่มเติมสำหรับบริการข้อมูล เช่น ข้อความ, การอัปโหลด และดาวน์โหลด, ซิงค์อัตโนมัติ หรือการใช้บริการระบุพิกัด เพื่อหลีกเลี่ยงค่าใช้จ่ายเพิ่มเติม ให้เลือกแผนบริการข้อมูลที่เหมาะกับความต้องการของคุณ ติดต่อผู้ให้บริการของคุณเพื่อรับรายละเอียดเพิ่มเติม

เครื่องหมายการค้า

- LG และโลโก้ LG เป็นเครื่องหมายการค้าจดทะเบียนของ LG Electronics
- เครื่องหมายการค้าและลิขสิทธิ์อื่นๆ ทั้งหมดเป็นสมบัติของเจ้าของนั้นๆ

DivX HD

เกี่ยวกับวิดีโอ DIVX: DivX® เป็นฟอร์แมตวิดีโอดิจิตอลที่สร้างโดย DivX, LLC บริษัทในเครือของ Rovi Corporation อุปกรณ์นี้เป็นอุปกรณ์ที่ได้รับการรับรอง DivX Certified® ซึ่งผ่านการทดสอบที่เข้มงวดเพื่อยืนยันว่าเล่นวิดีโอ DivX ได้ สำหรับข้อมูลเพิ่มเติมและเครื่องมือซอฟต์แวร์อื่นๆ ที่ใช้ในการแปลงไฟล์เป็นวิดีโอ DivX โปรดไปที่ divx.com

เกี่ยวกับ DIVX VIDEO-ON-DEMAND: อุปกรณ์ DivX Certified® นี้ต้องทำการลงทะเบียนเพื่อที่จะสามารถเล่นภาพยนตร์ DivX Video-on-Demand (VOD) ที่ซื้อได้ ในการรับรหัสการลงทะเบียนของคุณ ให้ไปที่ส่วน DivX VOD ในเมนูตั้งค่าอุปกรณ์ของคุณ ไปที่ vod.divx.com สำหรับข้อมูลเพิ่มเติมเกี่ยวกับวิธีการลงทะเบียน

DivX Certified® สำหรับเล่นวิดีโอ DivX® ไม่เกิน HD 720p รวมถึงเนื้อหาพรีเมียม

DivX®, DivX Certified® และโลโก้ที่เกี่ยวข้องเป็นเครื่องหมายการค้าของ Rovi Corporation หรือบริษัทในเครือ และใช้โดยได้รับอนุญาต

Dolby Digital Plus

ผลิตภายใต้การอนุญาตของ Dolby Laboratories Dolby, Dolby Digital Plus และสัญลักษณ์ตัวอักษร D สองตัว เป็นเครื่องหมายการค้าของ Dolby Laboratories

เกี่ยวกับคู่มือผู้ใช้นี้

ประกาศ: ซอฟต์แวร์โอเพ่นซอร์ส
ในการขอรับซอร์สโค้ดที่เกี่ยวข้องตาม GPL, LGPL, MPL และและใบอนุญาตโอเพ่นซอร์สอื่นๆ โปรดไปที่ http://opensource.lge.com/ เงื่อนไขใบอนุญาต การปฏิเสธการรับผิดชอบ และประกาศที่อ้างอิงถึงทั้งหมด สามารถดาวน์โหลดได้พร้อมกับซอร์สโค้ด

อุปกรณ์เสริม

อุปกรณ์เสริมต่างๆ เหล่านี้มีให้ใช้กับโทรศัพท์ของคุณ **(รายการต่างๆ ที่อธิบายด้านล่างนี้เป็นตัวเลือก)**

อะแดปเตอร์สำหรับชาร์จแบตเตอรี่

ชุดหูฟังสเตอริโอ

คู่มือแนะนำอย่างย่อ

สายเคเบิลข้อมูล

เครื่องมือถอด Micro-USIM

ศูนย์บริการ LG โดย บริษัท แอลจี อีเลคทรอนิคส์ (ประเทศไทย) จำกัด
ศูนย์ซ่อมสำนักงานใหญ่ตากสิน
เลขที่ 72/127 ถ. สมเด็จพระเจ้าตากสิน แขวงบุคคโล เขตธนบุรี
กรุงเทพฯ 10600
วันและเวลาทำการ : จันทร์-เสาร์, 08:00 - 18:00น.
Call center : 0-2878-5757

หมายเหตุ:
- ใช้แต่อุปกรณ์เสริมของแท้ของ LG เท่านั้น
- การไม่ปฏิบัติดังกล่าวอาจมีผลให้การรับประกันสิ้นสุดลง
- อุปกรณ์เสริมอาจแตกต่างกันในบางพื้นที่

การแก้ปัญหา

เนื้อหาในบทนี้จะแสดงถึงปัญหาต่างๆ ที่คุณอาจพบเมื่อใช้โทรศัพท์ คุณอาจต้องสอบถามผู้ให้บริการเพื่อแก้ไขปัญหาบางประการ แต่ปัญหาส่วนใหญ่คุณสามารถแก้ไขได้เองอย่างง่ายดาย

ข้อความ	สาเหตุที่เป็นไปได้	วิธีการแก้ไขที่เป็นไปได้
ข้อผิดพลาดของการ์ด Micro-USIM	ไม่ได้ใส่ Micro-USIM การ์ดในโทรศัพท์ หรือใส่ไม่ถูกต้อง	ตรวจสอบให้แน่ใจว่าใส่ Micro-USIM การ์ดอย่างถูกต้อง
ไม่มีการเชื่อมต่อกับเครือข่าย/ เครือข่ายขาดหาย	สัญญาณอ่อนหรือคุณอยู่นอกเครือข่ายผู้ให้บริการ	ไปที่บริเวณใกล้กับหน้าต่างหรือในที่เปิดโล่ง ตรวจสอบพื้นที่ให้บริการกับผู้ให้บริการเครือข่าย
	ผู้ให้บริการใช้บริการใหม่	ตรวจดูว่าการ์ด Micro-USIM ใช้งานมามากกว่า 6~12 เดือนหรือไม่ หากเป็นเช่นนั้น ให้เปลี่ยนการ์ด Micro-USIM ของคุณที่สาขาผู้ให้บริการเครือข่ายใกล้บ้าน ติดต่อผู้ให้บริการ
รหัสไม่ตรงกัน	ในการเปลี่ยนรหัสป้องกัน คุณต้องยืนยันรหัสใหม่โดยป้อนรหัสใหม่ซ้ำ	หากคุณลืมรหัส โปรดติดต่อผู้ให้บริการ
	รหัสที่คุณป้อนทั้งสองครั้งไม่ตรงกัน	
ไม่สามารถตั้งค่าแอปพลิเคชัน	ผู้ให้บริการไม่สนับสนุนหรือต้องลงทะเบียน	ติดต่อผู้ให้บริการ

ข้อความ	สาเหตุที่เป็นไปได้	วิธีการแก้ไขที่เป็นไปได้
ไม่สามารถโทรออกได้	ข้อผิดพลาดในการติดต่อหมายเลข	ระบบเครือข่ายใหม่ยังไม่ได้รับอนุญาต
	มีการใส่ Micro-USIM การ์ดใหม่	ตรวจสอบข้อกำหนดใหม่
	ถึงขีดจำกัดค่าโทรแบบเติมเงิน	ติดต่อผู้ให้บริการ หรือตั้งค่าการจำกัดการโทรใหม่โดยใช้รหัส PIN2
เปิดเครื่องโทรศัพท์ไม่ได้	กดปุ่มเปิด/ปิดแล้วปล่อยเร็วเกินไป	กดปุ่มเปิด/ปิดอย่างน้อยสองวินาที
	ไม่ได้ชาร์จแบตเตอรี่	ชาร์จแบตเตอรี่ ตรวจสอบสัญลักษณ์กำลังชาร์จบนหน้าจอ
ข้อผิดพลาดเกี่ยวกับการชาร์จ	ไม่ได้ชาร์จแบตเตอรี่	ชาร์จแบตเตอรี่
	อุณหภูมิภายนอกร้อนหรือเย็นเกินไป	ตรวจดูให้แน่ใจว่าโทรศัพท์กำลังชาร์จไฟที่อุณหภูมิปกติ
	มีปัญหาที่ขั้วสัมผัส	ตรวจสอบอุปกรณ์ชาร์จและการเชื่อมต่อของอุปกรณ์ชาร์จกับโทรศัพท์
	ไม่มีกระแสไฟฟ้า	เสียบปลั๊กอุปกรณ์ชาร์จในช่องอื่น
	อุปกรณ์ชาร์จชำรุด	เปลี่ยนอุปกรณ์ชาร์จ
	อุปกรณ์ชาร์จไม่ถูกต้อง	ใช้อุปกรณ์เสริมของแท้ของ LG เท่านั้น
ไม่อนุญาตให้ใช้ตัวเลข	กำลังใช้งานฟังก์ชันกำหนดหมายเลขโทรออก	ตรวจสอบเมนูตั้งค่าและปิดฟังก์ชันดังกล่าว

การแก้ปัญหา

ข้อความ	สาเหตุที่เป็นไปได้	วิธีการแก้ไขที่เป็นไปได้
ไม่สามารถรับ / ส่ง SMS และรูปภาพได้	หน่วยความจำเต็ม	ลบข้อความบางข้อความออกจากโทรศัพท์
เปิดไฟล์ไม่ได้	ไม่สนับสนุนรูปแบบไฟล์	ตรวจสอบรูปแบบไฟล์ที่สนับสนุน
หน้าจอไม่ทำงานเมื่อฉันรับสาย	เซนเซอร์หน้าจอมีปัญหา	หากคุณใช้เทปหรือกล่องป้องกัน ตรวจดูว่าอุปกรณ์ดังกล่าวปิดคลุมพื้นที่รอบเซนเซอร์รับสัญญาณหรือไม่ ตรวจดูให้แน่ใจว่าพื้นที่รอบเซนเซอร์หน้าจอสะอาด
ไม่มีเสียง	โหมดสั่น	ตรวจสอบการตั้งค่าสถานะของเมนูเสียงเพื่อให้แน่ใจว่าคุณไม่ได้อยู่ในโหมดสั่นหรือโหมดปิดเสียง
โทรศัพท์ค้างหรือไม่ทำงาน	ปัญหาซอฟต์แวร์ชั่วคราว	ลองใช้งานการอัปเดตซอฟต์แวร์ผ่านทางเว็บไซต์

คำถามที่พบบ่อย

ชนิด ชนิดย่อย	คำถาม	คำตอบ
BT Bluetooth อุปกรณ์	ฟังก์ชันที่ใช้ได้ผ่าน Bluetooth มีอะไรบ้าง	คุณสามารถเชื่อมต่ออุปกรณ์เสียง Bluetooth เช่น ชุดหูฟังสเตอริโอ/โมโน หรือชุดติดรถยนต์ได้ และเมื่อเซิร์ฟเวอร์ FTP เชื่อมต่อกับอุปกรณ์ที่ใช้งานร่วมกัน คุณสามารถแบ่งปันเนื้อหาที่จัดเก็บในมีเดียที่เก็บข้อมูลได้
BT Bluetooth ชุดหูฟัง	หากฉันเชื่อมต่อชุดหูฟัง Bluetooth ของฉัน ฉันจะสามารถฟังเพลงผ่านหูฟังแบบใช้สายขนาด 3.5 มม. ของฉันได้หรือไม่	เมื่อมีการเชื่อมต่อชุดหูฟัง Bluetooth ระบบเสียงทั้งหมดจะถูกเล่นผ่านชุดหูฟัง ดังนั้น คุณจะไม่สามารถฟังเพลงผ่านหูฟังแบบใช้สายของคุณได้
ข้อมูล รายชื่อ สำรองข้อมูล	ฉันจะสามารถสำรองข้อมูลรายชื่อได้อย่างไร	ข้อมูลรายชื่อสามารถซิงโครไนซ์ระหว่างโทรศัพท์ของคุณกับ Gmail™ ได้
ข้อมูล การซิงโครไนซ์	เป็นไปได้หรือไม่ที่จะตั้งค่าการซิงค์ทางเดียวกับ Gmail	มีเฉพาะการซิงโครไนซ์สองทางให้ใช้งาน
ข้อมูล การซิงโครไนซ์	เป็นไปได้หรือไม่ที่จะซิงโครไนซ์โฟลเดอร์อีเมลทั้งหมด	ถาดเข้าจะซิงโครไนซ์โดยอัตโนมัติ คุณสามารถดูโฟลเดอร์อื่นๆ ได้โดยการแตะ **ปุ่มเมนู** แล้วเลือก **โฟลเดอร์** เพื่อเลือกโฟลเดอร์
บริการของ Google™ ล็อกอิน Gmail	ฉันต้องล็อกอิน Gmail เมื่อต้องการเข้าถึง Gmail หรือไม่	เมื่อคุณล็อกอิน Gmail แล้ว คุณไม่จำเป็นต้องล็อกอิน Gmail อีก

คำถามที่พบบ่อย

ชนิด ชนิดย่อย	คำถาม	คำตอบ
บริการของ Google™ บัญชี Google	เป็นไปได้หรือไม่ที่จะฟิลเตอร์อีเมล	ไม่ได้ ไม่สนับสนุนการฟิลเตอร์อีเมลผ่านโทรศัพท์
ฟังก์ชันโทรศัพท์ อีเมล	จะเกิดอะไรขึ้นเมื่อฉันใช้งานแอปพลิเคชันอื่นขณะเขียนอีเมล	อีเมลของคุณจะถูกบันทึกเป็นร่างโดยอัตโนมัติ
ฟังก์ชันโทรศัพท์ เสียงเรียกเข้า	เมื่อฉันใช้ไฟล์ .MP3 เป็นเสียงเรียกเข้า จะมีการจำกัดขนาดไฟล์หรือไม่	ไม่มีการจำกัดขนาดไฟล์
ฟังก์ชันโทรศัพท์ เวลาข้อความ	โทรศัพท์ของฉันไม่แสดงเวลาที่ได้รับข้อความที่เก่าเกิน 24 ชั่วโมงได้ ฉันจะเปลี่ยนแปลงส่วนนี้ได้อย่างไร	คุณจะสามารถดูได้เฉพาะเวลาข้อความที่ได้รับในวันเดียวกันเท่านั้น
ฟังก์ชันโทรศัพท์ การนำทาง	เป็นไปได้หรือไม่ที่จะติดตั้งแอปพลิเคชันการนำทางอื่นในโทรศัพท์ของฉัน	แอปพลิเคชันที่มีอยู่ที่ Play Store™ และใช้งานร่วมกับฮาร์ดแวร์ได้สามารถติดตั้งและใช้งานได้
ฟังก์ชันโทรศัพท์ การซิงโครไนซ์	เป็นไปได้หรือไม่ที่จะซิงโครไนซ์รายชื่อจากแอคเคาท์อีเมลทั้งหมดของฉัน	สามารถซิงโครไนซ์ได้เฉพาะรายชื่อของ Gmail และเซิร์ฟเวอร์ MS Exchange (เซิร์ฟเวอร์อีเมลของบริษัท) เท่านั้น

ชนิด ชนิดย่อย	คำถาม	คำตอบ
ฟังก์ชันโทรศัพท์ รอและหยุดชั่วคราว	เป็นไปได้หรือไม่ที่จะบันทึกรายชื่อด้วยรอคอยและหยุดพักในรูปแบบหมายเลข	หากคุณโอนรายชื่อด้วยฟังก์ชัน W & P เป็นหมายเลข คุณจะไม่สามารถใช้คุณสมบัติเหล่านั้นได้ คุณจะต้องบันทึกแต่ละหมายเลขใหม่อีกครั้ง วิธีการบันทึกด้วยรอและหยุดชั่วคราว: 1. จากหน้าจอหลัก ให้แตะไอคอน **โทรศัพท์** 2. กดหมายเลขโทรศัพท์ และแตะ **ปุ่มเมนู** 3. แตะ **เพิ่มหยุดพัก 2 วินาที** หรือ **เพิ่มการรอ**
ฟังก์ชันโทรศัพท์ ระบบป้องกัน	ฟังก์ชันระบบป้องกันของโทรศัพท์มีอะไรบ้าง	คุณสามารถตั้งค่าโทรศัพท์ให้ต้องป้อนแบบปลดล็อคก่อนที่จะเข้าใช้หรือใช้งานโทรศัพท์ได้

คำถามที่พบบ่อย

ชนิด ชนิดย่อย	คำถาม	คำตอบ
ฟังก์ชันโทรศัพท์ ปลดล็อคแบบ	ฉันจะสร้างแบบปลดล็อคได้อย่างไร	1. จากหน้าจอหลัก ให้แตะ **ปุ่มเมนู** 2. แตะ **การตั้งค่าระบบ** > แท็บ **หน้าจอ** > **ล็อคหน้าจอ** 3. แตะ **เลือกแบบล็อคหน้าจอ** > **รูปแบบ** ในครั้งแรกจะมีการแสดงบทช่วยสอนสั้นๆ เกี่ยวกับการสร้างแบบปลดล็อค 4. ตั้งค่าโดยการวาดแบบของคุณหนึ่งครั้งและอีกครั้งเพื่อยืนยัน **ข้อควรระวังเมื่อใช้ล็อคแบบ** สิ่งสำคัญคือต้องจำแบบปลดล็อคที่คุณตั้งไว้ได้ คุณจะไม่สามารถเข้าใช้โทรศัพท์ของคุณได้หากคุณใช้แบบไม่ถูกต้องห้าครั้ง คุณมีโอกาสเพียงห้าครั้งในการป้อนแบบการปลดล็อค PIN หรือรหัสผ่านของคุณ หากคุณทำการป้อนทั้งหมด 5 ครั้งแล้ว คุณสามารถลองใหม่ได้อีกครั้งหลังจากผ่านไป 30 วินาที (หรือหากคุณตั้งค่าแบ็คอัพ PIN ไว้แล้ว คุณสามารถใช้รหัสแบ็คอัพ PIN เพื่อปลดล็อคแบบได้)

ชนิด ชนิดย่อย	คำถาม	คำตอบ
ฟังก์ชันโทรศัพท์ ปลดล็อคแบบ	ฉันควรทำอย่างไรหากฉันลืมแบบปลดล็อคและไม่ได้สร้างบัญชี Google ในโทรศัพท์	**หากคุณลืมแบบของคุณ:** หากคุณล็อกอินบัญชี Google ในโทรศัพท์แต่ป้อนรูปแบบไม่ถูกต้อง 5 ครั้ง ให้แตะปุ่ม ลืมแบบ จากนั้น คุณจะต้องลงชื่อเข้าใช้ด้วยแอคเคาท์ Google ของคุณเพื่อปลดล็อคโทรศัพท์ หากคุณไม่ได้สร้างบัญชี Google บนโทรศัพท์ หรือคุณลืมแอคเคาท์ คุณต้องทำการ Hard Reset **หมายเหตุ:** **หากคุณทำการรีเซ็ตค่าจากโรงงาน ข้อมูลแอปพลิเคชันผู้ใช้และข้อมูลผู้ใช้ทั้งหมดจะถูกลบ โปรดอย่าลืมสำรองข้อมูลสำคัญไว้ก่อนทำการรีเซ็ตค่าจากโรงงาน**
ฟังก์ชันโทรศัพท์ หน่วยความจำ	ฉันจะรู้ว่าหน่วยความจำเต็มได้หรือไม่	ได้ คุณจะได้รับการแจ้งเตือน
ฟังก์ชันโทรศัพท์ การสนับสนุนภาษา	เป็นไปได้หรือไม่ที่จะเปลี่ยนภาษาของโทรศัพท์ของฉัน	โทรศัพท์มีความสามารถหลายภาษา การเปลี่ยนภาษา: 1. จากหน้าจอหลัก ให้แตะ **ปุ่มเมนู** และแตะ **การตั้งค่าระบบ** 2. แตะแท็บ **ทั่วไป** > **ภาษาและการป้อน** > **ภาษา** 3. แตะภาษาที่ต้องการ

คำถามที่พบบ่อย

ชนิด ชนิดย่อย	คำถาม	คำตอบ
ฟังก์ชันโทรศัพท์ VPN	ฉันจะตั้งค่า VPN ได้อย่างไร	การกำหนดค่าการเข้าถึง VPN จะแตกต่างกันสำหรับแต่ละบริษัท ในการกำหนดค่าการเข้าถึง VPN จากโทรศัพท์ของคุณ คุณต้องมีรายละเอียดจากผู้ดูแลระบบเครือข่ายของบริษัทของคุณ
ฟังก์ชันโทรศัพท์ ระยะหมดเวลาหน้าจอ	หน้าจอของฉันปิดหลังจากเพียงแค่ 15 วินาที ฉันจะเปลี่ยนระยะเวลาสำหรับการปิดไฟหน้าจอได้อย่างไร	1. จากหน้าจอหลัก ให้แตะ **ปุ่มเมนู** 2. แตะ **การตั้งค่าระบบ** > แท็บ **หน้าจอ** 3. แตะ **ไทม์เอาต์หน้าจอ** 4. แตะระยะหมดเวลาไฟหน้าจอที่ต้องการ
ฟังก์ชันโทรศัพท์ Wi-Fi และเครือข่ายโทรศัพท์เคลื่อนที่	เมื่อใช้ได้ทั้ง Wi-Fi และเครือข่ายโทรศัพท์เคลื่อนที่ โทรศัพท์ของฉันจะใช้บริการใด	เมื่อใช้ข้อมูล โทรศัพท์ของคุณอาจใช้การเชื่อมต่อ Wi-Fi เป็นค่าเริ่มต้น (หากเปิดการเชื่อมต่อ Wi-Fi ในโทรศัพท์) อย่างไรก็ตาม จะไม่มีการแจ้งเตือนเมื่อโทรศัพท์เปลี่ยนจากบริการหนึ่งไปสู่อีกบริการหนึ่ง หากต้องการทราบว่ากำลังใช้การเชื่อมต่อข้อมูลใด ให้ดูไอคอนเครือข่ายโทรศัพท์เคลื่อนที่หรือ Wi-Fi ที่บนสุดของหน้าจอ
ฟังก์ชันโทรศัพท์ หน้าจอหลัก	เป็นไปได้หรือไม่ที่จะลบแอปพลิเคชันออกจากหน้าจอหลัก	ได้ เพียงแตะไอคอนค้างไว้จนกว่าไอคอนถังขยะปรากฏขึ้นที่บริเวณมุมขวาบนของหน้าจอ จากนั้น ลากไอคอนไปยังถังขยะโดยไม่ต้องยกนิ้วขึ้น
ฟังก์ชันโทรศัพท์ แอปพลิเคชัน	ฉันดาวน์โหลดแอปพลิเคชันและแอปพลิเคชันนั้นทำให้เกิดข้อผิดพลาดจำนวนมาก ฉันจะลบได้อย่างไร	1. จากหน้าจอหลัก ให้แตะ **ปุ่มเมนู** 2. แตะ **การตั้งค่าระบบ > แท็บ ทั่วไป > แอปฯ > ดาวน์โหลด** 3. แตะแอปพลิเคชัน แล้วแตะ **ถอนการติดตั้ง**

ชนิด ชนิดย่อย	คำถาม	คำตอบ
ฟังก์ชันโทรศัพท์ อุปกรณ์ชาร์จ	ฉันสามารถชาร์จโทรศัพท์ของฉันโดยใช้สายเคเบิลข้อมูล USB โดยไม่ติดตั้งไดรเวอร์ USB ที่จำเป็นได้หรือไม่	ได้ โทรศัพท์จะชาร์จไฟจากสายเคเบิล USB ไม่ว่าจะมีการติดตั้งไดรเวอร์ที่จำเป็นหรือไม่
ฟังก์ชันโทรศัพท์ การปลุก	ฉันสามารถใช้ไฟล์เพลงของฉันในการปลุกได้หรือไม่	ได้ ในการตั้งค่านาฬิกาปลุก ให้เลือกเพลงเป็นเสียงปลุก
ฟังก์ชันโทรศัพท์ การปลุก	การปลุกจะส่งเสียงหรือไม่หากโทรศัพท์ปิดอยู่	ไม่ ไม่สนับสนุนการทำงานนี้
ฟังก์ชันโทรศัพท์ การปลุก	หากตั้งค่าระดับเสียงดังเรียกเข้าของฉันเป็นปิดหรือสั่น ฉันจะได้ยินเสียงปลุกหรือไม่	การปลุกของคุณถูกกำหนดให้ส่งเสียงแม้ในสถานการณ์เหล่านี้
โซลูชันการกู้คืนข้อมูล Hard Reset (รีเซ็ตค่าจากโรงงาน)	ฉันจะทำการรีเซ็ตค่าจากโรงงานได้อย่างไร หากฉันไม่สามารถเข้าไปที่เมนูการตั้งค่าของโทรศัพท์ได้	หากโทรศัพท์ของคุณไม่สามารถแก้ไขสู่สภาพเดิมได้ ให้ใช้ Hard Reset (รีเซ็ตค่าจากโรงงาน) เพื่อตั้งค่าเริ่มต้นของโทรศัพท์

ENGLISH

User Guide

- Screen displays and illustrations may differ from those you see on actual phone.
- Some of the contents of this guide may not apply to your phone, depending on the software and your service provider. All information in this document is subject to change without notice.
- This handset is not suitable for people who have a visual impairment due to the tap screen keyboard.
- Copyright ©2014 LG Electronics, Inc. All rights reserved. LG and the LG logo are registered trademarks of LG Group and its related entities. All other trademarks are the property of their respective owners.
- Google™, Google Maps™, Gmail™, YouTube™, Hangouts™ and Play Store™ are trademarks of Google, Inc.

Table of contents

Guidelines for safe and efficient use 5

Important notice 12

Getting to know your phone.....18

Phone overview 18
Installing the micro-USIM card.....20
Charging your phone 21
Locking and unlocking the screen.....22
KnockON.....22
Stereo headset with microphone.....23
Plug & Pop.....24

Your Home screen.....25

Touch screen tips 25
Home screen 26
Extended home screen 26
Customizing the Home screen 27
Returning to recently-used applications.28
Notifications panel.....28
Opening the notifications panel.....29
Indicator icons on the Status Bar 29
On-screen keyboard 31
Entering accented letters.....31

Google account setup.....32

Connecting to Networks and Devices....33

Wi-Fi 33
Connecting to Wi-Fi networks 33
Turning Wi-Fi on and connecting to a Wi-Fi network.....33
Bluetooth.....34
Sharing your phone's data connection ...35
Wi-Fi Direct 37
SmartShare 37
Enjoying the content from Nearby devices.....38
PC connections with a USB cable.....39

Calls 40

Making a call.....40
Calling your contacts 40
Answering and rejecting a call.....40
Adjusting the in-call volume.....41
Making a second call.....41
Viewing your call logs.....41
Call settings.....42

Contacts.....43

Searching for a contact.....43
Adding a new contact.....43
Favourites contacts.....43
Creating a group.....44

Messaging.....45

Sending a message 45
Threaded box 46
Changing your message settings 46

Email 47

Managing an email account.....47
Working with account folders.....47
Composing and sending email.....48

Camera **49**
Getting to know the viewfinder 49
Using the advanced settings 50
Taking a quick photo 51
Using Shot & Clear mode 51
Using Dual camera mode 52
Using Time catch shot mode 52
Once you've taken a photo 53
From your Gallery 54

Video camera **55**
Getting to know the viewfinder 55
Using the advanced settings 56
Recording a quick video 57
After recording a video 57
From your Gallery 58
Adjusting the volume when viewing a video 58
Using Audio Zoom 58
Using Dual recording mode 59
Using Tracking zoom mode 59

Function **60**
QuickMemo 60
Using the QuickMemo options 61
Viewing the saved QuickMemo 61
QuickTranslator 62
QSlide 63
QTheater 64
QuickRemote 64
Zoom to Track 66
VuTalk 67
Register VuTalk Before Use 67
VuTalk Settings 67
Communicate Visually with VuTalk 68
LG SmartWorld 68
How to Get to LG SmartWorld from Your Phone 68
How to use LG SmartWorld 69
On-Screen Phone 70
On-Screen Phone icons 70
On-Screen Phone features 70
How to install On-Screen Phone on your PC 71

Multimedia **72**
Gallery 72
Viewing pictures 72
Playing videos 73
Editing photos 73
Deleting photos/videos 73
Setting as wallpaper 73
Videos 73
Playing a video 74
Music 75
Add music files to your phone 75
Transfer music using Media sync (MTP) 75
Playing a song 75

Utilities **78**
Slide Aside (Quick task-switching with THREE fingers) 78
Dual Window 78
Guest Mode 79

Table of contents

Setting your alarm 79
Using your calculator 80
Adding an event to your calendar.....80
Voice Recorder 81
Recording a sound or voice 81
Sending the voice recording 81
Task Manager.....81
Tasks.....82
POLARIS Viewer 5.....82
Google+ 83
Voice Search.....83
Downloads 83

The Web 84
Internet.....84
Using the Web toolbar 84
Viewing webpages.....84
Opening a page 85
Searching the web by voice.....85
Bookmarks.....85
History 85
Chrome 86
Viewing webpages.....86
Opening a page 86
Syncing with other devices 86

Settings 87
Networks.....87
Sound.....90
Display 91
General.....93

PC software (LG PC Suite) 100

Phone software update 103
Phone software update.....103

About this user guide 105
About this user guide.....105
Trademarks 105
DivX HD 106
Dolby Digital Plus.....106

Accessories.....107

Troubleshooting 108

FAQ 112

Guidelines for safe and efficient use

Please read these simple guidelines. Not following these guidelines may be dangerous or illegal.

Should a fault occur, a software tool is built into your device that will gather a fault log. This tool gathers only data specific to the fault, such as signal strength, cell ID position in sudden call drop and applications loaded. The log is used only to help determine the cause of the fault. These logs are encrypted and can only be accessed by an authorized LG Repair centre should you need to return your device for repair.

Exposure to radio frequency energy

Radio wave exposure and Specific Absorption Rate (SAR) information.

This mobile phone model LG-D958 has been designed to comply with applicable safety requirements for exposure to radio waves. These requirements are based on scientific guidelines that include safety margins designed to assure the safety of all persons, regardless of age and health.

- The radio wave exposure guidelines employ a unit of measurement known as the Specific Absorption Rate (SAR). Tests for SAR are conducted using standardised methods with the phone transmitting at its highest certified power level in all used frequency bands.
- While there may be differences between the SAR levels of various LG phone models, they are all designed to meet the relevant guidelines for exposure to radio waves.
- The SAR limit recommended by the International Commission on Non-Ionizing Radiation Protection (ICNIRP) is 2 W/kg averaged over 10g of tissue.
- The highest SAR value for this model phone tested for use at the ear is 0.381 W/kg (10 g) and when worn on the body is 0.405 W/Kg (10 g).
- This device meets RF exposure guidelines when used either in the normal use position against the ear or when positioned at least 1.5 cm away from the body. When a carry case, belt clip or holder is used for body-worn operation, it should not contain metal and should position the product at least 1.5 cm away from your body. In order to transmit data files or messages, this device requires a quality connection

to the network. In some cases, transmission of data files or messages may be delayed until such a connection is available. Ensure the above separation distance instructions are followed until the transmission is completed.

Product care and maintenance

⚠ WARNING

Only use batteries, chargers and accessories approved for use with this particular phone model. The use of any other types may invalidate any approval or warranty applying to the phone and may be dangerous.

- The flexibility of this product is limited to withstand ordinary and normal use. This phone may be bent flat up to 180 degrees for a limited period of time but should not be bent inward. Damages caused by misuse, including but not limited to intentionally bending or continually exerting force on the product, may lead to permanent damage to the display and/or other parts and functions of the phone.
- Do not disassemble this unit. Take it to a qualified service technician when repair work is required.
- Repairs under warranty, at LG's discretion, may include replacement parts or boards that are either new or reconditioned, provided that they have functionality equal to that of the parts being replaced.
- Keep away from electrical appliances such as TVs, radios and personal computers.
- The unit should be kept away from heat sources such as radiators or cookers.
- Do not drop.
- Do not subject this unit to mechanical vibration or shock.
- Switch off the phone in any area where you are required to by special regulations. For example, do not use your phone in hospitals as it may affect sensitive medical equipment.
- Do not handle the phone with wet hands while it is being charged. It may cause an electric shock and can seriously damage your phone.

- Do not charge a handset near flammable material as the handset can become hot and create a fire hazard.
- Use a dry cloth to clean the exterior of the unit (do not use solvents such as benzene, thinner or alcohol).
- Do not charge the phone when it is on soft furnishings.
- The phone should be charged in a well ventilated area.
- Do not subject this unit to excessive smoke or dust.
- Do not keep the phone next to credit cards or transport tickets; it can affect the information on the magnetic strips.
- Do not tap the screen with a sharp object as it may damage the phone.
- Do not expose the phone to liquid or moisture.
- Use accessories like earphones cautiously. Do not touch the antenna unnecessarily.
- Do not use, touch or attempt to remove or fix broken, chipped or cracked glass. Damage to the glass display due to abuse or misuse is not covered under the warranty.
- Your phone is an electronic device that generates heat during normal operation. Extremely prolonged, direct skin contact in the absence of adequate ventilation may result in discomfort or minor burns. Therefore, use care when handling your phone during or immediately after operation.
- If your phone gets wet, immediately unplug it to dry off completely. Do not attempt to accelerate the drying process with an external heating source, such as an oven, microwave or hair dryer.
- The liquid in your wet phone, changes the colour of the product label inside your phone. Damage to your device as a result of exposure to liquid is not covered under your warranty.

Efficient phone operation

Electronics devices

All mobile phones may receive interference, which could affect performance.

- Do not use your mobile phone near medical equipment without requesting

permission. Avoid placing the phone over pacemakers, for example, in your breast pocket.

- Some hearing aids might be disturbed by mobile phones.
- Minor interference may affect TVs, radios, PCs etc.
- Use your phone in temperatures between 0ºC and 40ºC, if possible. Exposing your phone to extremely low or high temperatures may result in damage, malfunction, or even explosion.

Road safety

Check the laws and regulations on the use of mobile phones in the area when you drive.

- Do not use a hand-held phone while driving.
- Give full attention to driving.
- Pull off the road and park before making or answering a call if driving conditions so require.
- RF energy may affect some electronic systems in your vehicle such as car stereos and safety equipment.
- When your vehicle is equipped with an air bag, do not obstruct with installed or portable wireless equipment. It can cause the air bag to fail or cause serious injury due to improper performance.
- If you are listening to music whilst out and about, please ensure that the volume is at a reasonable level so that you are aware of your surroundings. This is of particular importance when near roads.

Avoid damage to your hearing

To prevent possible hearing damage, do not listen at high volume levels for long periods.

Damage to your hearing can occur if you are exposed to loud sound for long periods of time. We therefore recommend that you do not turn on or off the handset close to your ear. We also recommend that music and call volumes are set to a reasonable level.

- When using headphones, turn the volume down if you cannot hear the people speaking near you, or if the person sitting next to you can hear what you are listening to.

NOTE: Excessive sound pressure from earphones and headphones can cause hearing loss

Glass Parts

Some parts of your mobile device are made of glass. This glass could break if your mobile device is dropped on a hard surface or receives a substantial impact. If the glass breaks, do not touch or attempt to remove it. Stop using your mobile device until the glass is replaced by an authorised service provider.

Blasting area

Do not use the phone where blasting is in progress. Observe restrictions and follow any regulations or rules.

Potentially explosive atmospheres

- Do not use your phone at a refueling point.
- Do not use near fuel or chemicals.
- Do not transport or store flammable gas, liquid or explosives in the same compartment of your vehicle as your mobile phone or accessories.

Guidelines for safe and efficient use

In aircraft

Wireless devices can cause interference in aircraft.

- Turn your mobile phone off before boarding any aircraft.
- Do not use it on the ground without permission from the crew.

Children

Keep the phone in a safe place out of the reach of small children. It includes small parts which may cause a choking hazard if detached.

Emergency calls

Emergency calls may not be available on all mobile networks. Therefore you should never depend solely on your phone for emergency calls. Check with your local service provider.

Battery information and care

- You do not need to completely discharge the battery before recharging. Unlike other battery systems, there is no memory effect that could compromise the battery's performance.
- Use only LG batteries and chargers. LG chargers are designed to maximise the battery life.
- Do not disassemble or short-circuit the battery.
- Replace the battery when it no longer provides acceptable performance. The battery pack may be recharged hundreds of times before it needs replacing.
- Recharge the battery if it has not been used for a long time to maximise usability.
- Do not expose the battery charger to direct sunlight or use it in high humidity, such as in the bathroom.

- Dispose of used batteries according to the manufacturer's instructions. Please recycle when possible. Do not dispose as household waste.
- If you need to replace the battery, take it to the nearest authorised LG Electronics service point or dealer for assistance.
- Always unplug the charger from the wall socket after the phone is fully charged to save unnecessary power consumption of the charger.
- Actual battery life will depend on network configuration, product settings, usage patterns, battery and environmental conditions.
- Make sure that no sharp-edged items such as animal's teeth or nails, come into contact with the battery. This could cause a fire.
- For your safety, do not remove the battery incorporated in the product.
- Do not leave the phone in hot or cold places, as this may deteriorate phone performance.
- Do not replace the battery by yourself. The battery can be damaged, which can cause overheat and injury. The battery must be replaced by the authorized service provider. The battery should be recycled or disposed separately from household waste.

DECLARATION OF CONFORMITY

Hereby, **LG Electronics** declares that this **LG-D958** product is in compliance with the essential requirements and other relevant provisions of Directive **1999/5/EC**. A copy of the Declaration of Conformity can be found at **http://www.lg.com/global/declaration**

Notice: Open Source Software

To obtain the corresponding source code under GPL, LGPL, MPL and other open source licences, please visit http://opensource.lge.com/

All referred licence terms, disclaimers and notices are available for download with the source code.

Important notice

Please read this before you start using your phone!

Please check to see whether any problems you encountered with your phone are described in this section before taking the phone in for service or calling a service representative.

1. Phone memory

When there is less than 10% of space available in your phone memory, your phone cannot receive new messages. You need to check your phone memory and delete some data, such as applications or messages, to make more memory available.

To uninstall applications:

1 Tap > > **Apps** tab > **Settings** > **General** tab > **Apps**.
2 Once all applications appear, scroll to and select the application you want to uninstall.
3 Tap **Uninstall**.

2. Optimizing battery life

Extend your battery's power by turning off features that you don't have to run constantly in the background. You can monitor how applications and system resources consume battery power.

Extending your phone's battery life:

- Turn off radio communications when you are not using. If you are not using Wi-Fi, Bluetooth or GPS, turn them off.
- Reduce screen brightness and set a shorter screen timeout.
- Turn off automatic syncing for Gmail, Calendar, Contacts and other applications.
- Some applications you have downloaded may reduce battery power.
- While using downloaded applications, check the battery charge level.

NOTE: If you accidently press the Power/Lock Key while the device is in your pocket, the screen will turn off automatically in order to save battery power.

To check the battery power level:

- Tap > > **Apps** tab > **Settings** > **General** tab > **About phone** > **Battery.**

The battery status (charging or discharging) and battery level (percentage charged) is displayed at the top of the screen.

To monitor and control how battery power is being used:

- Tap > > **Apps** tab > **Settings** > **General** tab > **About phone** > **Battery** > **Battery use**.

Battery usage time is displayed on the screen. It tells you how long it has been since you last connected your phone to a power source or, if currently connected, how long the phone was last running on battery power. The screen shows the applications or services using battery power, listed in order from the greatest to smallest amount used.

3. Before installing an open source application and OS

⚠ **WARNING**

If you install and use an OS other than the one provided by the manufacturer it may cause your phone to malfunction. In addition, your phone will no longer be covered by the warranty.

⚠ **WARNING**

To protect your phone and personal data, only download applications from trusted sources, such as Play Store™. If there are improperly installed applications on your phone, the phone may not work normally or a serious error may occur. You must uninstall those applications and all associated data and settings from the phone.

4. Using an unlock pattern

Set an unlock pattern to secure your phone. Tap > > **Apps** tab > **Settings** > **Display** tab > **Lock screen** > **Select screen lock** > **Pattern**. This opens a screen that will guide you through how to draw a screen unlock pattern. You have to create a Backup PIN as a safety measure in case you forget your unlock pattern.

Caution: Create a Google account before setting an unlock pattern and remember the Backup PIN you created when creating your pattern lock.

⚠ WARNING

Precautions to take when using pattern lock.

It is very important to remember the unlock pattern you set. You will not be able to access your phone if you use an incorrect pattern 5 times. You have 5 opportunities to enter your unlock pattern, PIN or password. If you have used all 5 opportunities, you can try again after 30 seconds.

When you can't recall your unlock Pattern, PIN or Password:

< If you have forgotten your pattern >

If you logged in to your Google account on the phone but failed to enter the correct pattern 5 times, tap the **Forgot pattern?** button at the bottom of the screen. You are then required to log in with your Google Account or you have to enter the Backup PIN which you entered when creating your Pattern Lock.

If you have not created a Google account on the phone or you forgot Backup PIN, you have to perform a hard reset.

< If you have forgotten your PIN or Password >

If you forget your PIN or Password, you will need to perform a hard reset.

Caution: If you perform a hard reset, all user applications and user data will be deleted.

NOTE: If you have not logged into your Google Account and have forgotten your Unlock Pattern, you will need to enter your Backup PIN.

5. Using the Hard Reset (Factory Reset)

If your phone does not restore to its original condition, use a Hard Reset (Factory Reset) to initialize it.

1 Turn the power off.
2 Press and hold the **POWER/LOCK Key** + **VOLUME Down Key** on the back of the phone.
3 Release the **POWER/LOCK Key** + **VOLUME Down Key** when the LG logo is displayed, then press and hold the **VOLUME Down Key** + **VOLUME Up Key** again.
4 Release all keys when the Factory hard reset screen is displayed.
5 Select **Yes** using **VOLUME UP/Down Key** and press the **POWER/LOCK Key** to continue or select **No** using **VOLUME Up/Down Key** and press the **POWER/LOCK Key** to cancel.
6 Select **Yes** using **VOLUME Up/Down Key** and press the **POWER/LOCK Key** once more to confirm or select **No** using **VOLUME Up/Down Key** and press the **POWER/LOCK Key** to cancel.

⚠ **WARNING**

If you perform a Hard Reset, all user applications, user data and DRM licenses will be deleted. Please remember to backup any important data before performing a Hard Reset.

6. Opening and switching applications

Multi-tasking is easy with Android, you can keep more than one application running at the same time. There is no need to quit an application before opening another one. Use and switch between several open applications. Android manages each application, stopping and starting them as needed to ensure that idle applications don't consume resources unnecessarily.

1 Touch and hold the **Home Key** . A list of recently used applications will be displayed.
2 Tap the application you want to access. This does not stop the previous app running in the background on the phone. Make sure to tap **Back Key** to exit an app after using it.

- To stop applications, tap **Task Manager** from the recent apps list, then tap **Stop** or **Stop all**.
- To remove an app from the recent apps list, swipe the app preview to the left or right. To clear all apps, tap **Clear all**.

7. Transferring music, photos and videos using Media sync (MTP)

1 Tap > > **Apps** tab > **Settings** > **General** tab > **Storage** to check out the storage media.
2 Connect the phone to your PC using the USB cable.
3 **Select USB connection method** will appear on your phone screen, Select the **Media sync (MTP)** option.
4 Open the memory folder on your PC. You can view the mass storage content on your PC and transfer the files from PC to Device memory folder or vice versa.
5 After transfering files ,slide down the status bar and tap **USB connected** and select **Charge phone** from USB connection type list.

8. Hold your phone upright

Hold your cell phone vertically, as you would a regular phone. Your phone has an internal antenna. Be careful not to scratch or damage the back of the phone, as this may affect performance.

When making/receiving calls or sending/receiving data, avoid holding the lower part of the phone where the antenna is located. Doing so may affect call quality.

9. When the screen freezes

If the screen freezes or the phone does not respond when you try to operate it:
Press and hold the **Power/Lock** key for 10 seconds to turn your phone off. If it still does not work, please contact the service center.

10. Do not connect your phone when you power on/off your PC

Make sure to disconnect your phone from the PC when powering your PC on or off as it might result in PC errors.

11. Hardware key control mode

If your phone display is damaged or broken, you can answer an incoming call, end a call, or turn off an alarm using the hardware keys.

1 Turn your phone off.
2 Press and hold the **Power/Lock Key** and the **VOLUME Down Key + VOLUME Up Key** at the same time for more than 6 seconds to enter the Hardware key control mode.
3 Press the **VOLUME UP/Down Key** to scroll to the desired option, then press the **Power/Lock Key** to confirm.

- **Answer a call:** Press the **VOLUME Down Key + VOLUME Up Key** at the same time.
- **End a call:** Press the **Power/Lock Key** during a call.
- **Stop an alarm:** When an alarm rings, press and hold the **Volume Up Key** or **Volume Down Key** to stop the alarm.

NOTE: If you use your phone with a broken display glass, your phone can break even more or you can be injured. Make sure to visit the LG authorized service center to get your phone repaired.

Getting to know your phone

Phone overview

Front Camera Lens

Proximity Sensor

Earpiece

Notification LED

Touch Screen

Back Key

- Return to the previous screen. Exit an app after using it.

Home Key

- Return to the Home screen from any screen.

Menu Key

- Check what options are available.

NOTE: Proximity sensor

When receiving and making calls, the proximity sensor automatically turns the backlight off and locks the touch screen by sensing when the phone is near your ear. This extends battery life and prevents you from unintentionally activating the touch screen during calls.

⚠WARNING

Placing a heavy object on the phone or sitting on it can damage the LCD and touch screen functions. Do not cover the LCD proximity sensor with protective film. This could cause the sensor to malfunction.

SIM Card Tray Eject Button Aperture

Microphone

QRemote Sensor

Rear Camera Lens

Flash

Volume Keys

- **On the home screen:** Controls ringer volume.
- **During a call:** Control your earpiece volume.
- **When playing a track:** Controls volume continuously.

Speaker

Microphone

Headset Jack

Charger/USB port

Power/Lock Key

- Switch your phone on/off by pressing and holding this key
- Short press to lock/unlock the screen

NFC Touch Point

WARNING

- This part encloses the battery compartment. Please do not open the back cover.
- Be careful not to damage the NFC touch point on the phone, which is part of the NFC antenna.

NOTE: The back cover of this product applies a “self-healing” technology, which self-repairs minor scratches in just a few minutes. Minor scratches are those cause by ordinary and normal use of the phone. Scratches caused by abrasive surface, misuse, including but not limited to intentional scratches, and damages caused by a fall or dropping the product, may not disappear. The “self-healing” results may vary depending on the extent of the damage as well as other conditions. Any warranty on the “self-healing” is hereby expressly excluded.

Installing the micro-USIM card

Before you start exploring your new phone, you may choose to insert the micro-USIM card.

The eject button is a small round aperture on the bottom of the tray door. To install a new micro-USIM card:

1 Insert the micro-USIM ejection tool that comes with the phone (or a thin pin) into the eject button aperture, and push gently but firmly until the tray pops out.

2 Remove the tray and place the micro-USIM card inside it, with the contacts out and the angled corner to the right. There is only one possible way to fit the card snugly into the tray.

3 Carefully reposition the tray in the slot and push it gently back into the phone.

NOTE: Make sure the gold contact area on the card is facing downwards.

Charging your phone

Charge the battery before using it for the first time. Use the charger to charge the battery. A computer can be also used to charge the device by connecting them via the USB cable.

⚠ WARNING

Use only LG-approved chargers, batteries and cables. If you use unapproved chargers, batteries or cables, it may cause battery charging delay or pop up message regarding slow charging, Or this can cause the battery to explode or damage the device, which are not covered by the warranty.

The charger connector is at the bottom of the phone. Insert the charger and plug it into an electrical outlet.

NOTE:

- The battery must be fully charged initially to improve battery lifetime.
- Do not open the back cover while your phone is charging.

Locking and unlocking the screen

If you do not use the phone for a while, the screen will be automatically turned off and locked. This helps to prevent accidental taps and saves battery power.

When you are not using the phone, press the **Power/Lock key** to lock your phone. If there are any programs running when you lock your screen, they may be still running in Lock mode. It is recommended that you exit all programs before entering Lock mode to avoid unnecessary charges (e.g. phone calls, web access and data communications).

To wake up your phone, press the **Power/Lock key**. The Lock screen will appear. Touch and slide the Lock screen in any direction to unlock your Home screen. The last screen you viewed will open.

KnockON

You can lock or unlock the screen by just double-tap.

To activate KnockON feature

1 Tap > > **Apps** tab > **Settings** > **General** tab > **Gestures**.

2 Place a checkmark on **Screen on/off**.

Double-tap the center screen quickly to unlock the screen. To lock the screen, double-tap the status bar in any screen (except on the camera viewfinder) or empty area on the Home screen.

NOTE: When turning the screen on, make sure you do not cover the proximity sensor. Doing so will turn the screen off immediately after turning it on in order to prevent abnormal turning on in your pocket or bag.

Stereo headset with microphone

With the headset connected, you can enjoy music or video with stereo sound, and easily switch from your music/video to take and end calls.

< Front >

- For an incoming call, press to receive or end a call.
- When you listen to music, press to stop playback or resume. Press twice to play the next track.

< Back >

1 Plug in the headset as shown below.

2 The applications panel displays and you can select an app to run.

NOTE: You can edit the applications to display on the panel and set not to show the applications panel. Please see **< Accessory >**.

3 If a call is coming when the headset is connected to the phone, press the ⊙ to take the call.

4 To end the call, press the ⊙ again.

Plug & Pop

Plug & Pop allows you to quickly choose apps to use when plugging in an earphone or On-the-Go device, such as a mouse or keyboard.

1 Plug in earphone or OTG (On-the-Go) device (i.e., mouse, keyboard, etc.).

2 The applications panel will display and you can select an app to run.

NOTE: You can edit the applications to display on the panel and set not to show the applications panel.

- Tap > > **Apps** tab > **Settings** > **General** tab > **Accessory** > **USB storage** or **Earphone**.

Your Home screen

Touch screen tips

Here are some tips on how to navigate on your phone.

Tap or touch – A single finger tap selects items, links, shortcuts and letters on the on-screen keyboard.

Touch and hold – Touch and hold an item on the screen by tapping it and not lifting your finger until an action occurs. For example, to open a contact's available options, touch and hold the contact in the Contacts list until the context menu opens.

Drag – Touch and hold an item for a moment and then, without lifting your finger, move your finger on the screen until you reach the target position. You can drag items on the Home screen to reposition them.

Swipe or slide – To swipe or slide, quickly move your finger across the surface of the screen, without pausing when you first tap it (so you don't drag an item instead). For example, you can slide the screen up or down to scroll through a list, or browse through the different Home screens by swiping from left to right (and vice versa).

Double-tap – Double-tap to zoom on a webpage or a map. For example, quickly double-tap a section of a webpage to adjust that section to fit the width of the screen. You can also double-tap to zoom in and out while viewing the picture.

Pinch-to-Zoom – Use your index finger and thumb in a pinching or spreading motion to zoom in or out when using the browser or Maps, or when browsing pictures.

Rotate the screen – From many applications and menus, the orientation of the screen adjusts to the device's physical orientation.

NOTE:

- To select an item, tap the center of the icon.
- Do not press too hard; the tap screen is sensitive enough to pick up a light, yet firm tap.
- Use the tip of your finger to tap the option you want. Be careful not to tap any other keys.

Your Home screen

Home screen

The Home screen is the starting point for many applications and functions, and it allows you to add items like application shortcuts, or Google widgets to give you instant access to information and applications. This is the default canvas and accessible from any menu by tapping .

Status Bar

Shows phone's status information including the time, signal strength, battery status, and notification icons.

Widget

Widgets are self-contained applications that can be accessed through the Apps screen or on the Home screen or an extended home screen. Unlike a shortcut, the Widget appears as an on-screen application.

Application Icons

Tap an icon (application, folder, etc.) to open and use it.

Location Indicator

Indicates which Home screen canvas you are viewing.

Quick Key Area

Provides one-touch access to the function in any home screen canvas.

Front Touch Keys

Extended home screen

The operating system provides multiple Home screen canvases to provide more space for adding icons, widgets, and more.

- Slide your finger left or right across the Home screen.

Customizing the Home screen

You can customize your Home screen by adding apps, widgets or changing wallpapers.

To add items on your Home screen

1 Touch and hold the empty part of the Home screen.
2 In the Add Mode menu, select the item you wish to add. You will then see this added item on the Home screen.
3 Drag it to the desired location and lift your finger.

TIP! To add an application icon to the Home screen from the Apps menu, touch and hold the application you want to add.

To remove an item from the Home screen

- **Home screen** > touch and hold the icon you want to remove > drag it to .

To add an app as a Quick key

- From the Apps menu or on the Home screen, touch and hold an application icon and drag it to the Quick key area. Up to 7 apps can be added.

To remove an app from the Quick key area

- Touch and hold the desired quick key and drag it to .

NOTE: **Apps** key cannot be removed.

To customize apps icons on the Home screen

1 Touch and hold an application icon until it is unlocked from its current position. Then drop it on the screen. The editing icon will appear in the upper right corner of the application.
2 Tap the application icon again and select the desired icon design and size.
3 Tap **OK** to save the change.

Returning to recently-used applications

1 Touch and hold . The screen displays a pop-up containing the icons of applications you used recently.
2 Tap an icon to open the application. Or tap to return to your previous screen.

Notifications panel

Notifications alert you the arrival of new messages, calendar events, and alarms, as well as to ongoing events, such as when you are on a call.
When a notification arrives, its icon appears at the top of the screen. Icons for pending notifications appear on the left, and system icons such as Wi-Fi or battery strength shown on the right.

NOTE: The available options may vary depending on the region or service provider.

Opening the notifications panel

Swipe down from the status bar to open the notifications panel.

Quick Toggle Area

Tap each quick toggle key to turn it on/off. Touch and hold the key to access the settings menu of the function. To see more toggle keys, swipe left or right. Tap to remove, add, or rearrange toggle keys.

QSlide Apps

Tap a QSlide app to open as a small window on your screen. Tap to remove, add, or rearrange QSlide apps.

Tap to clear all the notifications.

Notifications

The current notifications are listed, each with a brief description. Tap a notification to view it.

To close the notifications panel, touch and drag the tab toward the top of the screen.

Indicator icons on the Status Bar

Indicator icons appear on the status bar at the top of the screen to report missed calls, new messages, calendar events, device status and more.

Your Home screen

The icons displayed at the top of the screen provide information about the status of the device. The icons listed in the table below are some of the most common ones.

Icon	Description	Icon	Description
	No SIM card inserted		Ringer is silenced
	No network signal available		Vibrate mode is on
	Airplane mode is on		Battery fully charged
	Connected to a Wi-Fi network		Battery is charging
	Wired headset connected		Phone is connected to PC via USB cable
	Call in progress		Downloading data
	Missed call		Uploading data
	Bluetooth is on		GPS is on
	NFC is on		Receiving location data from GPS
	System warning		Data is synchronizing
	An alarm is set		New Gmail message available
	New voicemail available		New Hangouts message available

	New text or multimedia message		Choose input method
	A song is currently playing		DLNA content share
	Mobile hotspot is active		DLNA music playing

NOTE: The icons location in the status bar may differ according to the function or service.

On-screen keyboard

You can enter text using the on-screen keyboard. The on-screen keyboard appears automatically on the screen when you need to enter text. To manually display the keyboard, simply tap a text field where you want to enter text.

Using the keypad & entering text

Tap once to capitalize the next letter you type. Double-tap for all caps.

abc #!? Tap to switch to the marks and symbols keyboard.

Tap to switch to handwriting mode.

Tap to enter a space.

Tap to delete the previous character.

Entering accented letters

When you select French or Spanish as the text entry language, you can enter special French or Spanish characters (e.g. "á").

For example, to input "á", touch and hold the "a" key until the zoom-in key grows bigger and displays characters from different languages.

Then select the special character you want.

Google account setup

When you first turn on your phone, you have the opportunity to activate the network, to sign into your Google Account and select how you want to use certain Google services.

To set up your Google account:

- Sign into a Google Account from the prompted set-up screen.

  OR

- Tap > > **Apps** tab > select a Google application, such as **Gmail** > select **New** to create a new account.

If you have a Google account, tap **Existing**, enter your email address and password, then tap .

Once you have set up your Google account on your phone, your phone automatically synchronizes with your Google account on the Web.

Your contacts, Gmail messages, Calendar events and other information from these applications and services on the Web are synchronized with your phone. (This will depend on your synchronization settings.)

After signing in, you can use Gmail™ and take advantage of Google services on your phone.

Connecting to Networks and Devices

Wi-Fi

With Wi-Fi, you can use high-speed Internet access within the coverage of the wireless access point (AP). Enjoy wireless Internet using Wi-Fi, without extra charges.

Connecting to Wi-Fi networks

To use Wi-Fi on your phone, you need to access a wireless access point or 'hotspot'. Some access points are open and you can simply connect to them. Others are hidden or use security features; you must configure your phone to be able to connect to them. Turn off Wi-Fi when you're not using it to extend the life of your battery.

NOTE: If you are out of the Wi-Fi zone or have set Wi-Fi to **OFF**, additional charges may be applied by your mobile operator for mobile data use.

Turning Wi-Fi on and connecting to a Wi-Fi network

1 Tap > > **Apps** tab > **Settings** > **Networks** tab > **Wi-Fi**.
2 Set **Wi-Fi** to **ON** to turn it on and start scanning for available Wi-Fi networks.
3 Tap the Wi-Fi menu again to see a list of active and in-range Wi-Fi networks.
   - Secured networks are indicated by a lock icon.
4 Tap a network to connect to it.
   - If the network is secured, you are prompted to enter a password or other credentials. (Ask your network administrator for details)
5 The status bar displays icons that indicate Wi-Fi status.

Bluetooth

You can use Bluetooth to send data by running a corresponding application, but not from the Bluetooth menu as on most other mobile phones.

NOTE:
- LG is not responsible for the loss, interception or misuse of data sent or received via the Bluetooth wireless feature.
- Always ensure that you share and receive data with devices that are trusted and properly secured. If there are obstacles between the devices, the operating distance may be reduced.
- Some devices, especially those that are not tested or approved by Bluetooth SIG, may be incompatible with your device.

Turning on Bluetooth and pairing up your phone with a Bluetooth device

You must pair your device with another device before you connect to it.

1 Tap > > **Apps** tab > **Settings** > **Networks** tab > set **Bluetooth** to **ON**.

2 Tap the **Bluetooth** menu again. You will see the option to make your phone visible and option to search devices. Now tap **Search for devices** to view the devices in the Bluetooth Range.

3 Choose the device you want to pair with from the list.

Once the paring is successful, your device will connect to the other device.

NOTE: Some devices, especially headsets or hands-free car kits, may have a fixed Bluetooth PIN, such as 0000. If the other device has a PIN, you will be asked to enter it.

Send data using the Bluetooth wireless feature

1 Select a file or item, such as a contact, calendar event or media file, from an appropriate application or from **Downloads**.
2 Select the option for sending data via Bluetooth.

NOTE: The method for selecting an option may vary by data type.

3 Search for and pair with a Bluetooth-enabled device.

Receive data using the Bluetooth wireless feature

1 Tap > > **Apps** tab > **Settings** > **Networks** tab > set **Bluetooth** to **ON**.
2 Tap the **Bluetooth** menu again and mark the checkbox at the top of the screen to make your phone visible to other devices.

NOTE: To select the length of time that your device will be visible, tap > **Visibility timeout**.

3 Select **Accept** to confirm that you are willing to receive data from the device.

Sharing your phone's data connection

USB tethering and portable Wi-Fi hotspot are great features when there are no wireless connections available. You can share your phone's mobile data connection with a single computer via a USB cable (USB tethering). You can also share your phone's data connection with more than one device at a time by turning your phone into a portable Wi-Fi hotspot.

When your phone is sharing its data connection, an icon appears in the status bar and as an ongoing notification in the notifications drawer.

For the latest information about tethering and portable hotspots, including supported operating systems and other details, visit http://www.android.com/tether.

To share your phone's data connection as a portable Wi-Fi hotspot

1 Tap > > **Apps** tab > **Settings** > **Networks** tab > **Tethering & networks** > **Wi-Fi hotspot** switch to activate.

2 Enter a password and tap **Save**.

TIP! If your computer is running Windows 7 or a recent distribution of some flavours of Linux (such as Ubuntu), you will not usually need to prepare your computer for tethering. But, if you are running an earlier version of Windows or another operating system, you may need to prepare your computer to establish a network connection via USB. For the most current information about which operating systems support USB tethering and how to configure them, visit http://www.android.com/tether.

To rename or secure your portable hotspot

You can change the name of your phone's Wi-Fi network name (SSID) and secure its Wi-Fi network.

1 Tap > > **Apps** tab > **Settings** > **Networks** tab > **Tethering & networks** > **Wi-Fi hotspot**.

2 Tap **Set up Wi-Fi hotspot**.
- The **Set up Wi-Fi hotspot** dialogue box will open.
- You can change the **Network SSID** (name) that other devices see when scanning for Wi-Fi networks.
- You can also tap the **Security** menu to configure the network with Wi-Fi Protected Access 2 (WPA2) security using a pre-shared key (PSK).
- If you touch the **WPA2 PSK** security option, a password field is added to the **Set up Wi-Fi hotspot** dialogue box. If you enter a password, you will need to enter that password when you connect to the phone's hotspot with a computer or other device. You can set **Open** in the **Security** menu to remove security from your Wi-Fi network.

3 Tap **Save**.

ATTENTION! If you set the security option as Open, you cannot prevent unauthorised usage of online services by other people and additional charges may be incurred. To avoid unauthorized usage, you are advised to keep the security option active.

Wi-Fi Direct

Wi-Fi Direct supports a direct connection between Wi-Fi enabled devices without an access point. Due to the high battery usage of Wi-Fi direct, it is recommended that you plug your phone into a power outlet while using the Wi-Fi Direct feature. Check your Wi-Fi & Wi-Fi Directed network in advance and make sure the users are connected to the same network.

To turn on Wi-Fi Direct:

1 In Home screen, tap the **Menu Key** > **System settings** > **Wi-Fi.**
2 Tap **Wi-Fi Direct** at the bottom of the screen.
3 Select a device to connect with from the scanned device list.

SmartShare

You can use the SmartShare feature easily in the Gallery, Music, Video apps, etc.

Enjoying content via a variety devices

You can share your phone's contents with a variety devices. Tap to share the contents in the Gallery, Music, Videos, POLARIS Viewer 5.

Playing/Sending

Play: You can play the contents via a TV, a Bluetooth speaker or etc.
Beam: You can send the contents to the device of Bluetooth and SmartShare Beam supported.

- **SmartShare Beam:** Transferring the contents feature fast via Wi-Fi Direct.

< Play >

< Beam >

Enjoying the content from Nearby devices

You can enjoy the content of nearby devices (i.e. PC.NAS, Mobile) at **Gallery**, **Music**, **Videos** app.

Connecting devices

Connect your device and other devices supported by DLNA in the same Wi-Fi network.

Searching other devices

1 Tap Nearby devices, then you can see the DLNA-supported devices.
2 Connect to the device to view the content.

PC connections with a USB cable

Learn to connect your device to a PC with a USB cable in USB connection modes.

Transferring music, photos and videos using the USB mass storage mode

1 Connect your phone to a PC using a USB cable.
2 If you haven't installed the LG Android Platform Driver on your PC, you will need to manually change the settings. Choose **System settings** > **General** tab > **PC connection** > **Select USB connection method**, then select **Media sync (MTP)**.
3 You can now view the mass storage content on your PC and transfer the files.

Synchronize with Windows Media Player

Ensure that Windows Media Player is installed on your PC.

1 Use the USB cable to connect the phone to a PC on which Windows Media Player has been installed.
2 Select the **Media sync (MTP)** option. When connected, a pop-up window will appear on the PC.
3 Open Windows Media Player to synchronize music files.
4 Edit or enter your device's name in the pop-up window (if necessary).
5 Select and drag the music files you want to the sync list.
6 Start synchronization.

- The following requirements must be satisfied to synchronize with Windows Media Player.

Items	Requirement
OS	Microsoft Windows XP SP2, Vista or higher
Window Media Player version	Windows Media Player 10 or higher

- If the Windows Media Player version is lower than 10, install version 10 or higher.

Calls

Making a call

1 Tap to open the keypad.
2 Enter the number using the keypad. To delete a digit, tap the .
3 Tap to make a call.
4 To end a call, tap the **End** icon .

TIP! To enter "+" to make international calls, touch and hold 0+.

Calling your contacts

1 Tap to open your contacts.
2 Scroll through the contact list or enter the first few letters of the contact you want to call by tapping **Search contacts**.
3 In the list, tap you want to call.

Answering and rejecting a call

When you receive a call in Lock state, swipe the in any direction to Answer the incoming call.
Swipe the in any direction to Decline an incoming call.
Swipe the **Decline with message** icon from the bottom if you want to send a message.

TIP! Decline with message
You can send a message quickly using this function. This is useful if you need to reject a call with message during a meeting.

Adjusting the in-call volume

To adjust the in-call volume during a call, use the Volume up and down keys on the back side of the phone.

Making a second call

1 During your first call, tap **Menu key** > **Add call** and dial the number. You can also go to the recently dialled numbers list by tapping or can search contacts by tapping and selecting the contact you want to call.
2 Tap to make the call.
3 Both calls are displayed on the call screen. Your initial call is locked and put on hold.
4 Tap the displayed number to toggle between calls. Or tap **Merge calls** to start a conference call.
5 To end active calls, tap **End** or tap and slide the notification bar down and select the **End call** icon .

NOTE: You are charged for each call you make.

Viewing your call logs

On the Home screen, tap and choose the **Call logs** tab .
View a complete list of all dialled, received and missed calls.

TIP!
- Tap any call log entry to view the date, time and duration of the call.
- Tap the **Menu key** , then tap **Delete all** to delete all the recorded items.

Call settings

You can configure phone call settings such as call forwarding, as well as other special features offered by your carrier.

1 On the Home screen, tap .
2 Tap .
3 Tap **Call settings** and choose the options that you wish to adjust.

Contacts

Add contacts to your phone and synchronize them with the contacts in your Google account or other accounts that support contact syncing.

Searching for a contact

On the Home screen

1 Tap to open your contacts.
2 Tap **Search contacts** and enter the contact name using the keyboard.

Adding a new contact

1 Tap , enter the new contact's number, then tap the **Menu key** . Tap **Add to Contacts** > **New contact**.
2 If you want to add a picture to the new contact, tap the image area. Choose from **Take photo** or **Select from Gallery**.
3 Select the contact type by tapping .
4 Tap a category of contact information and enter the details about your contact.
5 Tap **Save**.

Favourites contacts

You can classify frequently called contacts as favourites.

Adding a contact to your favourites

1 Tap to open your contacts.
2 Tap a contact to view its details.
3 Tap the star to the right corner of the contact's name. The star will turn yellow colour.

Removing a contact from your favourites list

1 Tap to open your contacts.
2 Tap the tab, and choose a contact to view its details.
3 Tap the yellow colour star to the right corner of the contact's name. The star turns grey colour and the contact is removed from your favourites.

Creating a group

1 Tap to open your contacts.
2 Tap **Groups** and tap the **Menu key** . Select **New group**.
3 Enter a name for the new group. You can also set a ringtone for the newly created group.
4 Tap **Save** to save the group.

NOTE: If you delete a group, the contacts assigned to that group will not be lost. They will remain in your contacts.

Messaging

Your phone combines SMS and MMS into one intuitive, easy-to-use menu.

Sending a message

1 Tap on the Home screen and tap to open a blank message.
2 Enter a contact name or contact number in the **To** field. As you enter the contact name, matching contacts will appear. You can tap a suggested recipient. You can add more than one contact.

NOTE: You will be charged for a text message for every person to whom you send the message.

3 Tap the **Enter message** field and begin composing your message.
4 Tap to open the Options menu. Choose from **Quick message**, **Insert smiley**, **Schedule sending**, **Add subject** and **Discard**.

TIP! You can tap the icon to attach the file, that you want to share with message.

5 Tap **Send** to send your message.
6 Responses will appear on the screen. As you view and send additional messages, a message thread is created.

WARNING:

- The 160-character limit may vary from country to country, depending on the language and how the SMS is coded.
- If an image, video or audio file is added to an SMS message, it is automatically converted into an MMS message and you are charged accordingly.

Threaded box

Messages (SMS, MMS) exchanged with another party can be displayed in chronological order so that you can conveniently see an overview of your conversation.

Changing your message settings

Your phone message settings are pre-defined, so you can send messages immediately. You can change the settings according to your preferences.

- Tap the **Messaging** icon on the Home screen, tap ☰ and then tap **Settings**.

Email

You can use the Email application to read emails from services like Gmail. The Email application supports the following account types: POP3, IMAP and Exchange.

Your service provider or system administrator can provide you with the account settings you need.

Managing an email account

The first time you open the **Email** application, a set-up wizard opens to help you to set up an email account.

After the initial set-up, Email displays the contents of your inbox.

To add another email account:

- Tap > > **Apps** tab > **Email** > tap > **Settings** > **Add account**.

To change an email account's settings:

- Tap > > **Apps** tab > **Email** > tap > **Settings** > **General settings**.

To delete an email account:

- Tap > > **Apps** tab > **Email** > tap > **Settings** > tap > **Remove account** > Select the account to delete > **Remove** > select **Yes**.

Working with account folders

Tap > > **Apps** tab > **Email** > tap and select **Folders**.

Each account has an Inbox, Outbox, Sent and Drafts folder. Depending on the features supported by your account's service provider, you may have additional folders.

Composing and sending email

To compose and send a message

1 While in the **Email** application, tap the .
2 Enter an address for the message's intended recipient. As you enter text, matching addresses will be proposed from your Contacts. Separate multiple addresses using semicolons.
3 Tap the to add a Cc/Bcc and tap to attach files, if required.
4 Enter the text of the message.
5 Tap .

TIP! When a new email arrives in your Inbox, you will be notified by a sound or vibration.

Camera

The Multi Point AF (Autofocus) feature enables you to get a clearer and natural picture even if the objects are not in the center.

To open the Camera application, tap **Camera** on the Home screen.

Getting to know the viewfinder

1. **Flash** – Choose from **Off**, **On**, **Auto**.
2. **Swap camera** – Switch between the rear camera lens and the front camera lens.
3. **Shot mode** – Choose from **Normal, Shot & Clear**, **Dynamic tone (HDR)**, **Panorama**, **VR panorama**, **Burst shot**, **Beauty shot**, **Dual camera**, **Time catch shot**, **Intelligent auto**, **Sports** or **Night**.
4. **Settings** – Tap this icon to open the settings menu.
5. **Video mode** – Tap and slide down this icon to switch to video mode.
6. **Capture button**
7. **Gallery** – Tap to view the last photo you captured. This enables you to access your gallery and view saved photos while in camera mode.

NOTE: Please ensure the camera lens is clean before taking pictures.

Using the advanced settings

In the viewfinder, tap ⚙ to open the advanced options. You can change the camera settings by scrolling through the list. After selecting the option, tap ↩.

	To take a photo, say one of the following words: Cheese, Smile, Whiskey, Kimchi or LG.
	Defines and controls the amount of sunlight entering the photo.
	Tap to select the focus mode.
W10M	Selects photo resolution. If you choose high resolution, file size will increase, which means you will be able to store fewer photos in the memory.
AUTO	The ISO rating determines the sensitivity of the camera's light sensor. The higher the ISO, the more sensitive the camera. This is useful in darker conditions when you cannot use the flash.
AWB	Improves colour quality in various lighting conditions.
	Applies artistic effects to your pictures.
	Sets a delay after the capture button is pressed. This is ideal if you want to be in the photo.
	Activate this to use your phone's location-based services. Take pictures wherever you are and tag them with the location. If you upload tagged pictures to a blog that supports Geotagging, you can see the pictures displayed on a map. **NOTE:** This function is only available when the GPS function is active.
	Selects a shutter sound.
	Set the Volume Key whether to use for the capture or zoom.

	Opens the help guide to know how a function operates.
	Restores all camera default settings.

TIP!

- When you exit the camera, some settings return to their defaults, such as brightness, focus, iso, white balance, colour effect, timer and shot mode. Check these before you take your next photo.
- The setting menu is superimposed over the viewfinder, so when you change photo colour or quality elements, you will see a preview of the changed image behind the Settings menu.

Taking a quick photo

1 Open the **Camera** application and point the lens toward the subject your want to photograph.
2 Focus boxes will appear in the center of the viewfinder screen. You can also tap anywhere on the screen to focus on that spot.
3 When the focus box turns green, the camera has focused on your subject.
4 Tap to capture the photo.

Using Shot & Clear mode

This feature allows the camera to identify objects you may not want in your photo. After taking the photo, tap an outlined object* to remove it, then save the photo.

1 Open the **Camera** application.
2 Tap MODE > **Shot & Clear**.
3 Tap to take a picture.

4 Tap any of the outlined objects to remove them from the photo, then tap .

* When taking a picture, moving objects are shown as dashed lines.

NOTES

- Take a picture after fixing the camera in one place.
- If the colour of a subject is similar to the background, only a part may be detected or it may be difficult to erase.
- If a moving subject is too small or too large, it may be difficult to erase.
- If the subject is moving insignificantly, it may not be detected.

Using Dual camera mode

Allows you to take a picture with the front and rear cameras at the same time, combined into one picture.

1 Open the **Camera** application.

2 Tap MODE > **Dual camera**.

3 A small viewfinder box appears on the main viewfinder screen. Set up your shot.

- Drag the small viewfinder to move it where you want it in the shot.
- Touch and hold the small viewfinder to resize it, if necessary.
- Tap the small viewfinder to swap the lens between the main viewfinder and the small viewfinder.

4 Tap to take the combined picture.

Using Time catch shot mode

Sets the camera to capture missing moments by taking five sequential pictures before is tapped.

1 Open the **Camera** application.

2 Tap MODE > **Time catch shot**.

3 Tap to take a picture.
4 To view the moments just before the picture was taken, tap the image thumbnail at the bottom of the Camera screen.
5 Select the pictures that you want to keep, then tap at the top of the screen.

Once you've taken a photo

Tap the image thumbnail at the bottom of the Camera screen to view the last photo you took.

	Tap to share your photo using the **SmartShare** function.
	Tap to take another photo immediately.
	Tap to send your photo to others or share it via social network services.
	Tap to delete the photo.

TIP! If you have an SNS account set up on your phone, you can share your photo with your SNS community.

NOTE: Additional charges may apply when MMS messages are downloaded while roaming.

Tap the Menu key to open all advanced options.
Set image as – Tap to use the photo as a **Contact photo, Home screen wallpaper** or **Lock screen wallpaper.**
Move – Tap to move the photo to another place.
Copy – Tap to copy the selected photo and save it to another album.
Copy to Clip Tray – Tap to copy the photo and store in the Clip Tray.
Rename – Tap to edit the name of the selected photo.

Rotate left/right – To rotate left or right.

Crop – Crop your photo. Move your finger across the screen to select the area to be cropped.

Edit – View and edit the photo.

Slideshow – Automatically shows you the images in the current folder one after the other.

Add location – To add the location information.

Details – Find out more information about the file.

From your Gallery

Tap **Gallery** and select **Camera**.

- To view more photos, scroll left or right.
- To zoom in or out, double-tap the screen or place two fingers and spread them apart (move your fingers closer together to zoom out).

Video camera

Getting to know the viewfinder

1. **Flash** – Choose from **Off**, **On**, **Auto**.
2. **Swap camera** – Switch between the rear camera lens and the front camera lens.
3. **Recording mode** – Choose from **Normal**, **Live effect**, **Dual recording**, or **Tracking zoom**.
4. **Settings** – Tap this icon to open the settings menu.
5. **Camera mode** – Tap and slide up this icon to switch to camera mode.
6. **Start recording**
7. **Gallery** – Tap to view the last video you recorded. This enables you to access your gallery and view your saved videos while in video mode.

TIP!
When recording a video, place two fingers on the screen and pinch to use the Zoom function.

Using the advanced settings

Using the viewfinder, tap ⚙ to open all the advanced options.

Audio zoom	Tap to turn on Audio zoom feature. You can record only the sound you want clearly and loudly. After turning this on, focus the subject you want to zoom, on inside the blue circle. To zoom in on sounds as well as sight, pinch in. **NOTES** • Only available in landscape view. • Do not cover the microphones on both sides.
FHD	Tap to set the size (in pixels) of the video you are recording. **NOTES** • When UHD is set, video recording is limited for 5 minutes. • Object tracking is disabled in UHD, QVGA, QCIF. • Image capture button is disabled in UHD, FHD(60fps), QVGA, QCIF.
	Defines and controls of the amount of sunlight entering the lens. Slide the brightness indicator along the bar towards “-” for a lower brightness video or towards “+” for a higher brightness video.
	Tap to turn on Anti-shaking feature. It prevents shaking while video recording to get high video quality.
AWB	Improves colour quality in various lighting conditions.
	Choose a colour tone to use for your new view.
	Activate this to use your phone's location-based services.
	Set the Volume Key whether to use for the record or zoom.
	Opens the help guide to know how a function operates.
	Restores all camera default settings.

Recording a quick video

1 Open the **Camera** application and slide the **Video mode** button.
2 The video camera viewfinder appears on the screen.
3 Holding the phone, point the lens towards the subject you wish to capture in your video.
4 Tap once to start recording.
5 A red light will appear at the top left corner of the viewfinder with a timer showing the length of the video.
6 Tap on the screen to stop recording.

TIP!
– Tap to capture image during recording a video.
– Tap to pause during recording a video.

After recording a video

In the viewfinder, tap the video thumbnail at the bottom of the screen to view the last video you took.

	Tap to share your video using the **SmartShare** function.
	Tap to record another video immediately.
	Tap to send your video to others or share it via social network services.
	Tap to delete the video.

NOTE: Additional charges may apply when MMS messages are downloaded while roaming.

Video camera

From your Gallery

Tap **Gallery** and select **Camera**. Tap on video play icon to play the video.

Adjusting the volume when viewing a video

To adjust the volume of a video while it is playing, use the volume keys on the back side of the phone.

Using Audio Zoom

Focuses the audio recording on a particular area of your choice this will increase microphone sensitivity and reduce background noise.

1 Open the **Camera** application and change to video mode
2 Tap > **Audio zoom** and select **On**.
3 Tap an empty space on viewfinder to close the Setting pop-up window.
4 Hold the phone horizontally and tap to start recording.
5 Focus the subject you want to zoom in on inside the blue circle. Then, pinch to zoom in to increase sound sensitivity and decrease noise.
6 Tap to stop recording.

NOTES

- Do not cover the side microphones while using this feature.
- You must record in landscape orientation to use this function.

Using Dual recording mode

Allows you to record videos with the front and rear cameras at the same time, combined into one recording.

1 Open the **Camera** application and change to video mode

2 Tap MODE > **Dual recording**.

3 A small viewfinder box appears on the main viewfinder screen. Set up your shot.

- Drag the small viewfinder to move it where you want it in the shot.
- Touch and hold the small viewfinder to resize it, if necessary.
- Tap the small viewfinder to swap the lens between the main viewfinder and the small viewfinder.

4 Tap to start dual recording.

5 Tap to stop dual recording.

Using Tracking zoom mode

Allows you to define an area of the recording to focus on and enlarge. You can set the area before recording, then move it as necessary during the recording.

1 Open the **Camera** application and change to video mode

2 Tap MODE > **Tracking zoom**.

3 Drag the magnifying glass to the area to enlarge. The small screen shows the defined focus in large view.

4 Tap to start recording.

- While recording, you can move the small screen. Touch and drag it to the desired location.

5 Tap to stop recording.

QuickMemo

The **QuickMemo** allows you to create memos and capture screen shots.Capture screens, draw on them and share them with family and friends with QuickMemo.

OR

1 (While screen is switched off) Press and hold the Volume Up key.

OR

Touch and slide the status bar downward and tap .

2 Select the desired menu option from **Pen type**, **Colour**, **Eraser** and create a memo.

3 Tap in the Edit menu to save the memo with the current screen. To exit QuickMemo at any time, tap .

NOTE: Please use a fingertip while using the QuickMemo. Do not use your fingernail.

Using the QuickMemo options

You can easily use the QuickMenu options when using the QuickMemo.

	Tap to keep the current QuickMemo as a text overlay on the screen and continue to use the phone.
	Selects whether to use the background screen or not.
	Undo or Redo.
	Selects the pen type and the colour.
	Erases the memo that you created.
	Tap to share the memo with others via any of the available applications.
	Saves the memo with the current screen in the **Gallery** or **Notebook**.

Viewing the saved QuickMemo

Tap **Notebook/Gallery** and select the QuickMemo album.

QuickTranslator

Simply aim the camera of your smart phone at the foreign sentence you want to understand. You can get the real-time translation anywhere and anytime.
You can buy additional dictionaries for offline translation from the Google Play Store.

❶ Home language.
❷ Destination language.
❸ Translation of word.
❹ Translation of sentence.
❺ Translation of block.
❻ Settings.

1 Tap > > **Apps** tab > **QuickTranslator**.
2 Tap **Word**, **Line** or **Block**.
3 Tap and select the desired language.
4 Hold the phone toward the subject you want to translate for a few seconds.

NOTE: Only one dictionary is provided free of charge. Additional dictionaries must be purchased. Please select from the list below the dictionary you would like to install as your complimentary dictionary.

NOTE: There may be a difference in the rate of recognization depending on the size, font, colour, brightness and angle of the letters that need to be translated.

QSlide

From any screen, bring up a notepad, calendar, and more as a window inside your screen.

1		Tap to exit the QSlide and return to full window.
2		Tap to adjust transparency.
3		Tap to end the QSlide.
4		Tap to adjust the size.

1 Touch and slide the status bar downwards > tap QSlide apps or while using applications that support QSlide, tap . The function will be continuously displayed as a small window on your screen.

2 You can make a call, browse the Web, or choose other phone options. You can also use and tap the screen under the small windows when the transparency bar is not full .

NOTE: The QSlide can support up to two windows at the same time.

QTheater

QTheater allows you to see the slideshow for Photos, Videos, and YouTube.

1 From the lock screen, hold the phone horizontally.
2 Pull the screen with the thumb of both hands.
3 You can see the slideshow for desired functions.

NOTE: The screen lock mode should be set as Swipe before you use QTheater function.

1 Tap > **Apps tab** > **Settings** > **Display** tab > **Lock screen** > **Select screen lock**.
2 Select **Swipe**.

QuickRemote

QuickRemote turns your phone into a Universal Remote for your home TV, Set top box, audio system, DVD/Blu-ray players, air conditioner and projector.

1 Touch and slide the status bar downwards and tap > **ADD REMOTE**.

OR

Tap > > **Apps** tab > **QuickRemote** > tap .

2 Select the type and brand of device, then follow the on-screen instructions to configure the device(s).

3 Touch and slide the status bar downwards and use QuickRemote functions.

Tap the **Menu key** to select **Magic Remote setting, Edit remote name, Learn remote, Move remote, Delete remote, Edit room, Settings** and **Help.**

NOTE: The QuickRemote operates the same way as an ordinary remote control infrared (IR) signals. Be careful not to cover the infrared sensor on the back of the phone when you use the QuickRemote function. This function may not be supported depending on the model, the manufacturer or service company.

Zoom to Track

When you play a video, you can enlarge an object while tracking it.

1 When you play a video, tap .

2 Touch the magnifying glass and drag it to the object to track.

NOTE:

- While a video is playing, slide the left side of the screen up or down to adjust the screen brightness.
- While playing a video, slide the screen left or right to rewind or fast-forward.
- Do not press too hard; the touch screen is sensitive enough to pick up a light, but firm tap.
- Zoom to Track may not be available if the object moves too fast or off from the screen.

VuTalk

With the VuTalk feature, you can make an interactive and more creative notes with the other party. Visual communication is possible while sharing a photo, a map or camera preview.

NOTE:
- Only available with a phone that supports this feature as well.
- You can also use the VuTalk feature during a call.
- The screen will lock if there is no input.
- Requires data connection. Data charge will apply to both phones.

Register VuTalk Before Use

1 Tap > **Contacts** > .
You can also register VuTalk service while you are in a call.
2 Read the LG apps terms and conditions and privacy policy. If you agree, tap the check boxes, then tap **Accept**.

VuTalk Settings

1 Tap > **Contacts** > > **VuTalk settings** .
2 Set the following options as your preferences.
- **Notification sound:** Select the desired notification sound.
- **Vibrate:** Select the desired vibrate type.
- **Show request:** Checkmark this option to display a pop-up when a VuTalk request is received.
- **Contact sync:** Checkmark this option to sync contacts.

Communicate Visually with VuTalk

1 Tap > **Contacts** > .
Only the contacts who use the VuTalk feature will be displayed.
2 Tap a contact to start VuTalk with.
3 In the contact's details screen, tap . After the other party accepts your VuTalk request, you can start VuTalk with him/her.
4 Use the VuTalk screen to chat and visually communicate with your friend.
- Tap to attach a photo, take a new photo, map view, or a sticker.
- Tap the Pen icon and Eraser icon to write on the images you attached.

5 When you finish VuTalk, tap or to exit the VuTalk feature.
The created VuTalk screen is stored in the **Notebook** app.

NOTE: If you tap and go back to the Home screen, the VuTalk feature still runs in the background.

LG SmartWorld

LG SmartWorld offers an assortment of exciting content - games, applications, wallpaper and ringtones - giving LG phone users the chance to enjoy richer "Mobile Life" experiences.

How to Get to LG SmartWorld from Your Phone

1 Tap > > **Apps** tab > tap the icon to access **LG SmartWorld**.
2 Tap Sign in and enter ID/PW for LG SmartWorld. If you have not signed up yet, tap Register to receive your LG SmartWorld membership.
3 Download the content you want.

NOTE: What if there is no icon?

1 Using a mobile Web browser, access LG SmartWorld (www.lgworld.com) and select your country.
2 Download the LG SmartWorld App.
3 Run and install the downloaded file.
4 Access LG SmartWorld by tapping the icon.

How to use LG SmartWorld

- Participate in monthly LG SmartWorld promotions.

	Search content.
	Find content by category (e.g. Games, Education, Entertainment etc).

- Try the easy "Menu" buttons to find what you're looking for fast.
  Settings – Set Profile and Display.
  Sign in – Set your ID and Password.
- Try other useful functions as well. (Content Detail screen)

NOTE: LG SmartWorld may not be available from all carriers or in all countries.

On-Screen Phone

On-Screen Phone allows you to view your mobile phone screen from a PC via a USB or Wi-Fi connection. You can also control your mobile phone from your PC, using the mouse or keyboard.

On-Screen Phone icons

	Connects your mobile phone to your PC, or disconnects it.
	Changes the On-Screen Phone preferences.
	Exits the On-Screen Phone programme.
	Maximises the On-Screen Phone window.
	Minimize the On-Screen Phone window.

On-Screen Phone features

- Real-time transfer and control: displays and controls your mobile phone screen when connected to your PC.
- Mouse control: allows you to control your mobile phone by using the mouse to click and drag on your PC screen.
- Text input with keyboard: allows you to compose a text message or note using your computer keyboard.
- File transfer (mobile phone to PC): sends files from your mobile phone (e.g. photos, videos, music and POLARIS Viewer 5 files) to your PC. Simply right-click on the file which you want to send to PC and click on "Save to PC".
- File transfer (PC to mobile phone): sends files from your PC to your mobile phone. Just select the files you wish to transfer and drag and drop them into the On-Screen Phone window. The files sent are stored in internal SD card.

- Real-time event notifications: prompts a pop-up to inform you of any incoming calls or text/multimedia messages.

How to install On-Screen Phone on your PC

1 Visit LG Home (www.lg.com) and select a country of your choice.

2 Go to **SUPPORT** > **Mobile Support** > Select the Model (LG-D958) > Click **OSP** (On-Screen Phone) to download. You can install the On-Screen Phone on your PC.

Multimedia

Gallery

Open the **Gallery** application to view albums of your pictures and videos.

1 Tap > > **Apps** tab > **Gallery**.
You can manage and share all your image and video files with Gallery.

NOTE:
- Some file formats are not supported, depending on the software installed on the device.
- Some files may not play properly, depending on how they are encoded.

Viewing pictures

Launching Gallery displays your available folders. When another application, such as Email, saves a picture, the download folder is automatically created to contain the picture. Likewise, capturing a screenshot automatically creates the Screenshots folder. Select a folder to open it.

Pictures are displayed by creation date in a folder. Select a picture to view it full screen. Scroll left or right to view the next or previous image.

Zooming in and out

Use one of the following methods to zoom in on an image:
- Double-tap anywhere to zoom in.
- Spread two fingers apart on any place to zoom in. Pinch to zoom out, or double-tap to return.

Playing videos

Video files show the icon in the preview. Select a video to watch it and tap . The Videos application will launch.

Editing photos

When viewing an photo, tap the **Menu key** > **Edit.**

Deleting photos/videos

Use one of the following methods:

- In a folder, tap and select photos/videos by ticking, and then tap on **Delete**.
- When viewing a photo/Video, tap .

Setting as wallpaper

When viewing a photo, tap the **Menu key** > **Set image as** to set the image as wallpaper or assign to a contact.

NOTE:

- Some file formats are not supported, depending on the device software.
- If the file size exceeds the available memory, an error can occur when you open files.
- The resolution is automatically resized from Ultra-HD to Full-HD when the handset is connected to TV via Slimport (or Miracast).

Videos

Your phone has a built-in video player that lets you play all of your favorite videos. To access the video player, tap > > **Apps** tab > **Videos**.

Playing a video

1 Tap > > **Apps** tab > **Videos**.

2 Select the video you want to play.

	Tap the desired direction for audio zoom.
	Tap to use Zoom to Track feature.
	Tap to enter into Qslide mode.
	Tap to share your video via the SmartShare function.
	Tap to lock a video screen.
	Tap to view the video list.
	Tap to capture the screen shot.
	Tap to pause video playback.
	Tap to resume video playback.
	Tap to go 10 seconds forward.
	Tap to go 10 seconds backward.
	Tap to manage the video volume.
	Tap to change the ratio of the video screen.

To change the volume while watching a video, press the up and down volume keys on the rear side of the phone.

Touch and hold a video in the list. The **Share**, **Delete**, **Trim** and **Details** options will be displayed.

NOTE: UHD(Ultra-HD) video does not support **Trim** option when it plays at **Gallery** and **Videos** app.

Music

Your phone has a built-in music player that lets you play all your favorite tracks. To access the music player, tap > > **Apps** tab > **Music**.

Add music files to your phone

Start by transferring music files to your phone:

- Transfer music using Media sync (MTP).
- Download from the wireless Web.
- Synchronize your phone to a computer.
- Receive files via Bluetooth.

Transfer music using Media sync (MTP)

1 Connect the phone to your PC using the USB cable.

2 Select the **Media sync (MTP)** option. Your phone will appear as another hard drive on your computer. Click on the drive to view it. Copy the files from your PC to the drive folder.

3 When you're finished transferring files, swipe down on the Status Bar and tap **USB connected** > **Charge phone**. You may now safely unplug your device.

Playing a song

1 Tap > > **Apps** tab > **Music**.

2 Tap **Songs**.

3 Select the song you want to play.

	Tap to pause playback.
	Tap to resume playback.
	Tap to skip to the next track in the album, playlist, or shuffle. Touch and hold to fast forward.
	Tap to restart the current track or skip to the previous track in the album, playlist, or shuffle. Touch and hold to rewind.
	Tap to display the Volume slider bar, then adjust the playback volume on the slider bar.
	Tap to set audio effects.
	Tap to find the files with YouTube.
	Tap to open the current playlist.
	Tap to add the song to your favourites.
	Tap to play the current playlist in shuffle mode (tracks are played in random order).
	Tap to toggle through the repeat modes to repeat all songs, repeat current song, or repeat off.
	Tap to share your music via the SmartShare funtion.

To change the volume while listening to music, press the up and down volume keys on the back side of the phone.

Touch and hold any song in the list. The **Play**, **Add to playlist**, **Share**, **Set as ringtone**, **Delete**, **Details** and **Search** options will be displayed.

NOTE:

- Some file formats are not supported, depending on the device software.
- If the file size exceeds the available memory, an error can occur when you open files.

NOTE: Music file copyrights may be protected by international treaties and national copyright laws.

Therefore, it may be necessary to obtain permission or a licence to reproduce or copy music.

In some countries, national laws prohibit private copying of copyrighted material. Before downloading or copying the file, check the national laws of the relevant country concerning the use of such material.

Slide Aside (Quick task-switching with THREE fingers)

You can quickly switch to another task using three fingers.

1 Place three fingers on the screen which you are currently working on and slide the screen to the left. The current screen is saved and you can do another task.

- You can save up 3 (three) apps in the left side of the screen.

2 To reopen the saved screen and continue to use the app, place three fingers on a screen and slide it to the right.

NOTE: Please be careful not to place another fingers or palm on the screen.

Dual Window

The two split-screen can be viewed at the same time.

1 Touch and hold the Back button to split the screen.

2 Tap or drag app icon you want to use.

(Switch icon) : Switch two screens.

(Drag icon) : Drag to resize split screens.

(Menu icon) : Tap to view the app list, change to the full screen or close the current app.

NOTE: The Dual Window should be set before you use the function.

1 Tap > **Apps** tab > **Settings** > **General** tab > **Multitasking** > **Dual Window**.

2 Checkmark the **Dual Window** checkbox.

Guest Mode

To protect your privacy or limit some applications to your children, you can use the Guest mode.

When you lend your phone to others, you can limit the applications to be displayed. In advance, set the Guest mode and customize the options.

NOTE: To use the Guest mode, the pattern lock should be set in advance.

1 Tap > > **Apps** tab > **Settings** > **General** tab > **Guest mode**.

2 Tap to make Guest mode on.

Setting your alarm

1 Tap > > **Apps** tab > **Alarm/Clock** > .

2 After you set the alarm, your phone lets you know how much time is left before the alarm will go off.

3 Set **Repeat**, **Snooze duration**, **Vibration**, **Alarm sound, Alarm volume, Auto app starter, Puzzle lock** and **Memo**. Tap **Save**.

NOTE: To change alarm settings in the alarm list screen, tap the **Menu key** and select **Settings**.

Using your calculator

1 Tap > > **Apps** tab > **Calculator**.
2 Tap the number keys to enter numbers.
3 For simple calculations, tap the function you want to perform (+, –, x or ÷) followed by =.
4 For more complex calculations, tap > **Basic calculator**.
5 To check the history, tap > **Calculation history**.

Adding an event to your calendar

1 Tap > > **Apps** tab > **Calendar**.
2 On the screen, you can find the different view types for the Calendar (Day, Week, Month, Year, Agenda, Life Square).
3 Tap on the date for which you wish to add an event and tap ⊕.
4 Tap **Event name** and enter the event name.
5 Tap **Location** and enter the location. Check the date and enter the time you wish your event to start and finish.
6 If you wish to add a note to your event, tap **Link note** to select the saved notebook image. (Only available on the Phone calendar)
7 If you wish to repeat the alarm, set **REPEAT** and set **REMINDERS**, if necessary.
8 Tap **Save** to save the event in the calendar.

Voice Recorder

Use the voice recorder to record voice memos or other audio files.

Recording a sound or voice

1 Tap > > **Voice Recorder**.
2 Tap to begin recording.
3 Tap to end the recording.
4 Tap to listen to the recording.

NOTE: Tap to access your album. You can listen to the saved recording. The available recording time may differ from actual recording time.

Sending the voice recording

1 Once you have finished recording, you can send the audio clip by tapping .
2 Choose from **Bluetooth**, **Email**, **Gmail**, **Memo**, **Messaging** or **SmartShare Beam.** When you select **Email, Gmail, Memo,** or **Messaging** the voice recording is added to the message. You may then write and send the message as you usually would.

Task Manager

You can manage your applications using Task Manager. You can easily check the number of applications that are currently running and shut down certain applications.

Tasks

This task can be synchronized with MS Exchange account. You can create task, revise it and delete it in MS outlook or MS Office Outlook Web Access.

To Synchronize MS Exchange

1 From the Home Screen, Tap > > **Apps** tab > **Settings**.
2 Tap **General** tab > **Accounts & sync** > **Add account**.
3 Tap **Microsoft Exchange** to create Email address and Password.
4 Make sure if you checkmark Sync task.

NOTE: MS Exchange may not be supported depending on email server.

POLARIS Viewer 5

POLARIS Viewer 5 is a professional mobile office solution that lets users conveniently view various types of office documents, including Word, Excel and PowerPoint files, anywhere or anytime, using their mobile devices.

Tap > > **Apps** tab > **POLARIS Viewer 5**.

Viewing files

Mobile users can now easily view a wide variety of file types, including Microsoft Office documents and Adobe PDF, right on their mobile devices. When viewing documents using POLARIS Viewer 5, the objects and layout remain the same as in the original documents.

Google+

Use this application to stay connected with people via Google's social network service.

- Tap > > **Apps** tab > **Google+.**

NOTE: This application may not be available depending on the region or service provider.

Voice Search

Use this application to search webpages using voice.

1 Tap > > **Apps** tab > **Voice Search**.

2 Say a keyword or phrase when **Speak now** appears on the screen. Select one of the suggested keywords that appear.

NOTE: This application may not be available depending on the region or service provider.

Downloads

Use this application to see what files have been downloaded through the applications.

- Tap > > **Apps** tab > **Downloads**.

NOTE: This application may not be available depending on the region or service provider.

The Web

Internet

Use this application to browse the Internet. Browser gives you a fast, full-colour world of games, music, news, sports, entertainment and much more, right on your mobile phone wherever you are and whatever you enjoy.

NOTE: Additional charges apply when connecting to these services and downloading content. Check data charges with your network provider.

1 Tap > > **Apps** tab > **Internet**.

Using the Web toolbar

Tap slide it upwards with your finger to open.

	Tap to go back one page.
	Tap to go forward one page, to the page you connected to after the current one. This is the opposite of what happens when you tap , which takes you to the previous page.
	Tap to go to the Home page.
	Tap to add a new window.
	Tap to access bookmarks.

Viewing webpages

Tap the address field, enter the web address and tap **Go**.

Opening a page

To go to new page, tap → .

To go to another webpage, tap , scroll up or down, and tap the page to select it.

Searching the web by voice

Tap the address field, tap , speak a keyword, and then select one of the suggested keywords that appear.

NOTE: This feature may not be available depending on the region or service provider.

Bookmarks

To bookmark the current webpage, tap > **Save to bookmarks** > **OK**.

To open a bookmarked webpage, tap and select one.

History

Tap > **History** to open a webpage from the list of recently-visited webpages. To clear the history, tap **Menu key** → **Clear all history**.

The Web

Chrome

Use Chrome to search for information and browse webpages.

1 Tap > > **Apps** tab > **Chrome**.

NOTE: This application may not be available, depending on your region and service provider.

Viewing webpages

Tap the Address field, and then enter a web address or search criteria.

Opening a page

To go to a new page, tap → **New tab**.

To go to another webpage, tap , scroll up or down and tap the page to select it.

Syncing with other devices

Sync open tabs and bookmarks to use with Chrome on another device when you are logged in with the same Google account.

To view open tabs on other devices, tap **Menu key** → **Other devices**.

Select a webpage to open.

To add bookmarks, tap .

Settings

This section provides an overview of items you can change using your phone's System settings menus.

To access the Settings menu:

Tap > > **System settings**.

- or -

Tap > > **Apps** tab > **Settings**.

Networks

< Wi-Fi >

Wi-Fi – Turns on Wi-Fi to connect to available Wi-Fi networks.

TIP! How to obtain the MAC address

To set up a connection in some wireless networks with MAC filters, you may need to enter the MAC address of your phone in the router.

You can find the MAC address in the following user interface: tap > > **Apps** tab > **Settings** > **Networks** tab > **Wi-Fi** > > **Advanced Wi-Fi** > **MAC address**.

< Bluetooth >

Turn the Bluetooth wireless feature on or off to use Bluetooth.

< Mobile data >

Displays the data usage and set mobile data usage limit.

< Call >

Configure phone call settings such as call forwarding and other special features offered by your carrier.

Voicemail – Allows you to select your carrier's voicemail service.

Fixed dialing numbers – Turn on and compile a list of numbers that can be called from your phone. You'll need your PIN2, which is available from your operator. Only numbers within the fixed dial list can be called from your phone.

Incoming call pop-up – Display incoming call popup when using camera and videos.

Call reject – Allows you to set the call reject function. Choose from **Call reject mode** or **Reject calls from**.

Decline with message – When you want to reject a call, you can send a quick message using this function. This is useful if you need to reject a call during a meeting.

Privacy keeper – Hides the caller name and number for an incoming call.

Call forwarding – Choose whether to divert all calls when the line is busy, when there is no answer or when you have no signal.

Auto answer – Set the time before a connected hands-free device automatically answers an incoming call. Choose from Disable, 1 second, 3 seconds, and 5 seconds.

Connection vibration – Vibrates your phone when the other party answers the call.

Voice enhancement – Enhances voice quality in noisy environments so you can hear more clearly.

Save unknown numbers – Add unknown numbers to contacts after a call.

Power button ends call – Allows you to select your end call.

Call barring – Lock incoming, outgoing or international calls.

Call duration – View the duration of calls including Last call, Outgoing calls, Incoming calls and All calls.

Additional settings – Allows you to change the following settings:

Caller ID: Choose whether to display your number in an outgoing call.

Call waiting: If call waiting is activated, the handset will notify you of an incoming call while you are on a call (depending on your network provider).

< Share & connect >

NFC – Your phone is an NFC-enabled mobile phone. NFC (Near Field Communication) is a wireless connectivity technology that enables two-way communication between electronic devices. It operates over a distance of a few centimeters. You can share your content with an NFC tag or another NFC support device by simply tapping it with your device. If you tap an NFC tag with your device, it will display the tag content on your device.

To switch NFC on or off: From the Home screen, touch and slide the notification panel down with your finger, then select the NFC icon to turn it on.

NOTE: When airplane mode is activated, the NFC application can be used.

Using NFC: To use NFC, make sure your device is switched on, and activate NFC if disabled.

Direct/Android Beam – When this feature is turned on, you can beam app content to another NFC-capable device by holding the devices close together.

Just bring the device together(typically back to back) and then tap your screen. The app determines what gets beamed.

SmartShare Beam – Turn on to receive multimedia content via **SmartShare Beam** from LG phones or tablets.

Miracast – Mirror phone screen and sound onto Miracast dongle or TV Wirelessly.

Wireless storage – You can manage files on your phone in the computer or copy files to the phone from the computer without a USB connection. After switching on Wireless storage, make sure that the phone and computer are connected to the same network. Then, enter the web addresses shown on your phone in the address bar of the browser on your computer.

< Tethering & networks >

Wi-Fi hotspot – You can also use your phone to provide a mobile broadband connection. Create a hotspot and share your connection. Please read **"Sharing your phone's data connection"** for more information.

Bluetooth tethering – Allows you to set your phone whether you are sharing the Internet connection or not.

Help – Tap to view help information on the Wi-Fi hotspot and Bluetooth tethering functions.

Airplane mode – After switching to Airplane mode, all wireless connections are disabled.

NOTE: You must set a lock screen PIN or password before you can use credential storage.

Mobile networks – Set options for data roaming, network mode & operators, access point names (APNs) etc.

VPN – Displays the list of Virtual Private Networks (VPNs) that you've previously configured. Allows you to add different types of VPNs.

Sound

Sound profile – Choose Sound, Vibrate only or Silent.

Volumes – Adjust the phone's volume settings to suit your needs and your environment.

Vibrate strength – Allows you to set the vibrate strength for calls, notifications, and touch feedback.

Quiet mode – Set up your Quiet mode. Tap the **Turn quiet mode on now** switch to toggle it On or Off. You can schedule Quiet mode to activate automatically and designate exceptions to your Quiet mode.

- **Set quiet time:** Tap the switch to toggle it On or Off. You can also set the days and times to automatically turn Quiet mode on.
- **Vibrate:** Checkmark to provide vibration for allowed calls or notifications when Quiet mode is on.
- **Incoming call settings**
  - **Block incoming calls:** Checkmark to block all incoming calls.
  - **Allow repeated calls:** Checkmark to allow a call that is repeated within 3 minutes.
  - **Allowed contact lists:** Designate which Contacts calls will be allowed.
  - **Auto reply to blocked calls:** Set how to you want to automatically reply to silenced calls.
- **Help:** view the help of the Quiet mode

Phone ringtone – Set the ringtone for calls. You can also add a ringtone by tapping ⊕ at the top right corner of the screen.

Smart ringtone – Checkmark to increase phone ringtone volume automatically in noisy environments.

Incoming call vibration – Sets the incoming call vibration Options.

Gentle vibration – Checkmark to gradually increasing vibration up to current strength set.

Ringtone with vibration – Checkmark to set the phone to vibrate in addition to the ringtone when you receive calls.

Voice notifications – Tap the **Voice notifications** switch to toggle it On or Off. On allows your device to read out incoming call and message events automatically.

Notification sound – Allows you to set the sound for notifications. You can also add a sound by tapping ⊕ at the top right corner of the screen.

Touch feedback & system – Allows you to set the feedback (tones and/or vibration) while using your device.

Display

< Home screen >

Set the **Theme, Wallpaper, Screen swipe effect, Allow Home screen looping,** or **Portrait view only**.

Home backup & restore – You can backup and restore app/widget layouts and themes.

Help – Tap to view help information on Home screen.

< Lock screen >

Select screen lock – Set a screen lock type to secure your phone. Opens a set of screens that guide you through drawing a screen unlock pattern. Set **None**, **Swipe**, **Face Unlock**, **Pattern**, **PIN** or **Password**.

If you have enabled a Pattern lock type when you turn on your phone or wake up the screen, you will be asked to draw your unlock pattern to unlock the screen.

Swing Lock screen – Checkmark to move Lock screen naturally up or down, when you tilt your phone in that direction.

Screen swipe effect – Sets the screen swipe effect options. Choose from Ripple, Dewdrop, White hole, Particle, and Crystal.

NOTE: Screen swipe effect becomes Pattern effect if the screen lock is set to Pattern.

Weather animation – Checkmark to show weather animation for current location or primary city set in Weather based on auto data updates.

Wallpaper – Sets your Lock screen wallpaper. Select it from **Gallery** or **Wallpaper gallery**.

Shortcuts – Allows you to change the shortcuts on the **Swipe** Lock screen.

Owner info – Checkmark to set the device owner's name to be displayed on the Lock screen. Tap ⚙ to enter the text to be displayed as the Owner info.

Lock timer – Sets the amount of time before the screen automatically locks after the screen has timed-out.

Power button instantly locks – Checkmark to instantly lock the screen when the Power/Lock Key is pressed. This setting overrides the Security lock timer setting.

< Front touch buttons >

Set the Front Touch Keys displayed at the bottom of all of the screens. Set which ones are displayed, their position on the bar, and what they look like. Select the keys and order, the theme, and the background.

< SCREEN >

Brightness – Adjusts the brightness of the screen. For best battery performance, use the dimmest comfortable brightness.

Screen timeout – Sets the amount of time before the screen times out.

Screen-off effect – Sets the screen-off effect. Choose from Fade out, Black hole, Retro TV.

Auto-rotate screen – Checkmark to set the phone to automatically rotate the screen based on the phone orientation (portrait or landscape).

Screen mode - Set the screen mode. Choose from **Standard**, **Vivid**, or **Natural**.

Daydream – Tap the Daydream switch to toggle it On or Off. On allows the set screensaver to be displayed when the phone is sleeping while docked and/or charging. Choose from Clock, Charging, Colours, Photo Frame, and Photo Table.

< FONT >

Font type – Sets the type of font used for the phone and menus.

Font size – Sets the size of the font displayed in the phone and menus.

< SMART ON >

Smart screen – Checkmark to keep the screen from timing-out when the device detects your eyes looking at the screen.

Smart video – Checkmark to pause the video when it doesn't detect your eyes looking at the screen.

< ADVANCED SETTINGS >

Notification LED – Tap the switch to toggle it On or Off. On will activate the LED light for the notifications you select, in the colour you set for each one.

Auto-adjust screen tone – Checkmark to save battery power by adjusting screen brightness automatically with analysis of image colour.

Screen capture area – Allow you to set capture screen area. Choose from **Capture full screen** or **Capture part of screen**.

Aspect ratio correction – Allows you to change the aspect ratio of a downloaded application to fix screen distortion.

General

< Gestures >

Screen on/off – Checkmark to enable KnockON to turn the screen on and off. Quickly double-tap center screen to turn it on. Double-tap the Status Bar, an empty area on

the Home screen, or the Lock screen to turn the screen off. For the best results, do not move the phone while using the KnockON feature.

Answer an incoming call – Checkmark to enable you to bring the phone to your ear to automatically answer the incoming call.

Fade out ringtone – Checkmark to enable you to pick up the phone from the flat surface to fade out the incoming call ringtone.

Silence incoming calls – Checkmark to enable you to flip the phone to silence incoming calls.

Snooze or turn off alarm – Checkmark to enable you to simply flip the device to snooze or stop the alarm.

Pause video – Checkmark to enable you to simply flip the device to pause the currently playing video.

Move Home screen items – Checkmark to enable you to move an icon to another screen by tilting the phone. Tap and hold the icon and tilt the phone left or right, then let go on the screen where you want the icon.

Help – Opens a help guide on how to use the Gestures features of your device.

Motion sensor calibration – Allows you to improve the accuracy of the tilt and speed of the sensor.

< One-handed operation >

Dial keypad – Checkmark to enable you move the dial keypad to the right or left side of the device. Simply tap the arrow to move it to one side or the other.

LG keyboard – Checkmark to enable you move the keyboard to the right or left side of the device. Simply tap the arrow to move it to one side or the other.

Gesture control – Checkmark to enable you to swipe the keyboard left or right to adjust the position of LG keyboard.

Lock screen – Checkmark to enable you move the PIN Lock screen keypad to the right or left side of the device. Simply tap the arrow to move it to one side or the other.

Swipe front touch buttons – Checkmark to swipe the front touch buttons left or right side to adjust the position of buttons in order to use it easily with one hand.

Help – Displays information regarding one-handed operation.

< Storage >

INTERNAL STORAGE – View the internal storage usage.

< Battery >

BATTERY INFORMATION

The Battery charge information is displayed on a battery graphic along with the percentage of the remaining charge and its status.
Touch the Battery charge icon to display the Battery use screen to see battery usage level and battery use details. It displays which components and applications are using the most battery power. Tap one of the entries to see more detailed information.

Battery percentage on status bar – Checkmark to display the battery level percentage on the Status Bar next to the battery icon.

BATTERY SAVER

Tap the Battery saver switch to toggle it On or Off. Tap Battery saver to access the following settings:

Battery saver – Sets the battery charge percent level that will automatically turn on Battery saver. Choose from Immediately, 10% battery, 20% battery, 30% battery, and 50% battery.

Battery saver tips

Auto-sync – Checkmark to turn off Auto-sync when Battery saver is activated.

Wi-Fi – Checkmark to turn Wi-Fi off when data is not being used while Battery saver is activated.

Bluetooth – Checkmark to turn Bluetooth off when not connected while Battery saver is activated.

Vibrate on touch – Checkmark to turn off touch feedback when Battery saver is activated.

Brightness – Checkmark to set the screen brightness when Battery saver is activated. Tap ⚙ to change the setting.

Auto-adjust screen tone – Checkmark to turn on auto-adjust screen tone when Battery saver is activated.

Screen timeout – Checkmark to set the screen timeout when Battery saver is activated. Tap the Settings icon to change the setting.

Notification LED – Checkmark to turn off the LED light for notifications when Battery saver is activated.

< Apps >

View and manage your applications.

< Multitasking >

Slide Aside – Checkmark the **Slide Aside** checkbox to use Slide Aside feature. (Please see **Slide Aside**.)

Dual Window – Checkmark the **Dual Window** checkbox to use Dual Window feature. (Please see **Dual Window**.)

Split view – Checkmark the **Split view** checkbox to tap a link on the full screen to run dual windows automatically.

Help – Opens a help guide on how to use the Multitasking features of your device.

< Accounts & sync >

Permits applications to synchronize data in the background, whether or not you are actively working in them. Deselecting this setting can save battery power and lower (but not eliminate) data usage.

< Cloud >

Add a cloud account to quickly and easily use cloud service on LG apps.

< Guest mode >

To protect your privacy or limit some applications to your children, you can use the Guest mode.

When you lend your phone to others, you can limit the applications to be displayed. In advance, set the Guest mode and customize the options.

< Location access >

Access to my location – If you select Google's location service, your phone determines your approximate location using Wi-Fi and mobile networks. When you select this option, you're asked whether you consent to allowing Google to use your location when providing these services.

GPS satellites – If you select GPS satellites, your phone determines your location to street-level accuracy.

Wi-Fi & mobile network location – Lets apps use data from sources such as Wi-Fi and mobile networks to determine your approximate location.

< Security >

Encrypt phone – Allows you to encrypt data on the phone for security. You will be required to enter a PIN or password to decrypt your phone each time you power it on.

Set up SIM card lock – Set up Micro-USIM card lock or change the Micro-USIM card PIN.

Password typing visible – Show the last character of the hidden password as you type.

Phone administrators – View or deactivate phone administrators.

Unknown sources – Default setting to install non-Play store applications.

Verify apps – Disallow or warn before installation of apps that may cause harm.

Trusted credentials – Display trusted CA certificates.

Install from storage – Choose to install encrypted certificates.

Clear credentials – Remove all certificates.

< Language & input >

Use the Language & input settings to select the language for the text on your phone and to configure the on-screen keyboard, including words you've added to its dictionary.

< Backup & reset >

Change the settings for managing your settings and data.

Backup my data – Set to backup your settings and application data to the Google server.

Backup account – Set to backup your account.

Automatic restore – Set to restore your settings and application data when the applications are reinstalled on your device.

LG Backup service – Backs up all information on the device and restores it in the event of data loss or replacement.

Factory data reset – Reset your settings to the factory default values and delete all your data. If you reset the phone this way, you are prompted to re-enter the same information as when you first started Android.

< Date & time >

Use **Date & time** settings to set how dates will be displayed. You can also use these settings to set your own time and time zone rather than obtaining the current time from the mobile network.

< Accessibility >

Use the **Accessibility** settings to configure accessibility plug-ins you have installed on your phone.

NOTE: Requires additional plug-ins to become selectable.

< PC connection >

Select USB connection method – Set the desired mode: **Charge phone**, **Media sync (MTP)**, **Tethering**, **LG software** or **Send images (PTP)**.

Ask upon connecting – Ask in USB connection mode when connecting to a computer.

Help – Help for USB connection.

PC Suite – Check this to use LG PC Suite with your Wi-Fi connection.

Please note that Wi-Fi network should be connected to LG PC Suite via a Wi-Fi connection.

On-Screen Phone – Check this to receive Wi-Fi connection request from On-Screen Phone.

Help – Help for LG software.

< Accessory >

QuickWindow case – Activate to make features, such as music, weather, and clock, available in small view when using the QuickWindow case.

USB storage – Sets the Plug & Pop feature for USB storage. Checkmark the **App panel** option to automatically display the app panel when connecting an OTG (On-the-Go) USB cable. Tap **Edit app panel** to change the applications you want to make available.

Earphone – Sets the Plug & Pop feature for earphones. Checkmark the **App panel** option to automatically display the app panel when connecting an earphone. Tap **Edit app panel** to change the applications you want to make available.

< About phone >

View legal information and check your phone status and software version.

PC software (LG PC Suite)

"LG PC Suite" PC software is a program that helps you connect your device to a PC via a USB cable and Wi-Fi. Once connected, you can use the functions of your device from your PC.

With your "LG PC Suite" PC Software, You Can...

- Manage and play your media contents (music, movie, picture) on your PC.
- Send multimedia contents to your device.
- Synchronizes data (schedules, contacts, bookmarks) in your device and PC.
- Backup the applications in your device.
- Update the softwares in your device.
- Backup and restore the device data.
- Play multimedia contents of your PC from your device.
- Backup and create and edit the memos in your device

NOTE: You can use the Help menu from the application to find out how to use your "LG PC Suite" PC software.

Installing "LG PC Suite" PC Software

"LG PC Suite" PC software can be downloaded from the webpage of LG.

1 Go to www.lg.com and select a country of your choice.
2 Go to **SUPPORT** > **Mobile Support** > **Mobile Phone** > **Select the Model**
3 Click **PC Sync** from and click **DOWNLOAD** to download "LG PC Suite" PC software.

System Requirements for "LG PC Suite" PC software

- OS: Windows XP (Service pack 3) 32bit, Windows Vista, Windows 7, Windows 8
- CPU: 1 GHz or higher processors
- Memory: 512 MB or higher RAMs
- Graphic card: 1024 x 768 resolution, 32 bit colour or higher
- HDD: 500 MB or more free hard disk space (More free hard disk space may be needed depending on the volume of data stored.)
- Required software: LG integrated drivers, Windows Media Player 10 or later

NOTE: LG Integrated USB Driver
LG integrated USB driver is required to connect an LG device and PC and is installed automatically when you install "LG PC Suite" PC software application.

Synchronizing your Device to a PC

Data from your device and PC can be synchronized easily with "LG PC Suite" PC software for your convenience. Contacts, schedules and bookmarks can be synchronized.

The procedure is as follows:

1. Connect your device to PC. (Use a USB cable or Wi-Fi connection.)
2. The **Select USB connection method** will appear, then select **LG software**.
3. After connection, run the program and select the device section from the category on the left side of the screen.
4. Click **Personal information** to select.
5. Select the checkbox of contents to synchronize and click the **Sync** button.

NOTE: To synchronize your phone with your PC, you need to install LG PC Suite onto your PC. Please refer to previous pages to install LG PC Suite.

Moving contacts from your Old Device to your New Device

1 Export your contacts as a CSV file from your old device to your PC using a PC sync program.
2 Install "LG PC Suite" on the PC first. Run the program and connect your Android mobile phone to the PC using a USB cable.
3 On the top menu, select **Device** > **Import to device** > **Import contacts**.
4 A popup window to select the file type and a file to import will appear.
5 On the popup, click the **Select a file** and Windows Explorer will appear.
6 Select the contacts file to import in Windows Explorer and click the **Open**.
7 Click **OK**.
8 A **Field mapping** popup to link the contacts in your device and new contacts data will appear.
9 If there is a conflict between the data in your PC contacts and device contacts, make the necessary selections or modifications in LG PC Suite.
10 Click **OK**.

Phone software update

LG Mobile phone software update from the Internet

For more information about using this function, please visit http://www.lg.com/common/index.jsp → select your country and language.

This feature allows you to conveniently update the firmware on your phone to a newer version from the Internet without needing to visit a service center. This feature will only be available if and when LG makes a newer firmware version available for your device.

Because the mobile phone firmware update requires the user's full attention for the duration of the update process, please make sure you check all instructions and notes that appear at each step before proceeding. Please note that removing the USB data cable during the upgrade may seriously damage your mobile phone.

NOTE: LG reserves the right to make firmware updates available only for selected models at its own discretion and does not guarantee the availability of the newer version of the firmware for all handset models.

LG Mobile Phone software update via Over-the-Air (OTA)

This feature allows you to conveniently update your phone's software to a newer version via OTA, without connecting using a USB data cable. This feature will only be available if and when LG makes a newer firmware version available for your device.

You should first check the software version on your mobile phone: **Settings** > **General** tab > **About phone** > **Update Center > Software Update > Check now for update**.

Phone software update

NOTE: Your personal data from internal phone storage—including information about your Google account and any other accounts, your system/application data and settings, any downloaded applications and your DRM licence—might be lost in the process of updating your phone's software. Therefore, LG recommends that you backup your personal data before updating your phone's software. LG does not take responsibility for any loss of personal data.

NOTE: This feature depends on your network service provider, region and country.

About this user guide

About this user guide

- Before using your device, please carefully read this manual. This will ensure that you use your phone safely and correctly.
- Some of the images and screenshots provided in this guide may appear differently on your phone.
- Your content may differ from the final product, or from software supplied by service providers or carriers, This content may be subject to change without prior notice. For the latest version of this manual, please visit the LG website at www.lg.com.
- Your phone's applications and their functions may vary by country, region, or hardware specifications. LG cannot be held liable for any performance issues resulting from the use of applications developed by providers other than LG.
- LG cannot be held liable for performance or incompatibility issues resulting from registry settings being edited or operating system software being modified. Any attempt to customize your operating system may cause the device or its applications to not work as they should.
- Software, audio, wallpaper, images, and other media supplied with your device are licensed for limited use. If you extract and use these materials for commercial or other purposes, you may be infringing copyright laws. As a user, you are fully and entirely responsible for the illegal use of media.
- Additional charges may be applied for data services, such as messaging, uploading and downloading, auto-syncing, or using location services. To avoid additional charges, select a data plan that is suitable for your needs. Contact your service provider to obtain additional details.

Trademarks

- LG and the LG logo are registered trademarks of LG Electronics.
- All other trademarks and copyrights are the property of their respective owners.

DivX HD

ABOUT DIVX VIDEO: DivX® is a digital video format created by DivX, LLC, a subsidiary of Rovi Corporation. This is an official DivX Certified® device that has passed rigorous testing to verify that it plays DivX video. Visit divx.com for more information and software tools to convert your files into DivX videos.

ABOUT DIVX VIDEO-ON-DEMAND: This DivX Certified® device must be registered in order to play purchased DivX Video-on-Demand (VOD) movies. To obtain your registration code, locate the DivX VOD section in your device setup menu. Go to vod.divx.com for more information on how to complete your registration.

DivX Certified® to play DivX® video up to HD 720p, including premium content.

DivX®, DivX Certified® and associated logos are trademarks of Rovi Corporation or its subsidiaries and are used under license.

Dolby Digital Plus

Manufactured under license from Dolby Laboratories. Dolby, Dolby Digital Plus, and the double-D symbol are trademarks of Dolby Laboratories.

Notice: Open Source Software

To obtain the corresponding source code under GPL, LGPL, MPL and other open source licences, please visit http://opensource.lge.com/

All referred licence terms, disclaimers and notices are available for download with the source code.

Accessories

These accessories are available for use with the your phone. **(Items described below may be optional.)**

Travel adaptor

Stereo headset

Quick Start Guide

Data cable

Micro-USIM ejection tool

LG Service Center by LG Electronics (Thailand) Co.Ltd.
72/127 Somdetprachaw Taksin Rd.; Bookala, Thonburi,
Bangkok 10600
Working day : Mon - Sat , 08:00 - 18:00
Call center : 0-2878-5757

NOTE:
- Always use genuine LG accessories.
- Failure to do this may void your warranty.
- Accessories may vary in different regions.

Troubleshooting

This chapter lists some problems you might encounter when using your phone. Some problems require you to call your service provider, but most are easy to fix yourself.

Message	Possible causes	Possible corrective measures
Micro-USIM card error	There is no Micro-USIM card in the phone or it is inserted incorrectly.	Make sure that the Micro-USIM card is correctly inserted.
No network connection/ Dropped network	Signal is weak or you are outside the carrier network.	Move toward a window or into an open area. Check the network operator coverage map.
	Operator applied new services.	Check whether the Micro-USIM card is more than 6~12 months old. If so, change your Micro-USIM card at your network provider's nearest branch. Contact your service provider.
Codes do not match	To change a security code, you will need to confirm the new code by re-entering it.	If you forget the code, contact your service provider.
	The two codes you have entered do not match.	

Message	Possible causes	Possible corrective measures
No applications can be set	Not supported by service provider or registration required.	Contact your service provider.
Calls not available	Dialling error	New network not authorized.
	New Micro-USIM card inserted.	Check for new restrictions.
	Pre-paid charge limit reached.	Contact service provider or reset limit with PIN2.
Phone cannot be switched on	On/Off key pressed too briefly.	Press the On/Off key for at least two seconds.
	Battery is not charged.	Charge battery. Check the charging indicator on the display.

Troubleshooting

Message	Possible causes	Possible corrective measures
Charging error	Battery is not charged.	Charge battery.
	Outside temperature is too hot or cold.	Make sure phone is charging at a normal temperature.
	Contact problem	Check the charger and its connection to the phone.
	No voltage	Plug the charger into a different socket.
	Charger defective	Replace the charger.
	Wrong charger	Use only original LG accessories.
Number not allowed	The Fixed dialling number function is on.	Check the Settings menu and turn the function off.
Impossible to receive / send SMS & photos	Memory full	Delete some messages from your phone.
Files do not open	Unsupported file format	Check the supported file formats.

Message	Possible causes	Possible corrective measures
The screen does not turn on when I receive a call.	Proximity sensor problem	If you use a protection tape or case, make sure it has not covered the area around the proximity sensor. Make sure that the area around the proximity sensor is clean.
No sound	Vibration mode	Check the settings status in the sound menu to make sure you are not in vibration or silent mode.
Hangs up or freezes	Intermittent software problem	Try to perform a software update via the website.

FAQ

Category Sub-Category	Question	Answer
BT Bluetooth Devices	What are the functions available via Bluetooth	You can connect a Bluetooth audio device such as a Stereo/Mono headset or Car Kit. Also, when the FTP server is connected to a compatible device, you can share content stored on the storage media.
BT Bluetooth Headset	If my Bluetooth headset is connected, can I listen to my music through my 3.5 mm wired headphones?	When a Bluetooth headset is connected, all system sounds are played over the headset. As a result, you will not be able to listen to music through your wired headphones.
Data Contacts Backup	How can I backup Contacts?	The Contacts data can be synchronized between your phone and Gmail™.
Data Synchronization	Is it possible to set up one-way sync with Gmail?	Only two-way synchronization is available.
Data Synchronization	Is it possible to synchronize all email folders?	The Inbox is automatically synchronized. You can view other folders by tapping the **Menu Key** and select **Folders** to choose a folder.
Google™ Service Gmail Log-In	Do I have to log into Gmail whenever I want to access Gmail?	Once you have logged into Gmail, no need to log into Gmail again.

Category Sub-Category	Question	Answer
Google™ Service Google Account	Is it possible to filter emails?	No, email filtering is not supported via the phone.
Phone Function Email	What happens when I execute another application while writing an email?	Your email will automatically be saved as a draft.
Phone Function Ringtone	Is there a file size limitation for when I want to use MP3 file as ring tone?	There is no file size limitation.
Phone Function Message Time	My phone does not display the time of receipt for messages older than 24 hrs. How can I change this?	You will only be able to see the times for messages received the same day.
Phone Function Navigation	Is it possible to install another navigation application on my phone?	Any application that is available at Play Store™ and is compatible with the hardware can be installed and used.
Phone Function Synchronisation	Is it possible to synchronize my contacts from all my email accounts?	Only Gmail and MS Exchange server (company email server) contacts can be synchronized.

Category Sub-Category	Question	Answer
Phone Function Wait and Pause	Is it possible to save a contact with Wait and Pause in the numbers?	If you transferred a contact with the W & P functions saved into the number, you will not be able to use those features. You will need to re-save each number. How to save with Wait and Pause: 1. From the Home screen, tap the **Phone** icon . 2. Dial the number, then tap the **Menu Key** . 3. Tap **Add 2-sec pause** or **Add wait**.
Phone Function Security	What are the phone's security functions?	You are able to set the phone to require that an Unlock Pattern be entered before the phone can be accessed or used.

Category Sub-Category	Question	Answer
Phone Function Unlock Pattern	How do I create the Unlock Pattern?	1. From the Home screen, tap the **Menu Key** . 2. Tap **System settings** > **Display** tab > **Lock screen**. 3. Tap **Select screen lock** > **Pattern**. The first time you do this, a short tutorial about creating an Unlock Pattern will appear. 4. Set up by drawing your pattern once, and once again for confirmation. Precautions to take when using the pattern lock. It is very important to remember the unlock pattern you set. You will not be able to access your phone if you use an incorrect pattern five times. You have five chances to enter your unlock pattern, PIN or password. If you have used all 5 opportunities, you can try again after 30 seconds. (Or, if you preset the backup PIN, you can use the backup PIN code to unlock the pattern.)

Category Sub-Category	Question	Answer
Phone Function Unlock Pattern	What should I do if I forget the unlock pattern and I didn't create my Google account on the phone?	If you have forgotten your pattern: If you logged into your Google account on the phone but failed to enter the correct pattern 5 times, tap the forgot pattern button. You are then required to log in with your Google account to unlock your phone. If you have not created a Google account on the phone or you have forgotten it, you will have to perform a hard reset. Caution: If you perform a factory reset, all user applications and user data will be deleted. Please remember to backup any important data before performing a factory reset.
Phone Function Memory	Will I know when my memory is full?	Yes, you will receive a notification.
Phone Function Language Support	Is it possible to change my phone's language?	The phone has multilingual capabilities. To change the language: 1. From the Home screen, tap the **Menu Key** and tap **System settings**. 2. Tap **General** tab > **Language & input** > **Language**. 3. Tap the desired language.

Category Sub-Category	Question	Answer
Phone Function VPN	How do I set up a VPN?	VPN access configuration is different for each company. To configure VPN access from your phone, you must obtain the details from your company's network administrator.
Phone Function Screen time out	My screen turns off after only 15 seconds. How can I change the amount of time for the backlight to turn off?	1. From the Home screen, tap the **Menu Key**. 2. Tap **System settings** > **Display** tab. 3. Tap **Screen timeout**. 4. Tap the preferred screen backlight timeout time.
Phone Function Wi-Fi & mobile network	When Wi-Fi and mobile network are both available, which service will my phone use?	When using data, your phone may default to the Wi-Fi connection (if Wi-Fi connectivity on your phone is set to On). However, there will be no notification when your phone switches from one to the other. To know which data connection is being used, view the mobile network or Wi-Fi icon at the top of your screen.
Phone Function Home screen	Is it possible to remove an application from the Home screen?	Yes. Just touch and hold the icon until the dustbin icon appears at the top right hand side of the screen. Then, without lifting your finger, drag the icon to the trash can.

Category Sub-Category	Question	Answer
Phone Function Application	I downloaded an application and it causes a lot of errors. How do I remove it?	1. From the Home screen, tap the **Menu Key** . 2. Tap **System settings** > **General** tab > **Apps** > **DOWNLOADED**. 3. Tap the application, then tap **Uninstall**.
Phone Function Charger	Is it possible to charge my phone using a USB data cable without installing the necessary USB driver?	Yes, the phone will be charged by the USB cable regardless of whether the necessary drivers are installed or not.
Phone Function Alarm	Can I use music files for my alarm?	Yes. In the Alarm clock setting, select the song as the Alarm sound.
Phone Function Alarm	Will my alarm be audible if the phone is turned off?	No, this is not supported.
Phone Function Alarm	If my ringer volume is set to Off or Vibrate, will I hear my alarm?	Your alarm is programmed to be audible even in these scenarios.
Recovery Solution Hard Reset (Factory Reset)	How can I perform a factory reset if I can't access the phone's setting menu?	If your phone does not restore to its original condition, use a hard reset (factory reset) to initialize it.

LG Customer Information Center

สอบถามข้อมูลผลิตภัณฑ์และศูนย์บริการใกล้บ้าน

โทรฟรี
1-800-545454
กรุงเทพและปริมณฑล
0-2878-5757

เว็บไซต์และอีเมล์ :
http://www.lg.com/th และ support.lgeth@lge.com

โปรดอ่านคู่มือการใช้งานและเงื่อนไขการรับประกัน
จากบัตรรับประกันสินค้าเพื่อความเข้าใจในการใช้งาน
บันทึกชื่อรุ่นและหมายเลขประจำเครื่อง
เพื่อความสะดวกในการติดต่อ
กับศูนย์บริการของแอลจีทั่วประเทศ

PRINTED WITH SOY INK™

CE0168