Model	VC22****/VC23****/VC33****		
Language	English + Thai		
Page	17	Color(cover/body)	1/1
Material	Weight 80g	Size(W*H)	145mm*205mm
Date	2014.8.14	Designer	Chen Chen
Part No	MFL67892744	Description	Owners Manual

Chage Record

No.	Change content	ECO No.	Date	Designer	Confirm
1					
2					
3					
4					
5					
6					
7					
8					
9					

LG
Life's Good

ENGLISH

THAI

OWNER'S MANUAL
คู่มือการใช้งาน

NEW TYPE CYCLONE VACUUM CLEANER
เครื่องดูดฝุ่นแบบไซโคลน

This information contains important instructions for the safe use and maintenance of the vacuum cleaner. Especially, please read all of the information on page 2,3,4,5 for your safety. Please keep this manual in an easily accessible place and refer to it anytime.

คู่มือนี้จะให้คำแนะนำเกี่ยวกับความปลอดภัยในการใช้งาน และการบำรุงรักษาเครื่องดูดฝุ่น โดยเฉพาะอย่างยิ่งกรุณาอ่านที่หน้า 6,7,8,9 เพื่อความปลอดภัยของตัวท่านเอง และเก็บคู่มือนี้ในที่ที่ง่ายต่อการหยิบใช้ เพื่อความสะดวกในการใช้สอย

VC22****
VC23****
VC33****

MFL67892744

www.lg.com

IMPORTANT SAFETY INSTRUCTIONS

Read and follow all instructions before using your vacuum cleaner to prevent the risk of fire,electric shock, personal injury,or damage when using the vacuum cleaner.This guide do not cover all possible conditions that may occur.Always contact your service agent or manufacturer about problems that you do not understand. This appliance complies with the following ECDirectives:-2006/95/EC Low Voltage Directive-2004/108/EC EMC Directive.

This is the safety alert symbol.
This symbol alerts you to potential hazards that can kill or hurt you and others.
All safety messages will follow the safety alert symbol and either the word “WARNING” or “CAUTION.” These words mean:

WARNING This symbol will alert you to hazards or unsafe practices which could cause serious bodily harm or death.

CAUTION This symbol will alert you to hazards or unsafe practices which could cause bodily injury or property damage.

WARNING

- **Do not use the vacuum cleaner if the power cord or plug is damaged or faulty.**

  If the power cord is damaged, it must be replaced by an approved LG Electronics Service Agent to avoid a hazard.
- **This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.**

  Children should be supervised to ensure that they do not play with the appliance.
- **This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given**

⚠ WARNING

supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved. Children shall not play with the appliance. Cleaning and user maintenance shall not be made by children without supervision.

- **Disconnect electrical supply before servicing or cleaning the unit or when cleaner is not in use.**
  Failure to do so could result in electrical shock or personal injury.
- **Do not vacuum liquid, blade, gesso, substances, or small particles like cement, burning or smoking such as cigarettes, or hot ashes in cleaning.**
- **Do not vacuum flammable or explosive substances such as gasoline, benzene, thinners, propane (liquids or gases).**
  The fumes from these substances can create a fire hazard or explosion. Doing so could result in death or personal injury.
- **Do not handle plug or vacuum cleaner with wet hands.**
  Doing so could result in death or electrical shock.
- **Do not unplug by pulling on cord.**
  Doing so could result in product damage or electrical shock. To unplug, grasp the plug, not the cord.
- **Keep hair, loose clothing, fingers, and all parts of the body away from openings and moving parts.**
  Failure to do so could result in electrical shock or personal injury.
- **Do not pull or carry by cord, use cord as a handle, close a door on cord, or pull cord around sharp edges or corners. Do not run vacuum cleaner over cord. Keep cord away from heated surfaces.**
  Failure to do so could result in electrical shock or personal injury or fire or product damage.
- **Do not allow to be used as toy. Close attention is necessary when used by or near children.**
  Personal injury or product damage could result.
- **Do not use vacuum cleaner if it has been under water.**
  Personal injury or product damage could result. In these cases, contact LG Electronics Service Agent to avoid hazard.
- **Do not continue to vacuum if any parts appear missing or damaged.**
  Personal injury or product damage could result. In these cases, contact LG Electronics Service Agent to avoid hazard.
- **Do not use an extension cord with this vacuum cleaner**
  Fire hazard or product damage could result.
- **Using proper voltage.**
  Using improper voltage may result in damage to the motor and possible injury to the user. Proper voltage is listed onthe bottom of vacuum cleaner.
- **Turn off all controls before unplugging.**
  Failure to do so could result in electrical shock or personal injury.
- **Do not change the plug in any way.**
  Failure to do so could result in electrical shock or personal injury or product damage. Doing so result in death. If plug does not fit, contact a qualified electrician to install the proper outlet.
- **Repairs to electrical appliances may only be performed by qualified service engineers.**
  Improper repairs may lead to serious hazards for the user.
- **Do not plug in if control knob is not in OFF position.**
  Personal injury or product damage could result. (Depending on model)

IMPORTANT SAFETY INSTRUCTIONS

⚠ WARNING

- **Keep children away and beware of obstructions when rewinding the cord to prevent personal injury.**
  The cord moves rapidly when rewinding. (Depending on model)
- **The hose contains electrical wires. Do not use it if it is damaged, cut or punctured.**
  Failure to do so could result in death,or electrical shock. (Depending on model)

⚠ CAUTION

- **Do not put any objects into openings.**
  Failure to do so could result in product damage.
- **Do not use with any opening blocked: keep free of dust, lint, hair, and anything that may reduce air flow.**
  Failure to do so could result in product damage.
- **Do not use vacuum cleaner without dust tank and/or filters in place.**
  Failure to do so could result in product damage.
- **Do not use vacuum cleaner to pick up sharp hard objects, small toys, pins, paper clips, etc.**
  They may damage the cleaner or dust bin.
- **Store the vacuum cleaner indoors.**
  Put the vacuum cleaner away after use to prevent tripping over it.
- **Only use parts produced or recommended by LG Electronics Service Agents.**
  Failure to do so could result in product damage.
- **Use only as described in this manual. Use only with LG recommended or approved attachments and accessories.**
  Failure to do so could result in personal injury or product damage.
- **To avoid personal injury and to prevent the machine from falling when cleaning stairs, always place it at the bottom of stairs.**
  Failure to do so could result in personal injury or product damage.
- **Use accessory nozzles in sofa mode.**
  Failure to do so could result in product damage.
- **Make sure the filters (exhaust filter and motor safety filter) are completely dry before replacing in the machine.**
  Failure to do so could result in product damage.
- **Do not dry the filter in an oven or microwave.**
  Failure to do so could result in fire hazard.
- **Do not dry the filter in a clothes dryer.**
  Failure to do so could result in fire hazard.
- **Do not dry near an open flame.**
  Failure to do so could result in fire hazard.
- **Always clean the dust bin after vacuuming carpet cleaners or fresheners, powders and fine dust.**
  These products clog the filters,reduce airflow and can cause damage to the cleaner. Failure to clean the dust bin could cause permanent damage to the cleaner. (Depending on model)
- **Don ’t grasp the tank handle when you are moving the vacuum cleaner.**
  The vacuum cleaner s body may fall when separating tank and body. Personal injury or product damage could result. **You should grasp the carrier handle** when you aremoving the vacuum cleaner. (Depending on model)
- **If after emptying the dust tank the indicator light is on(red), clean the dust tank.**
  Failure to do so could result in product damage. (Depending on model)

⚠ CAUTION

Thermal protector :

This vacuum cleaner has a special thermostat that protects the vacuum cleaner in case of motor overheating. If the vacuum cleaner suddenly shuts off, turn off the switch and unplug the vacuum cleaner. Check the vacuum cleaner for possible source of overheating such as a full dust tank, a blocked hose or clogged filter. If these conditions are found, fix them and wait at least 30 minutes before attempting to use the vacuum cleaner. After the 30 minute period, plug the vacuum cleaner back in and turn on the switch.

คำแนะนำเพื่อความปลอดภัย

กรุณาอ่าน และปฏิบัติตามคำแนะนำต่อไปนี้ ก่อนที่จะใช้งานเครื่องดูดฝุ่น เพื่อป้องกันความเสี่ยงจากเพลิงไหม้ ไฟฟ้าช็อต, หรืออันตรายต่างๆ ที่อาจจะเกิดขึ้นได้ขณะใช้งาน คำแนะนำนี้ไม่ได้คลอมคลุมความเสี่ยงทั้งหมด ที่อาจจะเกิดขึ้น กรุณาติดต่อศูนย์บริการ หรือตัวแทนจำหน่าย สำหรับข้อสงสัยต่างๆของท่าน

สัญลักษณ์นี้คือ สัญลักษณ์เกี่ยวกับความปลอดภัย
สัญลักษณ์นี้ จะแจ้งเตือนให้ท่านทราบถึง อันตรายร้ายแรงที่อาจจะทำให้ท่านบาดเจ็บ หรือถึงแก่ชีวิตได้
ข้อความความปลอดภัยทั้งหมด จะใช้สัญลักษณ์ดังต่อไปนี้ "คำเตือน" หรือ "ข้อควรระวัง"

คำเตือน สัญลักษณ์นี้ จะแจ้งเตือนให้ท่านทรายถึง อันตายหรือการกระทำที่ไม่ปลอดภัย ซึ่งเป็นสาเหตุของการบาดเจ็บสาหัส หรือถึงแก่ชีวิตได้

ข้อควรระวัง สัญลักษณ์นี้ จะแจ้งเตือนให้ท่านทรายถึง อันตายหรือการกระทำที่ไม่ปลอดภัย ซึ่งเป็นสาเหตุของการบาดเจ็บ หรือเครื่องเสียหายได้

คำเตือน

- **ถอดปลั๊กทุกครั้ง เมื่อไม่ได้ใช้งาน หรือต้องการทำความสะอาดเครื่องดูดฝุ่น**
  การใช้งานไม่ถูกวิธี อาจจะทำให้ไฟฟ้าลัดวงจร หรือได้รับบาดเจ็บได้
- **ห้ามใช้เครื่องดูดฝุ่น ดูดสิ่งที่กำลังติดไฟ เช่น ก้นบุหรี่ หรือขี้เถ้าที่ยังติดไฟอยู่**
  ถ้าทำเช่นนั้น อาจจะทำให้ไฟฟ้าลัดวงจร หรือถึงแก่ชีวิตได้
- **ห้ามใช้เครื่องดูดฝุ่น ดูดวัตถุไวไฟต่างๆ เช่น เบนซิน, ทินเนอร์ (ไม่ว่าจะเป็นของเหลว หรือก๊าซ)**
  ถ้าทำเช่นนั้น อาจจะทำให้เสียชีวิต หรือได้รับบาดเจ็บได้
  ไอจากวัตถุไวไฟเหล่านี้ อาจจะทำให้เกิดเพลิงไหม้ หรือการระเบิดได้
- **ห้ามสัมผัสกับตัวปลั๊ก หรือตัวเครื่องในขณะที่มือเปียก**
  ถ้าทำเช่นนั้น อาจจะทำให้เสียชีวิต หรือไฟฟ้าช็อตได้
- **ห้ามถอดปลั๊ก โดยการดึงที่สายไฟ**
  ถ้าทำเช่นนั้น อาจจะเครื่องเสียหาย หรือไฟฟ้าช็อตได้
  ควรจับที่ตัวปลั๊ก
- **ให้ระวังเส้นผม, เสื้อผ้า, นิ้วมือ หรือส่วนต่างๆของร่างกาย เมื่อกำลังเคลื่อนย้ายอุปกรณ์ต่างๆ ในขณะที่เครื่องทำงาน โดยการดึงที่สายไฟ**
  การใช้งานไม่ถูกวิธี อาจจะทำให้ไฟฟ้าช็อต หรือได้รับบาดเจ็บได้
- **ห้ามเคลื่อนย้ายเครื่อง โดยการดึงสายไฟ หรือใช้สายไฟแทนด้ามจับ หรือดึงสายไฟในบริเวณที่เป็นมุม และเก็บสายไฟให้ห่างจากความร้อน**
  การใช้งานไม่ถูกวิธี อาจจะทำให้ไฟฟ้าช็อต, เพลิงไหม้, ได้รับบาดเจ็บได้ หรือตัวเครื่องเสียหายได้
- **ใช้งานเครื่องดูดฝุ่น และเก็บให้ห่างจากเด็กเล็ก**
  เพราะอาจจะทำให้เกิดอันตราย หรือเครื่องเสียหายได้
- **ห้ามใช้งานเครื่องดูดฝุ่น ถ้าสายไฟ หรือปลั๊กเสียหาย หรือไม่พร้อมใช้งาน และเก็บให้ห่างจากเด็กเล็ก**
  ถ้าสายไฟเสียหาย สายไฟที่จะเปลี่ยนต้องได้รับการรับรองจากศูนย์บริการแอลจี เพื่อหลีกเลี่ยงอันตรายที่อาจจะเกิดขึ้นได้
- **ห้ามใช้งานเครื่องดูดฝุ่น ในขณะที่เครื่องเปียกน้ำ**
  อาจจะทำให้ได้รับบาดเจ็บ หรือเครื่องเสียหายได้
  กรุณาติดต่อศูนย์บริการแอลจี สำหรับกรณีนี้ เพื่อหลีกเลี่ยงอันตรายต่างๆ ที่อาจจะเกิดขึ้น

คำเตือน

- **ห้ามใช้งานเครื่องดูดฝุ่น ถ้าชิ้นส่วนไม่ครบ หรือเสียหาย**
  เพราะอาจทำให้ได้รับบาดเจ็บ หรือเครื่องเสียหายได้ กรุณาติดต่อศูนย์บริการแอลจี เพื่อหลีกเลี่ยงอันตรายต่างๆ ที่อาจจะเกิดขึ้นได้
- **ห้ามต่อสายไฟ หรือเปลี่ยนสายไฟเครื่องดูดฝุ่น**
  เพราะอาจทำให้เกิดเพลิงไหม้ หรือเครื่องเสียหายได้
- **ใช้งานเครื่องดูดฝุ่นกับแรงดันไฟฟ้าที่เหมาะสม**
  ถ้าใช้กับแรงดันไฟฟ้าที่ไม่เหมาะสม อาจจะทำให้มอเตอร์เสียหาย และเกิดอันตรายกับผู้ใช้ได้ กรุณาดูแรงดันไฟฟ้าที่เหมาะสมที่ใต้เครื่องดูดฝุ่นของท่าน
- **ปิดเครื่องดูดฝุ่น ก่อนถอดปลั๊ก**
  การใช้งานไม่ถูกวิธี อาจจะทำให้ไฟฟ้าช็อต หรือได้รับบาดเจ็บได้
- **ห้ามเปลี่ยนปลั๊กเครื่องดูดฝุ่น ไม่ว่ากรณีใดก็ตาม**
  การใช้งานไม่ถูกวิธี อาจจะทำให้ไฟฟ้าลัดวงจร, เครื่องเสียหาย หรือได้รับบาดเจ็บได้ และอาจจะทำให้ถึงแก่ชีวิตได้ ถ้าเต้าเสียบได้ไม่มาตราฐาน กรุณาติดต่อช่างไฟฟ้าสำหรับการติดตั้งเต้าเสียบให้เหมาะสม
- **การซ่อมแซมเครื่องใช้ไฟฟ้า ต้องปฏิบัติโดยช่างผู้ชำนาญเท่านั้น**
  มิฉะนั้น อาจจะทำให้เกิดอันตรายร้ายแรงได้
- **ห้ามเสียบปลั๊ก ถ้าสวิตช์ยังไม่ได้ปิด**
  มิฉะนั้น ท่านอาจจะได้รับบาดเจ็บ หรือเครื่องเสียหายได้
- **เก็บเครื่องดูดฝุ่นให้ห่างจากเด็กเล็ก และเก็บสายไฟ อย่างระมัดระวัง**
  สายไฟจะถูกเก็บเข้าอย่างรวดเร็ว เมื่อท่านกดปุ่มเก็บสาย (ความเร็วในการเก็บสาย แตกต่างกันตามรุ่นเครื่องดูดฝุ่น)
- **ท่อดูดฝุ่นบางรุ่นสามารถควบคุมเครื่องได้ ซึ่งประกอบไปด้วยสายไฟ ห้ามใช้งานถ้าเกิดความเสียหาย**
  การใช้งานไม่ถูกวิธี อาจจะทำให้ถึงแก่ชีวิต หรือไฟฟ้าช็อตได้ (เฉพาะรุ่น)

THAI

คำแนะนำเพื่อความปลอดภัย

ข้อควรระวัง

- **ห้ามนำสิ่งของต่างๆ ใส่ในตัวเครื่องข้างใน**
  การใช้งานไม่ถูกวิธี อาจจะทำให้เครื่องเสียหายได้
- **ไม่ควรใช้งานเครื่องดูดฝุ่นดูดสิ่งที่มีขนาดใหญ่ เช่น ผ้า เป็นต้น เพราะจะทำให้แรงดูด และการระบายความร้อนลดลง**
  เพราะอาจจะทำให้เครื่องเสียหายได้
- **ห้ามใช้งานเครื่องดูดฝุ่น เมื่อไม่มีถังเก็บฝุ่น หรือแผ่นกรองฝุ่น**
  เพราะอาจจะทำให้เครื่องเสียหายได้
- **ห้ามใช้งานเครื่องดูดฝุ่น ดูดสิ่งที่แข็ง และแหลมคม เช่น เข็ม, คลิปติดกระดาษ เป็นต้น**
  สิ่งต่างๆเหล่านี้ จะทำให้เครื่อง หรือถังเก็บฝุ่นเสียหาย
- **ควรจัดเก็บเครื่องดูดฝุ่นในที่ร่ม**
  เก็บเครื่องดูดฝุ่นทุกครั้ง เมื่อใช้งานเสร็จ
- **เครื่องใช้ไฟฟ้านี้ ไม่ควรถูกใช้โดยเด็ก หรือบุคคลทีทุพลภาพ หรือขาดความรู้ ความเข้าใจในการใช้งาน เว้นแต่จะได้รับการอบรมจากผู้รู้ เพื่อให้ใช้เครื่องใช้ไฟฟ้า ได้อย่างถูกต้อง และเพื่อความปลอดภัยในการใช้งาน**
  เด็กควรจะมีผู้ดูแลอย่างใกล้ชิด เพื่อให้แน่ใจว่าจะไม่เล่นเครื่องดูดฝุ่น
- **ต้องใช้อะไหล่ หรือชิ้นส่วน ที่ได้รับการรับรองจากศูนย์บริการแอลจี เท่านั้น**
  การใช้งานไม่ถูกวิธี อาจจะทำให้เครื่องเสียหายได้
- **ควรใช้งานเครื่องดูดฝุ่นตามคู่มือการใช้งานนี้เท่านั้น**
  การใช้งานไม่ถูกวิธี อาจจะทำให้เครื่องเสียหาย หรือได้รับบาดเจ็บได้
- **เพื่อหลีกเลี่ยงการบาดเจ็บ และป้องกันเครื่องเสียหายจากความผิดพลาดในขณะใช้งาน ควรจะวางเครื่องดูดฝุ่นให้ติดพื้นเสมอ**
  การใช้งานไม่ถูกวิธี อาจจะได้รับบาดเจ็บ หรือเครื่องเสียหายได้
- **แผ่นกรองต่างๆของเครื่อง ต้องทำให้แห้งก่อนที่จะประกอบเข้าเครื่อง**
  การใช้งานไม่ถูกวิธี อาจจะทำให้เครื่องเสียหายได้
- **ห้ามใช้ไมโครเวฟ ในการทำให้แผ่นกรองแห้ง**
  การใช้งานไม่ถูกวิธี อาจจะทำให้เกิดเพลิงไหม้ได้
- **ห้ามใช้เครื่องอบผ้า ในการทำให้แผ่นกรองแห้ง**
  การใช้งานไม่ถูกวิธี อาจจะทำให้เกิดเพลิงไหม้ได้
- **ห้ามใช้เตาไฟ ในการทำให้แผ่นกรองแห้ง**
  การใช้งานไม่ถูกวิธี อาจจะทำให้เกิดเพลิงไหม้ได้
- **ควรทำความสะอาดถังเก็บฝุ่นเสมอ หลังจากที่ใช้ดูดพรม, แป้ง หรือทราย**
  สิ่งเหล้านี้ จะทำให้แผ่นกรองอุดตัน, แรงดูดตก และอาจจะสามารถทำให้เครื่องเสียหายได้
- **เมื่อต้องการเคลื่อนย้ายเครื่องดูดฝุ่น ไม่ควรจับที่ด้ามจับ บริเวณถังเก็บฝุ่น**
  เพราะตัวเครื่องอาจจะหลุดออกจากถัง ซึ่งอาจจะทำให้ได้รับบาดเจ็บ หรือเครื่องเสียหายได้ ท่านควรจะใช้ด้ามจับบริเวณตัวเครื่องสำการการเคลื่อนย้าย (เฉพาะรุ่น)

คำแนะนำเพื่อความปลอดภัย

⚠ ข้อควรระวัง

ระบบตรวจจับความร้อน

เครื่องดูดฝุ่นรุ่นนี้ จะมีระบบตรวจจับความร้อน สำหรับป้องกันเครื่องดูดฝุ่นในกรณีที่มอเตอร์ร้อนจัด ถ้าเครื่องดูดฝุ่นตัดการทำงานกระทันหัน ให้ปิดสวิตซ์ และถอดปลั๊กออก ตรวจเช็คเครื่องดูดฝุ่น เพื่อหาสาเหตุของการร้อนจัด เช่น ถังเก็บฝุ่นเต็ม, แผ่นกรองอุดตัน ถ้าเหล่านี้เป็นสาเหตุให้ท่านทำการจัดการ และรออย่างน้อย 30 นาที แล้วจึงใช้งานเครื่องดูดฝุ่นต่อ

THAI

Basic Parts

ชิ้นส่วนพื้นฐาน

Optional Parts

ชิ้นส่วนพิเศษ

- The different figure and quantity of the following part depend on the different models which youhave bought.
- ชิ้นส่วนพิเศษเหล่านี้ จะแตกต่างกันตามรุ่นที่ท่านซื้อ

Accessory

อปกรณ์เสริม

- These specifications are subject to change according to the agent / buyer's request.
- อุปกรณ์เหล่านี้ จะแตกต่างกันตามรุ่นที่ท่านซื้อ

1
3
2

4
4

4
7
6

8
9

10
11
12

13

14

17
16

23

24
18

25
21
20
19

26

27

28
22

29
22

30
②
①

31

Optional Parts
ชิ้นส่วนต่างๆ (เฉพาะรุ่น)

How to Use

Connecting the flexible hose

Push the end of the head **(1)** on the flexible hose **(2)** into the attachment point on the vacuum cleaner.

To remove the flexible hose from the vacuum cleaner, push the button **(3)** situated on the head, then pull upwards.

Assembling the tubes

(depending on model)

- **Metal tube (4)**
  - Fit together the tubes by twisting slightly.
- **Telescopic tube (6)**
  - Push spring latch **(7).**
  - Pull out tube to required length.
  - Release spring latch to lock.

Using the cleaning head and Accessory Nozzles (depending on model)

Fit the large cleaning head onto the end of the tube.

- **The 2 position head (8)** is equipped with a pedal **(9)** which allows you to alter its position according to the type of floor to be cleaned.
  Hard floor position (tiles, parquet floors...): Push the pedal to lower the brush.
  Carpet or rug position: Push the pedal to lift the brush up.
- **Crevice Tool (10)**

  For vacuuming in those normally inaccessible places i.e. reaching cobwebs, or down the side of a sofa!
- **Upholstery Nozzle (11)**

  For vacuuming upholstery, mattresses, etc. The thread collectrors help to pick up the threads and fluff.
- **Dusting brush (12)**

  For vacuuming picture frames furniture outlines, books and other uneven objects.

How to plug in and use

Pull out the mains lead to the desired length and plug into the socket.

Push the button **(13)** to start the vacuum cleaner. To stop it press the button **(13)** again.

⚠ **No liquid suction.**
Liquid suction can cause defect.

Adjusting the power level

(depending on model)

- The flexible hose handle **(16)** has a manual air flow regulator **(17)** which allows you to briefly reduce the suction level.

Carrying and storage

When you have switched off and unplugged the appliance, push the button **(14)** to automatically rewind the cord.

- Use stowage clip as shown when storing the cleaner **(18)**.

Emptying the dust tank

The cleaner is set to maximum power and the nozzle is off the floor. As below, if these things happen to your vacuum cleaner, please turn off the appliance, unplug it and remove hose. Take out the dust tank **(24)** and motor safety filter **(20)** from the cleaner. Then empty the dust tank **(19)** and clean the motor safety filter **(20)**.

- When the dust in the tank **(21)** reaches the maximum line.
- When a great deal of dust has clogged up the inner cover **(22)**.
- When the motor safety filter **(20)** is full of dust.

Wash the dust tank **(23)** with cold water. Dry fully in shade so that moisture is removed entirely.

⚠ **If after empting the dust tank the suction is low, clean the motor safety filter.**
Failure to do so could result in product damage.

Raising the dust tank

After turning off the appliance and unplug it, press the pushing button on the appliance and hold the tank handle, then raise the tank **(24)**.

Opening the dust tank

Please push the button **(25)** behind the tank, tank, then open the tank cover.

Fixing the dust tank

According to the arrow's direction **(26)**, please close the dust tank correctly and then put it in the vacuum cleaner.

Cleaning the motor safety filter

The motor safety filter is situated inside the appliance under the dust tank.
Each time that you clean the motor safety filter, we advise you to take out the motor safety filter **(27)**.

Wash it with cold water **(28)** and dry fully in shade so that moisture is removed entirely. And then replace it in the vacuum cleaner.

⚠ **Dry fully for more than 24 hours in shade.**

⚠ **Do not use vacuum cleaner without motor safety filter.**
Failure to do so could result in motor damage and weak suction.

What to do if your appliance does not work?

Check that the appliance is correctly plugged in and that the electrical socket is working.

What to do when the suction performance reduces?

- Stop the appliance and unplug it.
- Check that the tubes, flexible hose and cleaning tool are not blocked.
- Check dust in the tank does not reach the maximum line. Empty the dust tank if necessary.
- Check that the inner cover **(22)** is not clogged, Clean up it if necessary.
- Check that the motor safety filter **(20)** is not full of dust. Clean up it if necessary.

วิธีการใช้งาน

ต่อท่ออ่อน

เสียบหัวต่อ **(1)** ของท่ออ่อน **(2)** ที่ช่องเสียบบริเวณตัวเครื่องดูดฝุ่น

เมื่อต้องการถอดท่ออ่อน ให้กดที่ปุ่ม **(3)** บริเวณหัวของท่ออ่อน และดึงออก

ประกอบท่อต่างๆ ของเครื่องดูดฝุ่น (เฉพาะรุ่น)

ท่อดูด (4)

- ต่อท่อทั้ง อันเข้าด้วยกัน บิดเล็กน้อยให้แน่น

ท่อดูดแบบปรับความยาวได้ (6)

- จับบริเวณปุ่มล็อคสปริง **(7)**
- ดึงออกจนได้ความยาวที่ต้องการ
- ปล่อยปุ่มล็อคสปริง

การใช้งานหัวดูดต่างๆ (เฉพาะรุ่น)

ต่อหัวดูดกับท่อดูด

หัวดูดพื้นและพรม (8) จะมีแท่นเหยียบ **(9)** สำหรับปรับตามลักษณะของพื้นที่จะทำความสะอาด

พื้นแข็ง (พื้นกระเบื้อง, ปาร์เก้) เหยียบคันเหยียบให้ขนแปรงสั้นลง

พื้นพรม เหยียบคันเหยียบให้ขนแปรงยื่นออกมา

หัวดูดตามซอกมุม (10)

ใช้สำหรับพื้นที่ๆ หัวดูดปกติไม่สามารถเข้าถึงได้ เช่น หยากไย่บริเวณมุมเพดาน หรือซอกโซฟา เป็นต้น

หัวดูดสำหรับเบาะผ้า หรือเครื่องหนัง (11)

ใช้สำหรับดูดเบาะต่างๆ เช่นเบาะรถยนต์, โซฟาผ้า หรือเครื่องนอน โดยเส้นใยบริเวณหัวดูด จะช่วยให้การดูดมีประสิทธิภาพขึ้น

หัวดูดแบบแปรง (12)

ใช้สำหรับดูดกรอบรูป, ชั้นวางของ, หนังสือ หรือวัตถุรูปทรงต่างๆ เป็นต้น

การเสียบปลั๊ก และใช้งานเครื่องดูดฝุ่น

ดึงสายไฟจนได้ความยาวที่ต้องการ และเสียบปลั๊กเข้ากับเต้าเสียบ

กดปุ่มเปิดเครื่อง **(13)** และกดปุ่มเดิมซ้ำ เมื่อต้องการปิดเครื่อง

การปรับเปลี่ยนพลังดูด (เฉพาะรุ่น)

บรเวณด้ามจับของท่ออ่อน **(16)** จะมีปุ่มปรับพลังดูด **(17)** ทำให้ท่านสามารถเพิ่ม หรือลดพลังดูดได้

การเก็บเครื่องดูดฝุ่น

เมื่อท่านปิดเครื่อง และดึงปลั๊กออกแล้ว ให้ท่านกดปุ่ม **(14)** สายไฟจะถูกเก็บเข้าที่เองโดยอัตโนมัติ

ให้ใช้ช่องสำหรับยึดหัวดูดฝุ่น ในการจัดเก็บดังรูป **(18)**

การทำความสะอาดถังเก็บฝุ่น

เมื่อเปิดเครื่อง และพลังดูดถูกปรับไว้สูงสุด แต่เครื่องไม่ทำงานหรือพลังดูดต่ำ อาจจะมีสาเหตุดังนี้

- เมื่อฝุ่นในถังถึงเส้นบอกระดับสูงสุด **(21)**
- เมื่อมีฝุ่นอุดตัน บริเวณที่ครอบด้านในถัง **(22)**
- เมื่อมีฝุ่นอุดตัน บริเวณแผ่นกรองตรงมอเตอร์ **(20)**

ถ้ามีสิ่งเหล่านี้เกิดกับเครื่องดูดฝุ่นของท่าน กรุณาปิดเครื่อง ถอดปลั๊ก และท่อดูดออก ถอดถังเก็บฝุ่น **(24)** และแผ่นกรองตรงมอเตอร์ **(20)** ออกจากตัวเครื่อง จากนั้นเทฝุ่นในถังทิ้ง **(19)** และทำความสะอาดแผ่นกรองตรงมอเตอร์ **(20)** ล้างถังเก็บฝุ่นด้วยน้ำเย็น **(23)** และทิ้งไว้ให้แห้ง

ถ้าหลังจากทำความสะอาดถังเก็บฝุ่นแล้ว พลังดูดยังต่ำอยู่ ให้ทำความสะอาดแผ่นกรองตรงมอเตอร์

การใช้งานไม่ถูกวิธี อาจจะทำให้เครื่องเสียหายได้

การถอดถังเก็บฝุ่น

หลังจากปิดเครื่อง ถอดปลั๊กแล้ว ให้กดปุ่มที่ด้านบนของตัวเครื่อง จับที่ด้ามจับถังเก็บฝุ่น และดึงถังขึ้น **(24)**

การเปิดถังเก็บฝุ่น

กดที่ปุ่ม **(25)** ด้านหลังของถังเก็บฝุ่น และเปิดฝาครอบออก

การประกอบถังเก็บฝุ่น

ประกอบถังเก็บฝุ่นตามรูป **(26)** กรุณาปิดฝาครอบให้สนิท และใส่กลับไปในตัวเครื่องดูดฝุ่น

THAI

การทำความสะอาดแผ่นกรองตรงมอเตอร์

แผ่นกรองนี้จะอยู่ด้านในของตัวเครื่อง ใต้ถังเก็บฝุ่น เมื่อท่านต้องการทำความสะอาด ให้ถอดแผ่นกรองออก **(27)** ล้างแผ่นกรองด้วยน้ำเย็น **(28)** และทำให้แห้งสนิท จากนั้นใส่กลับเข้าที่เดิม

ห้ามใช้เครื่องดูดฝุ่น
โดยปราศจากแผ่นกรองตรงมอเตอร์
การใช้งานไม่ถูกวิธี อาจจะทำให้มอเตอร์เสียหาย และพลังดูดต่ำได้

จะทำอย่างไร? เมื่อเครื่องดูดฝุ่นไม่ทำงาน

ตรวจสอบปลั๊กไฟ และเต้าเสียบ ว่าอยู่ในสภาพพร้อมใช้งาน หรือมีกระแสไฟฟ้าหรือไม่

จะทำอย่างไร? เมื่อพลังดูดลดลง

- ปิดเครื่องดูดฝุ่น และถอดปลั๊กออก
- ตรวจสอบท่อดูด, ท่ออ่อน และทำความสะอาดอุปกรณ์ ไม่ให้มีสิ่งใดอุดตัน
- ตรวจสอบปริมาณฝุ่นในถัง ว่าฝุ่นอยู่ระดับเส้นสูงสุด หรือไม่ เทฝุ่นทิ้ง ถ้าจำเป็น
- ตรวจสอบที่ครอบด้านในถังเก็บฝุ่น **(22)** ไม่ให้มีสิ่งใดอุดตัน ทำความสะอาด ถ้าจำเป็น
- ตรวจสอบแผ่นกรองตรงมอเตอร์ **(20)** ไม่ให้มีฝุ่นอุดตัน ทำความสะอาด ถ้าจำเป็น

LG

Life's Good