LG
Life's Good

ENGLISH

OWNER'S MANUAL

NEW TYPE CYCLONE VACUUM CLEANER

This information contains important instructions for the safe use and maintenance of the vacuum cleaner. Especially, please read all of the information on page 4, 5, 6 for your safety. Please keep this manual in an easily accessible place and refer to it anytime.

VC42**NH***
VC42**NR***

MFL67607053

www.lg.com

Table of contents

Important safety instructions ..... **4~6**

How to use **7**

Assembling vacuum cleaner ..... 7~9

Operating vacuum cleaner ..... 10~11

Using carpet and floor nozzle / Hard Floor Nozzle 12

Using Hard Floor Nozzle / Turbine Nozzle 13

Using All Floor nozzle and mini turbine nozzle 14

Cleaning all floor nozzle 15

Using Turbine Nozzle 16

Cleaning Turbine nozzle 17

Using accessory nozzles ..... 18~19

Emptying dust tank 20

Cleaning dust tank 21

Cleaning filters and air guide tank 22

Cleaning exhaust filter 23

Assembling Tank Cover & Tank assembly 24

What to do if your vacuum cleaner does not work **25**

What to do when suction power decreases **25**

IMPORTANT SAFETY INSTRUCTIONS

Read and follow all instructions before using your vacuum cleaner to prevent the risk of fire,electric shock, personal injury,or damage when using the vacuum cleaner.This guide do not cover all possible conditions that may occur.Always contact your service agent or manufacturer about problems that you do not understand. This appliance complies with the following EC Directives:-2006/95/EC Low Voltage Directive-2004/108/EC EMC Directive

This is the safety alert symbol.
This symbol alerts you to potential hazards that can kill or hurt you and others.
All safety messages will follow the safety alert symbol and either the word “WARNING” or “CAUTION.”
These words mean:

WARNING This symbol will alert you to hazards or unsafe practices which could cause serious bodily harm or death.

CAUTION This symbol will alert you to hazards or unsafe practices which could cause bodily injury or property damage.

WARNING

- **Do not use the vacuum cleaner If the power cord or plug is damaged or faulty.**
  If the power cord is damaged,it must be replaced by an approved LG Electronics Service Agent to avoid a hazard.
- **This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.**
  Children should be supervised to ensure that they do not play with the appliance.
- **This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved. Children shall not play with the appliance. Cleaning and user maintenance shall not be made by children without supervision.**

IMPORTANT SAFETY INSTRUCTIONS

⚠ WARNING

- **Disconnect electrical supply before servicing or cleaning the unit or when cleaner is not in use.**
  Failure to do so could result in electrical shock or personal injury.
- **Do not vacuum liquid,blade,gesso,substances,or small particles like cement,burning or smoking such as cigarettes,or hot ashes in cleaning.**
- **Do not vacuum flammable or explosive substances such as gasoline, benzene, thinners, propane (liquids or gases).**
  The fumes from these substances can create a fire hazard or explosion. Doing so could result in death or personal injury.
- **Do not handle plug or vacuum cleaner with wet hands.**
  Doing so could result in death or electrical shock.
- **Do not unplug by pulling on cord.**
  Doing so could result in product damage or electrical shock. To unplug, grasp the plug, not the cord.
- **Keep hair, loose clothing, fingers, and all parts of the body away from openings and moving parts.**
  Failure to do so could result in electrical shock or personal injury.
- **Do not pull or carry by cord, use cord as a handle, close a door on cord, or pull cord around sharp edges or corners. Do not run vacuum cleaner over cord. Keep cord away from heated surfaces.**
  Failure to do so could result in electrical shock or personal injury or fire or product damage.
- **Do not allow to be used as toy. Close attention is necessary when used by or near children.**
  Personal injury or product damage could result.
- **Do not use vacuum cleaner if it has been under water.**
  Personal injury or product damage could result. In these cases, contact LG Electronics Service Agent to avoid hazard.
- **Do not continue to vacuum if any parts appear missing or damaged.**
  Personal injury or product damage could result. In these cases, contact LG Electronics Service Agent to avoid hazard.
- **Do not use an extension cord with this vacuum cleaner**
  Fire hazard or product damage could result.
- **Using proper voltage.**
  Using improper voltage may result in damage to the motor and possible injury to the user. Proper voltage is listed on the bottom of vacuum cleaner.
- **Turn off all controls before unplugging.**
  Failure to do so could result in electrical shock or personal injury.
- **Do not change the plug in any way.**
  Failure to do so could result in electrical shock or personal injury or product damage. Doing so result in death. If plug does not fit, contact a qualified electrician to install the proper outlet.
- **Repairs to electrical appliances may only be performed by qualified service engineers.**
  Improper repairs may lead to serious hazards for the user.
- **Do not plug in if control knob is not in OFF position.**
  Personal injury or product damage could result.
  (Depending on model)
- **Keep children away and beware of obstructions when rewinding the cord to prevent personal injury**
  The cord moves rapidly when rewinding.(Depending on model)
- **The hose contains electrical wires. Do not use it if it is damaged, cut or punctured.**
  Failure to do so could result in death,or electrical shock.
  (Depending on model)

IMPORTANT SAFETY INSTRUCTIONS

⚠ CAUTION

- **Do not put any objects into openings.**
  Failure to do so could result in product damage.
- **Do not use with any opening blocked: keep free of dust, lint, hair, and anything that may reduce air flow.**
  Failure to do so could result in product damage.
- **Do not use vacuum cleaner without dust tank and/or filters in place.**
  Failure to do so could result in product damage.
- **Do not use vacuum cleaner to pick up sharp hard objects, small toys, pins, paper clips, etc.**
  They may damage the cleaner or dust tank .
- **Store the vacuum cleaner indoors.**
  Put the vacuum cleaner away after use to prevent tripping over it.
- **Only use parts produced or recommended by LG Electronics Service Agents.**
  Failure to do so could result in product damage.
- **Use only as described in this manual. Use only with LG recommended or approved attachments and accessories.**
  Failure to do so could result in personal injury or product damage.
- **To avoid personal injury and to prevent the machine from falling when cleaning stairs, always place it at the bottom of stairs.**
  Failure to do so could result in personal injury or product damage.
- **Use accessory nozzles in sofa mode.**
  Failure to do so could result in product damage.
- **Make sure the filters (exhaust filter and motor safety filter) are completely dry before replacing in the machine.**
  Failure to do so could result in product damage.
- **Do not dry the filter in an oven or microwave.**
  Failure to do so could result in fire hazard.
- **Do not dry the filter in a clothes dryer.**
  Failure to do so could result in fire hazard.
- **Do not dry near an open flame.**
  Failure to do so could result in fire hazard.
- **Always clean the dust tank after vacuuming carpet cleaners or fresheners, powders and fine dust.**
  These products clog the filters,reduce airflow and can cause damage to the cleaner. Failure to clean the dust tank could cause permanent damage to the cleaner.
  (Depending on model)
- **Don 't grasp the tank handle when you are moving the vacuum cleaner.**
  The vacuum cleaner's body may fall when separating tank and body. Personal injury or product damage could result. **You should grasp the carrier handle** when you are moving the vacuum cleaner.(Depending on model)
- **If after emptying the dust tank the indicator light is on(red), clean the dust tank.**
  Failure to do so could result in product damage.
  (Depending on model)

Thermal protector :
This vacuum cleaner has a special thermostat that protects the vacuum cleaner in case of motor overheating. If the vacuum cleaner suddenly shuts off, turn off the switch and unplug the vacuum cleaner. Check the vacuum cleaner for possible source of overheating such as a full dust tank, a blocked hose or clogged filter. If these conditions are found, fix them and wait at least 30 minutes before attempting to use the vacuum cleaner. After the 30 minute period, plug the vacuum cleaner back in and turn on the switch. If the vacuum cleaner still does not run, contact a qualified LG authorised Service Agent.

How to use Assembling vacuum cleaner

❶ Carpet and Floor nozzle (depending on model)

Push the nozzle into the telescopic pipe.

❷ Telescopic pipe (depending on model)

- Push telescopic pipe firmly into hose handle.
- Grasp the spring latch to expand.
- Pull out the pipe to desired length.

⚠ **WARNING!**
No suction liquids.
Suction liquids can cause defects.

How to use Assembling vacuum cleaner

❶ Carpet and Floor nozzle (depending on model)

Push the nozzle into the telescopic pipe.

❷ Telescopic pipe (depending on model)

- Push telescopic pipe firmly into hose handle.
- Grasp the spring latch to expand.
- Pull out the pipe to desired length.

⚠ **WARNING!**
No suction liquids.
Suction liquids can cause defects.

❸ Connecting the hose to the vacuum cleaner

Push the fitting pipe on the flexible hose into the attachment point on the vacuum cleaner.
To remove the flexible hose from the vacuum cleaner, press the button situated on the fitting pipe, then pull the fitting pipe out of the vacuum cleaner.

How to use Operating vacuum cleaner

❶ How to operate (Hose slide type)

- Pull out the power cord to the desired length and plug into the socket.
- Place the control knob of the hose handle to the required position.
- To turn off, slide control knob to OFF position.
- Press the cord reel button to rewind the power cord after use.

❶ How to operate (Rotary type)

- Pull out the power cord to the desired length and plug into the socket.
- Slide the rotary control knob to adjust the suction level.
- The flexible hose handle has a manual air flow regulator which allows you to briefly reduce the suction level.
- Press the cord reel button to rewind the power cord after use.

❷

❸

❷ Park mode

- To store during vacuuming, for example to move a small piece of furniture or a rug, use park mode to support the flexible hose and nozzle.
  - Slide the hook on the nozzle into the slot on the rear side of vacuum cleaner.

❸ Storage

- When you have switched off and unplugged the vacuum cleaner, press the cord reel button to automatically rewind the cord.
- You can store your vacuum cleaner in a vertical position by sliding the hook on the nozzle into the slot on the underside of the vacuum cleaner.

How to use

Using carpet and floor nozzle / Hard Floor Nozzle

❶ Carpet and floor nozzle (depending on model)

- **The 2 position nozzle**
  This is equipped with a pedal which allows you to alter its position according to the type of floor to be cleaned.
- **Carpet or rug position**
  Press the pedal to lift the brush up.
- **Hard floor position** (tiles, parquets floor)
  Press the pedal to lower brush.

❷ Hard Floor Nozzle (depending on model)

- Efficient cleaning of hard floors (wood, linoleum, etc)

❸ Hard Floor Nozzle (depending on model)

- You can perform cleaning at any place like corner or crevice since revolution is free.

❹ Turbine Nozzle (depending on model)

- Cleaning turbine brush nozzle.
- Press the button on the rear side of the nozzle to separate the air cover.
- Use the dusting brush & crevice tool to vacuum clean the brush and fan.

❺ All Floor nozzle (depending on model)

- **The 2 position nozzle**
  This is equipped with a pedal which allows you to alter its position according to the type of floor to be cleaned.
- **Carpet or rug position** Press the pedal (⏢), then brush will rotate
- **Hard floor position** Press the pedal (△), then brush will stop rotating.

❻ Mini turbine nozzle (optional)

- Mini turbine is used for stairs and other hard to reach places.
- To clean the mini turbine nozzle, remove the nozzle cover : Remove 2 screws on the bottom and take mini turbine nozzle cover off as shown.
- Frequently clean and remove hair, string, and lint build-up in the brush area. Failure to do so could damage to mini turbine nozzle.

Cleaning All Floor nozzle

- Open the cover by pulling the hook.
- Clean the hole and brush of the nozzle.

How to use Cleaning all floor nozzle

⚠ CAUTION

Personal injury hazard. Always unplug the vacuum cleaner before cleaning. Failure to do so could result in personal injury.

- Push the lever outside.
- Open the cover and put up the brush.
  ⚠ Do not touch the brush because the brush is so hot after turning off the vacuum cleaner.
- Clean the brush and nozzle.
- Push the brush into the projection, put down the brush and close the cover.
- Push the lever inside.

⚠ CAUTION

- Do not block up the hole by hand or another object (paper, fabric, stockings, etc) when open the cover.
- Do not touch the brush when nozzle is overturned.

6 Turbine Nozzle (depending on model)

- Frequently clean and remove hair, string, and lint build-up in the brush area. Failure to do so could damage to mini turbine nozzle.

How to use Cleaning Turbine Nozzle

⚠ CAUTION
Personal injury hazard. Always unplug the vacuum cleaner before cleaning. Failure to do so could result in personal injury.

❶ Push the lever outside.

❷ Open the cover and put up the brush.
⚠ Do not touch the brush because the brush is so hot after turning off the vacuum cleaner.

❸ Clean the brush and nozzle.

❹ Push the brush into the projection, put down the brush and close the cover.

❺ Push the lever inside.

⚠ CAUTION
- Do not block up the hole by hand or another object (paper, fabric, stockings, etc) when open the cover.
- Do not touch the brush when nozzle is overturned.

How to use Using accessory nozzles

❻ Crevice Tool(depending on model)

Crevice tool is for vacuuming in those normally hard-to-reach places such as reaching cobwebs or between the cushions of a sofa.

❼ Upholstery Nozzle(depending on model)

Upholstery nozzle is for vacuuming upholstery, mattresses etc.

❽ Dusting Brush (depending on model)

Dusting brush is for vacuuming picture frames, furniture frames, books and other irregular surfaces.

NOTICE

Use accessory in the sofa mode.

How to use Using accessory nozzles

⑪ Crevice Tool(depending on model)

Crevice tool is for vacuuming in those normally hard-to-reach places such as reaching cobwebs or between the cushions of a sofa.

⑫ Upholstery Nozzle(depending on model)

Upholstery nozzle is for vacuuming upholstery, mattresses etc.

⑬ Dusting Brush (depending on model)

Dusting brush is for vacuuming picture frames, furniture frames, books and other irregular surfaces.

How to use Emptying dust tank

-When the dust in dust tank reaches the maximum line.

• Grasp the handle of the tank and then press the tank separation button.

Moving the vacuum cleaner

• Don't grasp the tank handle when you are moving the vacuum cleaner. The vacuum cleaner's body may fall when separating tank and body. You should grasp the carrier handle when you are moving the vacuum cleaner.

Cleaning the dust tank.
• Open the tank cap.
• Wash both parts with soft material.
Gently rinse both parts under a cold running tap.

NOTICE

If filters are damaged, do not use them.
In this cases, contact LG Electronics Service Agent.

How to use Cleaning dust tank

• Grasp the handle of the tank and then press the tank separation button.

Push button and pull out dust tank.
Raise dust tank cap.
Dry fully in shade so that moisture is entirely removed.

NOTICE

If suction power decreases after cleaning dust tank, clean air filter and motor safety filter. ➡ Next page

How to use Cleaning filters and air guide tank

If suction power is decreased after cleaning dust tank, clean air filter and motor safety filter.
Air filter and motor safety filter are located at the bottom of the dust tank as above.

- Open the air filter cover by pulling the air filter cover lever and take out air filter and a motor safety filter
- Separate the parts
- Wash air filter and motor safety filter with water.
- Do not wash filters with hot water.
- Dry fully in shade so that moisture is entirely removed.
- Air filter and motor safety filter should be cleaned as above.

⚠ WARNING!

Gently rinse both parts separately under a cold running tap until the water runs clear.
Do not use detergent or a washing machine or dishwasher.
Wash filters at least once a month.
Dry fully over than 24 hrs in shade.

How to use Cleaning exhaust filter

- The exhaust filter is a reusable HEPA filter.
- To change the exhaust filter, remove the filter cover on the body by release hook.
- Pull out the exhaust filter.
- Dust off filter.
- The exhaust filter should be cleaned at least once a year.

How to use Assembling Tank Cover & Tank assembly

① Set cover rib on handle hole.
② Press tank cover.

Slide the tank on product to match the tank ribs to groove of body.

If suction power is decreased after re-assemble, check dust tank assembled correctly.
• Check the guide rib whether it is right in tank groove.
• If guide rib is not put in tank hole, re-assemble dust tank in parallel.

What to do if your vacuum cleaner does not work

Check that the vacuum cleaner is plugged in correctly and that the electrical socket is working.

What to do when suction power decreases

- Turn off the vacuum cleaner and unplug it.
- Check the telescopic pipe, flexible hose and cleaning tool for blockages or obstructions. Check that the dust tank is not full. Empty if necessary.
- Check that the exhaust filter is not clogged. Clean the exhaust filter if necessary.
- Check that the air filter and the motor safety filter are not clogged. Clean the them if necessary.
- Check the inside of the dust separator.Clean the inside of the dust separator if necessary.

Note

הוראות

מה לעשות במקרה ששואב האבק אינו פועל

בדקו ששואב האבק מחובר לחשמל כהלכה וששקע החשמל תקין.

מה לעשות במקרה שעוצמת השאיבה פוחתת

- כבו את שואב האבק ונתקו אותו מהחשמל.
- בדקו אם הצינור הטלסקופי, הצינור הגמיש ואביזר הניקוי סתומים או חסומים.
- בדקו אם מכל האבק מלא. במקרה הצורך, רוקנו אותו.
- בדקו אם מסנן הפליטה סתום. במקרה הצורך, נקו את מסנן הפליטה.
- בדקו שמסנן האוויר ומסנן בטיחות המנוע אינם סתומים. במקרה הצורך, נקו אותם.
- בדקו את החלק הפנימי של מפריד האבק. נקו את החלק הפנימי של מפריד האבק, במקרה הצורך.

הרכבת מיכל ומכסה מיכל

① אחזו בידית המיכל ולאחר מכן לחצו על לחצן הפרדת המיכל
② לחץ על מכסה המיכל

החלק את המיכל אל תוך גוף המוצר בהתאמה לזיזים

אם עוצמת השאיבה פוחתת לאחר הרכבה מחדש, בדקו שמיכל האבק מותקן נכון
בדוק האם המיכל ממוקם כראוי על המסילות
אם הזיזים לא הוכנסו לחורי המיכל יש להתקין מחדש

- מסנן הפל'יטה הוא מסנן HEPA שניתן ל'שטוף ול'עשות בו שימוש חוזר .
- כדי ל'התל'יף את מסנן הפל'יטה, הסירו את מכסה המסנן על' הגוף על' ידי שחרור הוו .
- משכו החוצה את מסנן הפל'יטה .
- נערו את המסנן כדי ל'הסיר אבק . (אין ל'נקות את המסנן עם מים)
- יש ל'נקות את מסנן הפל'יטה ל'פחות פעם בשנה .

ניקוי מסננים ומיכל מסנן אוויר

אזהרה!

שטפו בעדינות את שני החלקים בנפרד תחת ברז מיקרים זורמים עד אשר מי השטיפה יהיו נקיים .

אין להשתמש בתכשיר **ניקוי או לנקות בסכוות כביסה או במדיח כלים** .

יש לנקות את המסנן לפחות פעם בחודש

נגב לגמרי בצל למשך מעל ל- 24 שעות.

אם כוח השאיבה פוחת ל"אחר ניקוי מיכל" האבק, נקו את מסנן האוויר ומסנן בטיחות המנוע .

- מסנן האוויר ומסנן בטיחות המנוע נמצאים בתא"ק המרכזי של" שואב האבק בתמונות ל"על" .
- פתחו את מכסה מסנן האוויר על" ידי משיכת המנוף של" המכסה , ומשכו את המסנן החוצה .
- הפרידו את התא"קים .
- שטפו את מסנן האוויר ומסנן בטיחות המנוע תחת ברז מים .
- אין ל"שטוף את המסננים עם מים חמים .
- הניחו ל"מסננים ל"התייבש במקום מוצל" עד ל"יבוש מוחל"ט .
- יש ל"נקות את מסנן האוויר ומסנן בטיחות המנוע במקרה ל"על" .

אופן השימוש ניקוי מיכל האבק

• אחזו בידית המכל ולאחר מכן לחצו על לחצן הפרדת המכל.

פתחו את המכסה על ידי לחיצת הלחצן ומשכו את מיכל האבק החוצה .

הרימו את מכסה מיכל האבק .

הניחו למיכל האבק להתייבש במקום מוצל עד ליבוש מוחלט .

חשוב

אם כוח השאיבה פוחת לאחר ניקוי מיכל האבק, נקו את מסנן האוויר ומסנן בטיחות המנוע . ← הדף הבא .

- **כאשר רמת מיכל האבק מגיעה לקו מקסימום (MAX)**
- אחזו בידית המכל ולאחר מכן לחצו על לחצן הפרדת המכל.

משכו החוצה

הזזת שואב האבק

- **אין** לאחוז בידית המכל להזזת שואב האבק.
  בעת הפרדת המכל מגוף השואב, גוף השואב עלול ליפול.
  להזזת שואב האבק, **יש** לאחוז בידית הנשיאה.

חשוב

אם המסננים ניזוקים, חל איסור להשתמש בהם.
במקרה זה, התקשרו לסוכן שירות של LG Electronics .

ידית המיכל
ניקוי " מיכל " האבק

- פתחו את מכסה המיכל .
- נקו את שני התל"קים עם ספוג או מטל"ית רכה .
- שטפו בעדינות את שני התל"קים תחת ברז מים קרים זורמים .

פייה לניקוי פינות

פייה לניקוי ריפוד

מברשת אבק

⓫ פייה ל'ניקוי פינות

פייה ל'ניקוי פינות ל'שאיבה במקומות שהגי שה אל'יהם קשה בדרך כל'ל', כגון קורי עכביש או בין כריות הספה .

⓬ פייה ל'ניקוי ריפוד

פייה ל'ניקוי ריפוד ל'שאיבת ריפוד, מזרוני ם וכדומה .

⓭ מברשת אבק

מברשת אבק ל'שאיבת מסגרות ש'ל' תמונות, רהיטים, ספרים ומשטחים ח ריגים אחרים .

אופן השימוש שימוש באביזרי הפיות

פייה לניקוי פינות

פייה לניקוי ריפוד

מברשת אבק

8 פייה ל'ניקוי פינות

פייה ל'ניקוי פינות ל'שאיבה במקומות שהגי שה אל'יהם קשה בדרך כל'ל', כגון קורי עכביש או בין כריות הספה .

9 פייה ל'ניקוי ריפוד

פייה ל'ניקוי ריפוד ל'שאיבת ריפוד, מזרוני ם וכדומה .

10 מברשת אבק

מברשת אבק ל'שאיבת מסגרות ע"ל' תמונות, רהיטים, ספרים ומשטחים ח ריגים אחרים .

חשוב

השתמשו באביזרי הפיות במודה של ספה .

אופן השימוש פיית טורבינה לניקוי

⚠ זהירות

סיכון לפגיעה קשה . יש לנתק את השואב מאספקת החשמל לפני ניקוי. אי מילוי הוראה זו עלולה להסתיים בפציעה

- יש לנקות את הפייה והמברשת
- פתחו את מכסה שואב האבק והרימו את המברשת.

⚠ אין לגעת במברשת האבק לאחר כיבוי שואב האבק עקב התחממות המברשת בזמן פעולה.

- דחפו את הלשונית החוצה
- הכנס את המברשת לתוך החריצים הורידו את המברשת וסגרו את המכסה
- דחפו את הלשונית פנימה

⚠ זהירות

- **אין לחסום את החור באמצעות היד או כל חפץ אחר (נייר, בד וכו') כאשר פותחים את המכסה.**
- **אין לגעת במברשת כאשר הפייה הפוכה.**

7 פיית טורבינה (בהתאם לדגם)

נקו והסירו לעיתים קרובות הצטברות של שיער,
חוטים ומוך באזור המברשת
אי מילוי הוראה זו עלולה לגרום לנזק לפיית טורבינה מיני.

אופן השימוש

פייה לניקוי כל סוגי הרצפות

⚠ זהירות

סיכון לפגיעה קשה . יש לנתק את השואב מאספקת החשמל לפני ניקוי. אי מילוי הוראה זו עלולה להסתיים בפציעה

- יש לנקות את הפייה והמברשת
- הכנס את המברשת לתוך החריצים הורידו את המברשת וסגרו את המכסה
- פתחו את מכסה שואב האבק והרימו את המברשת.

⚠ אין לגעת במברשת האבק לאחר כיבוי שואב האבק עקב התחממות המברשת בזמן פעולה.

- דחפו את הלשונית פנימה
- דחפו את הלשונית החוצה

⚠ זהירות

- **אין לחסום את החור באמצעות היד או כל חפץ אחר (נייר, בד וכו') כאשר פותחים את המכסה.**
- **אין לגעת במברשת כאשר הפייה הפוכה.**

אופן השימוש

השתמש זרבובית עבור כל הקומות ואת זרבובית טורבינה קטנה

5 פייה לכל סוגי הרצפות (בהתאם לדגם)

- **הפייה הדו-מצבית**
  פייה זו מצוידת בדוושה שמאפשרת לשנות את מצבה, בהתאם לסוג הרצפה שיש לנקות.
- **מצב שטיח או מרבד**
  לחצו על הדוושה (⏢) כדי שהמברשת תסתובב
- **מצב רצפה קשה**
  לחצו על הדוושה (⏢) כדי שהמברשת תפסיק להסתובב

לנקות את זרבובית עבור כל הקומות

- למשוך את הקרס כדי לפתוח את העטיפה.
- ניתן לנקות את החור ואת המברשת של הזרבובית.

6 זרבובית טורבינת קטנים (בהתאם לדגם)

- טורבינה קטנה עבור המדרגות שטחים קטנים אחרים.
- אם אתה רוצה לנקות את זרבובית טורבינה קטנה, אתה צריך להסיר את העטיפה של הזרבובית הראשון: אתה צריך להסיר את 2 ברגים בתחתית, ולהסיר את הכיסוי של הזרבובית טורבינת פי באיור.
- לעתים קרובות אתה צריך לנקות את להסיר שיער, המיתרים אשפה מוך באזור צחצוח. אחרת את הזרבובית טורבינת קטן יכול להיות פגום.

ניקוי הפייה המסתובבת

❸ זרבובית עבור רצפות קשה (בהתאם לדגם)

ניתן ל"בצע ניקוי במקום כגון פינה כי סיבוב פיית השאיבה הוא בחופשיות .

❹ פייה מסתובבת (בהתאם לדגם)

- ניקוי פיית המברשת המסתובבת .
- ל"חצו על" ת"ל"חצן בצד האחורי על" הפייה, כדי ל"הפריד את מכסה האוויר .
- השתמשו במברשת האבק ובפייה ל"ניקוי פינות כדי ל"ש אוב ול"נקות את המברשת והמאוורר .

❶ פיית שטיחים ורצפה (בהתאם לדגם)

- **הפייה הדו-מצבית**
  פייה זו מצוידת בדוושה שמאפשרת לשנות את מצבה, בהתאם לסוג הרצפה שיש לנקות.
- **מצב רצפה קשה**
  (מרצפות, רצפת פרקט וכדומה).
  ל'חצו על' הדוושה כדי ל'הוריד את המברשת.
- **מצב שטיח או מרבד.**
  ל'חצו על' הדוושה כדי ל'הרים את המברשת.

❷ זרבובית עבור רצפות קשה (בהתאם לדגם)

- ניקוי יעיל של רצפות קשה (כגון עץ, לינוליאום וכן הלאה)

❷ מצב חנייה

• לפסקות קצרות במרחק השאיבה, לדוגמה, כדי להזיז רהיט קטן או מרבד, השתמשו **במצב** החנייה על מנת לתמוך בצינור ובפייה.

- התליקו את הוו שנמצא בפייה לתוך החריץ שבתלקו האחורי של שואב האבק.

❸ אחסון

• לאחר כיבוי שואב האבק וניתוקו מהחשמל, לחצו על לחצן איסוף הכבל כדי לגלגל חזרה את הכבל אוטומטית.

• ניתן לאחסן את שואב האבק במצב אנכי על ידי הכנסת הוו שעל הפייה לתוך החריץ שבתלק התחתון של שואב האבק.

אופן השימוש הפעל"ת שואב האבק

1 אופן ההפעל"ה
(דגם הפעלה מהידית)

- **משכו את כבל" החשמל" ל"אורך הרצוי ותקעו אותו בשקע החשמל" .**
- אתה יכול ללחוץ על לחצן ההפעלה כדי להפעיל את שואב האבק.
- אתה יכול להחליק את הידית שליטה רוטרי לשנות את כוח היניקה.
- ידית צינור גמיש בעל וסת עבור זרימת אוויר ואתה יכול לצמצם את כוח היניקה.
- אתה יכול ללחוץ על כפתור סליל חוט כדי להריץ לאחור את כבלי החשמל.

1 אופן ההפעל"ה
(דגם עם וסת עוצמת שאיבה)

- **משכו את כבל" החשמל" ל"אורך הרצוי ותקעו אותו בשקע החשמל" .**
- דחפו את מתג בקרת העוצמה על" ידית הצינור ל"כיוון המצב הרצוי .
- כדי ל"כבות, דחפו את מתג בקרת העוצמה ל"מצב OFF .
- ל"חצו על" ל"חצן איסוף הכבל" כדי ל"גל"גל" חזרה את כבל" החשמל" ל"אחר השימוש .

אופן השימוש הרכבת שואב האבק

(בהתאם לדגם)

❶ פייה ל'ניקוי שטיח ורצפה

דחפו את הפייה ל'תוך הצינור הטל'סקופי.

❷ צינור טל'סקופי

- דחפו את הצינור הטל'סקופי ל'תוך ידית הצינור בחוזקה.
- חפסו את החפס הקפיצי.
- משכו את הצינור ל'אורך הרצוי.

3 חיבור הצינור ל"שואב האבק

- דחפו את קצה הראש ע"ל הצינור הגמיש ל"תוך נקודת החיבור שבשואב האבק .
- כדי ל"הסיר את הצינור הגמיש משואב האבק, ל"חצו ע"ל ת"ל"חצן שנמצא בראש ע"ל הצינור הגמיש, ול"אחר מכן משכו את הראש מתוך שואב האבק .

אזהרה

אין לשאוב נוזלים.
שאיבת נוזלים עלולה לגרום נזק.

אופן השימוש הרכבת שואב האבק

❶ פייה ל'ניקוי שטיח ורצפה

דחפו את הפייה ל'תוך הצינור הטל'סקופי.

❷ צינור טל'סקופי

- דחפו את הצינור הטל'סקופי ל'תוך ידית הצינור בחוזקה.
- תפסו את התפס הקפיצי.
- משכו את הצינור ל'אורך הרצוי.

אזהרה

אין לשאוב נוזלים.
יש איסור מוחלט לשאוב נוזל מכל סוג שהוא
הדבר יגרום לנזק בלתי הפיך לשואב
ונזק זה לא יכלל במסגרת באחריות

הוראות בטיחות חשובות

! זהירות

- **יש להשתמש באביזרי הפיות במצב שאיבת ספות (Sofa Mode) .**

  אי ביצוע הוראה זו עלול לגרום לנזק למכשיר .

- **יש להבטיח שהמסנים (מסנן הפליטה ומסנן בטיחות המנוע) יבשים לגמרי לפני שמחזירים אותם בחזרה לשואב האבק .**

  אי ביצוע הוראה זו עלול לגרום לנזק למכשיר.

- **אסור ליבש את המסנן בתנור או במיקרוגל .**

  אי ביצוע הוראה זו עלול לגרום לסכנת אש.

- **אסור ליבש את המסנן במכונת ייבוש .**

  אי ביצוע הוראה זו עלול לגרום לסכנת אש .

- **אסור ליבש את המסנן ליד אש .**

  אי ביצוע הוראה זו עלול לגרום לסכנת אש .

- **אין לאחוז בידית המיכל כאשר מעבירים את שואב האבק .**

  גוף השואב עלול ליפול כאשר מפרידים את המיכל והגוף.

  אי ביצוע הוראה זו עלול לגרום לפציעה אישית או נזק למכשיר.

  יש לאחוז בידית נשיאה כאשר מעבירים את שואב האבק .

  (בהתאם לדגם)

- **אם אחרי התרוקנות מיכל האבק, מחוון מצב מיכל האבק מראה אדום, נקו את מיכל האבק .**

  אי ביצוע הוראה זו עלול לגרום לנזק למכשיר .

  (בהתאם לדגם)

- **אל תניחו חפצים כלשהם בתוך הפתחים .**

  אי ביצוע הוראה זו עלול לגרום לנזק למכשיר .

- **אל תשתמשו כאשר אחד מן הפתחים חסום . שמרו על הפתחים מפני אבק, סוך, שיער או כל העלול להפחית את זרימת האוויר .**

  אי ביצוע הוראה זו עלול לגרום לנזק למכשיר .

- **אל תשתמשו בשואב האבק ללא מיכל אבק ו / או מסנן במקומם .**

  אי ביצוע הוראה זו עלול לגרום לנזק למכשיר .

- **אל תשתמשו בשואב האבק כדי לשאוב חפצים חדים וקשים, צעצועים קטנים, סיכות, מהדקים וכדי .**

  הם עלולים לגרום לנזק למכשיר או מיכל האבק .

- **אחסנו את שואב האבק בתוך הבית .**

  שמרו על שואב האבק הרחק מהדרך אחרי שימוש כדי למנוע תאונות .

- **שואב האבק הזה אינו מיועד לשימושם של ילדים או של אנשים מוגבלים ללא השגחה .**

  אי ביצוע הוראה זו עלול לגרום לפציעה אישית או נזק למכשיר.

- **יש להשתמש אך ורק בחלקים המיוצרים או מומלצים לשימוש על ידי סוכני השירות של LG Electronics .**

  אי ביצוע הוראה זו עלול לגרום לנזק למכשיר .

- **יש להשתמש בשואב האבק אך ורק בהתאם למחואר בחוברת זו . יש להשתמש אך ורק באביזרים המומלצים או מאושרים על ידי LG .**

  אי ביצוע הוראה זו עלול לגרום לפציעה אישית או נזק למכשיר.

- **למניעת פציעה אישית וסכנת נפילה של שואב האבק בעת ניקוי מדרגות, הציבו את שואב האבק במדרגה נמוכה ולשאוב את המדרגות שמעליו .**

  אי ביצוע הוראה זו עלול לגרום לפציעה אישית או נזק למכשיר.

מתג ניתוק תרמי :

שואב האבק הזה מצויד במתג ניתוק תרמי המיועד להגן עליו במקרה של התחממות יתר של המנוע . אם שואב האבק נכבה לפתע מעצמו, כבו את שואב האבק ונתקו אותו משקע החשמל שבקיר. נסו לגלות את הסיבה להתחממות היתר כגון שקית אבק מלאה, צינור יניקה חסום, או מסנן מלוכלך. אם מוצאים את הסיבות, טפלו בהן, והמתינו 30 דקות לפחות לפני השימוש בשואב האבק. לאחר 30 דקות, חברו את התקע לשקע החשמל שבקיר והדליקו את שואב האבק.

הוראות בטיחות חשובות

אזהרה

- **אין לגרור או לקחת את כבל החשמל, להשתמש בו כידית, או למשכו סביב קצוות חדים או פינות . אל תעבירו את שואב האבק מעל הכבל. שמרו על הכבל הרחק ממשטחים חמים .**
  אי ביצוע הוראה זו עלול לגרום להלם חשמלי, או פציעה אישית, או אש, או נזק למכשיר.
- **אין להשתמש במכשיר אם כבל החשמל או תקע פגום או לא תקין .**
  אי ביצוע הוראה זו עלול לגרום לפציעה אישית או נזק למכשיר.
  במקרים אלה, התקשרו לסוכן שירות של LG Electronics כדי למנוע סכנה .
- **אין להשתמש בשואב האבק אם הוא היה נמצא במים .**
  אי ביצוע הוראה זו עלול לגרום לפציעה אישית או נזק למכשיר .
  במקרים אלה, התקשרו לסוכן שירות של LG Electronics כדי למנוע סכנה .
- **יש לנתק את שואב האבק מהחשמל לפני השירות או ניקוי המכשיר או כאשר שואב האבק אינו בשימוש .**
  אי ביצוע הוראה זו עלול לגרום להלם חשמלי או פציעה אישית .
- **אין להשתמש בשואב האבק כדי להרים דבר הנמצא עדיין בבעירה או מעלה עשן, כגון סיגריות או אפר חם .**
  אי ביצוע הוראה זו עלול לגרום למוות, אש או הלם חשמלי.
- **אין לשאוב חומרים דליקים או נפיצים כגון גסולין, בנזן, מדללים, ופרופן (גזלים או גזים)**
  העשן מהחומרים האלה יכול ליצור סכנת אש או פיצוץ . אי ביצוע הוראה זו עלול לגרום למוות או פציעה אישית .
- **אל תטפלו בתקע או בשואב האבק בידיים רטובות .**
  אי ביצוע הוראה זו עלול לגרום למוות או הלם חשמלי .
- **הרחיקו שיער, לבוש רפוי, אצבעות וכל חלק גוף אחר מן הפתחים והחלקים הנעים .**
  אי ביצוע הוראה זו עלול לגרום להלם חשמלי או פציעה אישית .
- **תיקונים למכשירים אלקטרוניים חייבים להתבצע אך ורק על ידי מכוני מוסמך .**
  תיקונים בלתי נכונים עלולים לגרום לסכנות חמורות למשתמש .
- **אין לחבר את התקע לשקע החשמל אם בקרת העוצמה אינה במצב OFF (כבוי) .**
  אי ביצוע הוראה זו עלול לגרום לפציעה אישית או נזק למכשיר.
  (בהתאם לדגם)
- **שימרו על ילדים הרחק, ושימו לב למחסומים כאשר מגלגלים את כבל החשמל כדי למנוע פציעה אישית .**
  הכבל נע במהירות בעת הגילגול . (בהתאם לדגם)
- **יש בציוד כבלים חשמליים . אין להשתמש בציוד אם הוא ניזוק, חתוך או מוקב .**
  אי ביצוע הוראה זו עלול לגרום למוות או הלם חשמלי. (בהתאם לדגם)
- **אין להמשיך להשתמש בשואב האבק אם פריט כלשהו חסר או ניזוק .**
  אי ביצוע הוראה זו עלול לגרום לפציעה אישית או נזק למכשיר.
  במקרים אלה, התקשרו לסוכן שירות של LG Electronics כדי למנוע סכנה.
- **אין להשתמש בכבל מאריך עם שואב האבק .**
  אי ביצוע הוראה זו עלול לגרום לסכנת אש או נזק למכשיר.
- **השתמשו במתח חשמלי מתאים .**
  שימוש במתח חשמלי בלתי מתאים עלול לגרום לנזק למנוע ופציעה למשתמש .
  מתח חשמלי מתאים רשום על התווית בתחתית שואב האבק .
- **כבו את כל הבקרות לפני הניתוק מן החשמל .**
  אי ביצוע הוראה זו עלול לגרום להלם חשמלי או פציעה אישית .
- **אין להחליף את התקע בשום אופן .**
  אי ביצוע הוראה זו עלול לגרום להלם חשמלי, או פציעה אישית או נזק למכשיר. אם מחליפים את התקע, זה עלול לגרום למוות . אם התקע אינו מתאים, התקשרו לטכנאי מוסמך כדי להתקין את השקע המתאים .

הוראות בטיחות חשובות

קראו ומלאו אחר כל ההוראות טרם השימוש בשואב האבק שלכם וזאת על מנת למנוע סכנה של שריפה, התחשמלות, פגיעה אישית או נזק בעת השימוש בשואב האבק. מדריך זה אינו מכסה את כל המצבים האפשריים שעשויים לקרות. תמיד צרו קשר עם סוכן השירות או היצרן שלכם בנוגע לבעיות שאינן מובנות לכם. מכשיר זה תואם את תקנות ה- ECD להלן: תקן מתח חשמלי נמוך 2006/95/EC, תקן EMC 2004/108/EC.

זהו סמל של אזהרת בטיחות.
סמל זה מתריע בפניכם מפני סכנות אפשריות שיכולות להרוג או לפגוע בכם ובאנשים אחרים. כל הודעות הבטיחות ילוו בסמל אזהרת הבטיחות ביחד עם המילה "אזהרה – WARNING" או "זהירות – CAUTION". משמעות המילים היא:

אזהרה (WARNING) — סמל זה יתריע בפניכם מפני סכנות או שימושים לא בטוחים שעלולים לגרום לנזק גופני רציני או למוות.

זהירות (CAUTION) — סמל זה יתריע בפניכם מפני סכנות או שימושים לא בטוחים שעלולים לגרום לנזק גופני או לנזק לרכוש.

אזהרה (WARNING)

- **אין לעשות שימוש בשואב האבק במקרה וכבל החשמל או תקע החשמל פגומים או מקולקלים.**

  במידה וכבל החשמל פגום, יש להחליפו על ידי סוכן שירות של מכשירי חשמל תוצרת LG וזאת במטרה למנוע סכנה.

- **מכשיר זה אינו מיועד לשימוש על ידי אנשים (לרבות ילדים) הסובלים מלקויות גופניות, תחושתיות או שכליות, או חסרי ניסיון וידע, אלא אם כן הושמה עליהם השגחה או ניתנה להם הנחיה בכל הנוגע לשימוש במכשיר מצד אדם האחראי לבטיחותם.**

  ילדים יימצאו תחת השגחה במטרה לוודא כי הם אינם משחקים עם המכשיר.

- **מכשיר זה מותר לשימוש על ידי ילדים בגיל 8 ומעל ה ועל ידי אנשים הסובלים מלקויות גופניות, תחושתיות או שכליות או חסרי ניסיון וידע במידה והושמה עליהם השגחה וניתנה להם הנחיה בכל הנוגע לשימוש במכשיר בדרך בטוחה ובמידה והם מבינים את הסכנות המעורבות בשימוש במכשיר. נאסר על ילדים לשחק עם המכשיר. פעולות ניקוי ותחזוקה של המשתמש לא יבוצעו על ידי ילדים ללא השגחה.**

תוכן העניינים

הוראות בטיחות חשובות ..... 4~6

אופן השימוש 7

הרכבת שואב האבק ..... 7~9

הפעל"ת שואב האבק ..... 10~11

שימוש בפיית השטיח והרצפה \ פייה לרצפה קשה 12

שימוש בפייה לרצפה קשה \ פיית טורבינה 13

השתמש זרבובית עבור כל הקומות ואת זרבובית טורבינה קטנה 14

פייה לניקוי כל סוגי הרצפות 15

שימוש בפיית טורבינה 16

פיית טורבינה לניקוי 17

שימוש באביזרי הפיות ..... 18~19

ריקון מיכל" האבק 20

ניקוי מיכל" האבק 21

ניקוי מסננים ומיכל מסנן אוויר 22

ניקוי מסנן הפל"יטה 23

הרכבת מיכל ומכסה מיכל 24

מה ל"עשות במקרה ששואב האבק אינו פוע"ל ? 25

מה ל"עשות במקרה שביצועי השאיבה פוחתים ? 25

LG
Life's Good

עברית

מדריך למשתמש

סוג חדש של שואב אבק ציקלוני

המידע מכיל הנחיות חשובות לשימוש ולתחזוקה בטוחים של שואב האבק.
במיוחד, אנא קראו את כל המידע הכלול בעמודים 4 עד 6 למען בטיחותכם.
אנא שמרו מדריך זה במקום נגיש בקלות והתייחסו אליו בכל עת.

VC42**NH***
VC42**NR***

www.lg.com

MFL67607053