עברית

ENGLISH

LG
Life's Good

מדריך למשתמש

User Guide

LG-E975k

www.lg.com

MFL68722901 (1.0)

עברית

מדריך למשתמש

- תצוגות מסכים ואיורים עשויים להיראות שונים מאלה שאתה רואה בטלפון שבידך.
- ייתכן שחלק מהתוכן במדריך זה לא יחול על הטלפון שברשותך. הדבר תלוי בתוכנה ובספק השירות שלך. כל המידע במסמך זה נתון לשינוי ללא הודעה מוקדמת.
- מכשיר זה אינו מתאים ללקויי ראייה מפני שלוח המקשים שלו נמצא במסך המגע.
- Copyright ©2013 LG Electronics, Inc. כל הזכויות שמורות. LG והסמל של LG הם סימנים מסחריים רשומים של LG Group ושל החברות הקשורות אליה. כל הסימנים המסחריים האחרים הם רכושם של בעליהם בהתאמה.
- Google™, Google Maps™, Gmail™, YouTube™, Google Talk™ ו-Play Store™ הם סימנים מסחריים של Google, Inc.

תוכן העניינים

הנחיות לשימוש בטוח ויעיל.....5

הודעה חשובה 12

היכרות עם הטלפון שלכם..... 18

סקירה כללית של הטלפון 18
התקנת כרטיס ה-Micro-USIM..... 20
טעינת הטלפון 21
נעילת המסך וביטול הנעילה 21

המסך הראשי..... 22

עצות בנוגע למסך המגע..... 22
המסך הראשי 23
התאמה אישית של המסך הראשי... 24
חזרה ליישומים שהיו בשימוש לאחרונה 25
התראות 25
פתיחת לוח ההתראות..... 26
סמלי מחוונים בשורת המצב 26
מקלדת וירטואלית..... 28
הזנת אותיות עם סימני הטעמה 28

הגדרת חשבון Google 29

התחברות לרשתות ולמכשירים 30

Wi-Fi..... 30
התחברות לרשתות Wi-Fi..... 30
הפעלת Wi-Fi והתחברות לרשת Wi-Fi 30
Bluetooth 31
שיתוף החיבור של נתוני הטלפון 32
Wi-Fi Direct 34
חיבורים למחשב עם כבל USB..... 34

שיחות..... 36

ביצוע שיחה..... 36
התקשרות לאנשי הקשר 36
מענה לשיחה ודחיית שיחה 36
התאמת עוצמת הקול בשיחה 37
ביצוע שיחה נוספת..... 37
צפייה ביומני השיחות..... 37
הגדרות שיחה..... 38

אנשי קשר 39

חיפוש איש קשר 39
הוספת איש קשר חדש 39
אנשי קשר מועדפים 39
יצירת קבוצה..... 40

שליחת הודעות 41

שליחת הודעה 41
תיבה ברצף 42
שינוי הגדרות ההודעה..... 42

הודעת דוא"ל 43

ניהול חשבון דוא"ל..... 43
עבודה עם תיקיות החשבון 43
חיבור ושליחה של דוא"ל..... 44

מצלמה 45

הכרת התצוגה המקדימה..... 45
שימוש בהגדרות המתקדמות..... 46
צילום מהיר 47
לאחר שצילמת תמונה 48
מתוך הגלריה..... 49

מצלמת וידאו 50

הכרת התצוגה המקדימה 50
שימוש בהגדרות המתקדמות 51
הקלטת סרטון וידאו מהיר 51
לאחר הקלטת וידאו 52
צפייה בסרטוני הווידאו שנשמרו 52
כוונון העוצמה בעת צפייה בסרטוני
וידאו 52

פונקציה ייחודית של LG 53

הפונקציה QuickMemo 53
שימוש באפשרויות QuickMemo 54
הצגת ה-QuickMemo שנשמר 54
פונקציית פנקס רשימות 55
יצירת פתק 55
הכרת פנקס הרשימות 55
מדף ספרים 55
חלוניות של מאפייני עמודים 56
הצגת פנקס הרשימות השמור 56
פונקציית שינוי גודל תצוגה
בשידור חי 57
הפונקציה QSlide 58
פונקציית הפעלה כפולה 59
שיקוף 59
הפעלה כפולה 59
LG SmartWorld 60
גישה ל-LG SmartWorld מהטלפון ... 60
On-Screen Phone 61
תכונות הטלפון במסך המחשב 61
כיצד להתקין On-Screen Phone
במחשב 62

מולטימדיה 63

גלריה 63
הצגת תמונות 63
הפעלת סרטוני וידאו 64
עריכת תמונות/סרטוני וידאו 64
מחיקת תמונות 64
הגדרה כטפט 64
סרטוני וידאו 64
הפעלת קובץ וידאו 65
עורך הווידיאו 66
אשף הווידאו 67
מוסיקה 68
השמעת שיר 69
הוספת קובצי מוסיקה לטלפון 70
העבר מוסיקה באמצעות סנכרון
מדיה (MTP) 70

כלי שירות 72

הגדרת התראה 72
שימוש במחשבון 72
הוספת אירוע ללוח השנה 72
רשמקול 73
הקלטת צלילים או קול 73
שליחת ההקלטה הקולית 73
מנהל המשימות 74
משימות 74
Polaris Office 4 74
גיבוי 75
אודות גיבוי ושחזור של נתונים
בטלפונים חכמים 75
גיבוי 76
תזמון גיבוי 76
ניהול ושחזור קבצים 76

תוכן העניינים

Google+ 77
חיפוש קולי 77
הורדות 77

האינטרנט 78

אינטרנט 78
שימוש בסרגל הכלים של האינטרנט. 78
הצגת דפי אינטרנט 78
פתיחת דף 79
חיפוש באינטרנט באופן קולי 79
סימניות 79
היסטוריה 79
שימוש בדפדפן מוקפץ 79
Chrome 80
הצגת דפי אינטרנט 80
פתיחת דף 80
סנכרון עם מכשירים אחרים 80

הגדרות 81

אלחוט ורשתות 81
המכשיר 84
אישי 86
מערכת 88

תוכנת מחשב (LG PC Suite) 90

עדכון תוכנת הטלפון 93

עדכון תוכנת הטלפון 93

אודות מדריך למשתמש זה 94

אודות מדריך למשתמש זה 94
סימנים מסחריים 94
DivX HD 95
Dolby Mobile 95

אביזרים 96

פתרון בעיות 97

שאלות נפוצות 100

הקפד לקרוא הנחיות פשוטות אלה. אי עמידה בהנחיות אלו עלולה להיות מסוכנת או בלתי חוקית.

חשיפה לאנרגיית תדר רדיו

מידע על חשיפה לגלי רדיו ושיעור ספיגה סגולית (SAR).
טלפון נייד זה מדגם LG-E975k תוכנן לעמוד בדרישות הבטיחות הרלוונטיות לחשיפה לגלי רדיו. דרישות אלו מבוססות על קווים מנחים מדעיים, ואלה כוללים שולי בטיחות המיועדים להבטיח את בטיחותם של כל בני האדם, בלא קשר לגילם או למצב בריאותם.

- הנחיות החשיפה לגלי רדיו משתמשות ביחידת מידה הקרויה 'שיעור ספיגה סגולית' (SAR). בדיקות SAR מבוצעות באמצעות שיטות מתוקננות, כאשר הטלפון משדר ברמת העוצמה המרבית המאושרת עבורו בכל תחומי התדרים שבשימוש.
- אף כי עשויים להיות הבדלים בין רמות ה-SAR של דגמי טלפונים שונים של LG, כל הטלפונים מתוכננים לעמוד בהנחיות המתאימות של חשיפה לגלי רדיו.
- מגבלת ה-SAR המומלצת על-ידי הוועדה הבין-לאומית להגנה מפני קרינה בלתי מיינת (ICNIRP) היא ממוצע של 2 וואט/ק"ג על כל 10 גרם של רקמה.
- ערך ה- SAR הגבוה ביותר עבור דגם טלפון זה שנמדד לשימוש באוזן הוא 0.340 וואט/ק"ג (10 גר'), וכאשר הוא נישא על הגוף, ערך זה עומד על 0.391 וואט/ק"ג (10 גר').
- מכשיר זה עומד בהנחיות החשיפה ל-RF כשמשתמשים בו בתנוחת השימוש הרגילה ליד האוזן או כשהוא ממוקם לפחות 1.5 ס"מ מהגוף. כאשר נעשה שימוש בנרתיק נשיאה או בתפס או מנשא לחגורה, אסור שתהיה בהם מתכת כלשהי, והמרחק בין המכשיר לגוף צריך להיות לפחות 1.5 ס"מ. כדי לשדר קובצי נתונים או הודעות, מכשיר זה מחייב חיבור איכותי לרשת. במקרים מסוימים עלול שידור קבצי נתונים או הודעות להיות מושהה עד שחיבור כזה יהיה זמין. הקפד על שמירת הוראות המרחק המינימלי המוזכרות לעיל עד לסיום השידור.

הנחיות לשימוש בטוח ויעיל

טיפול במוצר ותחזוקה

⚠ אזהרה
השתמשו רק בסוללות, במטענים ובאביזרים המאושרים לשימוש עבור דגם ספציפי זה של טלפון. השימוש בסוגים אחרים עשוי לבטל את האישור או האחריות החלים על הטלפון ועלול להיות מסוכן.

- אין לפרק יחידה זו. כאשר נדרש תיקון, פנה לטכנאי שירות מוסמך.
- תיקונים במסגרת האחריות, לפי שיקול דעתה של LG, עשויים לכלול חלקים או לוחות חלופיים, חדשים או מחודשים, ובלבד שהם מצוידים בפונקציונליות זהה לזו של החלקים המוחלפים.
- אין לקרב את המכשיר למכשירים חשמליים כגון טלוויזיות, מכשירי רדיו ומחשבים אישיים.
- יש לשמור את היחידה הרחק ממקורות חום כדוגמת רדיאטורים או תנורי בישול.
- אין להפיל את היחידה.
- אין לאפשר זעזוע מכני או חבטה.
- יש לכבות את הטלפון בכל מקום שבו נדרש הדבר על-ידי תקנות מיוחדות. לדוגמה, אין להשתמש בטלפון בבתי חולים, שכן הפעלתו עלולה להשפיע על פעולת מכשור רפואי רגיש.
- אין לאחוז בטלפון בידיים רטובות בזמן הטענתו. אחיזה במצב כזה עלולה לגרום להתחשמלות ולהסב נזק כבד לטלפון.
- אין לטעון את הטלפון ליד חומר דליק, מכיוון שהמכשיר עלול להתחמם ולעלות באש.
- יש להשתמש במטלית יבשה לניקוי חלקו החיצוני של המכשיר (אין להשתמש בחומרים ממסים כגון בנזן, מדלל או אלכוהול).
- אין לטעון את הטלפון כאשר הוא נמצא על-גבי מצעים או ריפוד.
- יש לטעון את הטלפון באזור מאוורר היטב.
- אין לחשוף יחידה זו לכמות מוגזמת של עשן או אבק.
- אין להחזיק את הטלפון בסמוך לכרטיסי אשראי או כרטיסי נסיעה; הנתונים בפס המגנטי עלולים להיפגם.

- אין להקיש על המסך באמצעות חפצים חדים, שכן הדבר עלול לגרום נזק לטלפון.
- אין לחשוף את הטלפון לנוזלים או ללחות.
- יש לנקוט זהירות בשימוש באביזרים, כמו אוזניות. אין לגעת באנטנה שלא לצורך.
- אם זכוכית המכשיר שבורה או סדוקה, אל תגע בה או תנסה להסיר אותה ואל תשתמש במכשיר. האחריות אינה מכסה נזקים שנגרמו לתצוגת הזכוכית כתוצאה מפגיעה ושימוש לרעה.
- הטלפון שלך הוא מכשיר אלקטרוני המייצר חום במהלך הפעלה רגילה. בהיעדר אוורור הולם, מגע ישיר וממושך מאוד של העור עלול לגרום לאי-נוחות או לכוויות קלות. לפיכך, יש לנקוט זהירות בהחזקת הטלפון במהלך ההפעלה או מיד אחריה.
- אם הטלפון נרטב, נתק אותו מיד והנח לו להתייבש לגמרי. אל תנסה להאיץ את תהליך הייבוש בעזרת מקור חום חיצוני, כמו תנור, מיקרוגל או מייבש שיער.
- הנוזלים שחדרו לטלפון ישנו את צבע תווית המוצר שבתוך המכשיר. כתב האחריות אינו מכסדה נזק למכשיר כתוצאה מחשיפה לנוזלים.

תפעול יעיל של הטלפון

מכשירים אלקטרוניים

כל הטלפונים הניידים עלולים לספוג הפרעות שישפיעו לרעה על ביצועיהם.

- אין להשתמש בטלפון הנייד בסמוך לציוד רפואי ללא קבלת רשות. יש להימנע מהנחת הטלפון מעל לקוצב לב, למשל בכיס החזה.
- טלפונים ניידים עלולים להפריע לעזרי שמיעה מסוימים.
- הפרעה משנית עלולה להשפיע על מכשירי טלוויזיה, מכשירי רדיו, מחשבים וכולי.
- השתמש בטלפון שלך בטמפרטורות שבין 0ºC ו-40ºC, אם ניתן. חשיפת הטלפון לטמפרטורות נמוכות או גבוהות באופן קיצוני עלולה לגרום לנזק, לתקלות או אפילו לפיצוץ.

הנחיות לשימוש בטוח ויעיל

בטיחות בדרכים

בדוק את החוקים והתקנות הנוגעים לשימוש בטלפונים ניידים באזורים שבהם אתה נוהג.

- אין להחזיק את הטלפון ביד בזמן נהיגה.
- יש להפנות את מלוא תשומת הלב לנהיגה.
- רד לשול הדרך וחנה לפני ביצוע שיחה או מענה לשיחה, בהתאם לתנאי הדרך.
- אנרגיית תדר רדיו עשויה להשפיע על מערכות אלקטרוניות מסוימות בכלי רכב, כדוגמת מערכות סטריאו וציוד בטיחות.
- אם המכונית מצוידת בכרית אוויר מתנפחת, אין לחסום אותה על-ידי התקנה של ציוד אלחוטי נישא. הדבר עלול לגרום לכשל של הכרית או לפציעה חמורה עקב ביצועים לא נאותים שלה.
- אם אתה מאזין למוסיקה בעת תנועה, ודא שהעוצמה היא ברמה סבירה, כך שתמשיך להיות מודע לסביבתך. הדבר חשוב במיוחד בקרבת כבישים.

מנעו נזק לשמיעתכם

כדי למנוע נזק אפשרי לשמיעה, אל תאזין בעוצמות קול גבוהות לאורך זמן.

חשיפה לעוצמות קול גבוהות במשך פרקי זמן ארוכים עלולה להזיק לשמיעה. לכן אנו ממליצים שלא תדליק או תכבה את המכשיר סמוך לאוזנך. מומלץ גם להגדיר את עוצמת הקול של המוסיקה והשיחה לרמה סבירה.

- כאשר אתה משתמש באוזניות, הנמך את עוצמת הקול אם אינך מצליח לשמוע את האנשים שבסביבתך מדברים, או אם האדם שלצדך יכול לשמוע את מה שאתה שומע באוזניות.

הערה: עוצמת קול מופרזת מאוזניות פנימיות ואוזניות חיצוניות עלולה לפגוע בשמיעה.

חלקי זכוכית

חלקים מסוימים של ההתקן הנייד עשויים מזכוכית. זכוכית זו עלולה להישבר אם המכשיר ייפול על משטח קשה או יקבל מכה חזקה. אם הזכוכית נשברת, אל תנסה לגעת בה או להסיר אותה. יש להפסיק להשתמש בהתקן הנייד עד להחלפת הזכוכית על-ידי ספק שירות מורשה.

סביבה שבה מבוצעות עבודות עם חומרי נפץ

אין להשתמש בטלפון באזורים שבהם מתבצעות פעולות פיצוץ. שים לב להגבלות ועמוד בכל התקנות או הכללים.

סביבה שבה קיימת סבירות לפיצוץ

- אין להשתמש בטלפון באזורי תדלוק.
- אין להשתמש בו בסמוך לדלק או לכימיקלים.
- אין להוביל או לאחסן גז דליק, נוזלים דליקים או חומרי נפץ בתא הרכב המכיל את הטלפון הנייד או את אביזריו.

כלי טיס

התקנים אלחוטיים עלולים לגרום להפרעה במטוס.

- יש לכבות את הטלפון הנייד לפני העלייה למטוס.
- אין להשתמש בו על הקרקע ללא קבלת רשות מאנשי הצוות.

ילדים

יש לשמור על הטלפון במקום בטוח, מחוץ להישג ידם של ילדים קטנים. המכשיר כולל חלקים זעירים העלולים להוות סכנת חנק אם ינותקו מהטלפון.

שיחות חירום

רק רשתות סלולריות מסוימות מאפשרות לבצע שיחות חירום. לפיכך, בשום מקרה אין לסמוך רק על הטלפון לביצוע שיחות חירום. בדקו את הנושא עם חברת הסלולר המקומית.

מידע לגבי הסוללה והטיפול בה

- אין צורך לפרוק את הסוללה במלואה לפני טעינתה מחדש. בניגוד למערכות סוללה אחרות, אין השפעת זיכרון שעלולה לפגום בביצועי הסוללה.
- יש להשתמש אך ורק בסוללות ובמטענים של LG. מטעני LG מיועדים להארכת חיי הסוללה.
- אין לפרק או לקצר את הסוללה.
- יש להחליף את הסוללה כאשר היא אינה מפיקה עוד רמת ביצועים סבירה. ניתן לטעון מחדש את מארז הסוללה מאות פעמים לפני שיהיה צורך להחליפו.
- כדי להשיג שמישות סוללה מרבית, יש לטעון אותה מחדש אם לא הייתה בשימוש במשך זמן רב.
- אין לחשוף את מטען הסוללה לאור שמש ישיר או להשתמש בו בתנאי לחות גבוהה, כמו חדר אמבטיה.
- אין להשאיר את הסוללה במקומות חמים או קרים, שכן הדבר עלול לפגום בביצועיה.
- קיימת סכנת התפוצצות אם הסוללה הוחלפה בסוג סוללה שאינו מתאים.
- השלך סוללות משומשות על פי הוראות היצרן. יש למחזר, אם אפשר. אין להשליך אותן כאשפה ביתית.
- אם עליך להחליף סוללה, קח אותה למרכז השירות המורשה הקרוב של LG Electronics או לספק לצורך קבלת סיוע.
- יש לנתק תמיד את המטען מהשקע לאחר שהטלפון נטען במלואו כדי למנוע בזבוז מיותר של חשמל מצד המטען.
- אורך חיי הסוללה בפועל תלוי בתצורת הרשת, בהגדרות המוצר, באופי השימוש, בתנאי הסוללה ובתנאים הסביבתיים.

- הקפד שלא ייווצר מגע בין הסוללה לבין פריטים חדים כגון שיניים או ציפורניים של בעל חיים. מגע כזה עלול לגרום לשריפה.
- למען בטיחותך, אל תסיר את הסוללה המשולבת במוצר.
- אל תחליף את הסוללה בכוחות עצמך. הסוללה עלולה להינזק, מה שעלול להוביל להתחממות יתר ופציעה. החלפת הסוללה חייבת להיעשות על-ידי ספק השירות המורשה. את הסוללה יש למחזר או להשליך בנפרד מהאשפה הביתית.

הצהרת תאימות

בזאת, **LG Electronics** מצהירה שהמוצר **LG-E975k** תואם לדרישות היסודיות ולתנאים הרלוונטיים האחרים של הנחיה **1999/5/EC**. ניתן למצוא עותק של הצהרת התאימות בכתובת **http://www.lg.com/global/declaration**

תקנות ובטיחות

עבור אל **"הגדרות מערכת > אודות הטלפון > תקנות ובטיחות"** לקבלת מידע על תקנות ובטיחות

אנא קרא מידע זה לפני תחילת השימוש בטלפון!

לפני שתיקח את הטלפון לנקודת שירות או שתתקשר לנציג שירות, בדוק אם חלק מהבעיות שבהן נתקלת מתוארות בסעיף זה.

1. זיכרון הטלפון

כאשר שטח הזיכרון הפנוי קטן מ-10%, הטלפון לא יכול לקבל הודעות חדשות. עליך לבדוק את זיכרון הטלפון ולמחוק חלק מהנתונים, כגון יישומים או הודעות, כדי לפנות נפח זיכרון.

כדי להסיר התקנה של יישום:

1. גע ב- > הכרטיסייה **יישומים** > **הגדרות** > **יישומים** מתוך 'מכשיר'.
2. לאחר שיופיעו כל היישומים, גלול ובחר את היישום שאת התקנתו ברצונך להסיר.
3. גע ב**הסר התקנה**.

2. מיטוב חיי הסוללה

ניתן להאריך את משך חיי הסוללה בין טעינות על-ידי כיבוי תכונות שפעולתן הרציפה ברקע אינה דרושה. תוכל לפקח על המידה שבה יישומים ומשאבי מערכת צורכים כוח סוללה.

הארכת חיי הסוללה של הטלפון:

- כבה תקשורת רדיו שאינך משתמש בה. אם אינך משתמש ב-Wi-Fi, חיבור Bluetooth או GPS, כבה אותם.
- הפחת את בהירות המסך וקבע פרק זמן קצר יותר לכיבוי אוטומטי של המסך.
- בטל את הסנכרון האוטומטי של Gmail, לוח השנה, אנשי הקשר ויישומים אחרים.
- ייתכן שחלק מהיישומים שהורדת מפחיתים את כוח הסוללה.

כדי לבדוק את רמת הכוח של הסוללה:

- גע ב- > הכרטיסייה **יישומים** > **הגדרות** > **אודות הטלפון** מתוך 'מערכת' > **סוללה**

מצב הסוללה (בטעינה או בפריקה) ורמת הסוללה (כאחוז מהטעינה המלאה) מוצגים בחלקו העליון של המסך.

כדי לשלוט ולפקח על השימוש בכוח הסוללה:

- גע ב- > הכרטיסייה **יישומים** > **הגדרות** > **אודות הטלפון** מתוך 'מערכת' > **סוללה** > **שימוש בסוללה**.

זמן השימוש בסוללה מוצג במסך. הזמן המוצג מציין את משך הזמן שעבר מאז החיבור האחרון למקור מתח; לחלופין, אם הטלפון מחובר כעת, כמה זמן פעל הטלפון לאחרונה על כוח סוללה. במסך מוצגים היישומים או השירותים שצורכים כוח סוללה, והרשימה מסודרת לפי רמת הצריכה: מהגבוהה ביותר לנמוכה ביותר.

3. לפני התקנת יישום או מערכת הפעלה בקוד פתוח.

⚠ **אזהרה**

אם אתה מתקין או משתמש במערכת הפעלה שונה מזו שסיפק היצרן, הדבר עלול לגרום לתפקוד לקוי של הטלפון. בנוסף, האחריות על הטלפון תתבטל.

⚠ **אזהרה**

כדי להגן על הטלפון ועל הנתונים האישיים שלך, הורד יישומים ממקורות מהימנים בלבד, כגון Play Store™. התקנה שגויה של יישומים בטלפון עלולה לגרום לטלפון לפעול בצורה לא תקינה או להתרחשות שגיאה חמורה. יש להסיר מהטלפון את היישומים הללו ואת כל ההגדרות והנתונים הקשורים אליהם.

4. שימוש בתבנית ביטול נעילה

הגדר תבנית ביטול נעילה להגנה על הטלפון. גע ב- > הכרטיסייה **יישומים** > **הגדרות** > **נעל מסך** מתוך 'מכשיר' > **בחר נעילת מסך** > **תבנית.** פעולה זו פותחת מסך שינחה אותך כיצד לשרטט תבנית ביטול נעילה של המסך. עליך ליצור קוד PIN לגיבוי כאמצעי בטיחות למקרה שתשכח את תבנית ביטול הנעילה.
זהירות: צור חשבון Google לפני שתגדיר תבנית ביטול נעילה, וזכור את קוד ה-PIN לגיבוי שיצרת בזמן יצירת נעילת התבנית.

אזהרה
אמצעי זהירות שיש לנקוט בעת השימוש בנעילת תבנית.
חשוב מאוד לזכור את תבנית ביטול הנעילה שהוגדרה. אם תשתמש בתבנית שגויה 5 פעמים, תאבד את הגישה לטלפון. לרשותך 5 ניסיונות להזין את תבנית ביטול הנעילה, קוד ה-PIN או הסיסמה. אם ניצלת את כל 5 הניסיונות, תוכל לנסות שוב לאחר 30 שניות.

אם שכחת את תבנית ביטול הנעילה, קוד ה-PIN או הסיסמה:

< אם שכחת את התבנית >
אם נכנסת לחשבון Google דרך הטלפון, אך לא הצלחת להזין את התבנית הנכונה 5 פעמים, לחץ על הלחצן **שכחת את התבנית?** בתחתית המסך. לאחר מכן תתבקש להיכנס באמצעות חשבון Google, או שיהיה עליך להזין קוד PIN לגיבוי, שאותו הזנת בעת יצירת נעילת התבנית.
אם לא יצרת חשבון Google בטלפון או ששכחת את קוד ה-PIN לגיבוי, עליך לבצע איפוס קשיח.

< אם שכחת קוד PIN או סיסמה >
אם שכחת את קוד PIN או את הסיסמה, תצטרך לבצע איפוס קשיח.
זהירות: **אם תבצעו איפוס קשיח, כל יישומי המשתמש ונתוני המשתמש יימחקו.**

הערה: אם לא נכנסת לחשבון Google, ושכחת את תבנית ביטול הנעילה, תצטרך להזין קוד PIN לגיבוי.

5. שימוש באיפוס קשיח (איפוס להגדרות היצרן)

אם הטלפון אינו משתחזר למצבו המקורי, יש להשתמש באיפוס קשיח (איפוס להגדרות היצרן) כדי לאתחל אותו.

1. כבה את המכשיר.
2. לחץ לחיצה ארוכה על **מקש הפעלה/נעילה** + **מקש הנמכת עוצמת הקול** בטלפון.
3. שחרר את **מקש הפעלה/נעילה** רק כאשר מוצג הסמל של LG, ולאחר מכן לחץ והחזק מייד את **מקש הפעלה/נעילה** שוב.
4. שחרר את כל המקשים כשמוצג המסך 'שחזור נתוני היצרן'.
5. לחץ על **מקש עוצמת הקול** כדי לגלול אל האפשרות הרצויה, ולאחר מכן לחץ על **מקש הפעלה/נעילה** כדי לאשר.

אזהרה

אם תבצע איפוס קשיח, כל יישומי המשתמש, נתוני המשתמש ורשיונות DRM יימחקו. זכור לגבות את כל הנתונים החשובים לפני ביצוע איפוס קשיח.

שחזור נתוני היצרן - מוחק את כל הנתונים בטלפון' למעט כדלקמן. במקרה של כשל או שגיאה בהתקן, ייתכן שההתקן יתעד פרטי רישום שגיאה בנוגע למצב ההתקן בזמן אירוע השגיאה. המידע המתועד ברישום השגיאה עשוי לכלול נתונים על שמות יישומים והשימוש בהם, מיקום ומספר טלפון סלולרי, מצב GPS, שימוש בזיכרון ומידע נוסף לא אישי על מצב המכשיר. מידע זה מאוחסן בטלפון שלך, ו-LG תוכל לגשת אליו רק אם הטלפון יוחזר ל-LG לצורך תיקון ושירות. LG תשתמש בפרטי הרישום אך ורק כדי לאבחן, לתקן ולשפר את המוצרים והשירותים של LG.

6. פתיחת יישומים ומעבר ביניהם

קל לבצע ריבוי-משימות ב-Android, וניתן להפעיל יותר מיישום אחד בו-זמנית. אין צורך לצאת מיישום לפני פתיחת יישום אחר. ניתן להשתמש בכמה יישומים פתוחים ולעבור ביניהם.

מערכת Android מנהלת את היישומים, ועוצרת ומפעילה אותם בהתאם לצורך כדי

הודעה חשובה

להבטיח שיישומים לא פעילים לא יצרכו משאבים שלא לצורך.

כדי להפסיק יישומים:

1 לחץ לחיצה ארוכה על **מקש הבית** . תוצג רשימה של יישומים שהיו בשימוש לאחרונה.

2 הקש על היישום שאליו ברצונך לגשת. פעולה זו אינה מפסיקה את פעולתו של היישום הקודם ברקע של הטלפון. הקפד להקיש על מקש 'הקודם' כדי לצאת מיישום לאחר השימוש בו.

- כדי לעצור יישומים, הקש על **מנהל המשימות** מרשימת היישומים שהיו בשימוש לאחרונה, ולאחר מכן הקש על 'עצור' או על 'עצור הכל'.
- כדי להסיר יישום מרשימת היישומים שהיו בשימוש לאחרונה, החלק ימינה או שמאלה את התצוגה המקדימה של היישומים. כדי לנקות את כל היישומים, הקש על **נקה הכל**.

הערה: עבור ריבוי-משימות, הקש על מקש 'בית' כדי לעבור ליישום אחר בזמן שימוש ביישום. פעולה זו אינה מפסיקה את פעולתו של היישום הקודם ברקע של המכשיר. הקפד לגעת במקש 'הקודם' כדי לצאת מיישום לאחר השימוש בו.

7. העברת מוסיקה, תמונות וסרטוני וידאו באמצעות סינכרון מדיה (MTP)

1 גע ב- > הכרטיסייה **יישומים** > **הגדרות** > **אחסון** כדי לבדוק את מדיית האחסון.

2 חבר את הטלפון למחשב באמצעות כבל ה-USB.

3 **בחר שיטת חיבור USB** יופיע במסך הטלפון, בחר באפשרות **סינכרון מדיה (MTP)**.

4 פתח את תיקיית הזיכרון במחשב. באפשרותך להציג את תוכן האחסון בנפח גדול במחשב ולהעביר את הקבצים מהמחשב לתיקיית זיכרון ההתקן, או להיפך.

8. החזקת הטלפון באופן ניצב

החזק את הטלפון הסלולרי במאונך, כפי שמחזיקים טלפון רגיל. הטלפון שלך כולל אנטנה פנימית. היזהר שלא לשרוט או לגרום נזק לחלק האחורי של הטלפון כדי לא לגרום לירידה בביצועים.

כשאתה יוזם/מקבל שיחות או שולח/מקבל נתונים, הימנע מהחזקת הטלפון בחלק התחתון שלו, שבו נמצאת האנטנה. הדבר עשוי להשפיע על איכות השיחה.

9. כאשר המסך קופא

אם המסך קופא או שהטלפון אינו מגיב כשמנסים להפעיל אותו:

לחץ לחיצה ארוכה על מקש **הפעלה/נעילה** למשך 10 שניות כדי לכבות את הטלפון.

אם הוא עדיין לא פועל, פנה למרכז השירות.

סקירה כללית של הטלפון

אפרכסת

נורית חיווי

עדשת מצלמה הפונה לחזית

חיישן קרבה / בהירות

מקש הפעלה/נעילה

- הפעל/כבה את הטלפון על-ידי לחיצה ממושכת על מקש זה
- לחץ לחיצה קצרה כדי לנעול/לבטל נעילה של המסך

מסך המגע

מקש 'הקודם'

- חזרה למסך הקודם. צא מיישום לאחר שסיימת להשתמש בו.

מקש המסך הראשי (בית)

- חזרה למסך הראשי מכל מסך אחר.

מקש תפריט

- בדיקת האפשרויות הזמינות.

הערה: חיישן קרבה

בעת קבלת שיחות וביצוע שיחות, חיישן הקרבה מכבה אוטומטית את התאורה האחורית ונועל את המסך כאשר הוא חש שהטלפון קרוב לאוזן. תכונה זו מאריכה את חיי הסוללה ומונעת את הפעלת מסך המגע שלא בכוונה במהלך השיחה.

אזהרה

הנחת עצם כבד על הטלפון או ישיבה עליו עלולות לגרום לפגיעה בפונקציות של מסך המגע ומסך ה-LCD של הטלפון. אין לכסות את חיישן הקרבה של ה-LCD בציפוי מגן. הדבר עלול לגרום לתקלה בחיישן.

מקשי עוצמת קול

- **במסך הראשי:** שליטה בעוצמת הצלצול
- **במהלך שיחה:** שליטה בעוצמת האוזנייה
- **בעת השמעת רצועה:** שליטה רציפה בעוצמת השמע

עצה! הפונקציה QuickMemo

לחץ והחזק את המקשים Volume Up (הגברת עוצמת הקול) ו-Volume Down (החלשת עוצמת הקול) למשך שנייה אחת כדי להשתמש בפונקציה QuickMemo.

מקש הפעלה/נעילה

מגש כרטיס SIM

שקע אוזנייה

מיקרופון

עדשת המצלמה

מבזק (Flash)

נקודת מגע של NFC

רמקול

מיקרופון

יציאת MHL/USB/מטען

אזהרה

- חלק זה סוגר את תא הסוללה. אין לפתוח את המכסה האחורי.
- הקפד לא לפגוע בנקודת המגע של NFC בטלפון, המהווה חלק מאנטנת NFC.

התקנת כרטיס ה-Micro-USIM

לפני שתתחיל לחקור את הטלפון החדש שלך, כדאי להכניס את כרטיס ה--Micro USIM.

לחצן השליפה הוא פתח עגול קטן ממש מעל לדלת המגש. כדי להתקין כרטיס Micro-USIM חדש:

1. הכנס את הכלי לשליפת Micro-USIM שהגיע עם הטלפון (או סיכה דקה) לפתח לחצן השליפה, ולחץ בעדינות אך ביציבות עד שהמגש יקפוץ החוצה.
2. הוצא את המגש ומקם את כרטיס ה-Micro-USIM בתוכו, כאשר המגעים פונים החוצה והפינה בעלת הזווית נמצאת מימין. יש רק דרך אפשרית אחת להכניס בצורה נוחה את הכרטיס למגש.
3. מקם מחדש בזהירות את המגש בחריץ, ודחף אותו בעדינות בחזרה לטלפון.

הערה: ודא שאזור מגעי הזהב של הכרטיס פונה מטה.

טעינת הטלפון

מחבר המטען נמצא בחלק התחתון של הטלפון. הכנס קצה אחד של כבל הטעינה לטלפון וחבר את הקצה השני לשקע חשמל.

הערה: יש להקפיד על טעינה ראשונה מלאה של הסוללה כדי לשפר את אורך חייה.

נעילת המסך וביטול הנעילה

אם לא תשתמש בטלפון למשך זמן מה, המסך יכבה ויינעל באופן אוטומטי. כך נמנעות הקשות בשוגג ונחסך הספק הסוללה.

כשאינך משתמש בטלפון, הקש על **מקש הפעלה/נעילה** כדי לנעול את הטלפון.

אם יש תוכניות פועלות כשאתה נועל את המסך, הן עשויות להמשיך לפעול במצב נעילה. מומלץ לצאת מכל התוכניות לפני הכניסה למצב 'נעילה' כדי להימנע מחיובים מיותרים (כגון שיחות טלפון, גישה לאינטרנט ותקשורת נתונים).

כדי להעיר את הטלפון, הקש על **מקש הפעלה/נעילה**. מסך הנעילה יופיע. גע במסך הנעילה והחלק אותו בכיוון כלשהו כדי לבטל את נעילת המסך הראשי. המסך האחרון שהוצג ייפתח.

עצות בנוגע למסך המגע

להלן מספר עצות בנושא ניווט בטלפון.

הקש או גע – הקשה באצבע יחידה בוחרת פריטים, קישורים, קיצורי דרך ואותיות במקלדת שעל המסך.

גע והחזק – גע והחזק בפריט על המסך על-ידי נגיעה והשארת האצבע עד להתרחשות פעולה. לדוגמה, כדי לפתוח את האפשרויות הזמינות של איש קשר, גע והחזק באיש הקשר ברשימת אנשי הקשר עד שתפריט ההקשר ייפתח.

גרור – גע והחזק בפריט לרגע ולאחר מכן, מבלי להרים את האצבע, הזז את האצבע על המסך עד שתגיע למיקום היעד. ניתן לגרור פריטים במסך הראשי כדי לשנות את מיקומם.

בצע החלקה רגילה או החלקה מהירה – כדי לבצע החלקה רגילה או החלקה מהירה, הזז את האצבע במהירות על-גבי שטח המסך, מבלי להשהות את האצבע כשאתה נוגע במסך לראשונה (כדי לא לגרור פריט בטעות). לדוגמה, באפשרותך להחליק את המסך כלפי מעלה או מטה כדי לגלול רשימה, או לדפדף בין המסכים הראשיים השונים על-ידי החלקה משמאל לימין (ולהיפך).

הקש פעמיים – הקש פעמיים כדי להגדיל את התצוגה של דף אינטרנט או מפה. לדוגמה, הקש פעמיים במהירות על מקטע של דף אינטרנט כדי להתאים את גודלו של מקטע זה לרוחב המסך. באפשרותך גם להקיש פעמיים כדי להגדיל ולהקטין את התצוגה כשאתה מצלם תמונה (באמצעות המצלמה) וכשאתה משתמש במפות.

צבוט כדי לשנות את גודל התצוגה – השתמש באצבע המורה ובאגודל בתנועת צביטה או פריסה כדי להקטין או להגדיל את התצוגה כשאתה משתמש בדפדפן או במפות, או כשאתה מדפדף בתמונות.

סובב את המסך – ביישומים ותפריטים רבים, כיוון המסך מתאים את עצמו לכיוון הפיזי של המכשיר.

הערה:

- כדי לבחור פריט, הקש על מרכז הסמל.
- אין צורך ללחוץ חזק מדי, מסך המגע רגיש דיו כדי לחוש במגע קל אך החלטי.
- השתמש בקצה האצבע כדי לגעת באפשרות הרצויה. היזהרו שלא לגעת באף מקש אחר.

המסך הראשי

המסך הראשי הוא נקודת ההתחלה לפונקציות וליישומים רבים, והוא מאפשר לך להוסיף פריטים כגון קיצורי דרך ליישומים או וידג'טים של Google כדי לקבל גישה מיידית למידע וליישומים. זהו לוח ברירת המחדל והוא נגיש מכל תפריט על-ידי הקשה על .

שורת המצב

מציגה את מידע המצב של הטלפון כולל השעה, עוצמת האות, מצב הסוללה וסמלי התראות.

וידג'ט

וידג'טים הם יישומים עצמאיים שניתן לגשת אליהם ממסך היישומים או במסך הראשי או במסך ראשי מורחב. בניגוד לקיצור דרך, הווידג'ט מופיע כיישום במסך.

סמלי יישומים

הקש על סמל (יישום, תיקייה וכו') כדי לפתוח אותו ולהשתמש בו.

מציין מיקום

מציין איזה לוח של מסך ראשי אתה מציג.

אזור מקשים מהירים

מספק גישה בנגיעה אחת לפונקציה בכל לוח של מסך ראשי.

מסך ראשי מורחב

מערכת ההפעלה מספקת לוחות מרובים של מסך ראשי כדי לאפשר עוד שטח להוספת סמלים, וידג'טים ועוד.

החלק את האצבע שמאלה או ימינה על פני המסך הראשי.

התאמה אישית של המסך הראשי

באפשרותך להתאים אישית את המסך הראשי על-ידי הוספת יישומים, וידג'טים או על-ידי שינוי טפטים.

כדי להוסיף פריטים למסך הראשי:

1. לחץ לחיצה ארוכה בנקודה הריקה במסך הראשי.
2. בתפריט 'מצב הוספה', בחר את הפריט שברצונך להוסיף. הפריט שהוספת יופיע במסך הראשי.
3. גרור אותו למיקום הרצוי והרם את האצבע.

עצה! כדי להוסיף סמל יישום למסך הראשי, בתפריט 'יישומים', גע והחזק את היישום שברצונך להוסיף.

כדי להסיר פריט מהמסך הראשי:

- **מסך ראשי** > לחץ לחיצה ארוכה על הסמל שברצונך להסיר > גרור אותו אל

עצה! שימוש בתיקיות
ניתן לשלב מספר סמלי יישומים בתיקייה. שחרר סמל יישום אחד מעל אחר במסך ראשי, ושני הסמלים ישולבו.

הערה: המקש 'יישומים' אינו ניתן להסרה.

כדי להתאים אישית סמלי יישומים במסך הראשי

1. ע והקש על סמל יישומם עד שנעילתו מהמיקום הנוכחי תבוטל. לאחר מכן שחרר אותו במסך.
   סמל העריכה יופיע בפינה הימנית העליונה של היישום.
2. הקש על סמל היישום שוב ובחר בעיצוב ובגודל הרצויים עבור הסמל.
3. הקש על **אישור** כדי לשמור את השינוי.

חזרה ליישומים שהיו בשימוש לאחרונה

1 לחץ לחיצה ארוכה על המקש **בית**. על המסך יופיע חלון מוקפץ ובו סמלי היישומים שבהם השתמשת לאחרונה.
2 גע בסמל כדי לפתוח את היישום שלו. לחלופין, הקש על מקש **חזרה** כדי לחזור למסך הקודם.

התראות

התראות מדווחות לך על הגעת הודעות חדשות, אירועים בלוח השנה ומצבי חירום, וכן על אירועים מתמשכים, לדוגמה, כאשר אתה בשיחה.
מחלונית ההתראות באפשרותך להציג את הסטטוס הנוכחי של הטלפון ואת ההתראות הממתינות.
כשמגיעה התראה, הסמל שלה מופיע בחלק העליון של המסך. סמלים של התראות ממתינות מופיעים משמאל, וסמלי מערכת שמציגים דברים כגון Wi-Fi או עוצמת סוללה מופיעים מימין.

הערה: האפשרויות הזמינות משתנות בהתאם לאזור או לספק השירות.

פתיחת לוח ההתראות

החלק כלפי מטה משורת המצב כדי לפתוח את חלונית ההתראות.

אזור ההחלפה המהירה

הקש על כל מקש החלפה מהירה כדי להפעיל/לכבות אותו. גע והחזק את המקש כדי לגשת לתפריט ההגדרות של הפונקציה. להצגת מקשי החלפה נוספים, החלק שמאלה או ימינה. הקש על כדי להסיר, להוסיף או לשנות את הסדר של מקשי החלפה.

יישומי QSlide

הקש על יישום QSlide כדי לפתוח אותו כחלון קטן במסך. הקש על כדי להסיר, להוסיף או לשנות את הסדר של יישומי QSlide.

הקש כדי לנקות את כל ההתראות.

התראות

ההתראות הנוכחיות מפורטות, כל אחת עם תיאור קצר. הקש על התראה כדי להציג אותה.

די לסגור את לוח ההתראות, גע וגרור את הלשונית אל עבר הקצה העליון של המסך.

סמלי מחוונים בשורת המצב

סמלי מחוונים מופיעים בשורת המצב בחלקו העליון של המסך כדי לדווח על שיחות שלא נענו, הודעות חדשות, אירועים בלוח השנה, סטטוס המכשיר ועוד.

הסמלים המוצגים בחלקו העליון של המסך מספקים מידע על סטטוס המכשיר. הטבלה שלהלן מציגה אחדים מהסמלים הנפוצים ביותר.

סמל	תיאור
	אין כרטיס Micro-USIM
	אין אות
	מצב טיסה
	מחובר לרשת Wi-Fi
	אוזניות מחוברות
	מתבצעת שיחה
	החזקת שיחה בהמתנה
	שיחה שלא נענתה
	Bluetooth מופעל
	התראת מערכת
	התראה מוגדרת
	הודעה קולית חדשה
	הצלצול מושתק

סמל	תיאור
	מצב רטט
	הסוללה טעונה במלואה
	הסוללה נטענת
	הורדת נתונים
	העלאת נתונים
	GPS מחפש קליטה
	נתוני מיקום מתקבלים מ-GPS
	סינכרון נתונים מתבצע
	הודעת Gmail חדשה
	הודעת Google Talk חדשה
	הודעה חדשה
	שיר מושמע
	הטלפון מחובר למחשב באמצעות כבל USB או שחיבור כמודם סלולרי USB פעיל

	NFC פועל		נקודה חמה ניידת של Wi-Fi פעילה
	P2P פועל		הן חיבור כמודם סלולרי USB והן נקודה חמה ניידת פעילים

הערה: מיקום הסמלים בשורת המצב עשוי להשתנות בהתאם לפונקציה או לשירות.

מקלדת וירטואלית

ניתן להזין טקסט גם באמצעות המקלדת הווירטואלית. המקלדת מוצגת על המסך אוטומטית כשעליך להזין טקסט. כדי להציג ידנית את המקלדת, גע בשדה טקסט שבו תרצה להזין טקסט.

שימוש בלוח המקשים והזנת טקסט

הקש פעם אחת כדי להפוך את האות הבאה שתקליד לאות רישית. הקש פעמיים כדי שכל האותיות יהיו רישיות.

הקש כדי לעבור למקלדת של מספרים וסמלים.

הקש כדי להזין רווח.

הקש כדי ליצור שורה חדשה.

הקש כדי למחוק את התו הקודם.

הזנת אותיות עם סימני הטעמה

כאשר אתה בוחר ב'צרפתית' או 'ספרדית' כשפת הזנת טקסט, באפשרותך להזין תווים מיוחדים הקיימים בצרפתית או בספרדית (למשל "á").

לדוגמה, כדי להזין "á", גע ברציפות במקש "a" עד שמקש ההגדלה יגדל ויציג תווים של שפות שונות.

כעת בחר את התו המיוחד הרצוי.

הגדרת חשבון Google

כשאתה מפעיל את הטלפון בפעם הראשונה, יש לך הזדמנות להפעיל את הרשת, להיכנס לחשבון Google שלך ולבחור כיצד ברצונך להשתמש בשירותי Google מסוימים.

כדי להגדיר את חשבון Google שלך:

- היכנס לחשבון Google ממסך הנחיות ההתקנה.

או

- גע ב- > הכרטיסייה **יישומים** > בחר יישום של Google, כגון **Gmail** > בחר באפשרות **חדש** כדי ליצור חשבון חדש.

אם יש לך חשבון Google, גע באפשרות **קיים**, הזן את כתובת הדואר האלקטרוני ואת הסיסמה שלך, ולאחר מכן גע ב- .

לאחר שהגדרת את חשבון Google שלך בטלפון, הטלפון יסתנכרן באופן אוטומטי עם חשבון Google באינטרנט.

אנשי הקשר, ההודעות ב-Gmail, האירועים בלוח השנה ופרטים נוספים מיישומים ושירותים אלה באינטרנט יסתנכרנו עם הטלפון שלך. (הדבר תלוי בהגדרות הסנכרון שלך.)

לאחר הכניסה תוכל להשתמש ב-™Gmail ובשירותי Google דרך הטלפון.

התחברות לרשתות ולמכשירים

Wi-Fi

עם Wi-Fi באפשרותך להשתמש בגישה לאינטרנט מהיר בטווח כיסוי נקודת הגישה (AP) האלחוטית. תוכל ליהנות מאינטרנט אלחוטי באמצעות Wi-Fi, ללא תשלום נוסף.

התחברות לרשתות Wi-Fi

כדי להשתמש ב-Wi-Fi בטלפון, עליך לגשת לנקודת גישה אלחוטית, או 'נקודה חמה'. חלק מנקודות הגישה הן פתוחות, ופשוט ניתן להתחבר אליהן. אחרות נסתרות או שחלות בהן תכונות אבטחה אחרות, ולכן תצטרך להגדיר את הטלפון כך שיוכל להתחבר אליהן.

כאשר אינך משתמש ב-Wi-Fi, כבה אפשרות זו כדי להאריך את חיי הסוללה.

הערה: אם אתה נמצא מחוץ לאזור ה-Wi-Fi או שהגדרת את Wi-Fi כ**כבוי**, ייתכן שהמפעיל הסלולרי יחיל חיובים נוספים עבור שימוש בנתונים סלולריים.

הפעלת Wi-Fi והתחברות לרשת Wi-Fi

1 גע ב- > הכרטיסייה **יישומים** > **הגדרות** > **Wi-Fi** מהכרטיסייה 'אלחוט ורשתות'.

2 הגדר את **Wi-Fi** ל**פועל** כדי להפעיל אותו והתחל בסריקה לאיתור רשתות Wi-Fi זמינות.

3 הקש על התפריט 'Wi-Fi' פעם נוספת כדי להציג רשימה של רשתות Wi-Fi פעילות הנמצאות בטווח.

- הרשתות המאובטחות מסומנות בסמל של מנעול.

4 גע ברשת כדי להתחבר אליה.

- אם הרשת מאובטחת, תונחה להזין סיסמה או הרשאות אחרות (פנה אל מנהל המערכת לקבלת פרטים)

5 שורת המצב מציגה סמלים המציינים את מצב ה-Wi-Fi.

Bluetooth

ניתן לשלוח נתונים באמצעות Bluetooth על-ידי הפעלת יישום מתאים, אך לא דרך תפריט Bluetooth כמו במרבית הטלפונים הניידים.

הערה:
- LG אינה אחראית לאובדן, יירוט או שימוש לרעה של נתונים שנשלחו או נקלטו דרך תכונת Bluetooth אלחוטי.
- ודאו תמיד שאתם משתפים ומקבלים נתונים ממכשירים מהימנים המאובטחים כיאות. מכשולים בין המכשירים עלולים להקטין את מרחק הקליטה.
- חלק מהמכשירים, ובמיוחד אלה שלא נבדקו ואושרו על-ידי Bluetooth SIG, עלולים לא להתאים למכשירים שלך.

הפעלת Bluetooth ושיוך הטלפון שלך עם מכשיר Bluetooth

עליך לשייך את המכשיר שלך למכשיר אחר לפני שתתחבר אליו.

1 גע ב- > הכרטיסייה **יישומים** > **הגדרות** > הגדר את **Bluetooth** כ**פו־על** מהכרטיסייה 'אלחוט ורשתות'.

2 הקש על תפריט **Bluetooth** שוב. תראה את האפשרות להפוך את הטלפון שלך לגלוי ואת האפשרות לחפש מכשירים; כעת הקש על **חיפוש מכשי־רים** כדי להציג את המכשירים בטווח Bluetooth.

3 בחר מהרשימה את המכשיר שאליו ברצונך לשייך את הטלפון שלך.

לאחר שהשיוך הסתיים בהצלחה, הטלפון שלך יהיה מחובר למכשיר.

הערה: ייתכן שבמכשירים מסוימים, במיוחד אוזניות או דיבוריות לרכב, יהיהי קוד PIN קבוע ל-Bluetooth, לדוגמה 0000. אם למכשיר האחר יש קוד PIN, תתבקש להזין אותו.

שליחת נתונים באמצעות התכונה Bluetooth אלחוטי

1 בחר קובץ או פריט, כגון איש קשר, אירוע בלוח השנה או קובץ מדיה, מתוך יישום מתאים או מתוך **הורדות**.

2 בחר באפשרות לשליחת נתונים דרך Bluetooth.

הערה: ייתכן שהשיטה לבחירת אפשרות תהיה שונה בהתאם לסוג הנתונים.

3 חיפוש מכשיר המותאם לשימוש Bluetooth ושיוך אליו.

קבלת נתונים באמצעות התכונה Bluetooth אלחוטי

1 גע ב- > הכרטיסייה **יישומים** > **הגדרות** > הגדר את **Bluetooth למופעל**.

2 הקש על התפריט **Bluetooth** שוב והוסף סימן ביקורת בתיבת הסימון שבקצה העליון של המסך כדי שהטלפון שלך יהיה גלוי למכשירים אחרים.

הערה: כדי לבחור את משך הזמן שהמכשיר יהיה גלוי, גע ב- > **זמן לתפוגת הנראות**.

3 בחר באפשרות שייך כדי לאשר שאתה מוכן לקבל נתונים מהמכשיר.

שיתוף החיבור של נתוני הטלפון

חיבור כמודם סלולרי USB ונקודה חמה ניידת ב-Wi-Fi הן תכונות נהדרות כשאין חיבורים אלחוטיים זמינים. באפשרותך לשתף את חיבור הנתונים הנייד של הטלפון עם מחשב אחד, דרך כבל USB (חיבור כמודם USB). תוכל גם לשתף את חיבור הנתונים של הטלפון עם יותר ממכשיר אחד בו-זמנית, על ידי הפיכת הטלפון לנקודה חמה ניידת של Wi-Fi.

כאשר הטלפון משתף את חיבור הנתונים שלך, מופיעים סמל בשורת המצב והתראה מתמשכת במגירת ההתראות.

לקבלת המידע העדכני ביותר על חיבור כמודם ונקודות חמות ניידות, לרבות מערכות הפעלה נתמכות ופרטים נוספים, בקר בכתובת http://www.android.com/tether.

כדי לשנות את ההגדרות של נקודה חמה ניידת ב-Wi-Fi:

1 גע ב- > הכרטיסייה **יישומים** > **הגדרות** > **רשתות ושיתוף אינטרנט** > המתג **נקודה חמה ניידת ב-Wi-Fi** כדי להפעיל.

2 הזן סיסמה והקש על **שמור**.

עצה! אם במחשב שלך פועל Windows 7 או מהדורה עדכנית של סוגים מסוימים של Linux (כגון Ubuntu), בדרך כלל אין צורך להכין את המחשב לחיבור כמודם USB. לעומת זאת, אם במחשב פועלת גרסה מוקדמת יותר של Windows או מערכת הפעלה אחרת, ייתכן שיהיה עליך להכין את המחשב כדי להקים חיבור לרשת דרך USB. לקבלת המידע העדכני ביותר על מערכות ההפעלה שתומכות בחיבור כמודם USB וכיצד להגדירן, בקר בכתובת http://www.android.com/tether.

כדי לשנות את שמה של הנקודה החמה הניידת או לאבטח אותה

באפשרותך לשנות את השם של רשת ה-Wi-Fi של הטלפון (SSID) ולאבטח את רשת ה-Wi-Fi שלו.

1 גע ב- > הכרטיסייה **יישומים** > **הגדרות** > **רשתות ושיתוף אינטרנט** > **נקודה חמה ניידת ב-Wi-Fi**.

2 גע באפשרות **הגדר נקודה חמה של Wi-Fi**.

- תיבת הדו-שיח **הגדר נקודה חמה של Wi-Fi** תיפתח.
- באפשרותך לשנות את ה-**SSID של הרשת** (השם) אשר מחשבים אחרים רואים בעת סריקה לאיתור רשתות Wi-Fi.
- גע בתפריט **אבטחה** כדי לקבוע את תצורת הרשת עם אבטחה מסוג Wi-Fi Protected Access 2 (WPA2) המבוססת על מפתח ששותף מראש (PSK).
- נגיעה באפשרות האבטחה **WPA2 PSK** תגרום להוספת שדה סיסמה לתיבת הדו-שיח **הגדר נקודה חמה של Wi-Fi**. אם תזין סיסמה, יהיה עליך להזין סיסמה זו בעת התחברות לנקודה החמה של הטלפון בעזרת מחשב או התקן אחר. לחלופין, באפשרותך להגדיר את **פתח** בתפריט **אבטחה** כדי לבטל את האבטחה של רשת ה-Wi-Fi.

3 גע ב**שמור**.

שימו לב! אם תגדיר את אפשרות האבטחה כ'פתוח', לא תוכל למנוע שימוש בלתי מורשה בשירותים מקוונים על-ידי אנשים אחרים, וייתכן שתצבור חיובים נוספים. כדי למנוע שימוש בלתי מורשה, מומלץ לדאוג שאפשרות האבטחה תהיה פעילה.

Wi-Fi Direct

Wi-Fi Direct תומך בחיבור ישיר בין התקנים מאופשרי Wi-Fi ללא נקודת גישה. עקב ניצול הסוללה הגבוה ב-Wi-Fi Direct, מומלץ לחבר את הטלפון לשקע חשמל בעת השימוש בתכונה Wi-Fi Direct. בדוק את רשת Wi-Fi ו-Wi-Fi Directed מראש, וודא שהמשתמשים מחוברים לאותה הרשת.

חיבורים למחשב עם כבל USB

למד לחבר את המכשיר שלך למחשב באמצעות כבל USB במצבי חיבור USB.

העברת מוסיקה, תמונות וסרטוני וידאו באמצעות מצב אחסון בנפח גדול ב-USB

1. חבר את הטלפון שלך למחשב באמצעות כבל USB.
2. אם לא התקנת במחשב את LG Android Platform Driver, תצטרך לשנות את ההגדרות באופן ידני. בחר באפשרות **הגדרות מערכת** > **חיבור PC** > **שיטת חיבור USB** ולאחר מכן בחר באפשרות **סינכרון מדיה (MTP)**.
3. כעת באפשרותך להציג את תוכן האחסון בנפח גדול במחשב ולהעביר את הקבצים.

סנכרון עם Windows Media Player

ודא ש-Windows Media Player מותקן במחשב שלך.

1 השתמש בכבל ה-USB כדי לחבר את הטלפון למחשב שבו מותקן Windows Media Player.

2 בחר באפשרות **סנכרון מדיה (MTP)**. כאשר המכשיר מחובר, יופיע במחשב חלון מוקפץ.

3 פתח את Windows Media Player כדי לסנכרן קובצי מוסיקה.

4 ערוך או הזן את שם המכשיר בחלון המוקפץ (במקרה הצורך).

5 בחר את קובצי המוסיקה הרצויים וגרור אותם לרשימת הסנכרון.

6 התחל את הסנכרון.

- יש למלא את הדרישות הבאות כדי לבצע סנכרון עם Windows Media Player.

פריטים	דרישה
מערכת הפעלה	Microsoft Windows XP SP2, Vista או גרסה מתקדמת יותר
גרסת Window Media Player	Windows Media Player 10 ומעלה

- אם הגרסה של Windows Media Player נמוכה מ-10, התקן את גרסה 10 או גרסה מתקדמת יותר.

ביצוע שיחה

1 גע ב- כדי לפתוח את לוח המקשים.
2 הזן את המספר בלוח המקשים. כדי למחוק ספרה, הקש על הסמל .
3 גע ב- כדי לבצע שיחה.
4 כדי לסיים שיחה, הקש על הסמל **סיום** .

עצה! כדי להזין "+" לביצוע שיחות בינלאומיות, לחץ לחיצה ממושכת על הסמל 0+.

התקשרות לאנשי הקשר

1 גע ב- כדי לפתוח את אנשי הקשר.
2 גלול ברשימת אנשי הקשר או הזן את האותיות הראשונות של שם איש הקשר המבוקש על-ידי נגיעה ב**חפש אנשי קשר**.
3 ברשימה, גע פעמיים באיש הקשר או גע ב- שאליו ברצונך להתקשר.

מענה לשיחה ודחיית שיחה

כשאתה מקבל שיחה במצב נעילה, החלק את בכיוון כלשהו כדי לענות לשיחה הנכנסת.
החלק את בכיוון כלשהו כדי לסרב לשיחה נכנסת.
החזק והחלק את הסמל **סרב עם הודעה** מהחלק התחתון אם ברצונך לשלוח הודעה.

עצה! סרב עם הודעה
באמצעות פונקציה זו ניתן לשלוח הודעה במהירות. אפשרות זו שימושית כאשר אתה נדרש לדחות שיחה במהלך פגישה.

התאמת עוצמת הקול בשיחה

כדי להתאים את עוצמת הקול במהלך שיחה, השתמשו במקשי הגברת והחלשת עוצמת הקול שבצדו השמאלי של הטלפון.

ביצוע שיחה נוספת

1. במהלך השיחה הראשונה שלך, גע ב**תפריט** > **הוסף שיחה** וחייג את המספר. באפשרותך גם לעבור לרשימת המספרים שחויגו לאחרונה על-ידי נגיעה ב-, או לחפש אנשי קשר על-ידי נגיעה ב- ובחירת איש הקשר שאליו ברצונך להתקשר.
2. גע ב- כדי לבצע את השיחה.
3. שתי השיחות יוצגו במסך השיחות. השיחה הראשונה שלך תינעל ותועבר למצב המתנה.
4. כדי לעבור בין שיחות, גע במספר המוצג. לחלופין, גע באפשרות **מיזוג שיחות** כדי להתחיל שיחת ועידה.
5. כדי לסיים שיחות פעילות, גע באפשרות **סיום** או גע במקש**בית**, החלק את סרגל ההתראות כלפי מטה ובחר בסמל **סיים שיחה**.

הערה: תחויב עבור כל שיחה שתבצע.

צפייה ביומני השיחות

במסך הראשי, גע ב- ובחר בכרטיסייה **יומני שיחות** .
הצג רשימה מלאה של כל השיחות שחויגו, שהתקבלו ושלא נענו.

עצה! גע בכל אחד מהפריטים ביומן השיחות כדי לצפות בתאריך, בשעה ובמשך השיחה.

עצה! גע במקש ה**תפריט** ולאחר מכן גע באפשרות **מחק הכל** כדי למחוק את כל הפריטים המוקלטים.

הגדרות שיחה

באפשרותך לקבוע את התצורה של הגדרות שיחת טלפון, כגון הפניית שיחה, וכן תכונות מיוחדות אחרות שספק השירות שלך מציע.

1 במסך הראשי, גע ב- .
2 גע ב- .
3 הקש על **הגדרות שיחה** ובחר את האפשרויות שברצונך לשנות.

אנשי קשר

הוסף אנשי קשר לטלפון וסנכרן אותם עם אנשי הקשר בחשבון Google שלך או בחשבונות אחרים שתומכים בסנכרון אנשי קשר.

חיפוש איש קשר

במסך הראשי

1 גע ב- כדי לפתוח את אנשי הקשר.
2 גע ב**חפש אנשי קשר** והזן את שם איש הקשר באמצעות המקלדת.

הוספת איש קשר חדש

1 גע ב- , הזן את מספרו של איש הקשר החדש ולאחר מכן גע במקש ה**תפריט** . גע ב**הוסף לאנשי קשר** > **צור איש קשר חדש**.
2 אם ברצונכם להוסיף תמונה לאיש הקשר החדש, געו באזור התמונה. בחר מבין האפשרויות **צלם** או **בחר מהגלריה**.
3 בחר את סוג איש הקשר על-ידי לחיצה על .
4 גע בקטגוריית פרטי איש קשר והזן את פרטיו.
5 גע ב**שמור**.

אנשי קשר מועדפים

באפשרותך לסווג אנשי קשר שאליהם אתה מתקשר לעתים קרובות כמועדפים.

הוספת איש קשר למועדפים

1 גע ב- כדי לפתוח את אנשי הקשר.
2 גע באיש קשר כדי להציג את פרטיו.
3 הקש על הכוכב שמימין לשמו של איש הקשר. הכוכב ישנה את צבעו לצהוב.

הסרת איש קשר מרשימת המועדפים

1 גע ב- כדי לפתוח את אנשי הקשר.
2 גע בכרטיסייה ובחר איש קשר כדי להציג את פרטיו.
3 גע בכוכב הצהוב שמימין לשמו של איש הקשר. הכוכב ישנה את צבעו לאפור ואיש הקשר יוסר מהמועדפים שלך.

יצירת קבוצה

1 גע ב- כדי לפתוח את אנשי הקשר.
2 גע ב**קבוצות** ולאחר מכן גע במקש ה **תפריט** . בחר **קבוצה חדשה**.
3 הזן שם עבור הקבוצה החדשה. ניתן גם להגדיר עבורה רינגטון.
4 גע ב**שמור** כדי לשמור את הקבוצה.

הערה: אם תמחקו קבוצה, אנשי הקשר שהוקצו לקבוצה זו לא ילכו לאיבוד. הם יישארו ברשימת אנשי הקשר שלכם.

שליחת הודעות

הטלפון שלך משלב הודעות SMS ו-MMS בתפריט יחיד, אינטואיטיבי וקל לשימוש.

שליחת הודעה

1 גע ב- במסך הראשי, וגע ב- כדי לפתוח הודעה ריקה.
2 הזן שם של איש קשר או מספר להתקשרות בשדה **אל**. תוך כדי הזנת שם איש הקשר יופיעו אנשי קשר מתאימים. תוכל להקיש על נמען מוצע. ניתן להוסיף יותר מאיש קשר אחד.

הערה: תחויב בתשלום על הודעת טקסט עבור כל אדם שאליו תשלח את ההודעה.

3 גע בשדה '**הזן הודעה**' והתחל לחבר את ההודעה.
4 גע ב- כדי לפתוח את התפריט 'אפשרויות'. בחר מבין האפשרויות **הודעה מהירה**, **הוסף סמיילי**, **לוח זמנים נשלח**, **הוסף נושא וביטול** .

עצה! באפשרותך לגעת בסמל כדי לצרף להודעה את הקובץ שברצונך לשתף.

5 גע ב**שלח** כדי לשלוח את ההודעה.
6 התשובות יופיעו במסך. כאשר תציג ותשלח הודעות נוספות, ייווצר רצף הודעות.

אזהרה: מגבלת 160 התווים עשויה להשתנות במדינות שונות, בהתאם לשפה ולצורת הקידוד של הודעות SMS.

אזהרה:אם מוסיפים תמונה, סרטון וידאו או קובץ שמע להודעת SMS, ההודעה הופכת באופן אוטומטי להודעת MMS, ואתם תחויבו בהתאם.

תיבה ברצף

ניתן להציג הודעות (SMS, MMS) שהוחלפו עם אחרים בסדר כרונולוגי, כך שתוכל לראות בקלות מעין סקירה כללית של שיחתך.

שינוי הגדרות ההודעה

הגדרות ההודעות בטלפון שלך נקבעו מראש, כדי שתוכל לשלוח הודעות מייד. באפשרותך לשנות את ההגדרות לפי העדפותיך.

- גע בסמל **הודעות** במסך הראשי, גע ב- ≡ ולאחר מכן הקש על **הגדרות**.

הודעת דוא"ל

ניתן להשתמש ביישום הדוא"ל כדי לקרוא הודעות דוא"ל משירותים כגון Gmail. יישום הדוא"ל תומך בסוגי החשבונות הבאים: POP3, IMAP ו-Exchange.
ספק השירות או מנהל המערכת שלך יכולים לספק לך את הגדרות החשבון הדרושות.

ניהול חשבון דוא"ל

בפעם הראשונה שתפתח את יישום ה**דוא"ל**, ייפתח אשף התקנה שיעזור לך להגדיר חשבון דוא"ל.
לאחר ההגדרה הראשונית, יישום הדוא"ל יציג את תוכן תיבת הדואר הנכנס שלך. אם הוספת יותר מחשבון אחד, באפשרותך לעבור בין החשבונות.

כדי להוסיף חשבון דוא"ל:

- גע ב- > הכרטיסייה **יישומים** > **דוא"ל** > הקש על > **הגדרות** > **הוסף חשבון**.

כדי לשנות את ההגדרות של חשבון דוא"ל:

- גע ב- > הכרטיסייה **יישומים** > **דוא"ל** > הקש על > **הגדרות** > **הגדרות כלליות**.

כדי למחוק חשבון דוא"ל:

- גע ב- > הכרטיסייה **יישומים** > **דוא"ל** > הקש על > **הגדרות** > הקש על > **הסר חשבון** > בחר את החשבון למחיקה > **הסר** > בחר ב**כן**.

עבודה עם תיקיות החשבון

גע ב- > הכרטיסייה **יישומים** > **דוא"ל**, גע ב- ובחר באפשרות **תיקיות**.
לכל חשבון ישנן תיקיות דואר נכנס, דואר יוצא, פריטים שנשלחו וטיוטות. בהתאם לתכונות שבהן תומך ספק השירות של החשבון, ייתכן שיהיו לך תיקיות נוספות.

חיבור ושליחה של דוא"ל

כדי לחבר ולשלוח הודעה

1 ביישום **דוא"ל**, גע ב- .
2 הזן כתובת עבור הנמען המיועד של ההודעה. תוך כדי הזנת הטקסט יוצעו כתובות תואמות מרשימת אנשי הקשר שלך. הפרד בין כתובות מרובות באמצעות תווי נקודה-פסיק.
3 גע בשדה עותק/עותק מוסתר כדי להוסיף נמען שיקבל עותק/עותק מוסתר וגע ב- כדי לצרף קבצים, במקרה הצורך.
4 הזן את טקסט ההודעה.
5 גע ב- .

אם אינך מחובר לרשת, למשל אם אתה עובד במצב טיסה, ההודעות שאתה שולח יאוחסנו בתיקייה 'תיבת דואר יוצא' עד שתתחבר שוב לרשת. אם תיבת הדואר היוצא מכילה הודעות ממתינות, היא תוצג במסך **חשבונות**.

עצה! כשהודעת דוא"ל חדשה מגיעה לתיבת הדואר הנכנס, תקבל התראה על כך באמצעות צליל או רטט. הקש על התראת הדוא"ל כדי להפסיק לקבל התראות.

כדי לפתוח את יישום המצלמה, גע ב- > הכרטיסייה **יישומים** > .

הכרת התצוגה המקדימה

1. **מבזק** – בחר מבין האפשרויות **כבוי** , **מופעל** , **אוטומטי** .
2. **החלף מצלמה** – החלף בין עדשת המצלמה האחורית לבין עדשת המצלמה הקדמית.
3. **מצב צילום** – בחר מבין האפשרויות **רגיל, גוון דינמי, פנורמה, צילום מתמשך, צילום יופי, צילום לכידת זמן, ספורט או לילה**.
4. **הגדרות** – הקש על סמל זה כדי לפתוח את תפריט ההגדרות.
5. **מצב וידאו** – הקש והחלק סמל זה למטה כדי לעבור למצב וידאו.
6. **לחצן הצמצם**
7. **גלריה** – הקש כדי להציג את התמונה האחרונה שצילמת. כך ניתן להיכנס לגלריה ולצפות בתמונות השמורות כשאתה נמצא במצב מצלמה.

הערה: יש לוודא שעדשת המצלמה נקייה לפני הצילום.

שימוש בהגדרות המתקדמות

בתצוגה המקדימה, הקש על ⚙ כדי לפתוח את האפשרויות המתקדמות. ניתן לשנות את הגדרות המצלמה על-ידי גלילה ברשימה. לאחר בחירת האפשרות הרצויה, הקש על מקש **הקודם**.

	כדי לצלם תמונה, אמור אחת מהמילים הבאות: Cheese, Smile, Whiskey, Kimchi או LG.
	מגדיר וקובע את כמות אור השמש הנכנסת לתמונה.
	הקש כדי לבחור את מצב המיקוד.
W10M	בוחר את רזולוציית התמונה. אם תבחר ברזולוציה גבוהה, גודל הקובץ יגדל, ופירושו שתוכל לאחסן פחות תמונות בזיכרון.
	דירוג ה-ISO קובע את רגישות חיישן האור של המצלמה. ככל שערך ה-ISO גבוה יותר, כך המצלמה רגישה יותר. הדבר מועיל בתנאי תאורה חשוכים כאשר לא ניתן להשתמש במבזק.
	משפר את איכות הצבע בתנאי תאורה שונים.
	מוסיף אפקטים אמנותיים לתמונות.
	מגדיר השהיה לאחר לחיצה על לחצן הצילום. מצב זה אידיאלי למקרה שתרצו להיות בתמונה בעצמך.
	הפעל כדי להשתמש בשירותים מבוססי-המיקום של הטלפון. **הערה:** פונקציה זו זמינה כאשר פונקציית ה-GPS פעילה או מחוברת לרשת.
	בוחר צליל צמצם.
	הגדר את מקש עוצמת הקול כדי לבחור אם להשתמש בצילום או בהגדלה.
	פותח את מדריך העזרה כדי לדעת כיצד פועלת פונקציה.
	משחזר את כל הגדרות ברירת המחדל של המצלמה.

עצה!

- כשתצא מפונקציית המצלמה, חלק מההגדרות יחזרו לערכי ברירת המחדל שלהן, למשל איזון לבן, אפקט צבע, טיימר ומצב סצנה. בדקו אותם לפני הצילום הבא שלכם.
- תפריט ההגדרות מופיע מעל התצוגה המקדימה, כך שאם תשנה רכיבי צבע או איכות בתמונה, תראה תצוגה מקדימה של התמונה עם השינויים מאחורי תפריט ההגדרות.

צילום מהיר

1. פתח את יישום **המצלמה**.
2. תוך כדי החזקת הטלפון בצורה אופקית, כוון את העדשה אל מושא הצילום.
3. תיבת פוקוס תופיע במרכז מסך התצוגה המקדימה. ניתן גם להקיש במקום כלשהו במסך כדי להציב את הפוקוס בנקודה זו.
4. כשתיבת המיקוד הופכת לירוקה, זה סימן שהמצלמה התמקדה בנושא הצילום.
5. גע כדי ללכוד את התמונה.

לאחר שצילמת תמונה

הקש על התמונה הממוזערת בתחתית המסך 'מצלמה' כדי להציג את הצילום האחרון שצילמת.

	הקש כדי לצלם תמונה נוספת מיד.
	הקש כדי לשלוח את התמונה לאחרים או לשתף אותה בשירותי רשתות חברתיות.
	הקש כדי למחוק את התמונה.
	הקש כדי לשתף תמונה באמצעות הפונקציה **SmartShare**.

עצה! אם יש לך חשבון SNS והגדרת אותו בטלפון, באפשרותך לשתף את התמונה שלך עם קהילת SNS.

הערה: אם אתה מוריד הודעות MMS תוך כדי נדידה, ייתכן שיחולו חיובים נוספים.

גע במקש התפריט ≡ כדי לפתוח את כל האפשרויות המתקדמות.

הגדרת תמונה בתור – הקש כדי להשתמש בתמונה בתור תמונת איש קשר, טפט למסך הראשי, **טפט למסך הנעילה או טפט**.

העבר – גע כדי להעביר את התמונה למקום אחר.

העתק – גע כדי להעתיק את התמונה הנבחרת ולשמור אותה באלבום אחר.

העתק אל מגש הגזירים – הקש כדי להעתיק את התמונה ולאחסן אותה ב'מגש הגזירים'.

שנה שם – גע כדי לערוך את שם התמונה הנבחרת.

סובב שמאלה/ימינה – כדי לסובב שמאלה או ימינה.

חתוך – חתוך את התמונה. העבר את אצבעך לרוחב המסך כדי לבחור את האזור המיועד לחיתוך.

ערוך – הצג וערוך את התמונה.

הצגת שקופיות – מראה לך את התמונות בתיקייה הנוכחית בזו אחר זו באופן אוטומטי.

הוסף מיקום – המצלמה מוגדרת ככבויה, תיוג המיקום, פרטי מיקום התמונה חסרים, ניתן להוסיף את פרטי המיקום.

הסר מיקום – המצלמה מוגדרת כמופעלת, תיוג המיקום, צילומים של פרטי המיקום, ניתן למחוק את פרטי המיקום.

הצג במפה – המצלמה מוגדרת כמופעלת, תיוג המיקום, פרטי מיקום התמונה, ניתן להציג את המיקום התואם במפה.

פרטים – קבל מידע נוסף אודות התוכן.

מתוך הגלריה

הקש על **גלריה**.

- להצגת תמונות נוספות, גלול ימינה או שמאלה.
- כדי להגדיל או להקטין את המרחק מהתצוגה, הקש פעמיים על המסך או מקם שתי אצבעות והפרד אותן (קרב את האצבעות כדי להגדיל את המרחק מהתצוגה).

הכרת התצוגה המקדימה

1. **מבזק** – בחר מבין האפשרויות **כבוי** , **מופעל** .
2. **החלף מצלמה** – החלף בין עדשת המצלמה האחורית לבין עדשת המצלמה הקדמית.
3. **מצב הקלטה** – בחר מבין האפשרויות 'רגיל' או 'אפקט חי'.
4. **הגדרות** – הקש על סמל זה כדי לפתוח את תפריט ההגדרות.
5. **מצב מצלמה** – הקש והחלק סמל זה כלפי מעלה כדי לעבור למצב מצלמה.
6. **התחל הקלטה**
7. **גלריה** – הקש כדי להציג את סרטון הווידאו האחרון שהקלטת. כך ניתן להיכנס לגלריה ולצפות בסרטוני הווידאו השמורים כשאתה נמצא במצב וידאו.

עצה!
כשאתה מקליט וידאו, הצב שתי אצבעות על המסך וצבוט כדי להשתמש בפונקציית שינוי גודל התצוגה.

שימוש בהגדרות המתקדמות

באמצעות כוונת המצלמה, גע בסמל ⚙ כדי לפתוח את כל האפשרויות המתקדמות.

HD	הקש כדי להגדיר את הגודל (בפיקסלים) של סרטון הווידאו שאתה מקליט.
	מגדיר וקובע את כמות אור השמש הנכנסת לעדשה. החלק את מחוון הבהירות לאורך הפס, לכיוון הסימן "-" להפחתת בהירות הווידאו או לכיוון "+" להגברת בהירות הווידאו.
	משפר את איכות הצבע בתנאי תאורה שונים.
	בחר גוון צבע לשימוש בתצוגה החדשה.
	הפעל כדי להשתמש בשירותים מבוססי-המיקום של הטלפון. **הערה:** פונקציה זו זמינה כאשר פונקציית ה-GPS פעילה או מחוברת לרשת.
	הגדר את מקש עוצמת הקול כדי לבחור אם להשתמש בהקלטה או בהגדלה.
	פותח את מדריך העזרה כדי לדעת כיצד פועלת פונקציה.
	משחזר את כל הגדרות ברירת המחדל של המצלמה.

הקלטת סרטון וידאו מהיר

1. פתח את יישום **המצלמה** וגע בלחצן **מצב וידאו**.
2. כעת תופיע התצוגה המקדימה של מצלמת הווידאו על המסך.
3. החזק את הטלפון וכוון את העדשה אל הנושא שברצונך לצלם בסרטון הווידאו.
4. גע ב- פעם אחת כדי להתחיל בהקלטה.
5. נקודה אדומה תופיע בפינה השמאלית העליונה של התצוגה המקדימה יחד עם קוצב זמן שיציג את אורך הסרטון.
6. גע ב במסך כדי להפסיק את ההקלטה.

עצה!

– הקש כדי לצלם תמונה בעת הקלטת סרטון וידאו.

– הקש כדי להשהות הקלטת סרטון וידאו.

לאחר הקלטת וידאו

בתצוגה המקדימה, הקש על התמונה הממוזערת של הווידאו בתחתית המסך כדי להציג את הווידאו האחרון שצילמת.

	הקש כדי להקליט עוד סרטון וידאו מייד.
	הקש כדי לשלוח את הווידאו לאחרים או לשתף אותה בשירותי רשתות חברתיות.
	הקש כדי למחוק את הווידאו.
	הקש כדי לשתף וידאו באמצעות הפונקציה **SmartShare**.

הערה: אם אתה מוריד הודעות MMS תוך כדי נדידה, ייתכן שיחולו חיובים נוספים.

צפייה בסרטוני הווידאו שנשמרו

1 בתצוגה המקדימה, הקש על .
2 הגלריה שלך תופיע על המסך.
3 הקש על סרטון וידאו כדי להפעיל אותו באופן אוטומטי.

כוונון העוצמה בעת צפייה בסרטוני וידאו

לכוונון עוצמת הקול של סרטון וידאו בעת הפעלתו, השתמש במקשי עוצמת הקול בצדו השמאלי של הטלפון.

הפונקציה QuickMemo

השתמש ב**פונקציה QuickMemo** כדי ליצור תזכורות באופן מעשי ויעיל במהלך שיחה, עם תמונה שמורה או במסך הטלפון הנוכחי.

1 היכנס למסך הפונקציה QuickMemo על-ידי לחיצה בו-זמנית על המקשים Volume Up (הגברת עוצמת הקול) ו-Volume Down (החלשת עוצמת הקול) במסך שברצונך ללכוד.

או

או

גע והחלק את שורת המצב כלפי מטה וגע ב- .

2 בחר באפשרות התפריט הרצויה מבין **Pen type** (סוג עט), **Color** (צבע) ו-**Eraser** (מחק), וצור מזכר.

3 גע ב- בתפריט 'עריכה' ובחר באפשרות זו כדי לשמור את התזכו־רת עם המסך הנוכחי.

הערה: השתמש בקצה האצבע בזמן השימוש בפונקציה QuickMemo. אל תשתמש בציפורניך.

שימוש באפשרויות QuickMemo

ניתן להשתמש בקלות באפשרויות QuickMenu בעת שימוש בפונקציה QuickMemo.

	גע כדי לשמור את התזכורת הנוכחית על המסך ולהשתמש בטלפון בו-זמנית.
	בוחר אם להשתמש במסך הרקע או לא.
	בטל או בצע שוב.
	בוחר את סוג העט ואת הצבע.
	מוחק את התזכורת שיצרת.
	גע כדי לשלוח את התזכורת לאחרים או לשתף אותה בשירותי רשתות חברתיות.
	שומר את התזכורת עם המסך הנוכחי ב**גלריה/פנקס רשימות**.

הצגת ה-QuickMemo שנשמר

גע ב**גלריה/פנקס רשימות** ובחר את אלבום QuickMemo.

פונקציית פנקס רשימות

בעזרת היישום 'פנקס רשימות', תוכל לנהל ולהעניק גוון אישי למגוון רחב של סוגי מידע. פנקס רשימות מאפשר לך ליצור פתקים מיוחדים משלך יחד עם ציורים, תמונות, מפות ומדבקות.

יצירת פתק

1 גע ב- > הכרטיסייה **יישומים** > **פנקס רשימות**.
2 כדי ליצור פתק חדש, גע בפריט **פתק חדש**.
3 בחר את המצב הרצוי (**כריכה**, **כותרת**, **נייר**, **צבע נייר**) ולאחר מכן הקש על **אישור**.
4 יוצר פתק פשוט בעמוד ריק.

הכרת פנקס הרשימות

חלוניות של מאפייני עמודים

מדף ספרים

מדף ספרים

	חפש עמודי פתקים.
	שתף כקובץ פנקס רשימות, כקובץ PDF או כקובץ תמונה באמצעות דוא"ל/ Gmail.

	מחק את פנקס הרשימות השמור ממדף הספרים.

חלוניות של מאפייני עמודים

	בחר מצב קריאה בלבד או עריכה.
	בטל או בצע שוב.
	הקש על לחצן זה כדי לכתוב.
	בחר את סוג העט, עובי הקו, מידת השקיפות והצבע.
	מחק את התזכורת שיצרת.
	גע כדי לצרף קבצים לפתק.
	גע כדי לשלוח את הפתק לאחרים או לשתף אותו בשירותי רשתות חברתיות.
	שמור את הפתק עם המסך הנוכחי.
	בחר כדי לנעול או לבטל את נעילת המקש הקדמי.
	הקש על לחצן זה כדי להגדיל את אזור הזנת המידע.

הצגת פנקס הרשימות השמור

- תזכורות פנקס רשימות שמורות נמצאות במדף הספרים.
- אם אתה שומר תזכורות מתוך QuickMemo, פתק של QuickMemo נוצר ונשמר במדף הספרים באופן אוטומטי.

הערה: לקבלת מידע נוסף על מדריך פנקס הרשימות, ראה **פנקס רשימות** > **מדריך פנקס רשימות**.

פונקציית שינוי גודל תצוגה בשידור חי

שינוי גודל תצוגה בשידור חי מאפשר לך להגדיל או להקטין קטע של הווידאו המוצג כדי שהסריקה הרצויה תיראה גדולה או קטנה יותר.

1 כשאתה צופה בווידאו, השתמש באצבע המורה ובאגודל בתנועת צביטה או פריסה כדי להקטין או להגדיל את התצוגה.

הערה:

- במצב הצגת וידאו, החלק את המסך מעלה או מטה, בהירות המסך (צד שמאל), עוצמת הקול (צד ימין) תותאם.
- במצב הצגת וידאו, כשאתה מחליק את המסך ימינה או שמאלה, עוצמת הקול משתנה.

הערה: אין צורך ללחוץ חזק מדי, מסך המגע רגיש דיו כדי לחוש במגע קל אך החלטי.

הפונקציה QSlide

הפונקציה QSlide מאפשרת שכבת-על על מסך הטלפון שלך לצורך צפייה נוחה בחלונות מרובים.

1		גע כדי לצאת מהפונקציה QSlide ולחזור לחלון מלא.
2		הקש כדי לכוונן את השקיפות.
3		הקש כדי להפסיק את הפונקציה QSlide.
4		הקש כדי להתאים את הגודל.

1 גע והחלק את שורת המצב כלפי מטה > גע ביישומי QSlide או בעת שימוש בפונקציה שנתמכת על-ידי הפונקציה QSlide > גע ב- . הפונקציה תוצג באופן רציף כחלון קטן על המסך.

2 באפשרותך לבצע שיחה, לגלוש באינטרנט או לבחור אפשרויות אחרות בטלפון. באפשרותך גם להשתמש ולהקיש על המסך של החלונות הקטנים כשסרגל השקיפות אינו מלא. .

הערה: הפונקציה QSlide יכולה לתמוך בכמות של עד שני חלונות בו-זמנית.

עצה!
גע במגירת ההתראות והחלק אותה כלפי מטה באמצעות אצבעך.
גע ב- כדי לנהל את 'הגדרות מהירות' או את 'QSlide' במגירת ההתראות.

פונקציית הפעלה כפולה

באפשרותך להציג מסכים שונים בשני צגים המחוברים ביניהם באופן אלחוטי או באמצעות כבל.

1 מצב הפעלה כפולה מופעל על-ידי הקשה על מקש 'בית' בעת הפעלת תוכן בצג החיצוני.

2 באפשרותך להפסיק להפעיל את התוכן בצג החיצוני באמצעות מגירת ההתראות.

חשוב

- חבר את הטלפון החכם שלך לצג באופן אלחוטי (Miracast) או באמצעות כבל (כבל MHL).
- ניתן לחבר לטלפון החכם טלוויזיה או צג שתומכים ב-MHL או ב-Miracast.
- ייתכן שפונקציית ההפעלה הכפולה לא תתמוך בקובצי וידאו מסוימים.
- מומלץ להשתמש בכבל Shielded LG MHL.

שיקוף

הפעלה כפולה

הערה:
- הפעלה כפולה נתמכת על-ידי 3 יישומים - Videos, Media Home (MHL בלבד), Polaris Office 4.
- רזולוציית הטלוויזיה המינימלית הנדרשת עבור הפעלה כפולה היא 720p (1280x720)

LG SmartWorld

LG SmartWorld מציע מבחר תוכן מסעיר – גופנים, ערכות נושא, משחקים ויישומים.

גישה ל-LG SmartWorld מהטלפון

1 גע ב- > הכרטיסייה **יישומים** > הקש על סמל כדי לגשת אל **LG SmartWorld**.

2 הקש על 'כניסה למערכת' והזן שם משתמש וסיסמה ל-LG SmartWorld. אם עדיין לא נרשמת, הקש על 'הירשם' כדי לקבל חברות ב-LG SmartWorld.

3 הורד את התוכן הרצוי.

- כאשר תשתמש ברשת סלולרית, ייתכן שתחויב עבור העברת נתונים בהתאם לתוכנית הנתונים שאליה נרשמת אצל ספק השירות.
- ייתכן ש-LG SmartWorld לא יהיה זמין בכל המדינות ואצל כל הספקים.

הערה: מה לעשות אם אין סמל ?

1 באמצעות דפדפן אינטרנט של מכשיר נייד, גש ל-LG SmartWorld (www.lgworld.com) ובחר את מדינתך.

2 הורד את יישום LG SmartWorld.

3 הפעל והתקן את הקובץ שהורדת.

4 גש אל LG SmartWorld על-ידי הקשה על הסמל .

הטבה מיוחדת - רק LG SmartWorld

1 עצב סגנון משלך בטלפון החכם, השתמש ב'ערכת נושא התחלתית' ו'ערכת מקלדת וגופן' שסופקו ב-LG SmartWorld (עם זאת, שירות זה זמין במכשירים ספציפיים. בדוק באתר האינטרנט של LG SmartWorld אם הוא זמין או לא)

2 אתה מוזמן ליהנות מהשירות המיוחד של LG SmartWorld ולקבל מידע על המבצעים שאנו מציעים.

On-Screen Phone

On-Screen Phone מאפשר לך להציג את מסך הטלפון הנייד שלך ממחשב דרך חיבור USB או חיבור Wi-Fi. ניתן לשלוט בטלפון הנייד גם מהמחשב, באמצעות עכבר או מקלדת.

סמלי טלפון במסך המחשב

	לחיבור הטלפון הנייד למחשב וניתוקו.
	שנה את העדפות הטלפון במסך המחשב.
	ליציאה מתוכנית 'טלפון במסך המחשב'.
	הגדלה מרבית של חלון הטלפון במסך המחשב.
	מזעור של חלון הטלפון במסך המחשב.

תכונות הטלפון במסך המחשב

- העברה ושליטה בזמן אמת: הצגה של מסך הטלפון הנייד ושליטה עליו בעת החיבור למחשב.
- שליטה בעכבר: אפשרות לשלוט בטלפון הנייד על-ידי לחיצה וגרירה באמצעות העכבר במסך המחשב.
- הזנת טקסט באמצעות מקלדת: אפשרות לחבר הודעת טקסט או הערה באמצעות מקלדת המחשב.

- העברת קבצים (מטלפון נייד למחשב): שליחת קבצים מהטלפון הנייד (לדוגמה, תמונות, סרטוני וידאו, מוסיקה וקובצי Polaris Office) למחשב. לחץ באמצעות לחצן העכבר הימני על הקובץ שברצונך לשלוח למחשב ולחץ על 'שמור במחשב'.
- העברת קבצים (מהמחשב לטלפון הנייד): שליחת קבצים מהמחשב לטלפון הנייד. בחר את הקבצים שברצונך להעביר כדי לגרור אותם אל חלון 'טלפון במסך המחשב' ולשחררם שם. הקבצים שנשלחו מאוחסנים בכרטיס SD פנימי.
- התראות אירועים בזמן אמת: מופיע חלון מוקפץ הכולל הודעה על שיחות נכנסות או על הודעות טקסט/מולטימדיה.

כיצד להתקין On-Screen Phone במחשב

1. בקר באתר LG Home (www.lg.com) ובחר מדינה.
2. עבור אל **תמיכה** > **תמיכה בטלפון נייד** > בחר את הדגם (LG-E975k) > לחץ על **OSP** (On-Screen Phone) להורדה. ניתן להתקין את יישום 'טלפון במסך המחשב' (On-Screen Phone) במחשב האישי.

גלריה

באפשרותך לאחסן קובצי מולטימדיה בזיכרון פנימי כדי לקבל גישה נוחה לכל קובצי המולטימדיה שלך. השתמש ביישום זה כדי להציג קובצי מולטימדיה כגון תמונות וסרטוני וידאו.

1 גע ב- > הכרטיסייה **יישומים** > **גלריה**.
באפשרותך לנהל ולשתף את כל קובצי התמונות וסרטוני הווידאו שלך באמצעות הגלריה.

הערה:
- תבניות קבצים מסוימות אינן נתמכות, בהתאם לתוכנה המותקנת במכשיר.
- ייתכן שקבצים מסוימים לא יופעלו באופן תקין, בהתאם לקידוד שלהם.

הצגת תמונות

הפעלת הגלריה מציגה את התיקיות הזמינות שלך. כשיישום אחר, כגון דוא"ל, שומר תמונה, תיקיית ההורדה נוצרת באופן אוטומטי כדי להכיל את התמונה. בדומה לכך, לכידת צילום מסך יוצרת באופן אוטומטי את תיקיית צילומי המסך. בחר תיקייה כדי לפתוח אותה.

התמונות מוצגות בתיקייה לפי תאריך יצירה. בחר תמונה כדי להציג אותה במסך מלא. גלול שמאלה או ימינה כדי להציג את התמונה הבאה או הקודמת.

הגדלה או הקטנה של התצוגה

השתמש באחת השיטות הבאות כדי להגדיל תצוגת תמונה:
- הקש פעמיים בנקודה כלשהי כדי להגדיל את התצוגה.
- הזז שתי אצבעות בתנועת פריסה בנקודה כלשהי כדי להגדיל את התצוגה. צבוט כדי להקטין את התצוגה, או הקש פעמיים כדי לחזור.

הפעלת סרטוני וידאו

בקובצי וידאו מופיע סמל בתצוגה המקדימה. בחר סרטון וידאו כדי לצפות בו והקש על . יישום **סרטוני הווידאו** יופעל.

עריכת תמונות/סרטוני וידאו

כשאתה צופה בתמונה/וידאו, הקש על מקש ה**תפריט** והשתמש באפשרויות העריכה המתקדמות.

- הצגת שקופיות: צור הצגת שקופיות באמצעות התמונות בתיקייה הנוכחית.

מחיקת תמונות

השתמש באחת השיטות הבאות:

- בתיקייה, הקש על ובחר תמונות/סרטוני וידאו על-ידי סימון, ולאחר מכן הקש על **מחק**.
- כשאתה צופה בתמונה/וידאו, הקש על .

הגדרה כטפט

כשאתה צופה בתמונה, גע במקש ה**תפריט** > **הגדר תמונה כ-** כדי להגדיר את התמונה כטפט או לשייך אותה לאיש קשר.

הערה:

- חלק מתבניות הקבצים אינן נתמכות, בהתאם לתוכנת המכשיר.
- אם גודל הקובץ חורג מכמות הזיכרון הפנוי, עלולה להתרחש שגיאה בעת פתיחת קבצים.

סרטוני וידאו

הטלפון שלך כולל נגן וידאו מובנה שמאפשר לך להציג את כל סרטוני הווידאו המועדפים שלך. כדי לגשת לנגן הווידאו, גע ב- > הכרטיסייה **יישומים** > **סרטוני וידאו**.

הפעלת קובץ וידאו

1 גע ב- > הכרטיסייה **יישומים** > **סרטוני וידאו**.
2 בחר בסרטון הווידאו שברצונך להפעיל.

1 /	גע כדי להשהות/ להמשיך את הפעלת הווידאו.
2	גע כדי לעבור 10 שניות קדימה.
3	גע כדי לעבור 10 שניות אחורה.
4	גע כדי לשנות את עוצמת הווידאו.
5 / /	גע כדי לשנות את היחס של מסך הווידאו.
6	הקש כדי לצלם תמונה בעת הפעלת סרטון וידאו.
7	גע כדי להשתמש ב-QSlide.
8	גע עבור Smart Share
9 /	גע כדי לנעול/לבטל נעילת מסך וידאו.

כדי לשנות את עוצמת הקול במהלך צפייה בווידאו, הקש על מקשי הגברת/הנמכת עוצמת הקול שבצדו השמאלי של הטלפון.

גע נגיעה ממושכת באחד הסרטונים ברשימה. יוצגו האפשרויות **שתף**, **מחק**, **חתוך** **ופרטים**.

עורך הווידיאו

באפשרותך לערוך את התמונות ואת סרטוני הווידאו המאוחסנים בטלפון.

הערה: פונקציית עריכת הווידאו נתמכת רק עבור תמונות או סרטוני וידאו שהוקלטו בטלפון זה.

< מסך רשימת פרויקטים >

	צור פרויקט
	יש לייצא את הפרויקטים כדי להפעיל אותם ביישומים כגון יישום סרטוני הווידאו
	הפעל פרויקט
	מחק פרויקט
	שתף פרויקט עם יישום כגון YouTube

< מסך עריכת פרויקטים >

	עבור למסך רשימת הפרויקטים. הפרויקט הנוכחי שאתה עורך נשמר באופן אוטומטי
	פצל את סרטון הווידאו לשני חלקים בנקודת ההפעלה הנוכחית
	הוסף אפקט קול
	הוסף וידאו, תמונה או קטע שמע
	בטל פעולה
	בצע שוב פעולה
	הוסף טקסט לווידאו או לתמונה

אשף הווידאו

באפשרותך ליצור סרט מתמונות/סרטוני וידאו ופריטי מוסיקה שברשותך.

1 גע ב- > הכרטיסייה **יישומים** > **אשף הווידאו**.

2 לאחר שתצפה במבוא קצר המתאר את השלבים הבאים, הקש על **אישור**.

3 הקש על ⊕ כדי להוסיף לסרט שלך תמונות או וידאו.

4 הקש על התמונות או על סרטוני הווידאו הרצויים ולאחר מכן הקש על ☑.

- כדי להסיר תמונות או סרטוני וידאו, הקש על 🗑 ובחר את הקבצים הרצויים > ☑.
- כדי לשנות את הסדר שלהם, גע נגיעה ממושכת בתמונה/וידאו, ולאחר מכן גרור ושחרר למיקום הרצוי.

5 הקש על **בחר סגנון** כדי לבחור את הסגנון הרצוי לסרט.

- גלול ובחר את הסגנון הרצוי. כשתגלול בין הסגנונות תופיע תצוגה מקדימה.

6 הקש על **בחר מוסיקה** כדי להגדיר את מוסיקת הרקע.

7 הקש על ▶ כדי להפעיל את הסרט.

8 הקש על ✎ כדי לערוך את סרטון הווידאו בעזרת טקסט, מדבקה או נקודת קסם.

- לאחר עריכת הסרטון, הקש על ☑.

9 הקש על 💾 כדי לשמור את הסרטון.

10 הקש על ⓘ כדי להציג עזרה עבור השימוש בתכונה זו.

מוסיקה

הטלפון שלך כולל נגן מוסיקה מובנה שמאפשר לך להשמיע את כל הרצועות המועדפות שלך. כדי לגשת לנגן המוסיקה, גע ב- ▦ > הכרטיסייה **יישומים** > **מוסיקה**.

השמעת שיר

1 גע ב- > הכרטיסייה **יישומים** > **מוסיקה**.
2 גע ב**שירים**.
3 בחר בשיר שברצונך להשמיע.

1	/	הקש כדי להשהות/לחדש את ההפעלה.
2		הקש כדי לדלג לרצועה הבאה באלבום, ברשימת ההשמעה או בהשמעה אקראית. הקש והחזק כדי להריץ קדימה.
3		הקש כדי להפעיל מחדש את הרצועה הנוכחית או לדלג אל הרצועה הקודמת באלבום, ברשימת ההשמעה או בהשמעה האקראית. הקש והחזק כדי להריץ אחורה.
4		הקש כדי להציג את פס המחוון של עוצמת הקול, ולאחר מכן התאם את עוצמת הקול של ההשמעה בפס המחוון.
5		גע כדי להגדיר 'אפקטים קוליים'.

6	YouTube	הקש כדי לאתר את הקבצים ב-YouTube.
7		הקש כדי לפתוח את רשימת ההשמעה הנוכחית.
8		הקש כדי להוסיף שיר למועדפים שלך.
9		הקש כדי להפעיל את רשימת ההשמעה הנוכחית במצב אקראי (הרצועות מופעלות בסדר אקראי).
10		הקש כדי להחליף בין מצבי החזרה 'חזור על כל השירים', 'חזור על השיר הנוכחי', או 'החזרה מושבתת'.
11		SmartShare.

כדי לשנות את עוצמת הקול במהלך האזנה למוסיקה, הקש על מקשי הגברת/הנמכת עוצמת הקול שבצדו השמאלי של הטלפון.

גע ברציפות בשיר כלשהו ברשימה. יוצגו האפשרויות **השמע**, **הוסף לרשימת השמעה**, **שתף**, **הגדר כרינגטון**, **מחק**, **פרטים** ו**חפש**.

הוספת קובצי מוסיקה לטלפון

התחל על-ידי העברת קובצי מוסיקה לטלפון:

- העבר מוסיקה באמצעות סנכרון מדיה (MTP).
- הורד מהאינטרנט האלחוטי.
- סנכרן את הטלפון עם מחשב.
- קבל קבצים באמצעות Bluetooth.

העבר מוסיקה באמצעות סנכרון מדיה (MTP)

1. חבר את הטלפון למחשב באמצעות כבל ה-USB.
2. בחר באפשרות **סנכרון מדיה (MTP)**. הטלפון שלך יופיע ככונן קשיח נוסף במחשב. לחץ על הכונן כדי להציג אותו. העתק את הקבצים מהמחשב לתיקיית הכונן.
3. לאחר שתסיים להעביר קבצים, החלק מטה את שורת המצב וגע באפשרות **USB מחובר** > **טעינה בלבד**. כעת תוכל לנתק את ההתקן בבטחה.

הערה:

- חלק מתבניות הקבצים אינן נתמכות, בהתאם לתוכנת המכשיר.
- אם גודל הקובץ חורג מכמות הזיכרון הפנוי, עלולה להתרחש שגיאה בעת פתיחת קבצים.

הערה: זכויות היוצרים של קובצי מוסיקה עשויות להיות מוגנות על ידי אמנות בינלאומיות וחוקי זכויות יוצרים לאומיים.
לפיכך ייתכן שתצטרך להשיג אישור או רישיון כדי לשכפל או להעתיק מוסיקה. במדינות מסוימות, החוק המקומי אוסר על העתקה פרטית של חומרים המוגנים בזכויות יוצרים. לפני הורדה או העתקה של הקובץ, בדוק את החוקים הלאומיים של המדינה הרלוונטית ביחס לשימוש בחומרים מסוג זה.

הגדרת התראה

1 גע ב- > הכרטיסייה **יישומים** > **התראה/שעון** > .
2 לאחר הגדרת ההתראה, הטלפון שלך יודיע לך כמה זמן נותר עד להשמעת ההתראה.
3 הגדר **חזרה**, **אורך נודניק**, **רטט**, **צליל התראה**, **עוצמת התראה**, **הפע־לת יישום אוטומטית**, **נעילת פאזל** ו**תזכורת**. גע ב**שמור**.

הערה: כדי לשנות את הגדרות ההתראה במסך רשימת ההתראות, גע במקש ה**תפריט** ובחר 'הגדרות'.

שימוש במחשבון

1 גע ב- > הכרטיסייה **יישומים** > **מחשבון.**
2 הקישו על מקשי הספרות כדי להזין מספרים.
3 לביצוע חישובים פשוטים, גע בפעולה שברצונך לבצע (+, -, x או ÷), ולאחר מכן =.
4 עבור חישובים מורכבים יותר, החלק לשמאל ולאחר מכן בחר באפשרויות sin, cos, tan, log וכן הלאה.
5 כדי לבדוק את ההיסטוריה, גע ב- ובחר בהיסטוריית חישובים.

הוספת אירוע ללוח השנה

1 גע ב- > הכרטיסייה **יישומים** > **לוח שנה.**
2 במסך תוכל למצוא את סוגי התצוגה השונים של לוח השנה (יום, שבוע, לוח זמנים).
3 הקש על התאריך שבו ברצונך להוסיף אירוע וגע ב- .
4 גע באפשרות **שם אירוע** והזן את שם האירוע.
5 גע באפשרות **מיקום** והזן את המיקום. סמן את התאריך והזן את שעות ההתחלה והסיום של האירוע.

6 אם ברצונך להוסיף הערה לאירוע, גע באפשרות **תיאור** והזן את הפרטים.
7 אם ברצונך לחזור על ההתראה, הגדר **חזרה** והגדר **תזכורות** במקרה הצורך.
8 הקש על **שמור** כדי לשמור את האירוע בלוח השנה.

רשמקול

השתמש ברשמקול כדי להקליט תזכורות קוליות או קובצי שמע אחרים.

הקלטת צלילים או קול

1 גע ב- > הכרטיסייה **יישומים** ובחר באפשרות **רשמקול**.
2 גע ב- להתחלת ההקלטה.
3 גע ב- לסיום ההקלטה.
4 גע ב- כדי להאזין להקלטה שערכת.

הערה: גע ב- כדי לגשת לאלבום. תוכל להאזין להקלטה שנשמרה. זמן ההקלטה הזמין עשוי להיות שונה מזמן ההקלטה בפועל.

שליחת ההקלטה הקולית

1 לאחר שסיימת את ההקלטה, תוכל לשלוח את קליפ השמע על-ידי נגיעה ב- .
2 בחר מבין האפשרויות **Bluetooth**, **Drive**, **דואר אלקטרוני**, , **תזכורת**, **הודעות** או **SmartShare Beam**. כאשר אתה בוחר, הקלטת הקול נוספת להודעה שלך. לאחר מכן תוכל לכתוב ולשלוח את ההודעה כרגיל.

מנהל המשימות

באפשרותך לנהל את היישומים שלך באמצעות מנהל המשימות. ניתן לבדוק בקלות את מספר היישומים הפועלים כעת ולסגור יישומים מסוימים. ניתן גם להסיר התקנה של יישומים שהתקנת במכשיר.

משימות

ניתן לסנכרן משימה זו מול חשבון MS Exchange. ניתן ליצור משימה, לערוך אותה ואף למחוק אותה ב-MS Outlook או ב-MS Office Outlook Web Access.

כדי לסנכרן מול MS Exchange

1 במסך הראשי, גע ב- > **הגדרות**.
2 גע ב- **חשבונות וסנכרון** > **הוסף חשבון**.
3 גע ב- **Microsoft Exchange** כדי ליצור כתובת דוא"ל וסיסמה.
4 הקפד לסמן את המשימה 'סנכרון'.

Polaris Office 4

Polaris Office הוא פתרון מקצועי למשרד הנייד, שמאפשר למשתמשים להציג בנוחות סוגים שונים של מסמכים משרדיים, כולל קובצי Word, Excel ו-PowerPoint, בכל מקום ובכל זמן, באמצעות המכשירים הניידים שלהם.

גע ב- > הכרטיסייה **יישומים** > **Polaris Office 4**.

הצגת קבצים

כעת יכולים משתמש ניידים להציג מגוון רחב של סוגי קבצים, לרבות מסמכי Microsoft Office ו-Adobe PDF, ישירות במכשיר הנייד. בעת ההצגה של מסמכים בעזרת Polaris Office, האובייקטים והפריסה נותרים כפי שהיו במסמכים המקוריים.

גיבוי

אודות גיבוי ושחזור של נתונים בטלפונים חכמים

מומלץ ליצור ולשמור בקביעות קובץ גיבוי באחסון הפנימי, בייחוד לפני עדכון של פריט תוכנה. שמירת קובץ גיבוי עדכני בזיכרון האחסון עשויה לאפשר לך לשחזר את נתוני הטלפון החכם במקרה שהטלפון החכם שלך אובד, נגנב או ניזוק עקב בעיה לא צפויה.

יישום גיבוי זה נתמך בין טלפונים חכמים של LG, גרסאות תוכנה אחרות ומערכות הפעלה אחרות. עקב כך, כשאתה קונה טלפון חכם חדש של LG, באפשרותך לגבות את הנתונים מהטלפון הנוכחי שלך לטלפון החדש.

אם טענת מראש את היישום **גיבוי** בטלפון החכם שלך, תוכל לגבות ולשחזר בעזרתו את מרבית נתוני הטלפון החכם, **יישומים** לרבות יישומים לא מוגנים ואת ההגדרות שלהם, **יישומים (שהורדו)**, **יישומים (שהותקנו מראש)**, **סימניות**, **לוח שנה**, **יומן שיחות**, **אנשי קשר**, **המסך הראשי**, **הודעות** וכן **הגדרות מערכת**.

- בצע גיבוי ידני של נתוני הטלפון החכם.
- תזמן גיבויים אוטומטיים של נתוני הטלפון החכם.
- שחזר את נתוני הטלפון החכם.

הערה: שים לב שפונקציית הגיבוי אינה תומכת בגיבוי נתוני משתמשים ונתוני מדיה (תמונות/וידאו/מוסיקה). יש לגבות קבצים אלה באמצעות סנכרון מדיה (MTP). חבר את הטלפון למחשב באמצעות כבל USB וגע באפשרות סנכרון מדיה (MTP).

⚠ אזהרה

כדי להגן מפני כיבוי לא צפוי במהלך פעולות הגיבוי או השחזור עקב סוללה חלשה מדי, דאג שהסוללה תהיה תמיד טעונה באופן מלא.

גיבוי

1 גע ב- > הכרטיסייה **יישומים** > **גיבוי LG** > **גיבוי**.
2 בחר בתיבת הסימון לצד הפריט שברצונך לגבות, ולאחר מכן הקש על 'הבא' כדי לבצע את הגיבוי.
3 גע ב**אחסון** פנימי > **התחל**.
4 לאחר שכל הקבצים שנבחרו גובו, תוכל לגעת ב**אישור** כדי לסיים את הגיבוי.

תזמון גיבוי

באפשרותך גם לתכנת גיבויים אוטומטיים של הנתונים בטלפון החכם שלך, לפי הגדרת לוח הזמנים שלך.
לשם כך, בצע את הפעולות הבאות:
גע ב- > הכרטיסייה **יישומים** > **גיבוי LG** > **תזמן גיבוי**.

ניהול ושחזור קבצים

באפשרותך להגדיר את שחזור קובץ הגיבוי למצב הרצוי.
כדי לשחזר נתונים המאוחסנים בזיכרון הפנימי של המכשיר, יש לכבות את מצב אחסון בנפח גדול.
גע ב- > הכרטיסייה **יישומים** > **גיבוי LG** > **שחזור וניהול קבצים** > **אחסון פנימי**.

הערה:
תוכל גם לתזמן מחיקה אוטומטית של גיבויים ישנים ולשמור רק את הגיבוי האחרון. גע ב**תפריט** ממסך **גיבוי** ובחר באפשרות **הגדרות** > **גיבוי מתוזמן** > **מחיקה אוטומטית של גיבויים ישנים** כדי לבחור את מספר הגיבויים המתוזמנים שברצונך לשמור.

Google+

השתמש ביישום זה כדי לשמור על קשר עם אנשים באמצעות שירות הרשת החברתית של Google.

- גע ב- > הכרטיסייה **יישומים** > **Google+**.

הערה: ייתכן שיישום זה לא יהיה זמין, בהתאם לאזור או לספק השירות.

חיפוש קולי

השתמש ביישום זה כדי לחפש דפי אינטרנט באמצעות קולך.

1 גע ב- > הכרטיסייה **יישומים** > **חיפוש קולי**.
2 אמור מילת מפתח או צירוף מילים כשהאפשרות **דבר עכשיו** מופיעה על המסך. בחר אחת ממילות המפתח המוצעות שיופיעו.

הערה: ייתכן שיישום זה לא יהיה זמין, בהתאם לאזור או לספק השירות.

הורדות

השתמש ביישום זה כדי לראות אילו קבצים הורדו ביישומים.

- גע ב- > הכרטיסייה **יישומים** > **הורדות**.

הערה: ייתכן שיישום זה לא יהיה זמין, בהתאם לאזור או לספק השירות.

אינטרנט

השתמש ביישום זה כדי לגלוש באינטרנט. הדפדפן מעניק לך עולם מהיר וצבעוני של משחקים, מוסיקה, חדשות, ספורט, בידור והרבה יותר, היישר לתוך הטלפון הנייד שלך, בכל מקום ועבור כל תחומי העניין שלך.

הערה: יחולו חיובים נוספים בעת התחברות לשירותים אלה והורדת תוכן. בדקו את תעריפי העברת הנתונים אצל ספק הרשת שלכם.

1 גע ב- > הכרטיסייה **יישומים** > **אינטרנט**.

שימוש בסרגל הכלים של האינטרנט

גע נגיעה ממושכת בסרגל הכלים של האינטרנט והחלק אותו כלפי מעלה באמצעות האצבע כדי לפתוח אותו.

	גע כדי לחזור דף אחד אחורה.
	גע כדי להתקדם דף אחד קדימה, לדף שאליו התחברת אחרי הדף הנוכחי. זוהי הפעולה ההפוכה לעומת נגיעה במקש **חזרה**, שמחזירה אותך לדף הקודם.
	גע כדי לעבור לדף הבית.
	הקש כדי להוסיף חלון חדש.
	גע כדי לגשת לסימניות.

הצגת דפי אינטרנט

הקש על שדה הכתובת, הזן את כתובת האינטרנט והקש על **עבור**.

פתיחת דף

כדי לעבור לדף חדש, הקש על ←
כדי לעבור לדף אינטרנט אחר, הקש על , גלול מעלה או מטה והקש על הדף כדי לבחור אותו.

חיפוש באינטרנט באופן קולי

הקש על שדה הכתובת, הקש על , אמור מילת מפתח ולאחר מכן בחר אחת ממילות המפתח המוצעות שיופיעו.

הערה: ייתכן שתכונה זו לא תהיה זמינה, בהתאם לאזור או לספק השירות.

סימניות

כדי לסמן את דף האינטרנט הנוכחי בסימנייה, גע ב- > **הוסף לסימניות** > **אישור**.
כדי לפתוח דף אינטרנט שסומן בסימנייה, הקש על ובחר את אחת הסימניות.

היסטוריה

הקש על > **היסטוריה** כדי לפתוח דף אינטרנט מתוך רשימת דפי האינטרנט שבהם ביקרת לאחרונה. כדי לנקות את ההיסטוריה, הקש על תפריט ← **נקה את כל ההיסטוריה**.

שימוש בדפדפן מוקפץ

השתמש בתכונה זו כדי לגשת לאינטרנט מבלי לסגור את היישום הנוכחי.
בזמן שאתה צופה בתוכן, כגון אנשי קשר או פתקים המכילים כתובות אינטרנט, בחר כתובת אינטרנט ולאחר מכן הקש על 'דפדפן מוקפץ' כדי לפתוח את הדפדפן המוקפץ. הקש וגרור את הדפדפן כדי להעביר אותו למיקום אחר.
כדי להציג את הדפדפן במסך מלא, הקש על .
כדי לסגור את הדפדפן, הקש על .

האינטרנט

Chrome

השתמש ב-Chrome כדי לחפש מידע ולגלוש בדפי אינטרנט.

1 גע ב- > הכרטיסייה **יישומים** > **Chrome**.

הערה: ייתכן שיישום זה לא יהיה זמין, בהתאם לאזור ולספק השירות.

הצגת דפי אינטרנט

הקש על שדה הכתובת ולאחר מכן הזן כתובת אינטרנט או קריטריון חיפוש.

פתיחת דף

כדי לעבור לדף חדש, הקש על > **כרטיסייה חדשה**.

כדי לעבור לדף אינטרנט אחר, הקש על , גלול מעלה או מטה והקש על הדף כדי לבחור אותו.

סנכרון עם מכשירים אחרים

סנכרן כרטיסיות פתוחות וסימניות כדי להשתמש בהן ב-Chrome במכשיר אחר כשאתה מחובר עם אותו חשבון Google.

כדי להציג כרטיסיות פתוחות במכשירים אחרים, הקש על **תפריט** > **מכשירים אחרים**.

בחר דף אינטרנט כדי לפתוח אותו.

כדי להציג סימניות, הקש על .

סעיף זה מספק מבט כולל על פריטים שניתן לשנותם באמצעות תפריטי 'הגדרות המערכת' של הטלפון.

כדי לגשת אל התפריט 'הגדרות':

1 במסך הראשי, גע ב- > הכרטיסייה **יישומים** > **הגדרות**.
לחלופין,
במסך הראשי, גע ב- > **הגדרות מערכת**.

2 בחר קטגוריית הגדרות ובחר אפשרות.

אלחוט ורשתות

מכאן ניתן לנהל את קישורי Wi-Fi ו-Bluetooth. כמו כן, ניתן להגדיר רשתות ניידות ולעבור למצב טיסה.

< Wi-Fi >

Wi-Fi - מפעילה את Wi-Fi כדי להתחבר לרשתות Wi-Fi זמינות.

עצה! כיצד להשיג את כתובת ה-MAC

כדי להגדיר חיבור ברשתות אלחוטיות מסוימות עם מסנני MAC, ייתכן שתידרש להזין את כתובת ה-MAC של הטלפון שלך בנתב.

ניתן למצוא את כתובת ה-MAC בממשק המשתמש הבא: גע בכרטיסייה **יישומים** > **הגדרות** > **Wi-Fi** > > **מתקדם** > **כתובת MAC**.

< Bluetooth >

הפעל או כבה את התכונה האלחוטית של Bluetooth כדי להשתמש ב-Bluetooth.

< נתונים סלולריים >

להצגת השימוש בנתונים והגדרת גבולות לשימוש בהעברת נתונים סלולריים.

< שיחה >

קבע את התצורה של הגדרות שיחת טלפון, כגון הפניית שיחה, וכן תכונות מיוחדות אחרות שספק השירות שלך מציע.

תא קולי – מאפשר לך לבחור את שירות התא הקולי של הספק שלך.

מספרי חיוג קבועים – הפעל וצור רשימה של מספרים שאליהם ניתן להתקשר מהטלפון שלך. לצורך כך תזדקק לקוד PIN2 שניתן להשיגו אצל מפעיל השירות שלך. מהטלפון שלך ניתן להתקשר רק למספרים הכלולים ברשימת מספרי החיוג הקבועים.

חלון מוקפץ של שיחה קולית נכנסת – הצג חלון מוקפץ של שיחה קולית נכנסת כאשר יישום כלשהו נמצא בשימוש.

דחיית שיחות – מאפשר להגדיר את הפונקציה 'דחיית שיחות'. בחר מבין מצב דחיית שיחה או רשימת דחיות.

סרב עם הודעה – כשברצונך לדחות שיחה, באפשרותך לשלוח הודעה מהירה באמצעות פונקציה זו. אפשרות זו שימושית כאשר אתה נדרש לדחות שיחה במהלך פגישה.

שומר הפרטיות – מסתיר את השם ואת המספר של המתקשר עבור שיחה נכנסת.

העברת שיחה – בחר אם להפנות את כל השיחות כשהקו תפוס, כשאין תשובה או כשאין אות.

מענה אוטומטי – הגדר את משך הזמן לפני שדיבורית מחוברת תענה באופן אוטומטי לשיחה נכנסת. בחר מבין האפשרויות 'לא זמין', 'שנייה', '3 שניות' ו-'5 שניות'.

רטט התקשרות – הטלפון שלך רוטט כשהצד השני משיב לשיחה.

שמור מספרים לא ידועים – הוסף מספרים לא ידועים לאנשי קשר לאחר שיחה.

לחצן ההפעלה מסיים שיחה – מאפשר לך לבחור סיום שיחה.

משך שיחה – הצג את משך הזמן של שיחות, כולל שיחה אחרונה, כל השיחות, שיחות יוצאות ושיחות נכנסות.

הגדרות נוספות – מאפשר לך לשנות את ההגדרות הבאות:

שיחה מזוהה: בחר אם להציג את המספר שלך בשיחה יוצאת.

שיחה ממתינה: אם שיחה ממתינה מופעלת, הטלפון יודיע על שיחה נכנסת כאשר אתה כבר משוחח בטלפון (בהתאם לספק הרשת).

<שתף והתחבר>

NFC – הטלפון שלך הוא טלפון נייד שתומך ב-NFC. NFC (תקשורת שדה קרוב) היא טכנולוגיה לתקשורת אלחוטית המאפשרת תקשורת דו-כיוונית בין מכשירים אלקטרוניים. טכנולוגיה זו פועלת במרחק של סנטימטרים ספורים. באפשרותך לשתף את התוכן שלך עם תגית NFC או מכשיר אחר התומך ב-NFC פשוט על-ידי נגיעה בו באמצעות המכשיר שלך. אם תיגע בתגית NFC באמצעות המכשיר שלך, תוכן התגית

יוצג במכשיר. כדי להפעיל או לכבות את NFC: מתוך המסך הראשי, גע במגירת ההתראות והחלק אותה כלפי מטה באמצעות האצבע, ולאחר מכן בחר בסמל NFC כדי להפעיל אותו.

כדי להפעיל או לכבות את NFC: מתוך המסך הראשי, גע במגירת ההתראות והחלק אותה כלפי מטה באמצעות האצבע, ולאחר מכן בחר בסמל NFC כדי להפעיל אותו.

הערה: כאשר מצב טיסה מופעל, ניתן להשתמש ביישום NFC.

שימוש ב-NFC: כדי להשתמש ב-NFC, ודא שהמכשיר פועל והפעל את הגדרת ה-NFC אם היא מבוטלת.

שידור Android – כשתכונה זו פועלת, באפשרותך לשדר תוכן מהיישום למכשיר אחר התומך ב-NFC על-ידי החזקת המכשירים סמוכים זה לזה. פשוט קרב את המכשירים זה לזה (בדרך כלל גב אל גב) ולאחר מכן גע במסך. היישום קובע מה ישודר.

SmartShare Beam – אפשר קבלת קבצים מטלפונים של LG.

שרת מדיה – שתף תוכן מדיה בטלפון שלך עם מכשיר סמוך דרך DLNA.

Miracast – עם Miracast באפשרותך לשקף באופן אלחוטי את המסך והקול של הטלפון שלך אל פלאג של Miracast או אל טלוויזיה.

אחסון אלחוטי – שתף קבצים עם המחשב באמצעות Wi-Fi.

< רשתות ושיתוף אינטרנט >

נקודה חמה ניידת ב-Wi-Fi – באפשרותך גם להשתמש בטלפון כדי לספק חיבור פס רחב נייד. צור נקודה חמה ושתף את החיבור. עיין בנושא "שיתוף חיבור הנתונים של הטלפון" למידע נוסף.

חיבור כמודם סלולרי באמצעות Bluetooth – מאפשר לך להגדיר את הטלפון שלך בין אם אתה עושה שימוש משותף בחיבור לאינטרנט ובין אם לא.

עזרה – הקש כדי להציג את מידע העזרה בנוגע לנקודה חמה ניידת ב-Wi-Fi ולפונקציות שיתוף אינטרנט ב-Bluetooth.

מצב טיסה – לאחר המעבר למצב טיסה, כל החיבורים האלחוטיים מושבתים.

הערה: עליך להגדיר קוד PIN לנעילת המסך כדי שתוכל להשתמש במאגר האישורים.

רשתות ניידות – הגדר אפשרויות לנדידת נתונים, מצב רשת ומפעילים, שמות נקודות גישה (APN) וכו'.
אפליקצית מסרונים ברירת מחדל – מאפשר לך להגדיר את אפליקציית המסרונים שתשמש כברירת מחדל.
VPN – הצגה של רשימת הרשתות הווירטואליות הפרטיות (VPN) שאת תצורתן קבעת בעבר.

המכשיר

< צליל >
פרופיל צליל – בחר באפשרות 'צליל', ובחר בין האפשרויות 'רטט בלבד' או 'שקט'.
עוצמות קול – נהל את עוצמת הקול של הרינגטון בטלפון, צליל ההתראה, משוב מגע, מערכת, מוסיקה, וידאו, משחקים ומדיה אחרת.
זמן שקט – הגדר זמנים לכיבוי כל הצלילים למעט התראה ומדיה.
רינגטון טלפון – מאפשר לך להגדיר את רינגטון ברירת המחדל המשמש עבור שיחה נכנסת.
צלצול חכם – מאפשר לך להגביר את עוצמת הצלצול בסביבה רועשת.
רינגטון עם רטט – משוב רטט לשיחות ולהתראות.
צליל התראה – הגדרת צלצול ברירת המחדל להתראות.

< תצוגה >
בהירות - כוונן את בהירות המסך.
זמן קצוב למסך - הגדירו את משך הזמן הקצוב עד לכיבוי המסך.
סיבוב מסך אוטומטי – סימן ביקורת המאפשר לך להגדיר את הטלפון כך שיסובב באופן אוטומטי את המסך לפי כיוון הטלפון (לאורך או לרוחב).
חלום בהקיץ – הקש על המתג 'חלום בהקיץ' כדי להפעיל או להשבית אותו.
באמצעות האפשרות 'מופעל' ניתן להגדיר ששומר המסך יוצג כאשר הטלפון ישן

במהלך עגינה ו/או טעינה.
סוג גופן – שנה את הסוג של גופן התצוגה.
גודל גופן – שנה את גודל גופן התצוגה.
מסך חכם – הוסף סימן ביקורת כדי לאפשר למסך להישאר מופעל כאשר הטלפון מזהה את הפנים שלך.
תאורת מקשי מגע קדמיים – הגדר את משך זמן התאורה של הלחצן הקדמי.
הבזק התראה – נורית ההתראה נמצאת משמאל למצלמה הקדמית. באפשרותך לראות את האור של הנורית הקטנה כשהטלפון נטען או כשאתה מקבל התראה אם מסך ה-LCD כבוי. ניתן לקבוע את תצורת הבזק ההתראה להפעלה/כיבוי. באפשרותך להגדיר את האפשרויות השונות מתוך רשימת הפריטים של הבזק ההתראה.

< מסך ראשי >

הגדר את האפשרויות ערכת נושא, טפט, אפקט החלקת מסך, לאפשר לולאות מסך או תצוגה אנכית בלבד. בחר את האפשרות כדי להגדיר גיבוי ושחזור בית.

< נעילת מסך >

בחר נעילת מסך – הגדר סוג נעילת מסך כדי לאבטח את הטלפון. האפשרות פותחת סדרה של מסכים שמדריכה אותך בשרטוט תבנית ביטול נעילה של המסך. הגדר ללא, החלקה, שחרור נעילה באמצעות זיהוי פנים, תבנית, PIN או סיסמה. אם הפעלת סוג נעילת תבנית כשאתה מפעיל את הטלפון או מעיר את המסך, תתבקש לצייר את תבנית ביטול הנעילה כדי לבטל את נעילת המסך.

< מחוות >

השתק שיחות נכנסות – הפוך את המכשיר כדי להשתיק שיחות נכנסות.
נודניק או הפסקת התראה – הפוך את המכשיר כדי להפעיל נודניק או להפסיק התראה.
השהה וידאו – הפוך את המכשיר כדי להשהות את הווידאו הפועל.
עזרה – עזרה עבור פונקציות מחוות.
כיול חיישן תנועה – מאפשר לך לשפר את הדיוק של ההטיה והמהירות של החיישן.

< אחסון >

אחסון פנימי – הצגת השימוש באחסון הפנימי.

< סוללה >

מידע על הסוללה

המידע על טעינת הסוללה מוצג באיור של סוללה, לצד אחוז הטעינה הנותר והמצב. גע בסמל טעינת הסוללה כדי להציג את מסך ניצול הסוללה, על מנת לבדוק את רמת השימוש בסוללה ואת פרטי השימוש בסוללה. האיור מציג אילו רכיבים ויישומים צורכים את הכמות הרבה ביותר של אנרגיית סוללה. הקש על אחד מהערכים כדי להציג עוד מידע מפורט.

אחוז סוללה בשורת המצב – סימן ביקורת כדי להציג את אחוז רמת הסוללה בשורת המצב לצד סמל הסוללה.

חיסכון בחשמל

הקש על המתג 'חיסכון בחשמל' כדי להפעיל או להשבית אותו. הקש על 'חיסכון בחשמל' כדי לגשת להגדרות הבאות:

חיסכון בחשמל – מגדיר את רמת אחוז טעינת הסוללה שתפעיל באופן אוטומטי את התכונה 'חיסכון בחשמל'.

מצב חיסכון – הגדר את מצב החיסכון כדי להאריך את חיי הסוללה על-ידי מיטוב דינאמי של מדיניות הבקרה של ה-CPU.

עזרה – הקש כדי להציג מידע בנושאי עזרה בטיפים לחיסכון בחשמל.

< יישומים >

הצג ונהל את היישומים שלך.

< הקש ושלם >

כאשר NFC מופעל, ניתן להשתמש בתכונה 'הקש ושלם' כדי לשלם עבור פריטים פשוט על-ידי הצמדת הטלפון לקורא בקופה. אם במכשיר שלך לא מותקן יישום ברירת מחדל, תוכל לחפש יישומי תשלום אחרים ב-Google Play.

אישי

< חשבונות וסנכרון >

מתיר ליישומים לסנכרן נתונים ברקע, בין אם אתה עובד איתם באופן פעיל ובין אם

לא. ביטול הבחירה של הגדרה זו יכול לחסוך במתח הסוללה ולהפחית (אך לא לבטל) את השימוש בנתונים.

< ענן >

הוסף חשבון ענן על מנת להשתמש במהירות ובקלות בשירות ענן ביישומי LG.

< מיקום >

הפעל שירות מיקום; הטלפון יקבע את המיקום המשוער שלך באמצעות GPS, Wi-Fi ורשתות ניידות.

מצב – הגדר את מצב המיקום מתוך דיוק גבוה, חיסכון סוללה וחיישני המכשיר בלבד.

< אבטחה >

הצפן טלפון – מאפשר לך להצפין נתונים בטלפון למטרת אבטחה. תידרש להזין PIN או סיסמה כדי לבטל את הצפנת הטלפון בכל פעם שתפעיל אותו.

הגדר נעילת כרטיס SIM – הגדר נעילת כרטיס Micro-USIM או שנה את קוד ה-PIN של כרטיס ה-Micro-USIM.

הצגת סיסמה תוך כדי הקלדה – הצג את התו האחרון של סיסמה מוסתרת תוך כדי הקלדה.

מנהלי מערכת של הטלפון – הצג או נטרל את מנהלי המערכת של הטלפון.

מקורות לא ידועים – הגדרת ברירת המחדל להתקנת יישומים שמקורם אינו ב-Market.

אמת יישומים – הזהר או אל תאפשר התקנה של יישומים העלולים לגרום נזק.

גישה להתראות – הצג את ההתראות.

סוג אחסון – הצג את סוג האחסון.

אישורים מהימנים – הצג אישורי CA מהימנים.

התקן מהאחסון – להתקנת אישורים מוצפנים.

נקה אישורים – הסר את כל האישורים.

< שפה וקלט >

השתמש בהגדרות שפה וקלט כדי לבחור את השפה עבור הטקסט שיוצג בטלפון וכדי לקבוע את תצורת המקלדת על המסך, לרבות מילים שהוספת למילון.

< גיבוי ושחזור >

שנה את ההגדרות לניהול ההגדרות והנתונים שלך.

גבה את הנתונים שלי – הגדר כדי לגבות את ההגדרות ואת נתוני היישומים שלך לשרת Google.

גבה חשבון – הגדר כדי לגבות את החשבון שלך.

שחזור אוטומטי – הגדר כדי לשחזר את ההגדרות ואת נתוני היישומים כאשר היישומים מותקנים מחדש במכשיר שלך.

שירות LG Backup – מבצע גיבוי של כל המידע בהתקן ומשחזר אותו במקרה של אובדן נתונים או החלפה.

איפוס לנתוני יצרן – איפוס ההגדרות לערכי ברירות המחדל שהגדיר היצרן ומחיקת כל הנתונים. אם תאפס את הטלפון בצורה כזו, תתבקש להזין מחדש את אותו מידע שהזנת בפעם הראשונה שהפעלת את Android.

מערכת

< תאריך ושעה >

השתמשו בהגדרות **תאריך ושעה** כדי לקבוע את אופן התצוגה של התאריך. כמו כן, באפשרותך להשתמש בהגדרות אלה כדי להגדיר את השעה ואת אזור הזמן שלך, במקום לקבל את השעה הנוכחית מהרשת הניידת.

< נגישות >

השתמש בהגדרות ה**נגישות** כדי לקבוע את התצורה של כל יישומי ה-plug-in לנגישות שהתקנת בטלפון.

הערה: מחייב אפשרות לבחור יישומי plug-in נוספים.

< חיבור PC >

בחר שיטת חיבור USB – הגדר את המצב הרצוי: **טען בלבד, סינכרון מדיה (MTP), הצמדת התקנים, תוכנת LG או שלח תמונות (PTP)**.

שאל בעת חיבור – שאל במצב חיבור USB בעת התחברות למחשב.

עזרה – עזרה עבור חיבור USB.

PC Suite – סמן אפשרות זו כדי להשתמש ב-LG PC Suite עם חיבור Wi-Fi. שים לב כי

יש לחבר רשת Wi-Fi ל-LG PC Suite דרך חיבור Wi-Fi באמצעות 'אלחוט ורשתות'.
עזרה – עזרה עבור תוכנת LG.

<הדפסה>

מאפשר לך להדפיס את תוכנם של מסכים מסוימים (כגון דפי אינטרנט המוצגים ב-Chrome) במדפסת המחוברת לאותה רשת Wi-Fi של מכשיר ה-Android שלך.

< אודות הטלפון >

הצג מידע משפטי ובדוק את מצב הטלפון ואת גרסת התוכנה שלו.

תוכנת מחשב (LG PC Suite)

תוכנת המחשב LG PC Suite היא תוכנית שעוזרת לך לחבר את המכשיר למחשב באמצעות Wi-Fi וכבל USB. לאחר ההתחברות תוכל להשתמש בפונקציות של המכשיר מהמחשב.

בעזרת תוכנת המחשב LG PC Suite, ניתן...

- לנהל ולהפעיל את תוכני המדיה (מוסיקה, סרטים, תמונות) מהמחשב.
- לשלוח תוכן מולטימדיה למכשיר.
- לסנכרן נתונים (לוחות זמנים, אנשי קשר, סימניות) במכשיר ובמחשב.
- לגבות את היישומים במכשיר.
- לעדכן את התוכנות במכשיר.
- לגבות ולשחזר את נתוני המכשיר.
- להפעיל תוכן מולטימדיה מהמחשב באמצעות מכשיר אחר.
- לגבות, ליצור ולערוך את המזכרים במכשיר

הערה: באפשרותך להשתמש בתפריט העזרה של היישום כדי לגלות כיצד להשתמש בתוכנת המחשב LG PC Suite.

התקנת תוכנת המחשב LG PC Suite

ניתן להוריד את תוכנת המחשב LG PC Suite מדף האינטרנט של LG.

1 עבור אל www.lg.com ובחר מדינה.

2 עבור אל **תמיכה** > **תמיכה בטלפונים ניידים** > **טלפונים סלולריים של LG** > **בחר את הדגם**

   או

   עבור אל **תמיכה** > **טלפון נייד** > בחר את הדגם.

3 לחץ על **PC SYNC** מתוך **MANUALS & DOWNLOAD**, ולחץ על **DOWNLOAD** כדי להוריד את תוכנת המחשב LG PC Suite.

דרישות מערכת עבור תוכנת המחשב LG PC Suite

- מערכת הפעלה: Windows XP (Service pack 3) 32bit, Windows Vista, Windows 7, Windows 8
- מעבד: 1 GHz ומעלה
- זיכרון: רכיבי RAM בנפח 512 MB ומעלה
- כרטיס מסך: רזולוציה של 768 x 1024, צבע 32 סיביות ומעלה

- דיסק: שטח דיסק פנוי של לפחות 500 MB (ייתכן שיהיה צורך בשטח רב יותר, בהתאם לנפח הנתונים המאוחסנים).
- תוכנה דרושה: מנהלי התקנים משולבים של LG, Windows Media Player 10 ואילך

הערה: מנהל התקן USB משולב של LG
מנהל התקן USB משולב של LG דרוש כדי לחבר מכשיר של LG למחשב, והוא מותקן באופן אוטומטי בעת התקנה של יישום תוכנת המחשב LG PC Suite.

סינכרון המכשיר עם המחשב

באמצעות תוכנת המחשב LG PC Suite ניתן לסנכרן בקלות ובנוחות נתונים מהמכשיר ומהמחשב. ניתן לסנכרן אנשי קשר, לוחות זמנים וסימניות.

התהליך הוא כדלקמן:

1. חבר את המכשיר למחשב. (השתמש בכבל USB או בחיבור Wi-Fi).
2. האפשרות בחר שיטת חיבור USB תופיע, ולאחר מכן בחר באפשרות תוכנת LG.
3. לאחר ההתחברות, הפעל את התוכנית ובחר את מקטע המכשיר מתוך הקטגוריות בצד שמאל של המסך.
4. לחץ על פרטים אישיים כדי לבחור.
5. סמן את תיבות הסימון של התוכן שברצונך לסנכרן, ולחץ על הלחצן סינכרון.

הערה: כדי לסנכרן את הטלפון עם המחשב, עליך להתקין במחשב את LG PC Suite. כדי להתקין את LG PC Suite, עיין בדפים הקודמים.

העברת אנשי קשר מהמכשיר הקודם למכשיר החדש

1. יצא את אנשי הקשר מהמכשיר הישן כקובץ CSV למחשב באמצעות תוכנית לסינכרון עם מחשב.
2. תחילה התקן את LG PC Suite במחשב. הפעל את התוכנית וחבר את טלפון ה-Android שברשותך למחשב בכבל ה-USB.
3. בתפריט העליון, בחר באפשרות **טלפון** > **יבא/יצא אנשי קשר** > **יצא לטלפון שלך**.
4. יופיע חלון מוקפץ לבחירת סוג הקובץ והקובץ **לייצוא**.

5 בחלון המוקפץ, לחץ על **בחר קובץ**, וסייר Windows יופיע.
6 בחר בקובץ אנשי הקשר ל**ייצוא** בסייר Windows, ולחץ על **פתח**.
7 לחץ על **יצא**.
8 יופיע חלון מוקפץ **מיפוי שדות** לצורך קישור אנשי הקשר במכשיר לנתונים החדשים של אנשי קשר.
9 אם קיים קונפליקט בין הנתונים של אנשי הקשר מהמחשב לבין אנשי הקשר מהמכשיר, בצע את הבחירות או השינויים הדרושים ב-LG PC Suite.
10 לחץ על **אישור**.

עדכון תוכנת הטלפון

עדכון תוכנת הטלפון הנייד של LG מהאינטרנט

למידע נוסף אודות השימוש בפונקציה זו, בקר בכתובת בכתובת http://www.lg.com/common/index.jsp ← ובחר את המדינה והשפה שלך.

תכונה זו מאפשרת לך לעדכן בנוחות את הקושחה של הטלפון לגרסה חדשה יותר מהאינטרנט, ללא צורך לבקר במרכז שירות. תכונה זו תהיה זמינה רק אם LG תייצר גרסת קושחה חדשה שתהיה זמינה למכשיר שלך.

מאחר שעדכון הקושחה של הטלפון הנייד דורש את תשומת לבו המלאה של המשתמש במשך כל תהליך העדכון, הקפד לקרוא את כל ההוראות וההערות שיופיעו בכל שלב לפני שתתקדם הלאה. חשוב לזכור שהסרת כבל ה-USB או הסוללה במהלך השדרוג עלולה לגרום נזק חמור לטלפון הנייד.

הערה: LG שומרת על זכותה, על פי שיקול דעתה הבלעדי, להעמיד את עדכוני הקושחה לרשות דגמים נבחרים בלבד ואינה ערבה לזמינות הגרסה החדשה של הקושחה לכל דגמי הטלפון.

עדכון תוכנת הטלפון הנייד של LG באופן אלחוטי (OTA)

תכונה זו מאפשרת לך לעדכן בנוחות את תוכנת הטלפון לגרסה חדשה יותר דרך OTA, מבלי להתחבר באמצעות כבל נתונים USB. תכונה זו תהיה זמינה רק אם LG תייצר גרסת קושחה חדשה שתהיה זמינה למכשיר שלך.

תחילה עליך לבדוק את גרסת התוכנה בטלפון הנייד: **הגדרות** > **אודות הטלפון** > **Update Center** > **עדכון תוכנה** > **חפש עדכונים כעת**.

הערה: הנתונים האישיים שלך משטח האחסון הפנימי בטלפון—לרבות פרטי חשבון Google וכל חשבון אחר, נתונים והגדרות של המערכת/היישומים שלך, יישומים שהורדו ורישיון ה-DRM שלך—עשויים ללכת לאיבוד בתהליך עדכון התוכנה של הטלפון. לפיכך, LG ממליצה לך לגבות את הנתונים האישיים שלך לפני שתעדכן את תוכנת הטלפון. LG לא תישא באחריות לאובדן נתונים אישיים כלשהם.

הערה: תכונה זו תלויה בספק שירותי הרשת, באזור ובמדינה שלך.

אודות מדריך למשתמש זה

- לפני השימוש במכשיר, אנא קרא בעיון מדריך זה. הדבר יבטיח שתשתמש בטלפון שלך בצורה נכונה ובטוחה.
- חלק מהתמונות ומצילומי המסך המופיעים במדריך זה עשויים להיראות שונים בטלפון שלך.
- התוכן שלך עשוי להיות שונה מהמוצר הסופי או מהתוכנה המסופקת על-ידי ספקי שירות או מפעילים סלולריים. תוכן זה נתון לשינויים ללא הודעה מוקדמת. לקבלת הגרסה העדכנית של מדריך זה, בקר באתר האינטרנט של LG בכתובת www.lg.com.
- היישומים בטלפון שלך והפונקציות שלהם עשויים להשתנות בהתאם למדינה, לאזור או למפרטי החומרה. LG לא תישא באחריות לבעיות ביצועים הנובעות משימוש ביישומים שפותחו על-ידי ספקים פרט ל-LG.
- LG לא תישא באחריות לבעיות ביצועים או חוסר תאימות הנובעות מעריכת הגדרות רישום או משינויים בתוכנת מערכת ההפעלה. כל ניסיון להתאים אישית את מערכת ההפעלה שלך עלול לגרום למכשיר או ליישומים שלו להפסיק לפעול כמצופה.
- תוכנות, שמע, טפטים, תמונות ופריטי מדיה אחרים שסופקו יחד עם המכשיר שלך מורשים לשימוש מוגבל. אם תחלץ חומר זה ותשתמש בו למטרות מסחריות או אחרות, אתה עלול להפר חוקי זכויות יוצרים. כמשתמש, אתה נושא באחריות מלאה ובלעדית לשימוש לא חוקי במדיה.
- ייתכן שיחולו חיובים נוספים תמורת שירותי נתונים, כגון שליחת הודעות, העלאה והורדה, סנכרון אוטומטי או שימוש בשירותי מיקום. כדי להימנע מחיובים נוספים, בחר תוכנית נתונים מתאימה לצרכיך. פנה אל ספק השירות לקבלת פרטים נוספים.

סימנים מסחריים

- LG והלוגו של LG הם סימני מסחר רשומים של LG Electronics.
- כל יתר הסימנים המסחריים וזכויות היוצרים הם רכושם של בעליהם בהתאמה.

DivX HD

אודות סרטוני DivX: DivX® הוא פורמט וידאו דיגיטלי שיצרה DivX, LLC, חברה-בת של Rovi Corporation. זהו מכשיר הנושא אישור רשמי מסוג DivX Certified® להפעלת סרטוני DivX. לקבלת מידע נוסף וכלי תוכנה להמרת קבצים לתבנית וידאו DivX, בקר בכתובת www.divx.com.

אודות וידאו לפי דרישה (VOD) בתבנית DIVX: כדי להפעיל סרטי וידאו לפי דרישה (VOD) בהתקן זה הנושא את אישור DivX Certified®, יש לבצע רישום של ההתקן. לקבלת קוד הרישום, אתר את המקטע DivX VOD בתפריט ההגדרות של ההתקן. לקבלת מידע נוסף על אופן הרישום: vod.divx.com.

DivX Certified® להפעלת סרטוני וידאו DivX® עד HD 720p, כולל תוכן מעולה. DivX®, DivX Certified® וסמלי הלוגו הקשורים הם סימני מסחר של Rovi Corporation והשימוש בהם מתבצע ברישיון.

Dolby Mobile

מיוצר ברישיון מטעם Dolby Laboratories. Dolby וסמל double-D הם סימנים מסחריים של Dolby Laboratories.

הודעה: תוכנות קוד פתוח

לקבלת קוד המקור המתאים במסגרת GPS, LGPL, MPL ורישיונות קוד פתוח אחרים, בקר בכתובת http://opensource.lge.com/

כל תנאי הרישיון, כתבי הוויתור וההודעות הנזכרים זמינים להורדה עם קוד המקור.

אביזרים

האביזרים הבאים זמינים לשימוש עם הטלפון שלך. **(האביזרים המתוארים להלן עשויים להיות אופציונליים.)**

מתאם נסיעות

אוזניות סטריאו

מדריך להתחלה מהירה

כבל נתונים

כלי לשליפת Micro-USIMl

הערה:

- השתמש תמיד באביזרים מקוריים של LG.
- שימוש באביזרים שאינם מקוריים עלול לבטל את האחריות.
- סוג האביזרים עשוי להשתנות מאזור לאזור.

פתרון בעיות

בפרק זה מוצגות מספר בעיות שאתה עלול להיתקל בהן במהלך השימוש בטלפון. בעיות מסוימות יצריכו פנייה לספק השירות, אך את רובן תוכל לפתור בקלות בעצמך.

הודעה	גורמים אפשריים	אפשרויות לתיקון הבעיה
שגיאת Micro-USIM	אין כרטיס Micro-USIM בטלפון או שהוא הוכנס בצורה לא נכונה.	ודא שכרטיס ה-Micro-USIM הוכנס כהלכה.
אין חיבור לרשת/ החיבור חלש	האות חלש או שאתה נמצא מחוץ לטווח הרשת של ספק השירות.	התקרב לחלון או צא לאזור פתוח. בדוק את מפת הכיסוי של מפעיל הרשת הסלולרית.
	המפעיל החיל שירותים חדשים.	בדוק אם גילו של כרטיס ה-Micro-USIM עולה על 6-12 חודשים. אם כן, החלף אותו בסניף הקרוב ביותר של ספק הרשת שלך. פנה אל ספק השירות.
הקודים אינם תואמים	כדי לשנות קוד אבטחה, יש להזין את הקוד החדש שוב כדי לאשרו.	אם שכחת את הקוד, פנה אל ספק השירות.
	שני הקודים שהוזנו אינם זהים זה לזה.	
לא ניתן להגדיר יישומים	הוא לא נתמך על-ידי ספק השירות או שנדרש רישום עבורו.	פנה אל ספק השירות.

פתרון בעיות

הודעה	גורמים אפשריים	אפשרויות לתיקון הבעיה
לא ניתן לבצע שיחות	טעות בחיוג	הרשת החדשה אינה מורשית.
	הוכנס כרטיס Micro-USIM חדש	בדוק אם קיימות מגבלות חדשות.
	הגעת למגבלת החיוב ששולם מראש.	צור קשר עם חברת הסלולר או אפס את המגבלה בעזרת PIN2.
לא ניתן להפעיל את הטלפון	מקש הדלקה/כיבוי נלחץ מהר מדי.	לחץ על מקש ההפעלה/כיבוי למשך שתי שניות לפחות.
	הסוללה לא נטענה.	טען את הסוללה. בדוק את מחוון הטעינה בתצוגה.
שגיאת טעינה	הסוללה לא נטענה.	טען את הסוללה.
	הטמפרטורה החיצונית גבוהה או נמוכה מדי.	ודא שהטלפון נטען בטמפרטורה הרגילה.
	בעיית מגעים	בדוק את המטען ואת החיבור שלו לטלפון.
	אין מתח	חברו את המטען לשקע אחר.
	המטען פגום	החלף את המטען.
	מטען לא מתאים	השתמש רק באביזרים מקוריים של LG.

הודעה	גורמים אפשריים	אפשרויות לתיקון הבעיה
המספר אסור	פונקציית מספר קבוע מראש פועלת.	בדוק את התפריט 'הגדרות' ונטרל את הפונקציה.
לא ניתן לקבל/ לשלוח הודעות SMS ותמונות	הזיכרון מלא	מחק חלק מההודעות השמורות בטלפון.
הקבצים אינם נפתחים	אין תמיכה בתבנית הקובץ	בדוק את תבניות הקובץ הנתמכות.
המסך אינו נדלק כאשר מתקבלת שיחה.	בעיה בחיישן הקרבה	אם אתה משתמש בנרתיק או כיסוי להגנה, ודא שהוא אינו מכסה את האזור שסביב חיישן הקרבה. ודא שהאזור שמסביב לחיישן הקרבה נקי.
אין צליל	מצב רטט	בדוק את מצב ההגדרות בתפריט הצליל כדי לוודא שאינך במצב רטט או שקט.
ניתוק או קפיאה	בעיה של נתק בתוכנה	נסה לעדכן את התוכנה דרך אתר האינטרנט.

שאלות נפוצות

לפני שתיקח את הטלפון לנקודת שירות או שתתקשר לנציג שירות, בדוק אם חלק מהבעיות שבהן נתקלת מתוארות בסעיף זה.

קטגוריה תת קטגוריה	שאלה	תשובה
BT Bluetooth מכשירים	אילו פונקציות זמינות דרך Bluetooth?	ניתן לחבר מכשיר שמע Bluetooth, כגון אוזניות סטריאו/מונו או דיבורית לרכב, כדי לשתף תמונות, סרטוני וידאו, אנשי קשר וכו' דרך תפריט גלריה/אנשי קשר. כמו כן, כששרת FTP מחובר למכשיר תואם, ניתן לשתף תוכן המאוחסן במדיית האחסון.
BT Bluetooth אוזניות	אם אוזניות Bluetooth שלי מחוברות, האם אני יכול להאזין למוסיקה דרך אוזניות ה-3.5 מ"מ שלי?	כאשר אזניות Bluetooth מחוברות, כל הצלילים של המערכת מושמעים דרך האוזניות. כתוצאה מכך, לא תוכל להאזין למוסיקה דרך אוזניות חוטיות.
נתונים אנשי קשר גיבוי	איך ניתן לגבות את אנשי הקשר?	אפשר לסנכרן את נתוני אנשי הקשר בין הטלפון ו-Gmail™.
נתונים סינכרון	האם יש אפשרות להגדיר סינכרון חד כיווני עם Gmail?	קיים רק סינכרון דו כיווני.

קטגוריה תת קטגוריה	שאלה	תשובה
נתונים סינכרון	האם ניתן לסנכרן את כל תיקיות הדוא"ל?	תיבת הדואר הנכנס מסונכרנת באופן אוטומטי. באפשרותך להציג תיקיות אחרות על-ידי נגיעה ב**מקש התפריט** ≡ ובחירה באפשרות **תיקיות** כדי לבחור תיקייה.
שירות Google™ כניסה ל-Gmail	האם עליי להיכנס ל-Gmail בכל פעם שברצוני לגשת אל Gmail?	לאחר שהתחברת ל-Gmail, לא תצטרך להתחבר ל-Gmail שוב.
שירות Google™ חשבון Google	האם ניתן לסנן הודעות דוא"ל?	לא, אין תמיכה בסינון הודעות דוא"ל דרך הטלפון.
פונקציות הטלפון דוא"ל	מה קורה כאשר מפעילים יישום אחר בשעה שכותבים הודעת דוא"ל?	הודעת הדוא"ל תישמר באופן אוטומטי כטיוטה.
פונקציות הטלפון צלצול	האם יש מגבלת גודל קובץ לשימוש בקובץ MP3 כרינגטון?	אין מגבלה על גודל הקובץ.
פונקציות הטלפון שעת ההודעה	הטלפון שלי אינו מציג את שעת ההודעות שהתקבלו לפני יותר מ-24 שעות. כיצד אוכל לשנות זאת?	אפשר לראות רק את שעת קבלת ההודעה של הודעות שהתקבלו באותו יום.

שאלות נפוצות

קטגוריה תת קטגוריה	שאלה	תשובה
פונקציות הטלפון ניווט	האם ניתן להתקין בטלפון יישום ניווט אחר?	ניתן להתקין ולהשתמש בכל יישום שזמין ב-Android Market™ ותואם לחומרה.
פונקציות הטלפון סנכרון	האם ניתן לסנכרן את אנשי הקשר מכל חשבונות הדואל שלי?	ניתן לסנכרן רק אנשי קשר מ- Gmail ומ-MS Exchange server (שרת דוא"ל של חברה).
פונקציות הטלפון המתן והשהה	האם ניתן לשמור איש קשר שבוצעו עליו פעולות המתן והשהה?	אם העברת איש קשר כאשר פונקציות המתן או השהה נשמרו עם מספרו, לא תוכל להשתמש בתכונות אלה. תצטרך לשמור שוב כל מספר. כיצד לשמור עם פונקציות המתן והשהה? 1. מהמסך הראשי, גע בסמל **טלפון** . 2. חייג את המספר ולאחר מכן גע ב**מקש התפריט** . 3. גע ב**הוסף השהיה של 2 שניות** או ב**הוסף המתנה**.
פונקציות הטלפון אבטחה	מהן פונקציות האבטחה של הטלפון?	ניתן להגדיר את הטלפון כך שהוא ידרוש הזנת תבנית ביטול נעילה כתנאי לגישה או לשימוש בטלפון.

קטגוריה תת קטגוריה	שאלה	תשובה
פונקציות הטלפון ביטול נעילה תבנית	איך יוצרים תבנית ביטול נעילה?	1. מהמסך הראשי, גע ב**מקש התפריט** ☰. 2. גע ב**הגדרות מערכת** > **נעילת מסך**. 3. גע ב**בחר נעילת מסך** > **תבנית**. בפעם הראשונה שתעשה זאת תופיע הדרכה קצרה על יצירת תבנית ביטול נעילה. 4. הגדר על-ידי ציור התבנית פעם אחת, ולאחר מכן צייר אותה שוב לאישור. יש לנקוט אמצעי זהירות בעת שימוש בנעילת תבנית. חשוב מאוד לזכור את תבנית ביטול הנעילה שהוגדרה. אם תשתמש בתבנית שגויה חמש פעמים, תאבד את הגישה לטלפון. לרשותך חמישה ניסיונות להזין את תבנית ביטול הנעילה, קוד ה-PIN או הסיסמה. אם ניצלת את כל 5 הניסיונות, תוכל לנסות שוב לאחר 30 שניות. (לחלופין, אם קבעת מראש את קוד ה-PIN לגיבוי, תוכל להשתמש בקוד זה כדי לבטל את נעילת התבנית).

שאלות נפוצות

קטגוריה תת קטגוריה	שאלה	תשובה
פונקציות הטלפון ביטול נעילה תבנית	מה עליי לעשות אם שכחתי את תבנית ביטול הנעילה ולא יצרתי את חשבון Google בטלפון?	אם שכחת את התבנית: אם נכנסת לחשבון Google דרך הטלפון, אך לא הצלחת להזין את התבנית הנכונה 5 פעמים, גע בלחצן 'שכחת את התבנית?'. לאחר מכן תידרש להיכנס לחשבון Google שלך כדי לבטל את נעילת הטלפון. אם לא יצרת חשבון Google בטלפון או ששכחת אותו, תצטרך לבצע איפוס קשיח. זהירות: אם תבצעו שחזור נתוני יצרן, כל יישומי המשתמש ונתוני המשתמש יימחקו. זכור לגבות את כל הנתונים החשובים לפני ביצוע איפוס להגדרות היצרן.
פונקציות הטלפון זיכרון	האם אדע שהזיכרון שלי מלא?	כן, תקבל התראה.
פונקציות הטלפון תמיכה בשפה	האם ניתן לשנות את השפה של הטלפון?	לטלפון יש יכולות רב-לשוניות. כדי לשנות את השפה: 1. במסך הראשי, גע ב**מקש התפריט** ≡ וגע ב**הגדרות מערכת**. 2. גע ב**שפה וקלט** > **בחר שפה**. 3. הקש על השפה הרצויה.
פונקציות הטלפון VPN	כיצד מגדירים VPN?	תצורת הגישה ל-VPN שונה מחברה לחברה. כדי לקבוע תצורה של גישה ל-VPN מהטלפון, עליך לקבל את המידע ממנהל הרשת בחברה שלך.

קטגוריה תת קטגוריה	שאלה	תשובה
פונקציות הטלפון כיבוי אוטומטי של המסך	המסך שלי כבה לאחר 15 שניות בלבד. איך ניתן לשנות את פרק הזמן עד לכיבוי אור הרקע במסך?	1. במסך הראשי, לחץ על **מקש התפריט** ≡. 2. גע ב**הגדרות מערכת** > **תצוגה**. 3. תחת הגדרות תצוגה, גע ב**כיבוי אוטומטי של המסך**. 4. הקש על פרק הזמן המועדף עד לכיבוי המסך.
פונקציות הטלפון Wi-Fi ו- רשת ניידת	כאשר גם Wi-Fi וגם רשת ניידת זמינים, באיזה שירות ישתמש הטלפון?	בעת שימוש בנתונים, ייתכן שברירת המחדל של הטלפון תהיה חיבור ה-Wi-Fi (אם קישוריות Wi-Fi מוגדרת בטלפון שלך כמופעלת). עם זאת, לא תתקבל התראה על כך שהטלפון עבר מקישוריות אחת לאחרת. כדי לדעת איזו קישוריות פועלת כעת, הביטו בסמל של רשת ניידת או Wi-Fi המוצג בראש המסך.
פונקציות הטלפון המסך הראשי	האם אפשר להסיר יישום מהמסך הראשי?	כן. פשוט גע נגיעה ממושכת בסמל עד שיופיע סמל פח האשפה בחלק העליון במרכז המסך. ואז, מבלי להרים את האצבע, גררו את הסמל לפח האשפה.
פונקציות הטלפון יישום	הורדתי יישום שגרם הרבה שגיאות. איך אפשר להסיר אותו?	1. במסך הראשי, לחץ על **מקש התפריט** ≡. 2. גע ב**הגדרות יישום** > **הורדו**. 3. גע ביישום ולאחר מכן גע באפשרות **הסר התקנה**.

שאלות נפוצות

קטגוריה תת קטגוריה	שאלה	תשובה
פונקציות הטלפון מטען	האם ניתן לטעון את הטלפון באמצעות כבל נתונים של USB מבלי להתקין את מנהל ההתקן הדרוש של USB?	כן, הטלפון ייטען דרך כבל ה-USB בין אם מנהלי ההתקנים הדרושים מותקנים ובין אם לא.
פונקציות הטלפון התראה	האם ניתן להשתמש בקובצי מוסיקה להתראה?	כן. לאחר שמירת קובץ מוסיקה כרינגטון, באפשרותך להשתמש בו להתראה. 1. גע ברציפות בשיר ברשימת ספרייה. בתפריט שנפתח, גע באפשרות **הגדר כרינגטון**. 2. במסך של הגדרת שעון מעורר, בחר את השיר כרינגטון.
פונקציות הטלפון התראה	האם ההתראות ישמעו בכל מקרה, או שגם ההתראות יכובו כאשר הטלפון מכובה?	לא, אין תמיכה בכך.
פונקציות הטלפון התראה	אם עוצמת הצלצול הוגדרה ככבויה או רטט, האם אשמע את ההתראה?	ההתראה מתוכנתת להישמע אפילו בתרחישים אלו.
פתרונות התאוששות שימוש באיפוס קשיח (איפוס להגדרות היצרן)	כיצד ניתן לבצע שחזור נתוני יצרן אם אינני יכול לגשת לתפריט ההגדרות של הטלפון?	אם הטלפון אינו משתחזר למצבו המקורי, יש להשתמש באיפוס קשיח (איפוס להגדרות יצרן) כדי לאתחל אותו.

ENGLISH

User Guide

- Screen displays and illustrations may differ from those you see on actual phone.
- Some of the contents of this guide may not apply to your phone, depending on the software and your service provider. All information in this document is subject to change without notice.
- This handset is not suitable for people who have a visual impairment due to the touch screen keyboard.
- Copyright ©2013 LG Electronics, Inc. All rights reserved. LG and the LG logo are registered trademarks of LG Group and its related entities. All other trademarks are the property of their respective owners.
- Google™, Google Maps™, Gmail™, Hangouts™ and Play Store™ are trademarks of Google, Inc.

Table of contents

Guidelines for safe and efficient use 5

Important notice 12

Getting to know your phone 18
- Phone overview 18
- Installing the Micro-USIM card 20
- Charging the phone 21
- Locking and unlocking the screen.....21

Your Home screen 22
- Touch Screen tips 22
- Home screen 23
  - Customizing the Home screen 24
- Returning to recently-used applications...25
- Notifications 25
  - Opening the notifications panel.....26
  - Indicator icons on the Status Bar 26
- On-screen keyboard 28
  - Entering accented letters.....28

Google account setup 29

Connecting to Networks and Devices....30
- Wi-Fi 30
  - Connecting to Wi-Fi networks 30
  - Turning Wi-Fi on and connecting to a Wi-Fi network 30
- Bluetooth.....31
- Sharing your phone's data connection ...32
- Wi-Fi Direct 34
- PC connections with a USB cable.....34

Calls 36
- Making a call.....36
- Calling your contacts 36
- Answering and rejecting a call 36
- Adjusting the in-call volume.....37
- Making a second call 37
- Viewing your call logs 38
- Call settings.....38

Contacts 39
- Searching for a contact.....39
- Adding a new contact 39
- Favorite contacts 39
- Creating a group.....40

Messaging.....41
- Sending a message 41
- Threaded box 42
- Changing your message settings 42

E-mail 43
- Managing an email account.....43
- Working with account folders.....43
- Composing and sending email 44

Camera 45
- Getting to know the viewfinder 45
- Using the advanced settings 46
- Taking a quick photo 47
- Once you've taken a photo.....48
- From your Gallery 49

Video camera 50

Getting to know the viewfinder 50
Using the advanced settings 51
Recording a quick video.....51
After recording a video.....52
Watching your saved videos 52
Adjusting the volume when viewing a video 52

LG Unique Function.....53
QuickMemo function.....53
Using the QuickMemo options 54
Viewing the saved QuickMemo 54
Notebook function 55
Making a note 55
Getting to know the Notebook.....55
Bookshelf 55
Pages-Property panels 56
Viewing the saved notebook 56
Live Zooming function 57
QSlide function 58
Dual Play function.....59
Mirroring 59
Dual Play.....59
LG SmartWorld 60
How to Get to LG SmartWorld from Your Phone.....60
On-Screen Phone 61
On-Screen Phone icons.....61
On-Screen Phone features 61
How to install On-Screen Phone on your PC 62

Multimedia 63
Gallery.....63
Viewing pictures 63
Playing videos 64
Editing photos/videos 64
Deleting images.....64
Setting as wallpaper 64
Videos 65
Playing a video 65
Video Editor 66
Video Wiz.....67
Music 69
Playing a song.....69
Add music files to your phone.....70
Transfer music using Media sync (MTP)...71

Utilities 72
Setting your alarm 72
Using your calculator 72
Adding an event to your calendar.....72
Voice Recorder 73
Recording a sound or voice 73
Sending the voice recording 73
Task Manager.....74
Tasks.....74
Polaris Office 4 74
Backup.....75
About backing up and restoring smart phone data 75
Backup 76
Scheduling backup 76
File restore & management 76

Table of contents

Google+ 77
Voice Search.....77
Downloads 77

The Web 78

Internet.....78
Using the Web toolbar 78
Viewing webpages 78
Opening a page 79
Searching the web by voice 79
Bookmarks 79
History 79
Using Popup Browser 79
Chrome 80
Viewing webpages 80
Opening a page 80
Syncing with other devices 80

Settings 81

WIRELESS & NETWORKS 81
DEVICE 84
PERSONAL.....86
SYSTEM.....88

PC software (LG PC Suite) 90

Phone software update 92

Phone software update 92

About this user guide 94

About this user guide.....94
Trademarks 94
DivX HD 95
Dolby Mobile 95

Accessories.....96

Troubleshooting 97

FAQ 101

Guidelines for safe and efficient use

Please read these simple guidelines. Not following these guidelines may be dangerous or illegal.

Exposure to radio frequency energy

Radio wave exposure and Specific Absorption Rate (SAR) information.

This mobile phone model LG-E975k has been designed to comply with applicable safety requirements for exposure to radio waves. These requirements are based on scientific guidelines that include safety margins designed to assure the safety of all persons, regardless of age and health.

- The radio wave exposure guidelines employ a unit of measurement known as the Specific Absorption Rate (SAR). Tests for SAR are conducted using standardised methods with the phone transmitting at its highest certified power level in all used frequency bands.
- While there may be differences between the SAR levels of various LG phone models, they are all designed to meet the relevant guidelines for exposure to radio waves.
- The SAR limit recommended by the International Commission on Non-Ionizing Radiation Protection (ICNIRP) is 2 W/kg averaged over 10g of tissue.
- The highest SAR value for this model phone tested for use at the ear is 0.340 W/kg (10g) and when worn on the body is 0.391 W/Kg (10g).
- This device meets RF exposure guidelines when used either in the normal use position against the ear or when positioned at least 1.5 cm away from the body. When a carry case, belt clip or holder is used for body-worn operation, it should not contain metal and should position the product at least 1.5 cm away from your body. In order to transmit data files or messages, this device requires a quality connection to the network. In some cases, transmission of data files or messages may be delayed until such a connection is available. Ensure the above separation distance instructions are followed until the transmission is completed.

Guidelines for safe and efficient use

Product care and maintenance

⚠ **WARNING**

Only use batteries, chargers and accessories approved for use with this particular phone model. The use of any other types may invalidate any approval or warranty applying to the phone and may be dangerous.

- Do not disassemble this unit. Take it to a qualified service technician when repair work is required.
- Repairs under warranty, at LG's discretion, may include replacement parts or boards that are either new or reconditioned, provided that they have functionality equal to that of the parts being replaced.
- Keep away from electrical appliances such as TVs, radios and personal computers.
- The unit should be kept away from heat sources such as radiators or cookers.
- Do not drop.
- Do not subject this unit to mechanical vibration or shock.
- Switch off the phone in any area where you are required to by special regulations. For example, do not use your phone in hospitals as it may affect sensitive medical equipment.
- Do not handle the phone with wet hands while it is being charged. It may cause an electric shock and can seriously damage your phone.
- Do not charge a handset near flammable material as the handset can become hot and create a fire hazard.
- Use a dry cloth to clean the exterior of the unit (do not use solvents such as benzene, thinner or alcohol).
- Do not charge the phone when it is on soft furnishings.
- The phone should be charged in a well ventilated area.
- Do not subject this unit to excessive smoke or dust.

- Do not keep the phone next to credit cards or transport tickets; it can affect the information on the magnetic strips.
- Do not tap the screen with a sharp object as it may damage the phone.
- Do not expose the phone to liquid or moisture.
- Use accessories like earphones cautiously. Do not touch the antenna unnecessarily.
- Do not use, touch or attempt to remove or fix broken, chipped or cracked glass. Damage to the glass display due to abuse or misuse is not covered under the warranty.
- Your phone is an electronic device that generates heat during normal operation. Extremely prolonged, direct skin contact in the absence of adequate ventilation may result in discomfort or minor burns. Therefore, use care when handling your phone during or immediately after operation.
- If your phone gets wet, immediately unplug it to dry off completely. Do not attempt to accelerate the drying process with an external heating source, such as an oven, microwave or hair dryer.
- The liquid in your wet phone, changes the color of the product label inside your phone. Damage to your device as a result of exposure to liquid is not covered under your warranty.

Efficient phone operation

Electronics devices

All mobile phones may receive interference, which could affect performance.

- Do not use your mobile phone near medical equipment without requesting permission. Avoid placing the phone over pacemakers, for example, in your breast pocket.
- Some hearing aids might be disturbed by mobile phones.
- Minor interference may affect TVs, radios, PCs etc.

Guidelines for safe and efficient use

- Use your phone in temperatures between 0ºC and 40ºC, if possible. Exposing your phone to extremely low or high temperatures may result in damage, malfunction, or even explosion.

Road safety

Check the laws and regulations on the use of mobile phones in the area when you drive.

- Do not use a hand-held phone while driving.
- Give full attention to driving.
- Pull off the road and park before making or answering a call if driving conditions so require.
- RF energy may affect some electronic systems in your vehicle such as car stereos and safety equipment.
- When your vehicle is equipped with an air bag, do not obstruct with installed or portable wireless equipment. It can cause the air bag to fail or cause serious injury due to improper performance.
- If you are listening to music whilst out and about, please ensure that the volume is at a reasonable level so that you are aware of your surroundings. This is of particular importance when near roads.

Avoid damage to your hearing

To prevent possible hearing damage, do not listen at high volume levels for long periods.

Damage to your hearing can occur if you are exposed to loud sound for long periods of time. We therefore recommend that you do not turn on or off the handset close to your ear. We also recommend that music and call volumes are set to a reasonable level.

- When using headphones, turn the volume down if you cannot hear the people speaking near you, or if the person sitting next to you can hear what you are listening to.

NOTE: Excessive sound pressure from earphones and headphones can cause hearing loss.

Glass Parts

Some parts of your mobile device are made of glass. This glass could break if your mobile device is dropped on a hard surface or receives a substantial impact. If the glass breaks, do not touch or attempt to remove it. Stop using your mobile device until the glass is replaced by an authorised service provider.

Blasting area

Do not use the phone where blasting is in progress. Observe restrictions and follow any regulations or rules.

Potentially explosive atmospheres

- Do not use your phone at a refueling point.
- Do not use near fuel or chemicals.
- Do not transport or store flammable gas, liquid or explosives in the same compartment of your vehicle as your mobile phone or accessories.

Guidelines for safe and efficient use

In aircraft

Wireless devices can cause interference in aircraft.

- Turn your mobile phone off before boarding any aircraft.
- Do not use it on the ground without permission from the crew.

Children

Keep the phone in a safe place out of the reach of small children. It includes small parts which may cause a choking hazard if detached.

Emergency calls

Emergency calls may not be available on all mobile networks. Therefore you should never depend solely on your phone for emergency calls. Check with your local service provider.

Battery information and care

- You do not need to completely discharge the battery before recharging. Unlike other battery systems, there is no memory effect that could compromise the battery's performance.
- Use only LG batteries and chargers. LG chargers are designed to maximise the battery life.
- Do not disassemble or short-circuit the battery.
- Replace the battery when it no longer provides acceptable performance. The battery pack may be recharged hundreds of times before it needs replacing.
- Recharge the battery if it has not been used for a long time to maximise usability.
- Do not expose the battery charger to direct sunlight or use it in high humidity, such as in the bathroom.

- Do not leave the battery in hot or cold places, as this may deteriorate battery performance.
- There is risk of explosion if the battery is replaced with an incorrect type.
- Dispose of used batteries according to the manufacturer's instructions. Please recycle when possible. Do not dispose as household waste.
- If you need to replace the battery, take it to the nearest authorised LG Electronics service point or dealer for assistance.
- Always unplug the charger from the wall socket after the phone is fully charged to save unnecessary power consumption of the charger.
- Actual battery life will depend on network configuration, product settings, usage patterns, battery and environmental conditions.
- Make sure that no sharp-edged items such as animal's teeth or nails, come into contact with the battery. This could cause a fire.
- For your safety, do not remove the battery incorporated in the product.
- Do not replace the battery by yourself. The battery can be damaged, which can cause overheat and injury. The battery must be replaced by the authorized service provider. The battery should be recycled or disposed separately from household waste.

DECLARATION OF CONFORMITY

Hereby, **LG Electronics** declares that this **LG-E975k** product is in compliance with the essential requirements and other relevant provisions of Directive **1999/5/EC**. A copy of the Declaration of Conformity can be found at **http://www.lg.com/global/declaration**

Regulatory and Safety

Go to **"System settings > About phone > Regulatory and Safety"** to get regulatory and safety information

Important notice

Please read this before you start using your phone!

Please check to see whether any problems you encountered with your phone are described in this section before taking the phone in for service or calling a service representative.

1. Phone memory

When there is less than 10% of space available in your phone memory, your phone cannot receive new messages. You need to check your phone memory and delete some data, such as applications or messages, to make more memory available.

To uninstall applications:

1 Touch > **Apps** tab > **Settings** > **Apps**.
2 Once all applications appear, scroll to and select the application you want to uninstall.
3 Touch **Uninstall**.

2. Optimizing battery life

Extend your battery's life between charges by turning off features that you don't need to having running constantly in the background. You can monitor how applications and system resources consume battery power.

Extending your phone's battery life:

- Turn off radio communications you are not using. If you are not using Wi-Fi, Bluetooth or GPS, turn them off.
- Reduce screen brightness and set a shorter screen timeout.
- Turn off automatic syncing for Gmail, Calendar, Contacts and other applications.
- Some applications you have downloaded may reduce battery power.

To check the battery power level:

- Touch > **Apps** tab > **Settings** > **About phone** > **Battery.**

The battery status (charging or discharging) and battery level (percentage charged) is displayed at the top of the screen.

To monitor and control how battery power is being used:

- Touch > **Apps** tab > **Settings** > **About phone** > **Battery** > **Battery use**.

Battery usage time is displayed on the screen. It tells you how long it has been since you last connected your phone to a power source or, if currently connected, how long the phone was last running on battery power. The screen shows the applications or services using battery power, listed in order from the greatest to smallest amount used.

3. Before installing an open source application and OS

⚠ **WARNING**

If you install and use an OS other than the one provided by the manufacturer it may cause your phone to malfunction. In addition, your phone will no longer be covered by the warranty.

⚠ **WARNING**

To protect your phone and personal data, only download applications from trusted sources, such as Play Store™. If there are improperly installed applications on your phone, the phone may not work normally or a serious error may occur. You must uninstall those applications and all associated data and settings from the phone.

4. Using an unlock pattern

Set an unlock pattern to secure your phone. Touch > **Apps** tab > **Settings** > **Lock screen** > **Select screen lock** > **Pattern.** This opens a screen that will guide you through how to draw a screen unlock pattern. You have to create a Backup PIN as a safety measure in case you forget your unlock pattern.

Caution: Create a Google account before setting an unlock pattern and remember the Backup PIN you created when creating your pattern lock.

⚠ WARNING

Precautions to take when using pattern lock.

It is very important to remember the unlock pattern you set. You will not be able to access your phone if you use an incorrect pattern 5 times. You have 5 opportunities to enter your unlock pattern, PIN or password. If you have used all 5 opportunities, you can try again after 30 seconds.

When you can't recall your unlock Pattern, PIN, or Password:

< If you have forgotten your pattern >

If you logged in to your Google account on the phone but failed to enter the correct pattern 5 times, press the **Forgot pattern?** button at the bottom of the screen. You are then required to log in with your Google Account or you have to enter the Backup PIN which you entered when creating your Pattern Lock.

If you have not created a Google account on the phone or you forgot Backup PIN, you have to perform a hard reset.

< If you have forgotten your PIN or Password >

If you forget your PIN or Password, you will need to perform a hard reset.

Caution: If you perform a hard reset, all user applications and user data will be deleted.

NOTE: If you have not logged into your Google Account and have forgotten your Unlock Pattern, you will need to enter your Backup PIN.

5. Using the hard reset (Factory reset)

If your phone does not restore to its original condition, use a Hard Reset (Factory Reset) to initialize it.

1 Turn the power off.
2 Press and hold the **Power/Lock key + Volume Down key** on the phone.
3 Release the **Power/Lock Key** only when the LG logo is displayed, then immediately press and hold the **Power/Lock Key** again.
4 Release all keys when the Factory data reset screen is displayed.
5 Press the **Volume Key** to scroll to the desired option, then press the **Power/Lock Key** to confirm.

⚠ WARNING

If you perform a Hard Reset, all user applications, user data and DRM licenses will be deleted. Please remember to backup any important data before performing a Hard Reset.

Factory data reset - Erases all data on the phone, except as follows. In the event of device failure or error, your device may record in an error log information about the device's status at the time of the error event. The information recorded in the error log may include data about application names and usage, cell phone location and number, GPS status, memory usage and other non-personal device status information. This information is stored on your phone, and can only be accessed by LG if the phone is physically returned to LG for repair and service. The error log information is used by LG only to diagnose, repair, and improve LG's products and services.

6. Opening and switching applications

Multi-tasking is easy with Android, you can keep more than one application running at the same time. There is no need to quit an application before opening another one. Use and switch between several open applications.

Android manages each application, stopping and starting them as needed to ensure that idle applications don't consume resources unnecessarily.

1 Press and hold the **Home Key** . A list of recently used applications will be displayed.

2 Tap the application you want to access. This does not stop the previous app running in the background on the phone. Make sure to tap **Back Key** to exit an app after using it.

- To stop applications, tap **Task Manager** from the recent apps list, then tap Stop or Stop all.
- To remove an app from the recent apps list, swipe the app preview to the left or right. To clear all apps, tap **Clear all**.

7. Transferring music, photos and videos using Media sync (MTP)

1 Touch > **Apps** tab > **Settings** > **Storage** to check out the storage media.

2 Connect the phone to your PC using the USB cable.

3 **Select USB connection method** will appear on your phone screen, select the **Media sync (MTP)** option.

4 Open the memory folder on your PC. You can view the mass storage content on your PC and transfer the files from PC to Device memory folder or vice versa.

8. Hold your phone upright

Hold your cell phone vertically, as you would a regular phone. Your phone has an internal antenna. Be careful not to scratch or damage the back of the phone, as this may affect performance.

When making/receiving calls or sending/receiving data, avoid holding the lower part of the phone where the antenna is located. Doing so may affect call quality.

9. When the screen freezes

If the screen freezes or the phone does not respond when you try to operate it:

Press and hold the **Power/Lock** key for 10 seconds to turn your phone off.

If it still does not work, please contact the service center.

Getting to know your phone

Phone overview

Earpiece

Notification LED

Front-Facing Camera lens

Proximity / Luminance Sensor

Power/Lock key

- Switch your phone on/off by pressing and holding this key
- Short press to lock/unlock the screen

Touch screen

Back key

- Return to the previous screen. Exit an app after using it.

Home key

- Return to the Home screen from any screen.

Menu key

- Check what options are available.

NOTE: Proximity sensor

When receiving and making calls, the proximity sensor automatically turns the backlight off and locks the touch screen by sensing when the phone is near your ear. This extends battery life and prevents you from unintentionally activating the touch screen during calls.

WARNING

Placing a heavy object on the phone or sitting on it can damage the LCD and touch screen functions. Do not cover the LCD proximity sensor with protective film. This could cause the sensor to malfunction.

Volume keys

- **On the Home screen:** Controls ringer volume
- **During a call:** Controls your earpiece volume
- **When playing a track:** Controls volume continuously

TIP! QuickMemo function

Press and hold the Volume Up and Volume Down Keys for one second to use the QuickMemo function.

Power/Lock key

SIM card tray

Earphone Jack

Microphone

Camera lens

Flash

NFC touch point

Speaker

Charger/USB/MHL port

Microphone

⚠ WARNING

- This part encloses the battery compartment. Please do not open the back cover.
- Be careful not to damage the NFC touch point on the phone, which is part of the NFC antenna.

Installing the Micro-USIM card

Before you start exploring your new phone, you may choose to insert the Micro-USIM card.

The eject button is a small round aperture just above the tray door. To install a new Micro-USIM card:

1 Insert the Micro-USIM ejection tool that comes with the phone (or a thin pin) into the eject button aperture, and push gently but firmly until the tray pops out.

2 Remove the tray and place the Micro-USIM card inside it, with the contacts out and the angled corner to the right. There is only one possible way to fit the card snugly into the tray.

3 Carefully reposition the tray in the slot and push it gently back into the phone.

NOTE: Make sure the gold contact area on the card is facing downwards.

Charging the phone

The charger connector is at the bottom of the phone. Insert one end of the charging cable into the phone and plug the other end into an electrical outlet.

NOTE: The battery must be fully charged initially to improve battery lifetime.

Locking and unlocking the screen

If you do not use the phone for a while, the screen will be automatically turned off and locked. This helps to prevent accidental touches and saves battery power.

When you are not using the your phone, press the **Power/Lock key** to lock your phone.

If there are any programs running when you lock your screen, they may be still running in Lock mode. It is recommended that you exit all programs before entering Lock mode to avoid unnecessary charges (e.g. phone calls, web access and data communications).

To wake up your phone, press the **Power/Lock key**. The Lock screen will appear. Touch and slide the Lock screen in any direction to unlock your Home screen. The last screen you viewed will open.

Your Home screen

Touch Screen tips

Here are some tips on how to navigate on your phone.

Tap or touch – A single finger tap selects items, links, shortcuts and letters on the on-screen keyboard.

Touch and hold – Touch and hold an item on the screen by touching it and not lifting your finger until an action occurs. For example, to open a contact's available options, touch and hold the contact in the Contacts list until the context menu opens.

Drag – Touch and hold an item for a moment and then, without lifting your finger, move your finger on the screen until you reach the target position. You can drag items on the Home screen to reposition them.

Swipe or slide – To swipe or slide, quickly move your finger across the surface of the screen, without pausing when you first touch it (so you don't drag an item instead). For example, you can slide the screen up or down to scroll through a list, or browse through the different Home screens by swiping from left to right (and vice versa).

Double-tap – Double-tap to zoom on a webpage or a map. For example, quickly double-tap a section of a webpage to adjust that section to fit the width of the screen. You can also double-tap to zoom in and out after taking a picture (using the Camera), and when using Maps.

Pinch-to-Zoom – Use your index finger and thumb in a pinching or spreading motion to zoom in or out when using the browser or Maps, or when browsing pictures.

Rotate the screen – From many applications and menus, the orientation of the screen adjusts to the device's physical orientation.

NOTE:

- To select an item, touch the center of the icon.
- Do not press too hard; the touch screen is sensitive enough to pick up a light, yet firm touch.
- Use the tip of your finger to touch the option you want. Be careful not to touch any other keys.

Home screen

The Home screen is the starting point for many applications and functions, and it allows you to add items like application shortcuts, or Google widgets to give you instant access to information and applications. This is the default canvas and accessible from any menu by tapping .

Status bar
Shows phone's status information including the time, signal strength, battery status, and notification icons.

Widget
Widgets are self-contained applications that can be accessed through the Apps screen or on the Home screen or an extended home screen. Unlike a shortcut, the Widget appears as an on-screen application.

Application Icons
Tap an icon (application, folder, etc.) to open and use it.

Location Indicator
Indicates which Home screen canvas you are viewing.

Quick Key Area
Provides one-touch access to the function in any home screen canvas.

Extended home screen

The operating system provides multiple Home screen canvases to provide more space for adding icons, widgets, and more.

Slide your finger left or right across the Home screen.

Your Home screen

Customizing the Home screen

You can customize your Home screen by adding apps, widgets or changing wallpapers.

To add items on your Home screen:

1 Touch and hold the empty part of the Home screen.
2 In the Add Mode menu, select the item you wish to add. You will then see this added item on the Home screen.
3 Drag it to the desired location and lift your finger.

TIP! To add an application icon to the Home screen from the Apps menu, touch and hold the application you want to add.

To remove an item from the Home screen:

- **Home screen** > touch and hold the icon you want to remove > drag it to

TIP! Using folders
You can combine several app icons in a folder. Drop one app icon over another one on a Home screen, and the two icons will be combined.

NOTE: Apps key cannot be removed.

To customize apps icons on the Home screen

1 Touch and hold an application icon until it is unlocked from its current position. Then drop it on the screen.
The editing icon will appear in the upper right corner of the application.
2 Tap the application icon again and select the desired icon design and size.
3 Tap **OK** to save the change.

Returning to recently-used applications

1 Touch and hold the **Home key** . The screen displays a pop-up containing the icons of applications you used recently.
2 Touch an icon to open the application. Or touch the **Back key** to return to your previous screen.

Notifications

Notifications alert you to the arrival of new messages, calendar events, and alarms, as well as to ongoing events, such as when you are on a call.
From the notifications panel, you can view your phone's current status and pending notifications.
When a notification arrives, its icon appears at the top of the screen. Icons for pending notifications appear on the left, and system icons showing things like Wi-Fi or battery strength on the right.

NOTE: The available options may vary depending on the region or service provider.

Your Home screen

Opening the notifications panel

Swipe down from the status bar to open the notifications panel.

Quick Toggle Area

Tap each quick toggle key to turn it on/off. Touch and hold the key to access the settings menu of the function. To see more toggle keys, swipe left or right. Tap to remove, add, or rearrange toggle keys.

QSlide Apps

Tap a QSlide app to open as a small window on your screen. Tap to remove, add, or rearrange QSlide apps.

Tap to clear all the notifications.

Notifications

The current notifications are listed, each with a brief description. Tap a notification to view it.

To close the notifications panel, touch and drag the tab toward the top of the screen.

Indicator icons on the Status Bar

Indicator icons appear on the status bar at the top of the screen to report missed calls, new messages, calendar events, device status and more.

The icons displayed at the top of the screen provide information about the status of the device. The icons listed in the table below are some of the most common ones.

Icon	Description
	No Micro-USIM card

Icon	Description
	Vibrate mode

	No signal
	Airplane mode
	Connected to a Wi-Fi network
	Wired headset
	Call in progress
	Call hold
	Missed call
	Bluetooth is on
	System warning
	Alarm is set
	New voicemail
	Ringer is silenced
	NFC is on
	P2P is on

	Battery fully charged
	Battery is charging
	Downloading data
	Uploading data
	GPS is acquiring
	Receiving location data from GPS
	Data is syncing
	New Gmail
	New Google Talk message
	New message
	Song is playing
	Phone is connected to PC via USB cable or USB tethering is active
	Portable Wi-Fi hotspot is active
	Both USB tethering and portable hotspot are active

NOTE: The icons location in the status bar may differ according to the function or service.

On-screen keyboard

You can enter text using the on-screen keyboard. The on-screen keyboard appears automatically on the screen when you need to enter text. To manually display the keyboard, simply touch a text field where you want to enter text.

Using the keypad & entering text

Tap once to capitalize the next letter you type. Double-tap for all caps.

Tap to switch to the numbers and symbols keyboard.

Tap to enter a space.

Tap to create a new line

Tap to delete the previous character.

Entering accented letters

When you select French or Spanish as the text entry language, you can enter special French or Spanish characters (e.g. "á").

For example, to input "á", touch and hold the "a" key until the zoom-in key grows bigger and displays characters from different languages.

Then select the special character you want.

Google account setup

When you first turn on your phone, you have the opportunity to activate the network, to sign into your Google Account and select how you want to use certain Google services.

To set up your Google account:

- Sign into a Google Account from the prompted set-up screen.

  OR

- Touch > **Apps** tab > select a Google application, such as **Gmail** > select **New** to create a new account.

If you have a Google account, touch **Existing**, enter your email address and password, then touch .

Once you have set up your Google account on your phone, your phone automatically synchronizes with your Google account on the Web.

Your contacts, Gmail messages, Calendar events and other information from these applications and services on the Web are synchronized with your phone. (This will depend on your synchronization settings.)

After signing in, you can use Gmail™ and take advantage of Google services on your phone.

Connecting to Networks and Devices

Wi-Fi

With Wi-Fi, you can use high-speed Internet access within the coverage of the wireless access point (AP). Enjoy wireless Internet using Wi-Fi, without extra charges.

Connecting to Wi-Fi networks

To use Wi-Fi on your phone, you need to access a wireless access point or 'hotspot'. Some access points are open and you can simply connect to them. Others are hidden or use security features; you must configure your phone to be able to connect to them. Turn off Wi-Fi when you're not using it to extend the life of your battery.

NOTE: If you are out of the Wi-Fi zone or have set Wi-Fi to **OFF**, additional charges may be applied by your mobile operator for mobile data use.

Turning Wi-Fi on and connecting to a Wi-Fi network

1 Touch > **Apps** tab > **Settings** > **Wi-Fi**.
2 Set **Wi-Fi** to **ON** to turn it on and start scanning for available Wi-Fi networks.
3 Tap the Wi-Fi menu again to see a list of active and in-range Wi-Fi networks.
   - Secured networks are indicated by a lock icon.
4 Touch a network to connect to it.
   - If the network is secured, you are prompted to enter a password or other credentials. (Ask your network administrator for details)
5 The status bar displays icons that indicate Wi-Fi status.

Bluetooth

You can use Bluetooth to send data by running a corresponding application, but not from the Bluetooth menu as on most other mobile phones.

NOTE:

- LG is not responsible for the loss, interception or misuse of data sent or received via the Bluetooth wireless feature.
- Always ensure that you share and receive data with devices that are trusted and properly secured. If there are obstacles between the devices, the operating distance may be reduced.
- Some devices, especially those that are not tested or approved by Bluetooth SIG, may be incompatible with your device.

Turning on Bluetooth and pairing up your phone with a Bluetooth device

You must pair your device with another device before you connect to it.

1 Touch > **Apps** tab > **Settings** > set **Bluetooth** to **ON**.

2 Tap the **Bluetooth** menu again. You will see the option to make your phone visible and option to search devices Now tap **Search for devices** to view the devices in the bluetooth Range.

3 Choose the device you want to pair with from the list.

Once the paring is successful, your device will connect to the device.

NOTE: Some devices, especially headsets or hands-free car kits, may have a fixed Bluetooth PIN, such as 0000. If the other device has a PIN, you will be asked to enter it.

Send data using the Bluetooth wireless feature

1 Select a file or item, such as a contact, calendar event, or media file, from an appropriate application or from **Downloads**.
2 Select the option for sending data via Bluetooth.

NOTE: The method for selecting an option may vary by data type.

3 Search for and pair with a Bluetooth-enabled device.

Receive data using the Bluetooth wireless feature

1 Touch > **Apps** tab > **Settings** > set **Bluetooth** to **ON**
2 Tap the **Bluetooth** menu again and mark the checkbox at the top of the screen to make your phone visible to other devices.

NOTE: To select the length of time that your device will be visible, touch > **Visibility timeout**.

3 Select **Pair** to confirm that you are willing to receive data from the device.

Sharing your phone's data connection

USB tethering and portable Wi-Fi hotspot are great features when there are no wireless connections available. You can share your phone's mobile data connection with a single computer via a USB cable (USB tethering). You can also share your phone's data connection with more than one device at a time by turning your phone into a portable Wi-Fi hotspot.

When your phone is sharing its data connection, an icon appears in the status bar and as an ongoing notification in the notifications drawer.

For the latest information about tethering and portable hotspots, including supported operating systems and other details, visit http://www.android.com/tether.

To change Portable Wi-Fi hotspot settings:

1 Touch > **Apps** tab > **Settings** > **Tethering & networks** > **Wi-Fi hotspot** switch to activate.

2 Enter a password and tap **Save**.

TIP! If your computer is running Windows 7 or a recent distribution of some flavours of Linux (such as Ubuntu), you will not usually need to prepare your computer for tethering. But, if you are running an earlier version of Windows or another operating system, you may need to prepare your computer to establish a network connection via USB. For the most current information about which operating systems support USB tethering and how to configure them, visit http://www.android.com/tether.

To rename or secure your portable hotspot

You can change the name of your phone's Wi-Fi network name (SSID) and secure its Wi-Fi network.

1 Touch > **Apps** tab > **Settings** > **Tethering & networks** > **Wi-Fi hotspot.**

2 Touch **Set up Wi-Fi hotspot**.

- The **Set up Wi-Fi hotspot** dialogue box will open.
- You can change the **Network SSID** (name) that other computers see when scanning for Wi-Fi networks.
- You can also touch the **Security** menu to configure the network with Wi-Fi Protected Access 2 (WPA2) security using a pre-shared key (PSK).
- If you touch the **WPA2 PSK** security option, a password field is added to the **Set up Wi-Fi hotspot** dialogue box. If you enter a password, you will need to enter that password when you connect to the phone's hotspot with a computer or other device. You can set **Open** in the **Security** menu to remove security from your Wi-Fi network.

3 Tap **Save**.

ATTENTION! If you set the security option as Open, you cannot prevent unauthorised usage of online services by other people and additional charges may be incurred. To avoid unauthorized usage, you are advised to keep the security option active.

Wi-Fi Direct

Wi-Fi Direct supports a direct connection between Wi-Fi enabled devices without an access point. Due to the high battery usage of Wi-Fi direct, it is recommended that you plug your phone into a power outlet while using the Wi-Fi Direct feature. Check your Wi-Fi & Wi-Fi Directed network in advance and make sure the users are connected to the same network.

PC connections with a USB cable

Learn to connect your device to a PC with a USB cable in USB connection modes.

Transferring music, photos and videos using the USB mass storage mode

1 Connect your phone to a PC using a USB cable.
2 If you haven't installed the LG Android Platform Driver on your PC, you will need to manually change the settings. Choose **System settings** > **PC connection** > **USB connection method**, then select **Media sync (MTP)**.
3 You can now view the mass storage content on your PC and transfer the files.

Synchronize with Windows Media Player

Ensure that Windows Media Player is installed on your PC.

1. Use the USB cable to connect the phone to a PC on which Windows Media Player has been installed.
2. Select the **Media sync (MTP)** option. When connected, a pop-up window will appear on the PC.
3. Open Windows Media Player to synchronize music files.
4. Edit or enter your device's name in the pop-up window (if necessary).
5. Select and drag the music files you want to the sync list.
6. Start synchronization.

- The following requirements must be satisfied to synchronize with Windows Media Player.

Items	Requirement
OS	Microsoft Windows XP SP2, Vista or higher
Window Media Player version	Windows Media Player 10 or higher

- If the Windows Media Player version is lower than 10, install version 10 or higher.

Calls

Making a call

1 Touch to open the keypad.
2 Enter the number using the keypad. To delete a digit, touch the .
3 Touch to make a call.
4 To end a call, touch the **End** icon .

TIP! To enter "+" to make international calls, touch and hold 0+.

Calling your contacts

1 Touch to open your contacts.
2 Scroll through the contact list or enter the first few letters of the contact you want to call by touching **Search contacts**.
3 In the list, touch the contact twice or touch the you want to call.

Answering and rejecting a call

When you receive a call in Lock state, swipe the in any direction to Answer the incoming call.
Swipe the in any direction to Decline an incoming call.
Hold and slide the **Decline with message** icon from the bottom if you want to send a message.

TIP! Decline with message
You can send a message quickly using this function. This is useful if you need to reject a call with message during a meeting.

Adjusting the in-call volume

To adjust the in-call volume during a call, use the Volume up and down keys on the left-hand side of the phone.

Making a second call

1 During your first call, touch **Menu** > **Add call** and dial the number. You can also go to the recently dialled numbers list by touching or can search contacts by touching and selecting the contact you want to call.
2 Touch to make the call.
3 Both calls are displayed on the call screen. Your initial call is locked and put on hold.
4 Touch the displayed number to toggle between calls. Or touch **Merge calls** to start a conference call.
5 To end active calls, touch **End** or touch the **Home** key and slide the notification bar down and select the **End call** icon .

NOTE: You are charged for each call you make.

Calls

Viewing your call logs

On the Home screen, touch and choose the **Call logs** tab .
View a complete list of all dialled, received and missed calls.

TIP! Touch any call log entry to view the date, time and duration of the call.

TIP! Touch the **Menu** key , then touch **Delete all** to delete all the recorded items.

Call settings

You can configure phone call settings such as call forwarding, as well as other special features offered by your carrier.

1 On the Home screen, touch .
2 Touch .
3 Tap **Call settings** and choose the options that you wish to adjust.

Contacts

Add contacts to your phone and synchronize them with the contacts in your Google account or other accounts that support contact syncing.

Searching for a contact

On the Home screen

1 Touch to open your contacts.
2 Touch **Search contacts** and enter the contact name using the keyboard.

Adding a new contact

1 Touch , enter the new contact's number, then touch the **Menu** key . Touch **Add to Contacts** > **Create new contact**.
2 If you want to add a picture to the new contact, touch the image area. Choose from **Take photo** or **Select from Gallery**.
3 Select the contact type by touching .
4 Touch a category of contact information and enter the details about your contact.
5 Touch **Save**.

Favorite contacts

You can classify frequently called contacts as favorites.

Adding a contact to your favorites

1 Touch to open your contacts.
2 Touch a contact to view its details.
3 Touch the star to the right of the contact's name. The star will turn yellow color.

Removing a contact from your favorites list

1 Touch to open your contacts.
2 Touch the tab, and choose a contact to view its details.
3 Touch the yellow color star to the right of the contact's name. The star turns grey and the contact is removed from your favorites.

Creating a group

1 Touch to open your contacts.
2 Touch **Groups** and touch the **Menu** key . Select **New group**.
3 Enter a name for the new group. You can also set a ringtone for the newly created group.
4 Touch **Save** to save the group.

NOTE: If you delete a group, the contacts assigned to that group will not be lost. They will remain in your contacts.

Messaging

Your phone combines SMS and MMS into one intuitive, easy-to-use menu.

Sending a message

1 Touch on the Home screen and touch to open a blank message.
2 Enter a contact name or contact number in the **To** field. As you enter the contact name, matching contacts will appear. You can touch a suggested recipient. You can add more than one contact.

NOTE: You will be charged for a text message for every person to whom you send the message.

3 Touch the **Enter message** field and begin composing your message.
4 Touch to open the Options menu. Choose from **Quick message**, **Insert smiley**, **Schedule sending**, **Add subject**, and **Discard**.

TIP! You can touch the icon to attach the file you want to share to your message.

5 Touch **Send** to send your message.
6 Responses will appear on the screen. As you view and send additional messages, a message thread is created.

⚠ **WARNING:** The 160-character limit may vary from country to country, depending on the language and how the SMS is coded.

⚠ **WARNING:** If an image, video or audio file is added to an SMS message, it is automatically converted into an MMS message and you are charged accordingly.

Threaded box

Messages (SMS, MMS) exchanged with another party can be displayed in chronological order so that you can conveniently see an overview of your conversation.

Changing your message settings

Your phone message settings are pre-defined, so you can send messages immediately. You can change the settings according to your preferences.

- Touch the **Messaging** icon on the Home screen, touch ☰ and then tap **Settings**.

E-mail

You can use the E-mail application to read emails from services like Gmail. The E-mail application supports the following account types: POP3, IMAP and Exchange.

Your service provider or system administrator can provide you with the account settings you need.

Managing an email account

The first time you open the **E-mail** application, a set-up wizard opens to help you to set up an email account.

After the initial set-up, E-mail displays the contents of your inbox. If you have added more than one account, you can switch among accounts.

To add another email account:

- Touch > **Apps** tab > **E-mail** > tap > **Settings** > **Add account.**

To change an email account's settings:

- Touch > **Apps** tab > **E-mail** > tap > **Settings** > **General settings.**

To delete an email account:

- Touch > **Apps** tab > **E-mail** > tap > **Settings** > tap > **Remove account** > Select the account to delete > **Remove** > select **Yes.**

Working with account folders

Touch > **Apps** tab > **E-mail**, tap and select **Folders**.

Each account has an Inbox, Outbox, Sent and Drafts folder. Depending on the features supported by your account's service provider, you may have additional folders.

Composing and sending email

To compose and send a message

1 While in the **E-mail** application, touch the .
2 Enter an address for the message's intended recipient. As you enter text, matching addresses will be proposed from your Contacts. Separate multiple addresses using semicolons.
3 Touch the Cc/Bcc field to add a Cc/Bcc and Touch to attach files, if required.
4 Enter the text of the message.
5 Touch .
If you aren't connected to a network, for example, if you're working in airplane mode, the messages that you send will be stored in your Outbox folder until you connect to a network again. If it contains any pending messages, the Outbox will be displayed on the **Accounts** screen.

TIP! When a new email arrives in your Inbox, you will be notified by a sound or vibration.

Camera

To open the Camera application, Touch > **Apps** tab > .

Getting to know the viewfinder

1. **Flash** – Choose from **Off** , **On** , **Auto** .
2. **Swap camera** – Switch between the rear–facing camera lens and the front–facing camera lens.
3. **Shot mode** – Choose from **Normal**, **Dynamic tone**, **Panorama**, **Continuous shot**, **Beauty shot**, **Time catch shot**, **Sports or Night**.
4. **Settings** – Tap this icon to open the settings menu.
5. **Video mode** – Tap and slide down this icon to switch to video mode.
6. **Capture button**
7. **Gallery** – Tap to view the last photo you captured. This enables you to access your gallery and view saved photos while in camera mode.

NOTE: Please ensure the camera lens is clean before taking pictures.

Using the advanced settings

In the viewfinder, tap ⚙ to open the advanced options. You can change the camera settings by scrolling through the list. After selecting the option, tap the **Back** key.

	To take a photo, say one of the following words: Cheese, Smile, Whiskey, Kimchi or LG.
	Defines and controls the amount of sunlight entering the photo.
AF	Tap to select the focus mode.
W10M	Selects photo resolution. If you choose high resolution, file size will increase, which means you will be able to store fewer photos in the memory.
	The ISO rating determines the sensitivity of the camera's light sensor. The higher the ISO, the more sensitive the camera. This is useful in darker conditions when you cannot use the flash.
AWB	Improves color quality in various lighting conditions.
	Applies artistic effects to your pictures.
	Sets a delay after the capture button is pressed. This is ideal if you want to be in the photo.
	Activate this to use your phone's location-based services. **NOTE:** This function is available when the GPS function is active or connected network.
	Selects a shutter sound.
	Set the Volume Key whether to use for the capture or zoom.
	Opens the help guide to know how a function operates.
	Restores all camera default settings.

TIP!

- When you exit the camera, some settings return to their defaults, such as white balance, color effect, timer and scene mode. Check these before you take your next photo.
- The setting menu is superimposed over the viewfinder, so when you change photo color or quality elements, you will see a preview of the changed image behind the Settings menu.

Taking a quick photo

1 Open the **Camera** application.
2 Holding the phone horizontally, point the lens towards the subject you want to photograph.
3 A focus box will appear in the center of the viewfinder screen. You can also tap anywhere on the screen to focus on that spot.
4 When the focus box turns green, the camera has focused on your subject.
5 Touch to capture the photo.

Once you've taken a photo

Tap the image thumbnail at the bottom of the Camera screen to view the last photo you took.

	Tap to take another photo immediately.
	Tap to send your photo to others or share it via social network services.
	Tap to delete the photo.
	Tap to share photo using the **SmartShare** function.

TIP! If you have an SNS account and set it up on your phone, you can share your photo with your SNS community.

NOTE: Additional charges may apply when MMS messages are downloaded while roaming.

Touch the Menu key ≡ to open all advanced options.

Set image as – Touch to use the photo as a **Contact photo, Home screen Wallpaper, Lock screen wallpaper** or **Wallpaper**.

Move – Touch to move the photo to another place.

Copy – Touch to copy the selected photo and save it to another album.

Copy to Clip Tray – Tap to copy the photo and store in the Clip Tray.

Rename – Touch to edit the name of the selected photo.

Rotate left/right – To rotate left or right.

Crop – Crop your photo. Move your finger across the screen to select the area to be cropped.

Edit – View and edit the photo.

Slideshow – Automatically shows you the images in the current folder one after the other.

Add location – Camera setup is set to off, the Geotagging, picture location information is missing, the location information may be added.

Remove location – Camera setup is set to on Geotagging, photographs of the location information , the location information can be deleted.

Show on map – Camera setup is set to on Geotagging, picture position information, the corresponding location on the map can be viewed.

Details – Find out more information about the contents.

From your Gallery

Tap **Gallery**.

- To view more photos, scroll left or right.
- To zoom in or out, double-tap the screen or place two fingers and spread them apart (move your fingers closer (move your fingers closer together to zoom out).

Video camera

Getting to know the viewfinder

1. **Flash** – Choose from **Off**, **On**.
2. **Swap camera** – Switch between the rear–facing camera lens and the front-facing camera lens.
3. **Recording mode** – Choose from **Normal** or **Live effect.**
4. **Settings** – Tap this icon to open the settings menu.
5. **Camera mode** – Tap and slide up this icon to switch to camera mode.
6. **Start recording**
7. **Gallery** – Tap to view the last video you recorded. This enables you to access your gallery and view your saved videos while in video mode.

TIP!
When recording a video, place two fingers on the screen and pinch to use the Zoom function.

Using the advanced settings

Using the viewfinder, touch ⚙ to open all the advanced options.

HD	Tap to set the size (in pixels) of the video you are recording.
	Defines and controls of the amount of sunlight entering the lens. Slide the brightness indicator along the bar towards "-" for a lower brightness video or towards "+" for a higher brightness video.
AWB	Improves color quality in various lighting conditions.
	Choose a colour tone to use for your new view.
	Activate this to use your phone's location-based services. **NOTE:** This function is available when the GPS function is active or connected network.
	Set the Volume Key whether to use for the record or zoom.
	Opens the help guide to know how a function operates.
	Restores all camera default settings.

Recording a quick video

1 Open the **Camera** application and touch the **Video mode** button.
2 The video camera viewfinder appears on the screen.
3 Holding the phone, point the lens towards the subject you wish to capture in your video.
4 Touch once to start recording.
5 A red light will appear at the top left corner of the viewfinder with a timer showing the length of the video.
6 Touch on the screen to stop recording.

Video camera

TIP!

– Tap to capture an image during recording a video.

– Tap to pause recording a video.

After recording a video

In the viewfinder, tap the video thumbnail at the bottom of the screen to view the last video you took.

	Tap to record another video immediately.
	Tap to send your video to others or share it via social network services.
	Tap to delete the video.
	Tap to share video using the **SmartShare** function.

NOTE: Additional charges may apply when MMS messages are downloaded while roaming.

Watching your saved videos

1 In the viewfinder, tap .
2 Your Gallery will appear on the screen.
3 Tap a video to play it automatically.

Adjusting the volume when viewing a video

To adjust the volume of a video while it is playing, use the volume keys on the left side of the phone.

LG Unique Function

QuickMemo function

Use the **QuickMemo function** to practically and efficiently create memos during a call, with a saved picture or on the current phone screen.

1 Enter the QuickMemo function screen by pressing both the Volume up and down keys for one second on the screen you want to capture.

OR

OR

Touch and slide the status bar downward and touch .

2 Select the desired menu option from **Pen type**, **Color**, **Eraser**, and create a memo.

3 Touch in the Edit menu and select it to save the memo with the current screen.

NOTE: Please use a fingertip while using the QuickMemo function. Do not use your fingernail.

Using the QuickMemo options

You can easily use the QuickMenu options when using the QuickMemo function.

	Touch to keep the current memo on the screen and use the phone simultaneously.
	Selects whether to use the background screen or not.
	Undo or Redo.
	Selects the pen type and the colour.
	Erases the memo that you created.
	Touch to send your memo to others or share it via social network services.
	Saves the memo with the current screen in the **Gallery/Notebook**.

Viewing the saved QuickMemo

Touch **Gallery/Notebook** and select the QuickMemo album.

Notebook function

With the Notebook application, you can manage and personalize a wide variety of information. Notebook allows you to create your own special notes with drawings, images, maps and stickers.

Making a note

1 Touch > **Apps** tab > **Notebook**.
2 Touch **New note** to create a new note.
3 Select the desired mode (**Cover**, **Title, Paper, Paper color**) and then tap on **OK**.
4 Create a simple note on an empty page.

Getting to know the Notebook

Bookshelf

Pages-property panels

Bookshelf

	Search for pages of notes.
	Share as Notebook file, a PDF file or Image file via E-mail/Gmail.
	Delete the saved notebook from the Bookshelf.

Pages-Property panels

	Select the Read-only or edit mode.
	Undo or Redo.
	Tap this button to write.
	Select the Pen type, Thickness, Opacity and Color.
	Erase the memo that you created.
	Touch to attach files to the note.
	Touch to send your note to others or share it via social network services.
	Save the note with the current screen.
	Select to lock or unlock the Front key.
	Tap this button to enlarge the input area.

Viewing the saved notebook

- Saved Notebook memos are on the Bookshelf.
- If you save memos from QuickMemo, a QuickMemo note will be created and saved on the Bookshelf automatically.

NOTE: For more information of the Notebook guide, please see **Notebook** > **Notebook guide**.

Live Zooming function

Live Zooming allows you to zoom in or zoom out on a portion of a video that is being played to make the desired scan appear larger or smaller.

NOTE:

- When in video playback mode, slide the screen up or down, the screen brightness (Left side), the Volume (Right side) will be adjusted.
- When in video playback mode, when you slide the screen left or right, the playback position will be adjusted.

NOTE: Do not press too hard; the touch screen is sensitive enough to pick up a light, but firm touch.

QSlide function

The **QSlide function** enables an overlay on your phone's display for easy multi-window viewing.

1		Touch to exit the QSlide function and return to full window.
2		Tap to adjust transparency.
3		Tap to end the QSlide function.
4		Tap to adjust the size.

1 Touch and slide the status bar downward > touch QSlide apps or when using a function supported by the QSlide function > touch . The function will be continuously displayed as a small window on your screen.

2 You can make a call, browse the Web, or choose other phone options. You can also use and tap the screen of the small windows when the transparency bar is not full .

NOTE: The QSlide function can support up to two windows at the same time.

TIP!
Touch and slide the notification panel down with your finger.
Touch to manage the "Quick settings" or "QSlide" in the notification panel.

Dual Play function

You can display different screens on the two displays connected wirelessly or by cable.

1 Dual play mode is executed by tapping the Home key when playing content on the external display.

2 You can stop playing the content on the external display using the notification panel.

NOTE:

- Connect your smart phone to a display wirelessly (Miracast) or by cable (MHL cable).
- Some video files may not be supported by the dual play function.
- The Shielded LG MHL cable is recommended.

Mirroring

Dual Play

NOTE:
- Dual Play is supported by 3 applications - Videos, Media Home (MHL only), Polaris Office 4.
- The minimum TV resolution required for dual play is 720p (1280x720)

LG SmartWorld

LG SmartWorld offers an assortment of exciting content - fonts, themes, games and applications.

How to Get to LG SmartWorld from Your Phone

1 Touch > **Apps** tab > tap the icon to access **LG SmartWorld**.
2 Tap Sign in and enter ID/PW for LG SmartWorld. If you have not signed up yet, tap Register to receive your LG SmartWorld membership.
3 Download the content you want.

- When you use Cellular network, data fee could be charged by data plan that you signed- up with carrier.
- LG Smartworld may not be available from all carriers or in all countries.

NOTE: What if there is no icon?
1 Using a mobile Web browser, access LG SmartWorld (www.lgworld.com) and select your country.
2 Download the LG SmartWorld App.
3 Run and install the downloaded file.
4 Access LG SmartWorld by tapping the icon.

Special benefit only LG SmartWorld

1 Decorate your own style on your Smartphone, Use Home Theme & keyboard Theme & Font that provided on LG SmartWorld (However this service is available to specific device. please check in LG SmartWorld website whether it is feasible or not whether it is feasible or not)

2 Enjoy LG SmartWorld's special service by joining promotion that consistently provided

On-Screen Phone

On-Screen Phone allows you to view your mobile phone screen from a PC via a USB or Wi-Fi connection. You can also control your mobile phone from your PC, using the mouse or keyboard.

On-Screen Phone icons

	Connects your mobile phone to your PC, or disconnects it.
	Changes the On-Screen Phone preferences.
	Exits the On-Screen Phone programme.
	Maximises the On-Screen Phone window.
	Minimize the On-Screen Phone window.

On-Screen Phone features

- Real-time transfer and control: displays and controls your mobile phone screen when connected to your PC.
- Mouse control: allows you to control your mobile phone by using the mouse to click and drag on your PC screen.

LG Unique Function

- Text input with keyboard: allows you to compose a text message or note using your computer keyboard.
- File transfer (mobile phone to PC): sends files from your mobile phone (e.g. photos, videos, music and POLARIS Viewer 5 files) to your PC. Simply right-click on the file which you want to send to PC and click on "Save to PC".
- File transfer (PC to mobile phone): sends files from your PC to your mobile phone. Just select the files you wish to transfer and drag and drop them into the On-Screen Phone window. The files sent are stored in internal SD card.
- Real-time event notifications: prompts a pop-up to inform you of any incoming calls or text/multimedia messages.

How to install On-Screen Phone on your PC

1 Visit LG Home (www.lg.com) and select a country of your choice.

2 Go to **Support** > **Mobile Phone Support** > Select the Model (LG-E975k) > ClickOSP (On-Screen Phone) to download. You can install the On-Screen Phone on your PC.

Multimedia

Gallery

You can store multimedia files in internal memory for easy access to all your multimedia files. Use this application to view multimedia files like pictures and videos.

1 Touch > **Apps** tab > **Gallery**.
You can manage and share all your image and video files with Gallery.

NOTE:
- Some file formats are not supported, depending on the software installed on the device.
- Some files may not play properly, depending on how they are encoded.

Viewing pictures

Launching Gallery displays your available folders. When another application, such as Email, saves a picture, the download folder is automatically created to contain the picture. Likewise, capturing a screenshot automatically creates the Screenshots folder. Select a folder to open it.

Pictures are displayed by creation date in a folder. Select a picture to view it full screen. Scroll left or right to view the next or previous image.

Zooming in and out

Use one of the following methods to zoom in on an image:
- Double-tap anywhere to zoom in.
- Spread two fingers apart on any place to zoom in. Pinch to zoom out, or double-tap to return.

Playing videos

Video files show the icon in the preview. Select a video to watch it and tap . The **Videos** application will launch.

Editing photos/videos

When viewing an photo/video, tap the **Menu** key and use the advanced editing options.

- **Slideshow**: start a slideshow with the images in the current folder.

Deleting images

Use one of the following methods:

- In a folder, tap and select photos/videos by ticking, and then tap on **Delete**.
- When viewing a photo/Video, tap .

Setting as wallpaper

When viewing a photo, touch the **Menu** key > **Set image as** to set the image as wallpaper or to assign it to a contact.

NOTE:

- Some file formats are not supported, depending on the device software.
- If the file size exceeds the available memory, an error can occur when you open files.

Videos

Your phone has a built-in video player that lets you play all of your favorite videos. To access the video player, touch > **Apps** tab > **Videos**.

Playing a video

1 Touch > **Apps** tab > **Videos**.

2 Select the video you want to play.

1 /	Touch to pause/resume video playback.
2	Touch to go 10 seconds forward.
3	Touch to go 10 seconds backward.
4	Touch to manage the video volume.
5 / /	Touch to change the ratio of the video screen.
6	Tap to capture image during playing a video.
7	Touch to use QSlide.
8	Touch to Smart Share
9 /	Touch to lock/unlock a video screen.

To change the volume while watching a video, press the up and down volume keys on the left-hand side of the phone.

Touch and hold a video in the list. The **Share, Delete, Trim** and **Details** options will be displayed.

Video Editor

You can edit the photos or videos stored on the phone.

NOTE: Video Editing function is supported only for photos or videos which recorded with this phone.

< Project list screen >

	Creat project
	Projects should be exported to play in applications such as videos
	Play project
	Delete project
	Share project with application such as YouTube

< Project edit screen >

	Move to project list screen. Currently edited project is save automatically
	Split video clip into two portions over the playhead
	Add sound effect
	Add video, image or audio clip
	Undo an action
	Redo an action
	Add text to video or image clip

Video Wiz

You can make your own movie using your images/video and music.

1 Touch > **Apps** tab > **Video Wiz**.

2 After seeing the brief introduction on the steps to follow, tap **OK**.

3 Tap ⊕ to add images or video to your movie.

4 Tap the desired images or videos, then tap ✓.

- To remove images or videos, tap 🗑 and select the desired files > ✓.
- To rearrange them, touch and hold an image/video, and drag and drop it to the desired position.

5 Tap **Select style** to select the desired movie style.

- Scroll through and select the style you want. As you scroll through the styles, a preview will be displayed.

6 Tap **Select music** to set the background music.

7 Tap ▶ to play your movie.

8 Tap ✎ to edit the video clip using Text, Sticker or Magic Spot.

- After editing the video, tap ✓.

9 Tap 💾 to save the video.

10 Tap ⓘ to view the help information on using this feature.

Music

Your phone has a built-in music player that lets you play all your favorite tracks. To access the music player, touch > **Apps** tab > **Music.**

Playing a song

1 Touch > **Apps** tab > **Music**.
2 Touch **Songs**.
3 Select the song you want to play.

1	/	Tap to pause/ resume playback.
2		Tap to skip to the next track in the album, playlist, or shuffle. Touch and hold to fast forward.
3		Tap to restart the current track or skip to the previous track in the album, playlist, or shuffle. Touch and hold to rewind.

4		Tap to display the Volume slider bar, then adjust the playback volume on the slider bar.
5		Touch to set Sound Effects.
6		Tap to find the files with YouTube.
7		Tap to open the current playlist.
8		Tap to add the song to your favourites.
9		Tap to play the current playlist in shuffle mode (tracks are played in random order).
10		Tap to toggle through the repeat modes to repeat all songs, repeat current song, or repeat off.
11		SmartShare.

To change the volume while listening to music, press the up and down volume keys on the left-hand side of the phone.

Touch and hold any song in the list. The **Play**, **Add to playlist**, **Share, Set as ringtone, Delete, Details** and **Search** options will be displayed.

Add music files to your phone

Start by transferring music files to your phone:

- Transfer music using Media sync (MTP).
- Download from the wireless Web.
- Synchronize your phone to a computer.
- Receive files via Bluetooth.

Transfer music using Media sync (MTP)

1 Connect the phone to your PC using the USB cable.
2 Select the **Media sync (MTP)** option. Your phone will appear as another hard drive on your computer. Click on the drive to view it. Copy the files from your PC to the drive folder.
3 When you're finished transferring files, swipe down on the Status Bar and touch **USB connected** > **Charge only**. You may now safely unplug your device.

NOTE:
- Some file formats are not supported, depending on the device software.
- If the file size exceeds the available memory, an error can occur when you open files.

NOTE: Music file copyrights may be protected by international treaties and national copyright laws.
Therefore, it may be necessary to obtain permission or a licence to reproduce or copy music.
In some countries, national laws prohibit private copying of copyrighted material. Before downloading or copying the file, check the national laws of the relevant country concerning the use of such material.

Utilities

Setting your alarm

1 Touch > **Apps** tab > **Alarm/Clock** > .
2 After you set the alarm, your phone lets you know how much time is left before the alarm will go off.
3 Set **Repeat**, **Snooze duration**, **Vibration**, **Alarm sound, Alarm volume, Auto app starter, Puzzle lock** and **Memo**. Touch **Save**.

NOTE: To change alarm settings in the alarm list screen, touch and select **Settings**.

Using your calculator

1 Touch > **Apps** tab > **Calculator.**
2 Touch the number keys to enter numbers.
3 For simple calculations, touch the function you want to perform (+, –, x or ÷) followed by =.
4 For more complex calculations, slide the left then choose sin, cos, tan, log etc.
5 To check the history, touch , select calculation history.

Adding an event to your calendar

1 Touch > **Apps** tab > **Calendar.**
2 On the screen, you can find the different view types for the Calendar (Day, Week, Month, Agenda).
3 Tap on the date for which you wish to add an event and touch .
4 Touch **Event name** and enter the event name.
5 Touch **Location** and enter the location. Check the date and enter the time you wish your event to start and finish.

6 If you wish to add a note to your event, touch **Description** and enter the details.
7 If you wish to repeat the alarm, set **REPEAT** and set **REMINDERS**, if necessary.
8 Touch **Save** to save the event in the calendar.

Voice Recorder

Use the voice recorder to record voice memos or other audio files.

Recording a sound or voice

1 Touch > the **Apps** tab and select **Voice Recorder**.
2 Touch to begin recording.
3 Touch to end the recording.
4 Touch to listen to the recording.

NOTE: Touch to access your album. You can listen to the saved recording. The available recording time may differ from actual recording time.

Sending the voice recording

1 Once you have finished recording, you can send the audio clip by touching .
2 Choose from **Bluetooth, Drive, E-mail, Gmail, Memo, Messaging** or **SmartShare Beam**. When you select, the voice recording is added to the message. You may then write and send the message as you usually would.

Task Manager

You can manage your applications using Task Manager. You can easily check the number of applications that are currently running and shut down certain applications.

Tasks

This task can be synchronized with MS Exchange account. You can create task, revise it and delete it in MS outlook or MS Office Outlook Web Access.

To Synchronize MS Exchange

1 From the Home Screen, Touch > **Settings**.
2 Touch **Accounts & sync** > **Add account**.
3 Touch **Microsoft Exchange** to create Email address and Password.
4 Make sure if you checkmark Sync task.

Polaris Office 4

Polaris Office is a professional mobile office solution that lets users conveniently view various types of office documents, including Word, Excel and PowerPoint files, anywhere or anytime, using their mobile devices.
Touch > **Apps** tab > **Polaris Office 4.**

Viewing files

Mobile users can now easily view a wide variety of file types, including Microsoft Office documents and Adobe PDF, right on their mobile devices. When viewing documents using Polaris Office, the objects and layout remain the same as in the original documents.

Backup

About backing up and restoring smart phone data

It is recommended that you regularly create and save a backup file on the internal storage, especially before updating any software. Maintaining a current backup file in storage memory may allow you to recover smart phone data if your smart phone is lost, stolen, or corrupted by an unforeseen issue.

This Backup application is supported between LG smart phones, other S/W versions or OSs. As a result so, when you buy the new LG smart phone, you can backup the current Your phone data to your new phone.

If you have preloaded **Backup** application on your smart phone, you can backup and restore most of your smart phone data, **Applications** including unprotected applications, their settings, **Applications (Downloaded), Applications (Pre-installed), Bookmarks**, **Calendar, Call log**, **Contacts**, **Home screen, Messages** and **System settings** using this application You may:

- Perform a manual backup of your smart phone data.
- Schedule automatic backups of your smart phone data.
- Restore your smart phone data.

NOTE: Please note that the Backup function does not support the backup of User data & Media data (Picture/Video/Music). Please backup those files using the Media sync (MTP). Connect your phone to your computer using a USB cable and touch Media sync (MTP).

⚠ **WARNING**

To protect against unexpected shutoff during backup or restore operations, due to insufficient battery power, you should always keep your battery fully charged.

Utilities

Backup

1 Touch > **Apps** tab > **LG Backup** > **Backup.**
2 Select the check box next to the item you want to backup and tap **Next** to backup.
3 Touch **Internal Storage** > **Start.**
4 When all selected files have been backed up, you can touch **Done** to finish the back up.

Scheduling backup

You can also program automatic backups for the data on your smart phone according to your schedule setting. To do this, complete the following steps:
Touch > **Apps** tab > **LG Backup** > **Schedule backup.**

File restore & management

You can set to Backup file restore to desired status.
To restore data that is in your on-board device memory, mass storage mode must be turned off.
Touch > **Apps** tab > **LG Backup** > **File restore & management** > **Internal Storage**.

NOTE:
- All files that are stored on your smart phone are deleted before the backup file is restored.
- Please note that your phone data will be overwritten with the content of your backup.
- You can set Enable encryption to encrypt your backup files for extra protection.

Google+

Use this application to stay connected with people via Google's social network service.

- Touch > **Apps** tab > **Google +**.

NOTE: This application may not be available depending on the region or service provider.

Voice Search

Use this application to search webpages using voice.

1 Touch > **Apps** tab > **Voice Search**.

2 Say a keyword or phrase when **Speak now** appears on the screen. Select one of the suggested keywords that appear.

NOTE: This application may not be available depending on the region or service provider.

Downloads

Use this application to see what files have been downloaded through the applications.

- Touch > **Apps** tab > **Downloads**.

NOTE: This application may not be available depending on the region or service provider.

The Web

Internet

Use this application to browse the Internet. Browser gives you a fast, full-color world of games, music, news, sports, entertainment and much more, right on your mobile phone wherever you are and whatever you enjoy.

NOTE: Additional charges apply when connecting to these services and downloading content. Check data charges with your network provider.

1 Touch > **Apps** tab > **Internet**.

Using the Web toolbar

Touch and hold the Web toolbar and slide it upwards with your finger to open.

	Touch to go back one page.
	Touch to go forward one page, to the page you connected to after the current one. This is the opposite of what happens when you touch the **Back** key, which takes you to the previous page.
	Touch to go to the Home page.
	Touch to add a new window.
	Touch to access bookmarks.

Viewing webpages

Tap the address field, enter the web address and tap **Go**.

Opening a page

To go to new page, tap →
To go to another webpage, tap , scroll up or down, and tap the page to select it.

Searching the web by voice

Tap the address field, tap , speak a keyword, and then select one of the suggested keywords that appear.

NOTE: This feature may not be available depending on the region or service provider.

Bookmarks

To bookmark the current webpage, touch > **Add to bookmarks** > **OK**.
To open a bookmarked webpage, tap and select one.

History

Tap > **History** to open a webpage from the list of recently-visited webpages. To clear the history, tap Menu → **Clear all history**.

Using Popup Browser

Use this feature to access the Internet without closing the current application.
While viewing content, such as contacts or notes that include web addresses, select a web address, and then tap Popup Browser to open the pop-up browser. Tap and drag the browser to move it to another location.
To view the browser in full screen, tap .
To close the browser, tap .

The Web

Chrome

Use Chrome to search for information and browse webpages.

1 Touch > **Apps** tab > **Chrome**.

NOTE: This application may not be available, depending on your region and service provider.

Viewing webpages

Tap the Address field, and then enter a web address or search criteria.

Opening a page

To go to a new page, tap > **New tab**.

To go to another webpage, tap , scroll up or down and tap the page to select it.

Syncing with other devices

Sync open tabs and bookmarks to use with Chrome on another device when you are logged in with the same Google account.

To view open tabs on other devices, tap > **Other devices**.

Select a webpage to open.

To view bookmarks, tap .

Settings

This section provides an overview of items you can change using your phone's System settings menus.

To access the Settings menu:

1 On the Home screen, touch > **Apps** tab > **Settings**.
or
On the Home screen, touch > **System settings**.

2 Select a setting category and select an option.

WIRELESS & NETWORKS

Here, you can manage Wi-Fi and Bluetooth. You can also set up mobile networks and switch to airplane mode.

< Wi-Fi >

Wi-Fi – Turns on Wi-Fi to connect to available Wi-Fi networks.

TIP! How to obtain the MAC address

To set up a connection in some wireless networks with MAC filters, you may need to enter the MAC address of your phone in the router.

You can find the MAC address in the following user interface: touch **Apps** tab > **Settings** > **Wi-Fi** > > **Advanced Wi-Fi** > **MAC address**.

< Bluetooth >

Turn the Bluetooth wireless feature on or off to use Bluetooth.

< Mobile data >

Displays the data usage and set mobile data usage limit.

< Call >

Configure phone call settings such as call forwarding and other special features offered by your carrier.

Voicemail – Allows you to select your carrier's voicemail service.

Fixed dialing numbers – Turn on and compile a list of numbers that can be called from your phone. You'll need your PIN2, which is available from your operator. Only numbers within the fixed dial list can be called from your phone.

Incoming voice call pop-up – Display incoming voice call pop-up when an app is in use.

Call reject – Allows you to set the call reject function. Choose from **Call reject mode** or **Rejection list**.

Decline with message – When you want to reject a call, you can send a quick message using this function. This is useful if you need to reject a call during a meeting.

Privacy keeper – Hides the caller name and number for an incoming call.

Call forwarding – Choose whether to divert all calls when the line is busy, when there is no answer or when you have no signal.

Auto answer – Set the time before a connected hands-free device automatically answers an incoming call. Choose from Disable, 1 second, 3 seconds, and 5 seconds.

Connection vibration – Vibrates your phone when the other party answers the call.

Save unknown numbers – Add unknown numbers to contacts after a call.

Power key ends call – Allows you to select your end call.

Call barring – Lock incoming, outgoing or international calls.

Call duration – View the duration of calls including Last call, All calls, Dialled calls and Received calls.

Additional settings – Allows you to change the following settings:

Caller ID: Choose whether to display your number in an outgoing call.

Call waiting: If call waiting is activated, the handset will notify you of an incoming call while you are on a call (depending on your network provider).

<Share & Connect>

NFC – Your phone is an NFC-enabled mobile phone. NFC (Near Field Communication) is a wireless connectivity technology that enables two-way communication between electronic devices. It operates over a distance of a few centimeters. You can share your

content with an NFC tag or another NFC support device by simply touching it with your device. If you touch an NFC tag with your device, it will display the tag content on your device.

To switch NFC on or off: From the Home screen, touch and slide the notification panel down with your finger, then select the NFC icon to turn it on.

NOTE: When airplane mode is activated, the NFC application can be used.

Using NFC: To use NFC, make sure your device is switched on, and activate NFC if disabled.

Android Beam – When this feature is turned on, you can beam app content to another NFC-capable device by holding the devices close together.

Just bring the device together(typically back to back) and then touch your screen. The app determines what gets beamed.

SmartShare Beam – Enable to receive files from LG phones.

Media server – Share media content on your phone with nearby device via DLNA.

Miracast – With Miracast, you can wirelessly mirror your phone screen and sound onto a Miracast dongle or TV

Wireless storage – Share files with computer via Wi-Fi.

< Tethering & networks >

Wi-Fi hotspot – You can also use your phone to provide a mobile broadband connection. Create a hotspot and share your connection. Please read **"Sharing your phone's data connection"** for more information.

Bluetooth tethering – Allows you to set your phone whether you are sharing the Internet connection or not.

Help – Tap to view help information on the Wi-Fi hotspot and Bluetooth tethering functions.

Airplane mode – After switching to Airplane mode, all wireless connections are disabled.

NOTE: You must set a lock screen PIN or password before you can use credential storage.

Mobile networks – Set options for data roaming, network mode & operators, access point names (APNs) etc.

Default SMS app – Allows you to set the default SMS app.

VPN – Displays the list of Virtual Private Networks (VPNs) that you've previously configured. Allows you to add different types of VPNs.

DEVICE

< Sound >

Sound profile – Choose the Sound, either Vibrate only or Silent.

Volumes – Manage the volume of Phone ringtone, Notification sound, Touch feedback & system, Music, video, games and other media.

Quiet time – Set times to turn off all sounds except alarm and media.

Phone ringtone – Allows you to set your default incoming call ringtone.

Smart ringtone – Allows you to set increase phone ringtone volume automatically in noisy environments.

Ringtone with vibration – Vibration feedback for calls and notifications.

Notification sound – Allows you to set your default notification ringtone.

Touch feedback & system – Allows you to set the feedback (tones and/or vibration) while using your device.

< Display >

Brightness – Adjust the screen brightness.

Screen timeout – Set the time for screen timeout.

Auto-rotate screen – Checkmark to set the phone to automatically rotate the screen based on the phone orientation (portrait or landscape).

Daydream – Tap the Daydream switch to toggle it On or Off. On allows the set

screensaver to be displayed when the phone is sleeping while docked and/or charging.

Font type – Change the type of display font.

Font size – Change the size of the display font.

Smart Screen – Checkmark to allow the screen to stay on when phone detects your face.

Front touch key light – Set the front key light duration.

Notification flash – The Notification LED is located to the left of the front camera. You can see the small LED light on when the phone is charging or when you receive a notification if LCD screen turns off. You can configure the **Notification flash** to turn on/off. You can set the various options from the list of notification flash items.

< Home screen >

Set the **Theme**, **Wallpaper**, **Screen swipe effect, Allow Home screen looping** or **Portrait view only.** Select the option to set **Home backup & restore**.

< Lock screen >

Select screen lock – Set a screen lock type to secure your phone. Opens a set of screens that guide you through drawing a screen unlock pattern. Set **None, Swipe, Face Unlock, Pattern, PIN** or **Password**.

If you have enabled a Pattern lock type when you turn on your phone or wake up the screen, you will be asked to draw your unlock pattern to unlock the screen.

< Gestures >

Silence incoming calls – Flip the device to mute incoming calls.

Snooze or stop alarm – Flip the device to snooze or stop alarm.

Pause video – Flip the device to pause playing video.

Help – Help for gesture functions.

Motion sensor calibration – Allows you to improve the accuracy of the tilt and speed of the sensor.

< Storage >

INTERNAL STORAGE – View the internal storage usage.

< Battery >

BATTERY INFORMATION

The Battery charge information is displayed on a battery graphic along with the percentage of the remaining charge and its status.
Touch the Battery charge icon to display the Battery use screen to see battery usage level and battery use details. It displays which components and applications are using the most battery power. Tap one of the entries to see more detailed information.

Battery percentage on status bar – Checkmark to display the battery level percentage on the Status Bar next to the battery icon.

BATTERY SAVER

Tap the Battery saver switch to toggle it On or Off. Tap Battery saver to access the following settings:

Battery saver – Sets the battery charge percent level that will automatically turn on Battery saver.

Eco mode – Set the Eco mode to extend battery life by dynamically optimizing the CPU control policy.

Help – Tap to view help information on the battery saver tips.

< Apps >

View and manage your applications.

<Tap & pay>

When NFC is turned on, you can use the tap & pay feature to pay for items just by touching your phone to a reader at a register. If your device doesn't have a default app, you can browse Google Play for other payment apps.

PERSONAL

< Accounts & sync >

Permits applications to synchronize data in the background, whether or not you are

actively working in them. Deselecting this setting can save battery power and lower (but not eliminate) data usage.

< Cloud >

Add a cloud account to quickly and easily use cloud service on LG apps.

< Location >

Turn on location service, your phone determines your approximate location using GPS, Wi-Fi and mobile networks.

Mode – Set the location mode from **High accuracy, Battery saving** and **Device sensors only**.

< Security >

Encrypt phone – Allows you to encrypt data on the phone for security. You will be required to enter a PIN or password to decrypt your phone each time you power it on.

Set up SIM card lock – Set up Micro-USIM card lock or change the Micro-USIM card PIN.

Password typing visible – Show the last character of the hidden password as you type.

Phone administrators – View or deactivate phone administrators.

Unknown sources – Default setting to install non-market applications.

Verify apps – Disallow or warn before installation of apps that may cause harm.

Notification access – Display the notifications.

Storage type – Display the storage type.

Trusted credentials – Display trusted CA certificates.

Install from storage – Choose to install encrypted certificates.

Clear credentials – Remove all certificates.

< Language & input >

Use the Language & input settings to select the language for the text on your phone and to configure the on-screen keyboard, including words you've added to its dictionary.

< Backup & reset >

Change the settings for managing your settings and data.

Backup my data – Set to backup your settings and application data to the Google server.

Backup account – Set to backup your account.

Automatic restore – Set to restore your settings and application data when the applications are reinstalled on your device.

LG Backup service – Backs up all information on the device and restores it in the event of data loss or replacement.

Factory data reset – Reset your settings to the factory default values and delete all your data. If you reset the phone this way, you are prompted to re-enter the same information as when you first started Android.

SYSTEM

< Date & time >

Use **Date & time** settings to set how dates will be displayed. You can also use these settings to set your own time and time zone rather than obtaining the current time from the mobile network.

< Accessibility >

Use the **Accessibility** settings to configure accessibility plug-ins you have installed on your phone.

NOTE: Requires additional plug-ins to become selectable.

< PC connection >

Select USB connection method – Set the desired mode: **Charge only, Media sync (MTP), Tethering, LG software** or **Send images (PTP)**.

Ask upon connection – Ask in USB connection mode when connecting to a computer.

Help – Help for USB connection.

PC Suite – Checkmark this to use LG PC Suite with your Wi-Fi connection.

Please note that Wi-Fi network should be connected to LG PC Suite via a Wi-Fi connection through WIRELESS & NETWORKS.

Help – Help for LG software.

<Printing>

Allows you to print the content of certain screens (such as web pages displayed in Chrome) to a printer connected to the same Wi-Fi network as your Android device.

< About phone >

View legal information and check your phone status and software version.

PC software (LG PC Suite)

"LG PC Suite" PC software is a program that helps you connect your device to a PC via a USB cable and Wi-Fi. Once connected, you can use the functions of your device from your PC.

With your "LG PC Suite" PC Software, You Can...

- Manage and play your media contents (music, movie, picture) on your PC.
- Send multimedia contents to your device.
- Synchronizes data (schedules, contacts, bookmarks) in your device and PC.
- Backup the applications in your device.
- Update the softwares in your device.
- Backup and restore the device data.
- Play multimedia contents of your PC from your device.
- Backup and create and edit the memos in your device

NOTE: You can use the Help menu from the application to find out how to use your "LG PC Suite" PC software.

Installing "LG PC Suite" PC Software

"LG PC Suite" PC software can be downloaded from the webpage of LG.

1. Go to www.lg.com and select a country of your choice.
2. Go to **Support** > **MOBILE SUPPORT** > **LG Mobile Phones** > **Select the Model**
   or
   Go to **Support** > **Mobile** > **Select the Model**.
3. Click **PC SYNC** from **MANUALS & DOWNLOAD** and click **DOWNLOAD** to download "LG PC Suite" PC software.

System Requirements for "LG PC Suite" PC software

- OS: Windows XP (Service pack 3) 32bit, Windows Vista, Windows 7, Windows 8
- CPU: 1 GHz or higher processors
- Memory: 512 MB or higher RAMs
- Graphic card: 1024 x 768 resolution, 32 bit color or higher
- HDD: 500 MB or more free hard disk space (More free hard disk space may be needed depending on the volume of data stored.)
- Required software: LG integrated drivers, Windows Media Player 10 or later

NOTE: LG Integrated USB Driver
LG integrated USB driver is required to connect an LG device and PC and is installed automatically when you install "LG PC Suite" PC software application.

Synchronizing your Device to a PC

Data from your device and PC can be synchronized easily with "LG PC Suite" PC software for your convenience. Contacts, schedules and bookmarks can be synchronized.
The procedure is as follows:

1. Connect your device to PC. (Use a USB cable or Wi-Fi connection.)
2. The **Select USB connection method** will appear, then select **LG software**.
3. After connection, run the program and select the device section from the category on the left side of the screen.
4. Click **Personal information** to select.
5. Select the checkbox of contents to synchronize and click the **Sync** button.

NOTE: To synchronize your phone with your PC, you need to install LG PC Suite onto your PC. Please refer to previous pages to install LG PC Suite.

Moving contacts from your Old Device to your New Device

1. Export your contacts as a CSV file from your old device to your PC using a PC sync program.
2. Install "LG PC Suite" on the PC first. Run the program and connect your Android mobile phone to the PC using a USB cable.
3. On the top menu, select **Phone** > **Import/Export contacts** > **Export to your phone**.
4. A popup window to select the file type and a file to **export** will appear.
5. On the popup, click the **Select a file** and Windows Explorer will appear.
6. Select the contacts file to **export** in Windows Explorer and click the **Open**.
7. Click **Export**.
8. A **Field mapping** popup to link the contacts in your device and new contacts data will appear.
9. If there is a conflict between the data in your PC contacts and device contacts, make the necessary selections or modifications in LG PC Suite.
10. Click **OK**.

Phone software update

LG Mobile phone software update from the Internet

For more information about using this function, please visit http://www.lg.com/common/index.jsp → select your country and language.

This feature allows you to conveniently update the firmware on your phone to a newer version from the Internet without needing to visit a service center. This feature will only be available if and when LG makes a newer firmware version available for your device.

Because the mobile phone firmware update requires the user's full attention for the duration of the update process, please make sure you check all instructions and notes that appear at each step before proceeding. Please note that removing the USB data cable during the upgrade may seriously damage your mobile phone.

NOTE: LG reserves the right to make firmware updates available only for selected models at its own discretion and does not guarantee the availability of the newer version of the firmware for all handset models.

LG Mobile Phone software update via Over-the-Air (OTA)

This feature allows you to conveniently update your phone's software to a newer version via OTA, without connecting using a USB data cable. This feature will only be available if and when LG makes a newer firmware version available for your device.

You should first check the software version on your mobile phone: **Settings** > **About phone** > **Update Center** > **Software update** > **Check now for update**.

NOTE: Your personal data from internal phone storage—including information about your Google account and any other accounts, your system/application data and settings, any downloaded applications and your DRM licence—might be lost in the process of updating your phone's software. Therefore, LG recommends that you backup your personal data before updating your phone's software. LG does not take responsibility for any loss of personal data.

NOTE: This feature depends on your network service provider, region and country.

About this user guide

- Before using your device, please carefully read this manual. This will ensure that you use your phone safely and correctly.
- Some of the images and screenshots provided in this guide may appear differently on your phone.
- Your content may differ from the final product, or from software supplied by service providers or carriers, This content may be subject to change without prior notice. For the latest version of this manual, please visit the LG website at www.lg.com.
- Your phone's applications and their functions may vary by country, region, or hardware specifications. LG cannot be held liable for any performance issues resulting from the use of applications developed by providers other than LG.
- LG cannot be held liable for performance or incompatibility issues resulting from edited registry settings being edited or operating system software being modified. Any attempt to customize your operating system may cause the device or its applications to not work as they should.
- Software, audio, wallpaper, images, and other media supplied with your device are licensed for limited use. If you extract and use these materials for commercial or other purposes is, you may be infringing copyright laws. As a user, you are fully are entirely responsible for the illegal use of media.
- Additional charges may be applied for data services, such as messaging, uploading and downloading, auto-syncing, or using location services. To avoid additional charges, select a data plan to is suitable for your needs. Contact your service provider to obtain additional details.

Trademarks

- LG and the LG logo are registered trademarks of LG Electronics.
- All other trademarks and copyrights are the property of their respective owners.

DivX HD

ABOUT DIVX VIDEO: DivX® is a digital video format created by DivX, LLC, a subsidiary of Rovi Corporation. This is an official DivX Certified® device that plays DivX video. Visit divx.com for more information and software tools to convert your files into DivX videos.

ABOUT DIVX VIDEO-ON-DEMAND: This DivX Certified® device must be registered in order to play purchased DivX Video-on-Demand (VOD) movies. To obtain your registration code, locate the DivX VOD section in your device setup menu. Go to vod.divx.com for more information on how to complete your registration.

DivX Certified® to play DivX® video up to HD 720p, including premium content.

DivX®, DivX Certified® and associated logos are trademarks of Rovi Corporation or its subsidiaries and are used under license.

Dolby Mobile

Manufactured under license from Dolby Laboratories. Dolby and the double-D symbol are trademarks of Dolby Laboratories.

Notice: Open Source Software

To obtain the corresponding source code under GPL, LGPL, MPL and other open source licences, please visit http://opensource.lge.com/

All referred licence terms, disclaimers and notices are available for download with the source code.

Accessories

These accessories are available for use with the your phone. **(Items described below may be optional.)**

Travel adaptor

Stereo headset

Quick Start Guide

Data cable

Micro-USIM ejection tool

NOTE:

- Always use genuine LG accessories.
- Failure to do this may void your warranty.
- Accessories may vary in different regions.

Troubleshooting

This chapter lists some problems you might encounter when using your phone. Some problems require you to call your service provider, but most are easy to fix yourself.

Message	Possible causes	Possible corrective measures
Micro-USIM error	There is no Micro-USIM card in the phone or it is inserted incorrectly.	Make sure that the Micro-USIM card is correctly inserted.
No network connection/ Dropped network	Signal is weak or you are outside the carrier network.	Move toward a window or into an open area. Check the network operator coverage map.
	Operator applied new services.	Check whether the Micro-USIM card is more than 6~12 months old. If so, change your Micro-USIM at your network provider's nearest branch. Contact your service provider.
Codes do not match	To change a security code, you will need to confirm the new code by re-entering it.	If you forget the code, contact your service provider.
	The two codes you have entered do not match.	

Message	Possible causes	Possible corrective measures
No applications can be set	Not supported by service provider or registration required.	Contact your service provider.
Calls not available	Dialling error	New network not authorized.
	New Micro-USIM card inserted.	Check for new restrictions.
	Pre-paid charge limit reached.	Contact service provider or reset limit with PIN2.
Phone cannot be switched on	On/Off key pressed too briefly.	Press the On/Off key for at least two seconds.
	Battery is not charged.	Charge battery. Check the charging indicator on the display.

Message	Possible causes	Possible corrective measures
Charging error	Battery is not charged.	Charge battery.
	Outside temperature is too hot or cold.	Make sure phone is charging at a normal temperature.
	Contact problem	Check the charger and its connection to the phone.
	No voltage	Plug the charger into a different socket.
	Charger defective	Replace the charger.
	Wrong charger	Use only original LG accessories.
Number not allowed	The Fixed dialling number function is on.	Check the Settings menu and turn the function off.
Impossible to receive / send SMS & photos	Memory full	Delete some messages from your phone.
Files do not open	Unsupported file format	Check the supported file formats.

Troubleshooting

Message	Possible causes	Possible corrective measures
The screen does not turn on when I receive a call.	Proximity sensor problem	If you use a protection tape or case, make sure it has not covered the area around the proximity sensor. Make sure that the area around the proximity sensor is clean.
No sound	Vibration mode	Check the settings status in the sound menu to make sure you are not in vibration or silent mode.
Hangs up or freezes	Intermittent software problem	Try to perform a software update via the website.

FAQ

Please check to see if any problems you have encountered with your phone are described in this section before taking the phone in for service or calling a service representative.

Category Sub-Category	Question	Answer
BT Bluetooth Devices	What are the functions available via Bluetooth?	You can connect a Bluetooth audio device such as a Stereo/Mono headset or Car Kit to share pictures, videos, contacts, etc. via Gallery/Contacts menu. Also, when the FTP server is connected to a compatible device, you can share content stored on the storage media.
BT Bluetooth Headset	If my Bluetooth headset is connected, can I listen to my music through my 3.5 mm wired headphones?	When a Bluetooth headset is connected, all system sounds are played over the headset. As a result, you will not be able to listen to music through your wired headphones.
Data Contacts Backup	How can I backup Contacts?	The Contacts data can be synchronized between your phone and Gmail™.
Data Synchronization	Is it possible to set up one-way sync with Gmail?	Only two-way synchronization is available.

Category Sub-Category	Question	Answer
Data Synchronization	Is it possible to synchronize all email folders?	The Inbox is automatically synchronized. You can view other folders by Touching the **Menu Key** ≡ and select **Folders** to choose a folder.
Google™ Service Gmail Log-In	Do I have to log into Gmail whenever I want to access Gmail?	Once you have logged into Gmail, you will not need to log into Gmail again.
Google™ Service Google Account	Is it possible to filter emails?	No, email filtering is not supported via the phone.
Phone Function Email	What happens when I execute another application while writing an email?	Your email will automatically be saved as a draft.
Phone Function Ringtone	Is there a file size limitation for when I want to use an. MP3 file as a ring tone?	There is no file size limitation.
Phone Function Message Time	My phone does not display the time of receipt for messages older than 24 hrs. How can I change this?	You will only be able to see the times for messages received the same day.
Phone Function Navigation	Is it possible to install another navigation application on my phone?	Any application that is available at Android Market™ and is compatible with the hardware can be installed and used.

Category Sub-Category	Question	Answer
Phone Function Synchronisation	Is it possible to synchronize my contacts from all my email accounts?	Only Gmail and MS Exchange server (company email server) contacts can be synchronized.
Phone Function Wait and Pause	Is it possible to save a contact with Wait and Pause in the numbers?	If you transferred a contact with the W & P functions saved into the number, you will not be able to use those features. You will need to re-save each number. How to save with Wait and Pause: 1. From the Home screen, touch the **Phone** icon . 2. Dial the number, then touch the **Menu Key** . 3. Touch **Add 2-sec pause** or **Add wait**.
Phone Function Security	What are the phone's security functions?	You are able to set the phone to require that an Unlock Pattern be entered before the phone can be accessed or used.

Category Sub-Category	Question	Answer
Phone Function Unlock Pattern	How do I create the Unlock Pattern?	1. From the Home screen, touch the **Menu Key** ☰. 2. Touch **System settings** > **Lock screen**. 3. Touch **Select screen lock** > **Pattern**. The first time you do this, a short tutorial about creating an Unlock Pattern will appear. 4. Set up by drawing your pattern once, and once again for confirmation. Precautions to take when using the pattern lock. It is very important to remember the unlock pattern you set. You will not be able to access your phone if you use an incorrect pattern five times. You have five chances to enter your unlock pattern, PIN or password. If you have used all 5 opportunities, you can try again after 30 seconds. (Or, if you preset the backup PIN, you can use the backup PIN code to unlock the pattern.)

Category Sub-Category	Question	Answer
Phone Function Unlock Pattern	What should I do if I forget the unlock pattern and I didn't create my Google account on the phone?	If you have forgotten your pattern: If you logged into your Google account on the phone but failed to enter the correct pattern 5 times, touch the forgot pattern button. You are then required to log in with your Google account to unlock your phone. If you have not created a Google account on the phone or you have forgottenn it, you will have to perform a hard reset. Caution: If you perform a factory reset, all user applications and user data will be deleted. Please remember to backup any important data before performing a factory reset.
Phone Function Memory	Will I know when my memory is full?	Yes, you will receive a notification.
Phone Function Language Support	Is it possible to change my phone's language?	The phone has multilingual capabilities. To change the language: 1. From the Home screen, touch the **Menu Key** ≡ and touch **System settings**. 2. Touch **Language & input** > **Select language**. 3. Touch the desired language.

Category Sub-Category	Question	Answer
Phone Function VPN	How do I set up a VPN?	VPN access configuration is different for each company. To configure VPN access from your phone, you must obtain the details from your company's network administrator.
Phone Function Screen time out	My screen turns off after only 15 seconds. How can I change the amount of time for the backlight to turn off?	1. From the Home screen, press the **Menu Key** ≡. 2. Touch **System settings** > **Display**. 3. Under Display settings, touch **Screen timeout**. 4. Touch the preferred screen backlight timeout time.
Phone Function Wi-Fi & mobile network	When Wi-Fi and mobile network are both available, which service will my phone use?	When using data, your phone may default to the Wi-Fi connection (if Wi-Fi connectivity on your phone is set to On). However, there will be no notification when your phone switches from one to the other. To know which data connection is being used, view the mobile network or Wi-Fi icon at the top of your screen.
Phone Function Home screen	Is it possible to remove an application from the Home screen?	Yes. Just touch and hold the icon until the dustbin icon appears at the top and center of the screen. Then, without lifting your finger, drag the icon to the trash can.

Category Sub-Category	Question	Answer
Phone Function Application	I downloaded an application and it causes a lot of errors. How do I remove it?	1. From the Home screen, press the **Menu Key** ☰. 2. Touch **App settings** > **DOWNLOADED**. 3. Touch the application, then touch **Uninstall**.
Phone Function Charger	Is it possible to charge my phone using a USB data cable without installing the necessary USB driver?	Yes, the phone will be charged by the USB cable regardless of whether the necessary drivers are installed or not.
Phone Function Alarm	Can I use music files for my alarm?	Yes. After saving a music file as a ringtone, you can use it as your alarm. 1. Touch and hold a song in a library list. In the menu that opens, touch **Set as ringtone**. 2. In the alarm clock setting screen, select the song as a ringtone.
Phone Function Alarm	Will my alarm be audible or will it go off if the phone is turned off?	No, this is not supported.
Phone Function Alarm	If my ringer volume is set to Off or Vibrate, will I hear my alarm?	Your alarm is programmed to be audible even in these scenarios.

Category Sub-Category	Question	Answer
Recovery Solution Hard Reset (Factory Reset)	How can I perform a factory reset if I can't access the phone's setting menu?	If your phone does not restore to its original condition, use a hard reset (factory reset) to initialize it.

LG

Life's Good

PRINTED WITH SOY INK™

CE0168