LG
Life's Good

ENGLISH
العربية

OWNER'S MANUAL

AIR CONDITIONER

Please read this manual carefully before operating your set and retain it for future reference.

TYPE : WALL MOUNTED

MFL68587207
Rev : 01 (11T14)

www.lg.com

ENGLISH

TIPS FOR SAVING ENERGY

Here are some tips that will help you to minimize the power consumption when you use the air conditioner. You can use your air conditioner more efficiently by referring to the instructions below :

- Do not cool the indoor excessively. This may be harmful for your health and may consume more electricity.
- Block sunlight with blinds or curtains while you are operating the air conditioner.
- Keep doors or windows closed tightly while you are operating the air conditioner.
- Adjust the direction of the air flow vertically or horizontally to circulate indoor air.
- Speed up the fan to cool or warm indoor air quickly, in a short period of time.
- Open windows regularly for ventilation as the indoor air quality may deteriorate if the air conditioner is used for many hours.
- Clean the air filter once every 2 weeks. Dust and impurities collected in the Air filter may block the air flow or weaken the cooling / dehumidifying functions.

For your records

Staple your receipt to this page in case you need it to prove the date of purchase or for warranty purposes. Write the model number and the serial number here:

Model number : _____

Serial number : _____

You can find them on a label on the side of each unit.

Dealer's name : _____

Date of purchase : _____

IMPORTANT SAFETY INSTRUCTIONS

READ ALL INSTRUCTIONS BEFORE USING THE APPLIANCE.

Always comply with the following precautions to avoid dangerous situation and ensure peak performance of you product.

WARNING

It can result in serious injury or death when the directions are ignored.

CAUTION

It can result in minor injury or product damage when the directions are ignored.

WARNING

• Installation or repairs made by unqualified persons can result in hazards to you and others.
• Air conditioner shall be installed in accordance with national wiring regulations.
• The information contained in the manual is intended for use qualified service technician familiar with safety procedures and equipped with the proper tools and test instruments.
• Failure to carefully read and follow all instructions in this manual can result in equipment malfunction, property damage, personal injury and/or death.
• This appliance is not intend for use by persons (including children) with reduced physical, senary or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for theirs safety.
• Children should be supervised to ensure that they do not play with the appliance.
• When the power cord is to be replaced,replacement work shall be performed by authorized personnel only genuine replacement parts.

INSTALLATION

• Use a standard circuit breaker and fuse conforming with the rating of the air conditioner. Failure to do so may result in electric shock or product failure.
• Contact an authorized service center when you install or relocate the air conditioner. Failure to do so may result in serious injury or product failure.
• Always use a power plug and socket with a ground terminal. Failure to do so may result in electric shock or product failure.
• Install the panel and the cover of the control box safely. Failure to do so may result in explosion or fire.
• Install a dedicated electric outlet and circuit breaker before you use the air conditioner. Failure to do so may result in electric shock or product failure.
• Do not modify or extend the power cable. If the power cable or cord has scratches or skin peeled off or deteriorated then it must be replaced. It may result in fire or electric shock.
• Be cautious when you unpack or install the air conditioner. Failure to do so may result in serious injury or product failure.
• Do not install the air conditioner on an unstable surface or where there may be a danger of it falling. It may result in death, serious injury, or product failure.

OPERATION

• Do not let the air conditioner run for a long time when the humidity is very high or when a door or window has been left open. Failure to do so may result in product failure.
• Make sure that the power cord is not pulled or damaged while the air conditioner is operating. Failure to do so may result in fire, electric shock, or product failure.
• Do not place any objects on the power cord. It may result in electric shock or product failure.
• Do not turn on or off the air conditioner by plugging in or unplugging the power plug. It may result in fire or electric shock.
• Do not touch, operate or repair the air conditioner with wet hands. It may result in electric shock or product failure.
• Do not place a heater or other heating appliances near the power cable. It may result in fire, electric shock, or product failure.
• Do not allow water to run into the air conditioner. It may result in explosion or fire.
• Do not leave flammable substances such as gasoline, benzene and thinner near the air conditioner. It may result in explosion or fire.
• Do not use the air conditioner for an extended period of time in a small place without ventilation. Ventilate the place regularly. Failure to do so may result in explosion or fire.
• When there is a gas leak, ventilate sufficiently before using the air conditioner again. Failure to do so may result in explosion or fire.
• Unplug the power plug if there is a noise, smell or smoke coming from the air conditioner. Failure to do so may result in explosion or fire.
• Stop operating and close the window in storm or hurricane. If possible remove the product from the window before hurricane arrives.
• Do not touch the electrostatic filter after opening the front grille. Failure to do so may result in electric shock or product failure.
• Contact an authorized service center when the air conditioner is submerged into water due to flooding. Failure to do so may result in explosion or fire.
• Be cautious water could not enter the product.
• Make sure to ventilate sufficiently when this air conditioner and a heating appliance such as a heater are used simultaneously. Failure to do so may result in explosion or fire, serious injury, or product failure.
• Turn the main power off and unplug the power plug when you clean or repair the air conditioner. Failure to do so may result in death, serious injury, or product failure.
• Unplug the power plug when the air conditioner is not used for an extended period of time. Failure to do so may result in product failure.
• For inner cleaning, contact an Authorized Service Center or a dealer.
• Do not use harsh detergent that causes corrosion or damage on the unit. Harsh detergent may also cause failure of product, fire, or electric shock.

⚠CAUTION

INSTALLATION

• Make sure to check if there is a refrigerant leak after you install or repair the air conditioner. Failure to do so may result in product failure.
• Install the drain hose properly for smooth drainage of condensed water. Failure to do so may result in product failure.
• Keep level even when installing the product.
• Install the air conditioner where the noise from the outdoor unit or the exhaust gas will not inconvenience the neighbors. Failure to do so may result in conflict between neighbors.
• When transporting the equipment, there should be at least 2 or more people, or a forklift. It may result in serious injury.
• Do not install the air conditioner where it will be exposed to sea wind (salt spray) directly. It may result in product failure.

OPERATION

• Do not expose people, animals or plants to the cold or hot wind from the air conditioner. It may result in serious injury.
• Do not use the product for special purposes, such as preserving foods, works of art, etc. It is a consumer air conditioner, not a precision refrigeration system. It may result in death, fire or electric shock.
• Do not block the inlet or outlet of air flow. It may result in explosion or product failure.
• Do not use strong cleaning agents or solvents when you clean the air conditioner, or spray water. Use a smooth cloth. It may result in serious injury or product failure.
• Never touch the metal parts of the air conditioner when you remove the air filter. It may result serious injury or product failure.
• Do not place any objects on the air conditioner. It may result in product failure.
• Always insert the filter securely after cleaning. Clean the filter every two weeks or more often if necessary.
• Do not insert hands or other objects through the air inlet or outlet while the air conditioner is operating. It may result in electric shock.
• Do not drink the water drained from the air conditioner. It may result in serious health complications.
• Use a sturdy stool or ladder when you clean, maintain or repair the air conditioner at a height. Failure to do so may result in serious injury or product failure.
• Do not mix the batteries for the remote control with other types of batteries or mix new batteries with used batteries. Failure to do so may result in product failure.
• Do not recharge or disassemble the batteries. Failure to do so may result in explosion, fire or serious injury.
• Stop using the remote control if there is a battery fluid leak. If your cloth or skin is explosion to the battery fluid from a leak, wash it off with clean water. Failure to do so may result in serious injury.
• If you swallow the battery fluid from a leak. Wash out the inside of your mouth thoroughly and then consult a doctor. Failure to do so may result in serious health complications.

ENGLISH

CONTENTS

2 TIPS FOR SAVING ENERGY

3 IMPORTANT SAFETY INSTRUCTIONS

7 BEFORE USE

7 COMPONENTS
7 - INDOOR UNIT TYPE 1
7 - OUTDOOR UNIT
8 - INDOOR UNIT TYPE 2
8 - OUTDOOR UNIT
9 INSERTING BATTERIES
9 INSTALLING THE REMOTE CONTROL HOLDER
9 OPERATING METHOD

10 USING THE REMOTE CONTROL

10 WIRELESS REMOTE CONTROL

11 BASIC FUNCTIONS

11 COOLING YOUR ROOM (COOLING OPERATION)
11 HEATING YOUR ROOM (HEATING OPERATION)
11 REMOVING HUMIDITY (DEHUMIDIFYING OPERATION)
12 ADJUSTING THE FAN SPEED
12 ADJUSTING THE AIR FLOW DIRECTION
12 SETTING THE TIMER
12 CANCEL THE TIMER SETTING

13 ADVANCED FUNCTIONS

13 CHANGING ROOM TEMPERATURE QUICKLY (JET COOL)
14 OPERATING THE AIR CONDITIONER WITHOUT THE REMOTE CONTROL
14 RESTARTING THE AIR CONDITIONER AUTOMATICALLY
14 - DISABLING AUTO RESTART

15 MAINTENANCE

16 CLEANING THE AIR FILTER
16 CLEANING TRIPLE FILTER (OPTIONAL)

17 TROUBLESHOOTING

17 SELF-DIAGNOSIS FUNCTION
17 BEFORE REQUESTING SERVICE

BEFORE USE

COMPONENTS

INDOOR UNIT TYPE 1

*The feature can be changed according a type of model.

NOTE

• The number of operation lamps and their locations may vary, depending on the model of the air conditioner.

OUTDOOR UNIT

*The feature can be changed according a type of model.

INDOOR UNIT TYPE 2

*The feature can be changed according a type of model.

NOTE

• The number of operation lamps and their locations may vary, depending on the model of the air conditioner.

OUTDOOR UNIT

*The feature can be changed according a type of model.

INSERTING BATTERIES

Insert batteries before using the remote control. The battery type used is AAA (1.5 V).

1. Remove the battery cover.

2. Insert the new batteries and make sure that the (+) and (-) terminals of the batteries are installed correctly.

3. Reattach the battery cover.

NOTE

• If the display screen of the remote control starts to fade, replace the batteries.

INSTALLING THE REMOTE CONTROL HOLDER

Install the holder where there is no direct sunlight to protect the remote control.

1. Choose a safe and easily-accessible place.

2. Fix the holder by fastening the 2 screws firmly with a screwdriver.

3. Slide the remote control into the holder.

OPERATING METHOD

Point the remote control towards the signal receiver at the bottom of the air conditioner to operate it.

*The feature can be changed according a type of model.

NOTE

• The remote control may operate other electronic devices if pointed towards them. Make sure to point the remote control towards the signal receiver of the air conditioner.

• For proper operation, use a soft cloth to clean the signal transmitter and receiver.

ENGLISH

USING THE REMOTE CONTROL

You can operate the air conditioner more conveniently with the remote control.

WIRELESS REMOTE CONTROL

Control panel	Display screen	Description
	-	**On/Off button :** Turn the power On/Off.
TEMP		**Temperature adjustment buttons :** Adjust the room temperature when cooling.
MODE		**Operation mode selection button :** Select the operation mode. Cooling operation ( ) Dehumidifying operation ( ) Heating operation ( )
JET MODE	Po	**Jet cool button :** Cools down the indoor temperature within a short period of time.
FAN SPEED		**Indoor fan speed button :** Adjust the fan speed.
SWING	-	**Air flow direction button :** Adjust the air flow direction vertically.
OFF TIMER	hr.	**Off timer button :** Set up automatic off
TIMER CLEAR	-	**Timer clear button :** Cancel timer setting

*Some functions may not be supported, depending on the model.

BASIC FUNCTIONS

COOLING YOUR ROOM (COOLING OPERATION)

1. Press ⏻ to turn on the power.
2. Press MODE repeatedly to select the cooling operation.
- ❄ is displayed on the display screen.

3. Press ⌄ or ⌃ to set the desired temperature.
- The temperature range is 18°C - 30°C.

HEATING YOUR ROOM (HEATING OPERATION)

1. Press ⏻ to turn on the power.
2. Press MODE repeatedly to select the heating operation.
- ☼ is displayed on the display screen.

3. Press ⌄ or ⌃ to set the desired temperature.
- The temperature range is 16°C - 30°C.

NOTE

• This function may not be supported, depending on the model.

REMOVING HUMIDITY (DEHUMIDIFYING OPERATION)

This mode removes excess moisture from an environment with high humidity or in the rainy season, in order to prevent mold. This mode adjusts the room temperature and the fan speed automatically to maintain the optimal level of humidity.

1. Press ⏻ to turn on the power.
2. Press MODE repeatedly to select the dehumidifying operation.
- 💧 is displayed on the display screen.

NOTE

• In this mode you cannot adjust the room temperature, as it is adjusted automatically. Also, the room temperature is not displayed on the display screen.

ENGLISH

ADJUSTING THE FAN SPEED

1. Press FAN SPEED to adjust the fan speed.

Remark	Speed
	High
	Medium
	Low
	Natural wind

.

ADJUSTING THE AIR FLOW DIRECTION

1. To adjust the direction of the air flow vertically, press SWING change the air flow direction automatically.

NOTE

- Adjusting the air deflector arbitrarily may cause product failure.
- If you restart the air conditioner, it starts to operate with the previously set direction of air flow.

SETTING THE TIMER

Use the off timer mode to turn off the air conditioner automatically.

1. Press ⏻ to turn on the power.
2. Press OFF TIMER repeatedly to select the hour you want to turn air conditioner off (Up to 7 hours). The hour increases automatically with long press.

- OFF is displayed on the display screen.

CANCEL THE TIMER SETTING

1. Press TIMER CLEAR to cancel all timer setting.

ADVANCED FUNCTIONS

The air conditioner offers some additional advanced functions.

CHANGING ROOM TEMPERATURE QUICKLY (JET COOL)

This mode allows you to cool indoor air quickly in summer.

1. Press ⏻ to turn on the power.
2. Press JET MODE

- In jet cooling mode, strong air blows out at a temperature of 18°C for 30 minutes.

ENGLISH

OPERATING THE AIR CONDITIONER WITHOUT THE REMOTE CONTROL

You can use the On/Off button of the indoor unit to operation the air conditioner when the remote control is unavailable. However, the fan speed is set to high.

1. Open the front cover.
- Lift up both side of the cover slightly.

Type 1 Type 2

*The feature can be changed according a type of model.

2. Press the On/Off button.

Type 1 Type 2

*The feature can be changed according a type of model.

- For cooling and heating model, the operation mode changes, depending on the room temperature.

Room Temp.	Set Temp.	Operation mode
Below 21°C	24°C	Heating operation
Above 21°C and below 24°C	23°C	Dehumidifying operation
Above 24°C	22°C	Cooling operation

- For cooling only model, the temperature is set to 22°C.

RESTARTING THE AIR CONDITIONER AUTOMATICALLY

When the air conditioner is turned on again after a power failure, this function restores the previous settings. This function is a factory default setting.

DISABLING AUTO RESTART

1. Open the front cover.
- Lift up both side of the cover slightly.

Type 1 Type 2

*The feature can be changed according a type of model.

2. Press the On/Off button and hold it for 6 seconds.
- The unit will beep twice and the lamp will blink twice 4 times.

Type 1 Type 2

*The feature can be changed according a type of model.

- To re-enable the function, press the On/Off button and hold it for 6 seconds. The unit will beep twice and the lamp will blink 4 times.

NOTE

• If you press and hold the On/Off button for 3-5 seconds, the unit will switch to the test operation. In the test operation, the unit blows out strong air for cooling for 18 minutes and then returns to the factory default setting.

MAINTENANCE

Clean the product regularly to maintain optimal performance and to prevent possible breakdown.

* The feature can be changed according a type of model.

Item	Cleaning interval	Cleaning method
Air filter	2 weeks	See “Cleaning Air filter”
Triple filter	3 months	See “Cleaning the Triple filter”
Indoor unit surface	Regularly	Use a soft, dry cloth. Do not use bleach or abrasives.
Outdoor unit	Regularly	Use steam to clean the heat exchanger coils and the panel vents (consult with technician).

CAUTION

• Turn off the power and unplug the power cord before you perform any maintenance; otherwise it may cause electric shock.
• Never use water that is hotter than 40°C when you clean the filters. It may cause deformation or discoloration.
• Never use volatile substances when you clean the filters. They may damage the surface of the product.
• Do not washed the 3M filter with water, because the filter can be damaged.

NOTE

• The location and shape of the filter may differ, depending on the model.
• Make sure to clean the heat exchanger coils of the outdoor unit regularly, as dirt collected in the coil may decrease the operational efficiency or increase energy costs.

ENGLISH

CLEANING THE AIR FILTER

Cleaning the Air filter once every 2 weeks or more if necessary.

1. Turn off the power and unplug the power cord.
2. Open the front cover.
- Lift up both sides of the cover slightly.

Type 1

Type 2

* The feature can be changed according a type of model.

3. Hold the knob of the Air filter, lift it up slightly and remove it from the unit.

Type 1

Type 2

* The feature can be changed according a type of model.

4. Clean the filter with a vacuum cleaner or with warm water.
- If dirt is difficult to remove, wash the filter in lukewarm water with detergent.
5. Dry the filter in the shade.

NOTE

• For inner cleaning, contact an Authorized Service center or a dealer. Do not use harsh detergent that causes corrosion or damage on the unit. Harsh detergent may also cause failure of product, fire, or electric shock.

CLEANING TRIPLE FILTER (OPTIONAL)

1. Turn off the power and unplug the power cord.
2. Open the front cover and remove Air filter (See “Cleaning Air filter").
3. Pull out the Triple filter.

Type 1

Type 2

4. Dry the filer in direct sunlight for 2 hours.

NOTE

• The location and shape of the filters may differ, depend on the model.

TROUBLESHOOTING

SELF-DIAGNOSIS FUNCTION

This product has a built-in self-diagnosis function. If an error occurs, the lamp of the indoor unit will blink in 2 seconds intervals. If this occurs, contact your local dealer or service center.

BEFORE REQUESTING SERVICE

Please check the following before you contact the service center. If the problem persists, contact your local service center.

Problem	Possible causes	Corrective action
There is a burning smell and a strange sound coming from the unit.	-	Turn off the air conditioner, unplug the power cord and contact the service center.
Water leaks from the indoor unit even when the humidity level is low.		
The power cord is damaged or generating excessive heat.		
A switch, a circuit breaker (safety, ground) or a fuse is not operated properly.		
The air conditioner does not works.	The air conditioner is unplugged.	Check whether the power cord is plugged into the outlet.
	A fuse is blown or the power supply is blocked.	Replace the fuse or check if the circuit breaker has tripped.
	A power failure has occurred.	Turn off the air conditioner when a power failure occurs. When the power is restored, wait 3 minutes, and then on the air conditioner.
	The voltage is too high or too low.	Check if the circuit breaker has tripped.
	The air conditioner turned off automatically at a preset time.	Press the power button again.

Problem	Possible causes	Corrective action
The air conditioner does not generate cool air.	Air is not circulating properly.	Make sure that there are no curtains, blinds or furniture blocking the front of the air conditioner.
	The Air filter is dirty.	Clean the Air filter once every 2 weeks. See “Cleaning Air filter” for more information.
	The room temperature is too high.	In summer, it may take some time to cool indoor air. In this case, select the jet cool operation to cool indoor air quickly.
	Cold air is escaping from the room.	Make sure that no cold air is escaping through ventilation points in the room.
	The desired temperature is higher than the set temperature.	Set the desired temperature to a level lower than the current temperature.
	There is a heating source nearby.	Avoid using a heat generator such as an electric oven or a gas burner while the air conditioner is in operation.
	Air circulation operation is selected.	In the air circulation operation, air blows from the air conditioner without cooling or heating the indoor air. Switch the operation mode to the cooling operation.
It is not possible to adjust the fan speed.	The auto operation, jet operation or dehumidifying operation is selected.	In some operation modes, such as the jet or dehumidifying operation modes, you cannot adjust the fan speed. Select an operation mode in which you can adjust the fan speed.
It is not possible to adjust the temperature.	The air circulation operation or jet operation is selected.	In some operation modes, such as the air circulation or jet operation mode, you cannot adjust the temperature. Select an operation mode in which you can adjust the temperature.

NOTE

LG

Life's Good

LG
Life's Good

العربية

دليل المالك

مكيف الهواء

الرجاء قراءة هذا الدليل بعناية قبل التشغيل والإحتفاظ به ليكون مرجعاً فى المستقبل.

نوع المكيف: المعلق على الحائط

قم بزيارة موقعنا: www.lg.com

العربية

نصائح لتوفير الطاقة

هنا بعض النصائح التي تساعدك على تقليل استهلاك الطاقة عند استخدام مكيف الهواء.

و يمكنك أن تستخدم أجهزة تكييف الهواء بشكل أكثر كفاءة بالرجوع إلى التعليمات التالية:

- التبريد بشكل مفرط في الأماكن الداخلية قد يكون ضاراً بصحتك، وربما تستهلك مزيداً من الكهرباء.
- منع أشعة الشمس بالستائر عند تشغيل مكيف الهواء.
- إبقاء الأبواب أو النوافذ مغلقة تماماً عند تشغيل مكيف الهواء.
- اضبط اتجاه تدفق الهواء عموديا أو أفقيا لتعميم الهواء في المكان الداخلي.
- تسريع مروحة الهواء في المكان الداخلي إلى بارد أو دافئ في وقت قصير.
- قم بفتح النوافذ بإنتظام بغرض التهوية لأن جودة الهواء بالداخل قد تتدهور إذا تم إستخدام مكيف الهواء لعدة ساعات
- تنظيف مرشح الهواء مرة كل أسبوعين. تراكم الغبار والشوائب قد يمنع مرور تيار الهواء أو قد يضعف خاصيتي التبريد أو إزالة الرطوبة

لسجلاتك

الصق إيصالك بهذه الصفحة إذا كنت في حاجة إليه لإثبات تاريخ الشراء أو لأغراض الضمان.

اكتب رقم الموديل والرقم التسلسلي هنا:

رقم الموديل:

الرقم التسلسلي:

يمكنك العثور عليهما على الملصق الموجود على جانب كل وحدة.

اسم الوكيل:

تاريخ الشراء:

إرشادات الأمان الهامة

اقرأ جميع التعليمات قبل استخدام الجهاز.

امتثل الاحتياطات التالية دائماً لتجنب المواقف الخطرة ولضمان أعلى آداء لمنتجك

تحذير

قد يؤدي إلى وقوع إصابة خطيرة أو الوفاة عند تجاهل الإرشادات

تنبيه

قد يؤدي إلى الإصابة الطفيفة أو تلف المنتج عند تجاهل الإرشادات

تحذير

- التركيب أو الإصلاحات التي أجريت من قبل أشخاص غير مؤهلين قد تعرضك وتعرض الآخرين للأخطار.
- يجب أن يتوافق التركيب مع قوانين البناء المحلية، أو في حالة غياب القوانين المحلية، أن يتوافق مع قانون الكهرباء القومي NFPA 70/ANSI C1-1003 أو الطبعة الحالية لقانون الكهرباء الكندي الجزء CSA C.22.1 1
- المقصود بالمعلومات الواردة في دليل الاستخدام للاستعمال من قبل الفني المؤهل مع الإجراءات السليمة والتجهيز بالأدوات المناسبة و أجهزة الاختبار.
- الفشل في القراءة بعناية واتباع جميع التعليمات الواردة في هذا الدليل يؤدي إلى عطل المعدات، وتلف الممتلكات و إصابة الشخص / أو الموت.

التركيب

- استخدام قاطع الدائرة الكهربائية القياسية والمصاهر المطابقان لتصنيف مكيف الهواء. و عدم القيام بذلك قد يؤدي إلى الصدمة الكهربائية أو فشل المنتج.
- الاتصال بمركز الخدمة المعتمد عند التركيب أو نقل مكيف الهواء. و عدم القيام بذلك سيؤدي إلى وقوع الإصابة الخطيرة أو فشل المنتج.
- استخدم دائما قابس الطاقة والمأخذ الكهربائي مع السلك الأرضي. و عدم القيام بذلك قد يؤدي إلى الصدمة الكهربائية أو فشل المنتج
- قم بتركيب لوحة وغطاء صندوق التحكم بأمان. و عدم القيام بذلك قد يؤدي إلى انفجار أو حريق.
- قم بتركيب المنفذ الكهربائي المخصص و قاطع الدائرة قبل استخدام مكيف الهواء. و عدم القيام بذلك قد يؤدي إلى الصدمة الكهربائية أو فشل المنتج.
- استخدم قاطع الدائرة القياسي والمصاهر المطابقان لتصنيف مكيف الهواء. و عدم القيام بذلك قد يؤدي إلى الصدمة الكهربائية أو فشل المنتج.
- عدم تعديل أو تمديد كابلات الطاقة. وإذا كان كابل الطاقة أو السلك مخدوشاً أو مقشراً أو متدهوراً، فيجب إستبداله. فإنه قد يؤدي إلى الحريق أو الصدمة الكهربائية.
- كن حذرا عند فك أو تركيب مكيف الهواء. و عدم القيام بذلك سيؤدي إلى وقوع الإصابة الخطيرة أو فشل المنتج.
- الاتصال بمركز الخدمة المعتمد عند التركيب أو نقل مكيف الهواء. و عدم القيام بذلك سيؤدي إلى وقوع الإصابة الخطيرة أو فشل المنتج.
- لا تقم بتركيب مكيف الهواء على السطح الغير مستقر أو يكون هناك خطرا من سقوطه. فإنه قد يؤدي إلى الوفاة أو الإصابة الخطيرة، أو فشل المنتج.

التشغيل

• لا تدع مكيف الهواء يعمل لفترة طويلة عند الرطوبة العالية أو عند فتح الباب أو النافذة. و عدم القيام بذلك قد يؤدي إلى فشل المنتج.

• التأكد من أن سلك الطاقة لا يُسحَب أو لا يُعطَب حينما يعمل المكيف. و عدم القيام بذلك سيؤدي إلى الحريق، و الصدمة الكهربائية، أو فشل المنتج.

• لا تضع أي شيء على سلك الكهرباء. فإنه قد يؤدي إلى الصدمة الكهربائية أو فشل المنتج.

• عدم تشغيل أو إيقاف مكيف الهواء عن طريق التوصيل بالقابس الكهربائي أو إلغاء التوصيل. فإنه قد يؤدي إلى الحريق أو الصدمة الكهربائية.

• لا تلمس أو تشغل أو تصلح مكيف الهواء بأيد مبتلة. فإنه قد يؤدي إلى الصدمة الكهربائية أو فشل المنتج.

• لا تضع السخان أو أجهزة التدفئة الأخرى بالقرب من كابل الطاقة. فإنه قد يؤدي إلى الحريق، والصدمة الكهربائية، أو فشل المنتج.

• لا تسمح للماء أن يدخل إلى مكيف الهواء. فإنه قد يؤدي إلى الانفجار أو الحريق.

• لا تترك المواد القابلة للاشتعال مثل الغازولين، أوالبنزين أومرقق الدهان بالقرب من مكيف الهواء. فإنه قد يؤدي إلى الانفجار أو الحريق.

• لا تستخدم مكيف الهواء لفترة طويلة في مكان صغير دون التهوية، و أن تهوّي المكان بشكل منتظم. و عدم القيام بذلك قد يؤدي إلى الانفجار أو الحريق.

• عند وجود تسرب الغاز، عليك أن تهوّي تهوية كافية قبل استخدام مكيف الهواء مرة أخرى. و عدم القيام بذلك قد يؤدي إلى الانفجار أو الحريق.

• قم بفصل القابس الكهربائي إذا كان هناك ضجيجا، أو رائحة أو دخانا يتصاعد من مكيف الهواء. و عدم القيام بذلك قد يؤدي إلى الانفجار أو الحريق.

•إيقاف التشغيل وإغلاق النافذة في حالة العاصفة أو الإعصار. و من الممكن أن تنقل المنتج من النافذة قبل وصول الإعصار.

• لا تلمس المرشح الإستاتيكي بعد فتح الغطاء الأمامي. و عدم القيام بذلك يؤدي إلى الصدمة الكهربائية أو فشل المنتج.

• اتصل بمركز الخدمة المعتمد إذا كان مكيف الهواء مغموراً في المياه بسبب الفيضانات. و عدم القيام بذلك قد يؤدي إلى الانفجار أو الحريق.

•كن حذرا من دخول المياه إلى المنتج.

• التأكد من التهوية الكافية عند استخدام مكيف الهواء وجهاز التدفئة مثل السخان في وقت واحد.

وعدم القيام بذلك سيؤدي إلى الحريق، والإصابة الخطيرة، أو فشل المنتج.

• قم بإيقاف الكهرباء الرئيسية وافصل القابس الكهربائي عند التنظيف أو إصلاح مكيف الهواء.

و عدم القيام بذلك قد يؤدي إلى الوفاة أو الإصابة الخطيرة، أو فشل المنتج.

• افصل القابس الكهربائي عند عدم استخدام مكيف الهواء لفترة ممتدة من الزمن. و عدم القيام بذلك قد يؤدي إلى فشل المنتج.

• لا تضع أي شيء على مكيف الهواء. فإنه قد يؤدي إلى فشل المنتج.

• للتنظيف الداخلي، اتصل بمركز الخدمة المعتمد أو الوكيل.

لا تستخدم المنظفات القاسية التي تسبب التآكل أو التلف على الوحدة.

والمنظفات القاسية قد تسبب أيضا فشل المنتج، أوالحريق، أو الصدمة الإلكترونية.

⚠ تنبيه

التركيب

• تأكد بالفحص ما إذا كان هنالك تسريب لغاز التبريد بعد التركيب أو إصلاح مكيف الهواء أم لا. و عدم القيام بذلك قد يؤدي إلى فشل المنتج.

• ركّب خرطوم التصريف بشكل صحيح لتصريف الماء المكثف على نحو سلس. و عدم القيام بذلك قد يؤدي إلى فشل المنتج.

• الحفاظ على الدرجة المستقيمة عند تركيب المنتج.

• ركّب مكيف الهواء بحيث لا يزعج الجيران بالضوضاء أو الغاز العادم. و عدم القيام بذلك قد يؤدي إلى الصراع بين الجيران.

• عندنقل المعدات، ينبغي أن يكون هناك شخصين على الأقل أو أكثر، أو رافعة شوكية. فإنه قد يؤدي إلى الإصابة الخطيرة.

• لا تقم بتركيب مكيف الهواء إذا كان المكيف معرض لرياح البحر (رش الملح) مباشرة. فإنه قد يؤدي إلى فشل المنتج.

التشغيل

• عدم تعرض الناس أو الحيوانات أو النباتات للرياح الباردة أو الساخنة القادمة من مكيف الهواء. فإنه قد يؤدي إلى الإصابة الخطيرة.

•عدم استخدام المنتج لأغراض خاصة، مثل الحفاظ على الأطعمة، والأعمال الفنية، وما إلى ذلك. لأنه مكيف هواء للإستخدام المترلي، ليس له نظام التبريد الدقيق. فإنه قد يؤدي إلى الموت، أوالحريق أو الصدمة الكهربائية.

• لا تسد مدخل أو منفذ تدفق الهواء. فإنه قد يؤدي إلى الانفجار أو فشل المنتج.

• لا تستخدم مواد التنظيف أو المذيبات القوية أو رذاذ الماء عند تنظيف المكيف بل إستخدم قطعة قماش ناعمة. فإنه قد يؤدي إلى الإصابة الخطيرة أو فشل المنتج.

• لا تلمس أجزاء مكيف الهواء المعدنية عند إزالة فلتر الهواء. فإنه قد يؤدي إلى الإصابة الخطيرة أو فشل المنتج.

• لا تضع أي شيء على مكيف الهواء. فإنه قد يؤدي إلى فشل المنتج.

• قم دائماً بإدراج المرشح بشكل آمن بعد التنظيف. نظّف المرشح مرة واحدة كل أسبوعين أو أكثر من مرة إذا لزم الأمر.

• عدم إدخال اليد أو غيرها من الأشياء إلى مدخل أو منفذ الهواء حينما يعمل مكيف الهواء. فإنه قد يؤدي إلى الصدمة الكهربائية.

• لا تشرب الماء الذي ينضب من مكيف الهواء. فإنه قد يؤدي إلى المضاعفات الصحية الخطيرة.

• استخدم المقعد القوي أو السلم عند القيام بتنظيف أوصيانة أو إصلاح مكيف الهواء فى المكان المرتفع. و عدم القيام بذلك سيؤدي إلى وقوع الإصابة الخطيرة أو فشل المنتج.

•لا تخلط بطاريات جهاز التحكم عن بعد بأنواع أخرى من البطاريات، أو تخلط البطاريات الجديدة بالبطاريات المستعملة. و عدم القيام بذلك يؤدي إلى فشل المنتج.

• .عدم إعادة شحن أو تفكيك البطاريات. و عدم القيام بذلك يؤدي إلى الانفجار أو الحريق أو إلحاق الإصابة الخطيرة

• التوقف عن استخدام جهاز التحكم عن بعد بوجود تسرب السائل من البطارية. وإذا أصيبت بشرتك أو قماشك بسائل البطارية المتسرب، فاغسله بالماء النظيف.

و عدم القيام بذلك سيؤدي إلى وقوع الإصابة الخطيرة.

• إذا ابتلعت سائل البطارية المتسرب، فاغسل داخل فمك جيدا ثم استشر الطبيب. و عدم القيام بذلك يؤدي إلى المضاعفات الصحية الخطيرة.

جدول المحتويات

2 نصائح لتوفير الطاقة

3 إحطياطات الأمان الهامة

7 قبل الإستعمال

7 وحدة داخلية النوع 1
7 وحدة خارجية
8 وحدة داخلية النوع 2
8 وحدة خارجية
9 إدراج البطاريات
9 تثبيت حامل جهاز التحكم عن بعد
9 طريقة التشغيل

10 استخدام جهاز التحكم عن بعد

10 جهاز التحكم عن بعد اللاسلكي

11 الوظائف الأساسية

11 تبريد غرفتك
11 تسخين غرفتك
11 إزالة الرطوبة
12 ضبط سرعة المروحة
12 ضبط اتجاه تدفق الهواء
12 ضبط المؤقت
12 إلغاء إعدادات المؤقت

13 الوظائف المتقدمة

13 تغيير درجة حرارة الغرفة بسرعة
14 تشغيل مكيف الهواء بدون جهاز التحكم عن بعد
14 إعادة تشغيل مكيف الهواء تلقائياً

15 الصيانة

16 تنظيف فلتر الهواء
16 تنظيف الفلتر الثلاثي (اختياري)

17 المشاكل والحلول

17 وظيفة التشخيص الذاتي
17 قبل طلب الخدمة

العربية

قبل الإستعمال

المكونات

وحدة داخلية

النوع 1

*قد تتغير مميزات الجهاز وفقاً لنوع الموديل

ملاحظة!

قد يختلف عدد مصابيح التشغيل و مواقعها، إعتماداً على موديل جهاز التكييف.

وحدة خارجية

* قد تتغير مميزات الجهاز وفقاً لنوع الموديل

المكونات

النوع 2

وحدة داخلية

*قد تتغير مميزات الجهاز وفقاً لنوع الموديل

ملاحظة!

قد يختلف عدد مصابيح التشغيل و مواقعها، إعتماداً على موديل جهاز التكييف.

وحدة خارجية

* قد تتغير مميزات الجهاز وفقاً لنوع الموديل

إدراج البطاريات

قم بإدراج البطاريات قبل استخدام جهاز التحكم عن بعد. نوع البطارية المستخدمة هي إي إي إي (1.5فولت)

1 قم بإزالة غطاء البطارية.

2 أدرج البطاريات الجديدة مع التأكد من أن شحنة + و – للبطاريات مركبة بشكل صحيح.

3 أعد غطاء البطارية.

ملاحظة!

إذا تلاشت شاشة عرض جهاز التحكم عن بعد، قم بإستبدال البطاريات.

تثبيت حامل جهاز التحكم عن بعد

قم بتركيب الحامل فى المكان الذي لا يوجد فيه ضوء الشمس المباشر لحماية جهاز التحكم عن بعد.

1 اختر مكاناً آمناً ويسهل الوصول إليه.

2 قم بتثبيت الحامل عن طريق الربط بمسمارين و مفك البراغي.

3 ضع جهاز التحكم عن بعد في الحامل.

طريقة التشغيل

أشر جهاز التحكم عن بعد نحو متلقى الإشارة في الجزء السفلي من جهاز تكييف الهواء لتشغيلها.

ملاحظة!

- قد يعمل جهاز التحكم عن بعد مع الأجهزة الإلكترونية الأخرى إذا أشير نحوها. تأكد من أن تشير جهاز التحكم عن بعد باتجاه متلقى الإشارة فى جهاز تكييف الهواء.
- للتشغيل السليم، استخدم قطعة قماش ناعمة لتنظيف جهاز إرسال واستقبال الإشارة.

العربية

إستخدام جهاز التحكم عن بعد

يمكنك تشغيل مكيف الهواء بسهولة أكثر مع جهاز التحكم عن بعد.

جهاز التحكم عن بعد اللاسلكي

لوحة التحكم	شاشة العرض	الوصف
	-	**زر تشغيل / إيقاف**: لتشغيل / إيقاف الطاقة.
TEMP	88 °C	**أزرار تعديل درجة الحرارة**: تضبط درجة حرارة الغرفة عند التبريد.
MODE		**زر اختيار وضع العملية**: اختيار وضع العملية. عملية التبريد (❄) عملية التجفيف (💧) تسخين غرفتك (☀)
JET MODE	Po	**زر التبريد النفاث**: يبرد درجة الحرارة في الأماكن المغلقة في زمن يسير.
FAN SPEED		**زر سرعة المروحة الداخلية**: لضبط سرعة المروحة.
SWING	-	**زر اتجاه تدفق الهواء**: لضبط اتجاه تدفق الهواء عموديا
OFF TIMER	88hr.	**مؤقت إيقاف التشغيل**: لضبط إيقاف التشغيل أوتوماتيكياً
TIMER CLEAR	-	**زر إلغاء المؤقت**: إلغاء إعدادات المؤقت

بعض الوظائف قد لا تكون متوفرة، وذلك اعتماداً على الموديل

العربية

الوظائف الأساسية

تبريد غرفتك (عملية التبريد)

1 اضغط على زر ⏻ لتشغيل الطاقة.

2 اضغط على زر MODE بشكل متكرر لتحديد عملية التبريد

– ❄ يعرض على شاشة العرض.

3 اضغط على زر ⌄ أو ⌃ لضبط درجة الحرارة المطلوبة.

– معدل درجة الحرارة هو 18 درجة مئوية – 30 درجة مئوية.

تسخين غرفتك (عملية التسخين)

1 اضغط على زر ⏻ لتشغيل الطاقة.

2 اضغط على زر MODE

– ☼ يعرض على شاشة العرض.

3 اضغط على زر ⌄ أو ⌃ لضبط درجة الحرارة المطلوبة.

– معدل درجة الحرارة هو 16 درجة مئوية – 30 درجة مئوية.

ملاحظة

قد تتغير مميزات الجهاز وفقاً لنوع الموديل

إزالة الرطوبة (عملية التجفيف)

هذا الوضع يزيل الرطوبة الزائدة من البيئة ذات الرطوبة العالية أو في موسم الأمطار، من أجل منع العفن من التواجد فيها، وهذا الوضع يضبط درجة حرارة الغرفة وسرعة المروحة تلقائيا للحفاظ على المستوى الأمثل من الرطوبة.

1 اضغط على زر ⏻ لتشغيل الطاقة.

2 اضغط على زر MODE بشكل متكرر لتحديد عملية التجفيف.

– 💧 يعرض على شاشة العرض.

ملاحظة!

في هذا الوضع لا يمكنك ضبط درجة حرارة الغرفة، حيث يتم تعديلها تلقائياً. أيضا، درجة حرارة الغرفة لا تظهر على شاشة العرض.

ضبط سرعة المروحة

1 اضغط على زر FAN SPEED بشكل متكرر لضبط سرعة المروحة.

الرمز	السرعة
	مرتفع
	متوسط
	منخفض
	رياح طبيعية

.

ضبط اتجاه تدفق الهواء

1 لضبط اتجاه تدفق الهواء عموديا،

اضغط على زر SWING لتغيير اتجاه تدفق الهواء تلقائيا.

ملاحظة!

- ضبط حارف الهواء بشكل تعسفي قد يسبب فشل المنتج.
- إذا قمت بإعادة تشغيل مكيف الهواء، يبدأ في العمل مع تحديد الاتجاه السابق من تدفق الهواء، لذلك قد يكون حارف الهواء

تحديد المؤقت

استخدم وضع إيقاف ضبط الوقت لإيقاف مكيف الهواء تلقائياً.

1 اضغط على زر ⏻ لتشغيل الطاقة.

2 اضغط على زر OFF TIMER بشكل متكرر لتحديد الساعة التي ترغب في إيقاف مكيف الهواء. (إلى 7 ساعة)

(الساعة تزيد تلقائيا بالضغط لفترة طويلة.)

– OFF يتم عرضها على شاشة العرض في هذا الوضع.

إلغاء إعدادات المؤقت

1. إضغط TIMER CLEAR لإلغاء إعدادات المؤقت.

وظائف متقدمة

يقدم مكيف الهواء بعض الوظائف المتقدمة الإضافية.

تغيير درجة حرارة الغرفة

بسرعة (جيت كول)

هذا الوضع يسمح لك أن تبرّد الهواء في الأماكن المغلقة بسرعة في الصيف.

1 اضغط على زر ⏻ لتشغيل الطاقة.

2 اضغط على زر JET MODE

– في وضع التبريد النفاث، يهب الهواء القوي عند درجة الحرارة 18 درجة مئوية لمدة 30 دقيقة.

تشغيل المكيف بدون إستخدام جهاز التحكم عن بعد

يمكنك إستخدام زر التشغيل\الإيقاف الموجود في الوحدة الداخلية لتشغيل المكيف في حالة عدم توفر جهاز التحكم عن بعد. عليه، فإن المروحة تكون عند السرعة القصوى.

1. إفتح الغطاء الأمامي.
- إرفع جانبي الغطاء برفق.

* قد تختلف بعض الخصائص وفقاً لنوع الموديل.

2. إضغط زر التشغيل\الإيقاف.

* قد تختلف بعض الخصائص وفقاً لنوع الموديل.
- يتغير إعداد التشغيل في موديل التبريد والتسخين بتغير درجة حرارة الغرفة.

درجة حرارة الغرفة	ضبط درجة الحرارة	وضع التشغيل
أدني من 21 درجة مئوية	24 درجة مئوية	وضع التسخين
أعلي من 21 درجة مئوية وأدني من 24 درجة مئوية	23 درجة مئوية	وضع إزالة الرطوبة
أعلي من 24 درجة مئوية	22 درجة مئوية	وضع التبريد

إعادة تشغيل مكيف الهواء تلقائيا

عندما يتم تشغيل مكيف الهواء مرة أخرى بعد انقطاع التيار الكهربائي،
تعيد هذه الوظيفة الإعداد السابق . هذه الوظيفة هي الإعداد الافتراضي من المصنع

تعطيل إعادة التشغيل التلقائي

1. إفتح الغطاء الأمامي.
- إرفع جانبي الغطاء برفق.

2. اضغط على زر تشغيل/إيقاف وابق على ذلك

حوالي 6 ثوان.

–سوف يصدر صوت التنبيه مرتين من الوحدة و يضيء

المصباح 4 مرات.

❊ يمكن تغيير الخاصية وفقًا لنوع الطراز.

ملاحظة

إذا كنت تضغط مع الاستمرار على زر تشغيل / إيقاف لمدة 3-5 ثوان بدلا من 6 ثوان،
تتحول الوحدة إلى عملية الاختبار.
ففي عملية الاختبار ، يهب الهواء القوي من الوحدة للتبريد لمدة 18 دقيقة
ثم يعود إلى الإعدادات الافتراضية من المصنع

الصيانة

نظف المنتج بانتظام للحفاظ على الأداء الأمثل ومنع التعطل المحتمل.

*قد لا يقدَّم هذا، اعتماداً على الموديل.

البند	فترة التنظيف	طريقة التنظيف
مرشح الهواء	أسبوعان	انظر "تنظيف مرشح الهواء."
الفلتر الثلاثي	٣ أشهر	إذهب إلى "تنظيف الفلتر الثلاثي"
سطح الوحدة الداخلية	بانتظام	استخدام قطعة القماش الناعمة الجافة. لا تستخدم مواد التبييض أو المزيلات
الوحدة الخارجية	بانتظام	استخدم البخار لتنظيف لفائف المبادلات الحرارية وفتحات اللوحة (تشاور مع الفني)

تنبيه

- قم بإيقاف الطاقة وفصل سلك الطاقة قبل إجراء أي الصيانة، وإلا فإنه قد يسبب صدمة كهربائية.
- لا تستخدم الماء الذي سخونته أكثر من 40 درجة مئوية عند تنظيف الفلاتر. فإنه قد يسبب تشوه أو تغير لونها.
- لا تستخدم المواد المتطايرة عند تنظيف الفلاتر. لأنها قد تسبب التلف في سطح المنتج.

ملاحظة!

- قد يختلف موقع وشكل المرشحات، اعتمادا على الموديل.
- تأكد من تنظيف ملف المبادل الحراري للوحدة الخارجية بانتظام، لأن تراكم الأوساخ حول الملفات قد يقلل الكفاءة التشغيلية أو يزيد تكلفة الطاقة.

تنظيف مرشح الهواء

نظف مرشح الهواء مرة واحدة كل أسبوعين أو

أكثر من مرة إذا لزم الأمر.

1 قم بإيقاف الطاقة وفصل سلك الطاقة.

2 افتح الغطاء الأمامي.

– ارفع جانبي الغطاء قليلا.

*قد تتغير الميزة

وفقا لنوع الموديل

3 امسك مقبض مرشح الهواء، ثم ارفعه

قليلا ثم أخرجه من الوحدة.

*قد تتغير الميزة
وفقا لنوع الموديل

4 نظف المرشح بالمكنسة الكهربائية أو

بالماء الدافئ.

– إذا كانت الأوساخ تصعب إزالتها، فاغسل المرشح

في ماء فاتر مع المنظفات.

5 قم بتجفيف المرشح في الظل.

ملاحظة!

•للتنظيف الداخلي، اتصل بمركز
الخدمة المعتمد أو الوكيل. لا تستخدم
المنظفات القاسية التي تسبب التآكل أو
التلف على الوحدة. وقد تسبب المنظفات القاسية
فشل المنتج، أوالحريق، أو الصدمة الإلكترونية.

تنظيف الفلتر الثلاثي (اختياري)

1 أطفئ المكيف وافصل سلك الطاقة

2 إفتح الغطاء الأمامي وأزل فلتر الهواء(إذهب إلى تنظيف الفلتر الهواء)

3 إسحب الفلتر الثلاثي

النوع 1

النوع 2

* يمكن لهذه الميزة أن تتغير وفقاً لنوع النموذج

4 جفف الفلتر في اشاعات الشمس مباشرةً لمدة ساعتين

مشاكل وحلول

وظيفة التشخيص الذاتية

توجد في هذا المنتج وظيفة التشخيص الذاتية المدمجة. في حالة حدوث الخطأ، سيومض مصباح الوحدة الداخلية لمدة ثانتين. وفي هذه الحالة، اتصل بالوكيل المحلي أو مركز الخدمة.

قبل طلب الخدمة

يرجى التحقق مما يلي قبل الاتصال بمركز الخدمة. وإذا استمرت المشكلة، فاتصل بمركز الخدمة المحلي.

المشكلة	الأسباب المحتملة	الاجراءات التصحيحية
توجد رائحة حريق و صوت غريب قادم من الوحدة.	-	قم بإيقاف تشغيل المكيف، افصل سلك الطاقة، ثم اتصل بمركز الخدمة.
تسرب المياه من الوحدة الداخلية عند انخفاض مستوى الرطوبة.		
تلف سلك الطاقة أو توليد الحرارة المفرطة.		
لا يعمل مفتاح التبديل أو قاطع الدائرة الكهربائية (الأمان، الأرضي) أو المصهر بشكل صحيح.		
مكيف الهواء لا يعمل	جهاز تكييف الهواء غير موصول.	تحقق من أن سلك الطاقة موصول بمأخذ التيار.
	إنفجار المصهر أو إمداد الطاقة محظور.	استبدل المصهر أو تحقق من سقاطة قاطع الدائرة الكهربائية.
	حدث انقطاع في التيار الكهربائي.	قم بإيقاف تشغيل مكيف الهواء عند انقطاع التيار الكهربائي. فإذا تم استعادة الطاقة، انتظر 3 دقائق، ثم قم بتشغيل مكيف الهواء.
	الجهد الكهربائي مرتفع أو منخفض	تحقق من سقاطة قاطع الدائرة الكهربائية.
	يتوقف مكيف الهواء عن العمل تلقائيا في الوقت المسبق.	اضغط على زر الطاقة مرة أخرى.

مشاكل وحلول	الأسباب المحتملة	الاجراءات التصحيحية
مكيف الهواء لا يولد الهواء البارد.	عدم تعميم الهواء بشكل صحيح.	تأكد من أنه لا توجد ستائر، أو أن الأثاث قد يحجب واجهة مكيف الهواء.
	مرشح الهواء متسخ.	انظر "تنظيف مرشح ,نظف مرشح الهواء مرة واحدة كل أسبوعين الهواء" لمزيد من المعلومات.
	درجة حرارة الغرفة مرتفعة جدا.	في الصيف، قد يستغرق وقتا ليبرد الهواء في الأماكن المغلقة. في هذه الحالة، حدد عملية التبريد النفاث لتبريد الهواء في الأماكن المغلقة بسرعة.
	يخرج الهواء البارد من الغرفة.	تأكد من أن الهواء البارد لا يخرج من خلال نقاط التهوية في الغرفة.
	درجة الحرارة المطلوبة أعلى من درجة الحرارة المضبوطة.	اضبط درجة الحرارة المطلوبة إلى المستوى الأدنى من درجة الحرارة الحالية.
	يوجد مصدر التدفئة في مكان قريب.	تجنب استخدام مولد الحرارة مثل الفرن الكهربائي أو موقد الغاز حينما يعمل مكيف الهواء.
	يتم تحديد عملية تدوير الهواء.	في عملية تدوير الهواء، يهب الهواء من المكيف من دون تبريد أو تسخين الهواء في الأماكن المغلقة. استخدم وضع التشغيل لعملية التبريد.
عدم إمكانية ضبط سرعة المروحة.	اختيار التشغيل التلقائي، أو عملية التبريد النفاث أو عملية التجفيف.	في بعض أوضاع العملية، مثل عملية التبريد النفاث أو وضع عملية التجفيف لا يمكنك ضبط سرعة المروحة. حدد عملية الوضع الذي يمكنك ضبط سرعة المروحة.
وليس من الممكن لضبط درجة الحرارة.	اختيار عملية تدوير الهواء أو عملية التبريد النفاث.	في بعض أوضاع العملية، مثل تدوير الهواء أو وضع عملية التبريد النفاث، لا يمكنك ضبط درجة الحرارة. حدد عملية الوضع الذي يمكنك ضبط درجة الحرارة.

ملاحظة!

LG

Life's Good