LG
Life's Good

繁體中文
简体中文
ENGLISH

使用手冊
用户手冊
User Guide

LG G2 mini
LG-D620k

MFL69323601 (1.0)

www.lg.com

繁體中文

使用手冊

- 畫面顯示及插圖可能與實際手機上顯示的有所不同。
- 視乎軟件或服務供應商而定，本手冊中的部份內容可能不適用於您的手機。 此文件中所有資訊如有更改，恕不另行通知。
- 由於使用觸控螢幕鍵盤，此手機不適合視障人士使用。
- Copyright ©2015 LG Electronics, Inc. 保留所有權利。 LG 及 LG 標誌乃 LG 集團及其相關公司的註冊商標。 所有其他商標均屬於其擁有者。
- Google™、Google Maps™、Gmail™、YouTube™、Hangouts™ 及 Play Store™ 均為 Google, Inc 的商標。

目錄

安全及有效使用準則 5

重要通知 10

了解您的手機 14
- 手機概覽 14
- 安裝 SIM 卡及電池 16
- 為手機充電 18
- 使用記憶卡 19
- 將螢幕鎖定及解鎖 20

您的桌面 21
- 觸控螢幕提示 21
- 桌面 21
  - 擴展桌面 22
  - 自訂桌面 22
- 返回最近使用的應用程式 23
- 通知面板 23
  - 開啟通知面板 24
  - 狀態欄上的指示圖示 25
- 螢幕鍵盤 26
  - 輸入重音字母 26

Google 帳號設定 27
- 要設定 Google 帳號 27

連接到網絡及裝置 28
- Wi-Fi 28
  - 連接至 Wi-Fi 網絡 28
  - 開啟 Wi-Fi 並連接至 Wi-Fi 網絡 28
- 藍牙 28
- 享手機的數據連接 29
- Wi-Fi Direct 30
- SmartShare 31
- 盡享附近裝置的內容 31
- 使用 USB 纜線進行 PC 連接 32

通話功能 33
- 撥打電話 33
- 從通訊錄中撥打電話 33
- 調節通話音量 33
- 通話期間撥打第二個電話 33
- 檢視通話記錄 34
- 通話設定 34

通訊錄 35
- 搜尋通訊錄 35
- 新增通訊錄 35
- 最愛通訊錄 35
- 建立群組 36

訊息 37
- 發送訊息 37
- 訊息串連方塊 38
- 更改訊息設定 38

電子郵件 39
- 管理電郵帳號 39
- 處理帳號資料夾 39
- 編寫及發送電子郵件 39

相機 40
- 了解取景器 40
- 使用進階設定 41
- 快速拍照 42
- 使用時間捕捉拍攝模式 42
- 當拍攝相片後 42

視像攝錄機 44
- 了解取景器 44
- 使用進階設定 45

錄製短片 45
錄製影片後 46

功能 47
Knock Code 47
QuickMemo+ 47
使用 QuickMemo+ 選項 48
檢視已儲存的 QuickMemo+ 48
QSlide 49
QuickRemote 49

多媒體 51
媒體匣 51
檢視圖片 51
播放影片 51
編輯相片 51
刪除相片/影片 51
設定為牆紙 52
影片 52
播放影片 52
音樂 53
播放歌曲 53
新增音樂檔案至手機 55
FM 收音機 55

實用程式 56
定鬧鐘 56
使用計算機 56
新增事件至日曆 56
語音備忘錄 57
錄製聲音或語音 57
工作 57
ThinkFree 檢視器 58
Google+ 58
語音搜尋 58
下載 58
LG SmartWorld 59
如何從手機進入 LG SmartWorld 59
如何使用 LG SmartWorld 59

網絡功能 60
互聯網 60
使用網絡工具列 60
檢視網頁 60
開啟頁面 60
以語音搜尋網站 60
書簽 61
歷史記錄 61
Chrome 61
檢視網頁 61
開啟頁面 61

設定 62
網絡 62
聲音 64
顯示 64
一般 66

PC 軟件 (LG PC Suite) 70

手機軟件更新 72
手機軟件更新 72

有關本使用者指南 73
有關本使用者指南 73
Trademarks 73
DivX HD 73
Dolby Digital Plus 74

目錄

配件 75

疑難排解 76

常見問題解答 79

安全及有效使用準則

請讀取以下簡易的使用規則。 違反這些準則可能會發生危險或觸犯法律。

如果發生故障，您裝置中內置的軟件工具會建立一份故障日誌。

此工具只會收集與故障相關的數據，例如訊號強度、通話時突然斷線的手機 ID 位置和載入的應用程式。 此日誌只用作協助確定發生故障的原因。 這些日誌會被加密，如您需要退回裝置進行維修，只有已授權的 LG 維修中心才可存取其內容。

無線電波暴露準則

無線電波暴露及特定吸收比率 (SAR) 資訊。

本型號手機 LG-D620k 之設計符合適用的無線電波暴露安全要求。 這些要求乃基於可確保所有使用者安全的科學指引，範圍涵蓋任何年齡與任何健康狀況的人士。

- 無線電波暴露指引的量度單位叫作特定吸收比率或 SAR。 SAR 測試使用標準方法進行，用手機以在所有使用的頻帶最高的合格電源水平傳輸。
- 雖然不同型號 LG 手機的 SAR 水平有所差異，但所有這些手機的設計均符合無線電波暴露的相關指引。
- 國際非離子化輻射保護委員會 (ICNIRP) 建議的 SAR 限制，即平均 10 克組織 2 W/kg。
- 本型號手機在耳朵旁邊使用時的最高 SAR 值為 0.336 瓦特/千克（10 克），佩戴在身上時的最高 SAR 值為 0.332 瓦特/千克（10 克）。
- 在將手機置於耳邊正常使用或使其距身體至少 1.5 厘米遠的情況下，此流動電話符合關於 RF 暴露的指引。 如果隨身攜帶手機，所用的手機套或其他裝置中不可包含金屬物品，並應使手機與身體至少保持 1.5 厘米的距離。 要傳輸數據檔案或訊息時，該裝置與網絡進行有效的連接。 在某些情況下，數據檔案或訊息的傳送可能會延遲，直至這類連接可用為止。 請確保遵守以上的特別距離指示，知道傳輸完成為止。

產品保護及維護

警告

請僅使用經認可適用於此特定型號手機的電池、充電器及配件。 使用其他種類的配件可能會導致手機的認可或保養失效，並可能引致危險。

- 請勿拆開此裝置。 如手機需要維修，請由合資格的維修技師進行維修。
- 根據 LG 的政策，保養期內的維修可能會包括更換部件或主板，這些用於更換的部件或主板可能全新的或是經過翻新的，但其功能與被更換的部件相同。

- 請遠離如電視、收音機或個人電腦等電器產品而使用手機。
- 裝置需遠離發熱來源，如散熱器或烹調器具。
- 請勿摔落手機。
- 請勿讓此裝置遭機械震動或衝擊。
- 請於任何有特殊限制的地方關閉手機。 例如，請勿在醫院內使用手機，否則它可能會對敏感的醫療設備造成影響。
- 請勿以潮濕的雙手對充電中的手機進行操作。 這可能會引致觸電和造成手機嚴重損壞。
- 請不要在易燃材料附近為手機充電，因為充電期間手機會發熱並導致火災。
- 使用乾布清潔裝置表面（請勿使用苯、稀釋劑或酒精等溶劑）。
- 切勿在布質家具上為手機充電。
- 手機應在通風良好的環境中充電。
- 請勿讓此裝置接觸過多煙霧或塵埃。
- 請勿將手機置於信用咭或車票附近，這可能會影響磁帶上的資料。
- 請勿以尖銳物件敲打螢幕，否則可能會對手機造成損毀。
- 請勿將手機暴露於液體或濕氣中。
- 請小心使用配件，例如耳機。 如非必要，請勿觸及天線。
- 如果玻璃螢幕碎裂，請勿使用、接觸或嘗試移除或修補玻璃。 因妄用或不正確使用而導致玻璃螢幕受損並不在保養範圍內。
- 您的手機是一部電子裝置，在正常操作期間，會產生熱力。 在沒有足夠通風的環境下，長時間與皮膚直接接觸可能導致不適或輕度灼傷。 因此，操作期間或操作之後處理手機時，請謹慎使用。

有效地操作手機

電子裝置

所有手機均可能受訊號干擾，這可能會影響手機效能。

- 請勿在未得到批准下在醫療儀器附近使用您的手機。 避免將手機放置在心臟起搏器附近，例如您胸口上的口袋。
- 一些助聽器可能會受手機干擾。
- 手機可能會輕微干擾電視、收音機、個人電腦等。
- 如可能，請在介乎0°C與 40°C的溫度中使用手 機。 將手機曝露在極低或極高的溫度下可能會 導致手機損壞、故障或甚至爆炸。

道路安全

檢查您駕駛時所在地區使用手機的法例及規則。

- 駕駛時切勿使用手持手機。
- 請專心一致駕駛。
- 請視乎駕駛情況，駛離馬路並停泊好汽車後才撥打或接聽電話。
- RF 能量可能會影響車內某些電子系統，例如車載立體聲音響及安全設備等。
- 如果您的汽車配有氣囊，切勿讓已安裝的無線設備或手提無線設備阻擋氣囊。 這可能會導致氣袋無法正常彈出，使其失去保護作用或造成嚴重人身傷害。
- 如果在外出時聆聽音樂，請確保將音量設定至合適水平，以便可以對周圍環境產生警覺。 這在路邊時特別重要。

避免損害您的聽覺

避免聽力受損，請不要長時間在高音量下收聽。

如果長時間以較大音量收聽，可能會對聽覺造成損害。 所以我們建議開啟或關閉手機時，不要將它放於太近耳朵。 我們亦建議將音樂及通話音量設定至合適水平。

- 使用耳機時，如果您未能聽見附近的人說話，或者坐在您身邊的人能聽見您正在聆聽的聲音，就應將聆聽音量調低。

注意：耳機的過大聲音壓力可能導致聽覺受損

玻璃部件

您的手機的部分部件以玻璃製造。 如您的手機摔在堅硬的表面上或受猛烈撞擊，玻璃部件可能會破裂。 如玻璃破裂，請勿接觸或嘗試移除碎片。 請停止使用您的手機，直至授權的服務供應商為您更換玻璃部件。

爆破地區

請勿在進行爆破時使用手機。 請嚴格遵守相關限制、規定或條例。

潛在爆炸氣壓

- 請勿在加油站使用手機。
- 請勿在燃料或化學物質附近使用手機。
- 請勿在放置了手機及配件的汽車車廂運送或擺放易燃氣體、液體或爆炸物。

在飛機上

無線裝置可引致飛機干擾。
- 登機前，請先關掉手機。
- 未經地勤人員批准，請勿在陸上使用手機。

兒童

請將手機放在兒童接觸不到的安全地方。 手機包含微細零件，如果拆開，可能造成哽咽危險。

緊急通話

某些流動網絡可能無法使用緊急通話。 因此，您不應僅倚賴手機作為緊急通話的方式。 請向您本地的服務供應商查詢。

電池資料及保護

- 充電前，您無須完全放電。 跟其他電池系統不同，沒有記憶影響可降低電池的效能。
- 只使用 LG 電池及充電器。 LG 充電器是為將電池壽命擴至最大而設。

- 請勿拆解電池或造成電池短路。
- 請保持電池的金屬接點清潔。
- 當電池不再提供可接受的效能，請更換電池。 電池組在必須更換前可重新充電數百次。
- 如果電池很久沒有使用，重新充電以擴展其用量。
- 請勿直接將充電器暴露於日光下或高濕度環境（如浴室）中。
- 請勿將電池置於過熱或過冷的地方，此類場合可能會損害電池效能。
- 若使用類型不當的電池，則有發生爆炸的危險。
- 請根據製造商的指示來處理廢棄電池。 盡量回收利用。 請勿作為家庭廢棄物處理。
- 如果需要更換電池，請帶同手機前往最近的授權 LG 電子產品服務點或經銷商以尋求協助。
- 請謹記在手機完全充電後從牆壁插座拔出充電器，避免充電器造成不必要的電力損耗。
- 電池的實際壽命將取決於網絡設定、產品設定、使用模式、電池及環境條件。
- 請勿讓如動物牙齒、指甲等尖銳物與電池發生接觸。 這可能會引起火災。

確認聲明

LG Electronics 在此聲明 LG-D620k 這項產品符合 1999/5/EC 指令的基本規定和其他相關條文。 確認聲明副本請見：http://www.lg.com/global/declaration

重要通知

使用手機前請閱讀此重要通知！

在您將手機送往維修或致電服務人員前，請檢查您手機出現的問題有否在此部分描述。

1. 手機記憶體

當手機記憶體的可用空間少於 10%，手機便無法接收新訊息。 您需要檢查您的手機記憶體，並刪除一些數據如應用程式或訊息，以騰出更多可用記憶。

要解除安裝應用程式：

1 點按 [O] > [⊞] > **應用程式**標籤 > **設定** > **一般**標籤 > **應用程式**。
2 當所有應用程式出現後，捲動並選擇您想解除安裝的應用程式。
3 點按**解除安裝**。

2. 充分利用電池壽命

關閉無須持續在背景運行的功能，便能延長電池電量。 您可監控應用程式及系統資源的電池電量消耗。

延長手機電池壽命

- 不使用無線電通訊時將其關閉。 不使用 Wi-Fi、藍牙或 GPS 時，請將其關閉。
- 降低螢幕亮度，並設定較短的螢幕逾時。
- 關閉 Gmail、日曆、通訊錄及其他應用程式的自動同步。
- 您下載的部分應用程式可能會減少電池壽命。
- 使用已下載的應用程式期間，請檢查電池電量。

要檢查電池充電量：

- 點按 [O] > [⊞] > **應用程式**標籤 > **設定** > **一般**標籤 > **關於手機** > **電池**。

電池狀態（充電中或放電中）及電池存量（已充電的百分比）會在螢幕顯示。

要監控與控制使用的電池電力：

- 點按 [O] > [⊞] > **應用程式**標籤 > **設定** > **一般**標籤 > **關於手機** > **電池** > **電池使用狀況**。

螢幕將會顯示電池使用時間。 會告知您的手機自上次連接到電源的時間，或如果目前已連接到電源，便會告知手機最後使用電池電力運作的時間。 畫面會顯示使用電池電力的應用程式或服務，按照用量高至低排序。

3. 在安裝開放原始碼的應用程式及操作系統前

⚠ **警告：**

如果您安裝及使用並非由製造商提供的作業系統，可能會造成您的手機故障。 此外，您的手機不再受保養。

⚠ **警告：**

爲了保護您的手機和您的個人資料，請只從受信任的來源下載應用程式，例如 Play Store™。 如不正確安裝應用程式，手機可能無法正常運作，或出現嚴重錯誤。 您必須從手機解除安裝該等應用程式及其所有相關數據和設定。

4. 使用解鎖圖形

設定解鎖圖形以保護您的手機。 點按 [○] > [ ] > **應用程式**標籤 > **設定** > **顯示**標籤 > **鎖定螢幕** > **選擇螢幕鎖定** > **圖形**。 此會開啟指導您如何繪畫螢幕解鎖圖形的畫面。 您必須新增一個備份 PIN 作為安全措施，以防您忘記您的解鎖圖形。

警告：請於設定解鎖圖形前建立 Google 帳號，並緊記您於新增圖形鎖時所設定的備份 PIN 碼。

⚠ **警告：**

使用圖形鎖定時的注意事項。

請記住您所設定的解鎖圖形，這是非常重要的。 如果錯誤輸入圖形的次數達到 5 次，您將無法存取您的手機。 您有 5 次輸入解鎖圖形、PIN 或密碼的機會。 如果您已使用全部 5 次機會，您可在 30 秒後再次嘗試。

當您記不起您的解鎖圖形、PIN 或密碼：

< 如果您忘記了您的圖形 >

如果您已用手機登入至您的 Google 帳號但 5 次輸入錯誤的圖形，請按**忘記解鎖圖形？** 按鈕。 您將需要使用您的 Google 帳號登入，或輸入您於新增時設定的備份 PIN 碼。

如果您尚未在手機上建立 Google 帳號或忘記備份 PIN，您需要進行硬性重新設定。

< 如您忘記了您的 PIN 碼或密碼 >

如您忘記您的 PIN 或密碼，您需要進行硬體重新設定。

警告：如您進行硬體重新設定，所有使用者應用程式及資料將被刪除。

注意：如您並未登入至您的 Google 帳號，及忘記了您的解鎖圖形，您需要輸入您的備份 PIN。

5. 開啟及切換應用程式

有了 Android，多任務處理變得簡易，您可以同時執行多個應用程式。 開啟新的應用程式時，您無需退出原來的應用程式。 使用及切換數個開啟中的應用程式。 Android 會管理每一個應用程式，根據需要停止及啟動程式，確保閒置的應用程式不會耗用不必要的資源。

1 點按**最近使用的應用程式鍵** □。 將會顯示最近使用的應用程式列表。
2 點按要存取的應用程式。 此舉不會停止之前的應用程式於手機背景上執行。 使用後，請確保點按**返回鍵** ◁ 以結束應用程式。

- 若要停止應用程式，請在最近使用的應用程式列表點擊**工作管理員**，然後點擊**停止**或**停止全部**。
- 若要從最近使用的應用程式列表移除應用程式，請向左或向右滑動應用程式預覽。 若要清除所有應用程式，請點擊**全部清除**。

6. 使用媒體裝置 (MTP) 傳輸音樂、相片及影片

1 點按 ○ > > **應用程式**標籤 > **設定** > **一般**標籤 > **儲存裝置**以查看儲存媒體。
2 使用 USB 線將手機連接到電腦。
3 向下滑動狀態欄再選取**媒體裝置 (MTP)** 選項。
4 開啟電腦上的憶體資料夾。 您可以於電腦上檢視大容量儲存內容，並可將檔案從電腦傳輸至裝置的記憶體資料夾，相反亦然。

7. 將手機直立

如使用其他電話一樣，垂直握住您的手機。 手機備有內置天線。 小心不要刮花或損壞手機背部，這可能會影響效能。

撥打/接聽電話或傳送/接收資料時，避免握住手機的較低部分（因備有天線）。 這樣做可能影響通話品質。

8. 螢幕凍結時

如果螢幕凍結或當您嘗試操作手機時沒有回應：

取出電池，重新插入，然後開啟手機。 如果仍然無法運作，請聯絡服務中心。

了解您的手機

手機概覽

注意：距離感應器
當接收及撥出通話時，距離感應器會感應手機接近您的耳朵，並自動關閉畫面背光照明及鎖上觸控螢幕。 這將延長電池壽命並且防止通話時不小心啟動觸控畫面。

警告：
若將較重物體置於手機上，或坐在手機上會損壞 LCD 和觸控畫面功能。 請勿將保護貼掩蓋 LCD 的距離感應器。 這可能會導致感應器出現故障。

警告

請勿破壞手機上的 NFC 觸控點，它是 NFC 天線的一部分。

安裝 SIM 卡及電池

開始使用您的新手機前，您需要先設定手機。 插入 SIM 卡及電池。

1 要取下電池蓋，請用一隻手握住手機。再用另一隻手，如圖中所示用食指打開電池蓋。

2 如圖所示將 SIM 卡推入相應的插槽。 確保卡片的金屬接觸面朝下。

3 對準手機及電池的金屬接觸面插入電池 (1) 並且按下電池直至發出卡嗒聲，放置到位 (2).

4 將背蓋對準電池盒 (1) 並且按下背蓋直至發出卡嗒聲，放置到位 (2)。

為手機充電

首次使用前請為電池充滿電量。 請使用充電器為電池充電。 經 USB 纜線連接，電腦亦可為電池充電。

⚠ **警告：**
只使用 LG 認可的充電器、電池、及纜線。 使用未經認可的充電器或纜線，可能會導致電池充電緩慢或彈出關於充電緩慢的訊息。 由未經認可的充電器或纜線而導致電池爆炸或裝置損壞並不包括於保養範圍。

咪高風位於手機底部。 插入充電器，並將其連接至電源插座。

注意：
- 第一次充電時必須將電池完全充電，以提高電池壽命。
- 請勿於充電時打開電池蓋。

使用記憶卡

手機支援容量最多為 32GB 的 microSD™ 或 microSDHC™ 記憶卡。 這些記憶咭是特別為流動電話或其它小型裝置所設計的，適合儲存例如音樂、程式、影片、以及相片等多媒體檔案於您的手機上使用。

要安裝記憶卡：

將記憶卡插入插槽中。 並確保金屬接觸面朝下。

要安全取出記憶卡：

點按 > **應用程式**標籤 > **設定** > **一般標籤** > **儲存裝置** > **移除 SD 卡**。

注意：
- 只能使用與手機相容的記憶卡。 使用不相容的記憶咭可能損壞記憶咭與儲存的資料，也可能損害手機。
- 裝置使用 FAT32，任何一個檔案的大小上限為 4 GB。

警告：
手機開啟時，請勿插入或移除記憶卡。 這樣可能會損壞您的記憶卡及手機，而記憶卡內儲存的資料亦可能損壞。

要格式化記憶卡：
您的記憶卡可能已格式化。 如尚未格式化，您必須在使用前將其格式化。

注意：格式化記憶卡時，所有記憶卡上的資料均會被刪除。

1 點按 以開啟應用程式清單。
2 捲動及點按**設定** > **一般標籤** > **儲存裝置**。
3 點按 **移除 SD 卡**。
4 點按**清除 SD 卡** > **清除 SD 卡** > **全部清除**。
5 如您已設定圖形鎖定，輸入圖形鎖定，然後選擇**全部清除**。

注意：如您的記憶卡包含其他內容，記憶卡格式化後的資料夾結構可能會改變，因為所有舊檔案經已刪除。

將螢幕鎖定及解鎖

如果您暫時不使用手機，螢幕會自動關閉及鎖定。 這有助防止意外按鍵，並可節省電池電力。

當您並非使用手機時，按**電源/鎖定鍵** 以鎖定您的手機。

如鎖定手機時正在執行程式，其於鎖定模式時可能仍在執行。 建議先結束所有程式，再進入鎖定模式，避免造成不必要的收費（例如：通話、存取網絡及數據通訊）。

要喚醒手機，按**電源/鎖定鍵** 。 會顯示鎖定畫面。 點按並向任何方向滑動鎖定畫面，以解除鎖定桌面。 您最後檢視的畫面將會開啟。

您的桌面

觸控螢幕提示

以下為如何於手機上瀏覽的一些提示。

點按或觸控 – 用手指單次點按以選擇項目、連結、捷徑及螢幕鍵盤上的字母。

觸摸並按住 – 用手指點按項目並一直不放手，直至有其他動作產生。 例如，要開啟聯絡人的可用選項，觸摸並按住通訊錄上的該聯絡人，直至開啟內容功能表。

拖拉 – 觸摸並按住項目片刻，然後於螢幕上移動手指但不抬起，直至到達目標位置。 您可在桌面拖放項目改變其放置。

撥動或滑動 – 要撥動或滑動，快速移動您的手指以橫跨螢幕表面，並於首次接觸螢幕時不停止動作（否則會變成拖拉項目）。 例如，您可向上或向下滑動螢幕以捲動列表，或向左或向右掃動以瀏覽不同桌面（反之亦然）。

點按兩下 – 輕觸兩下即可放大網頁或地圖。 例如，快速雙點網頁的一部分以調整至適合螢幕的闊度。 檢視圖片時，您亦可以點按兩下以進行縮放。

捏動縮放 – 使用瀏覽器或地圖，或瀏覽圖片時，捏緊或散開食指及拇指以放大或縮小。

旋轉螢幕 – 於許多應用程式及功能表，螢幕的方向會根據裝置本身的方向而作出調整。

注意：

- 要選擇項目，請點按圖示的正中心。
- 請勿過份用力按壓；只需輕力但確切地觸控，觸控螢幕已能感應。
- 使用指尖點按所需選項。 請注意不要點按其他按鍵。

桌面

主桌面是眾多應用程式與功能的起點，讓您可新增如應用程式捷徑、Google小工具等項目，讓您可即時存取資訊及應用程式。 此為預設桌布，點按 [○] 即可從任何功能表中存取。

您的桌面

狀態欄
顯示手機的狀態資訊，包括時間、訊號強度、電池狀態及通知圖示。

小工具
小工具為獨立的應用程式，可在應用程式畫面、桌面或擴展的桌面上存取。 與捷徑不同，小工具顯示為螢幕上的應用程式。

應用程式圖示
點按圖示（應用程式、資料夾等）以開啟並使用應用程式。

位置指示器
指出您正檢視的桌面桌布

快速按鍵區
在任何桌面桌布提供一觸式功能存取。

擴展桌面

作業系統提供多個桌面桌布，讓您有更多空間新增圖示、小工具等。

▶ 在桌面上向左或右滑動手指。

自訂桌面

您可以新增應用程式、小工具或更換牆紙，以自訂您的桌面。

要將項目新增至桌面

1 或點按並按住桌面的空白部分。
2 於新增模式功能表中，選擇您想新增的項目。 您將於桌面上看見已新增的項目。
3 將其拖拉至理想的位置，然後放開手指。

提示！ 要將應用程式圖示從應用程式功能表新增至桌面，觸摸並按住您想新增的應用程式。

要從桌面移除項目

▶ 桌面 > 點按並按住要移除的圖示 > 將圖示拖放至 移除 。

要將應用程式新增為快速按鍵

▶ 從應用程式功能表或桌面上，觸摸並按住應用程式圖示，將其拖動至快速按鍵區。

要從快速按鍵區移除應用程式

▶ 觸摸並按住所需快速按鍵，並其拖動至 移除 。

注意: **應用程式**鍵無法移除。

要在桌面上自訂應用程式圖示

1 觸摸並按住應用程式圖示，直至它從目前位置解除鎖定。 然後將其放於畫面上。 編輯圖示 將會顯示於應用程式的右上角。
2 再次點按應用程式圖示，並選擇所需的圖示設計及大小。
3 點按**確定**以儲存變更。

返回最近使用的應用程式

1 點按 □. 將會顯示最近使用的應用程式清單。
2 點按圖示以開啟應用程式。 或點按 ◁ 以返回上一個畫面。

通知面板

通知提醒您收到新訊息、日曆事件、鬧鐘、以及進行中事項（如正在通話）等。
收到通知時，其圖示會顯示於畫面頂部。 等候通知的圖示會顯示於左方，而 Wi-Fi 或電力等的系統圖示則顯示於右方。

注意：可用選項視乎不同地區或服務供應商而可能有所不同。

開啟通知面板

從狀態欄向下掃動以開啟通知面板

快速切換區

點按每個快速切換按鍵以開啟/關閉。 觸摸並按住按鍵，以存取功能的設定功能表。 要查看更多切換按鍵，向左或右方掃動。 點按 以移除、新增切換按鍵。

QSlide 應用程式

點按 QSlide 應用程式以在您的螢幕上開啟小視窗。 點按 以移除、新增或重新整理 QSlide 應用程式。

通知

連同簡單說明，列出目前的通知。 點按通知以進行檢視。

點按以清除所有通知。

如要關閉通知面板，點按標籤並將其拖動至螢幕頂部。

狀態欄上的指示圖示

於畫面頂部的狀態欄上顯示的指示圖示，報告未接來電、新訊息、日曆事件、裝置狀態等。

顯示於畫面頂部的圖示提供有關裝置狀態的資訊。 以下圖表所列出的為最常用的圖示。

圖示	說明	圖示	說明
	沒有插入 SIM 卡		鈴聲靜音
	沒有可用的網絡訊號		已開啟震動模式
	已開啟飛航模式		電池已完全充電
	已連接至 Wi-Fi 網絡		電池充電中
	已連接有線耳機		手機已通過 USB 線連接至電腦
	正在通話		數據下載
	未接來電		數據上載
	藍牙開啟		GPS 開啟
	NFC 已開啟		正在同步資料
	系統警告		新 Gmail 訊息
	鬧鐘已設定		新 Hangouts 訊息
	新語音留言		選取輸入法

	新文字訊息		Wi-Fi 熱點已啟動
	目前正在播放歌曲		

注意：狀態欄上的圖示位置根據功能或服務可能有所不同。

螢幕鍵盤

您可以使用螢幕鍵盤輸入文字。 螢幕鍵盤在您需要輸入文字時會自動在螢幕上顯示。 要手動顯示鍵盤，只需點按您要輸入文字的文字欄位即可。

使用鍵盤與輸入文字

點擊一次以將您要輸入的下一個字母大寫。 點按兩下即可大寫所有字母。

點按切換至數字及符號鍵盤。

點按以輸入一個空格。

點按以新建一行。

點按以刪除前一字母。

輸入重音字母

當您選擇法文或西班牙文作為文字輸入語言，您可輸入特殊的法文或西班牙文字元（例如：「á」）。

例如，要輸入「á」，點按並按住「a」鍵直至放大鍵放大並顯示其他語言的字元。然後選擇所需的特別字元。

Google 帳號設定

第一次開啟您的手機時，您可以啟動網絡，以登入至您的 Google 帳號，並選擇您想如何使用某些 Google 服務。

要設定 Google 帳號

- 於系統提示的設定畫面登入 Google 帳號。

  或者

- 點按 [○] > [⊞] > **應用程式**標籤 > Google > Gmail > 點按**明白了** > 選擇**新增電郵地址**，以建立新帳戶或新增您的帳戶。

於手機上設定了您的 Google 帳號後，您的手機會自動於網上與您的 Google 帳號進行同步。您的通訊錄、Gmail 訊息、日曆事件及其他資訊會從網上的應用程式及服務同步至您的手機。（這視乎您的同步設定。）

登入後，您可使用 Gmail™ 並在手機上使用 Google 服務。

連接到網絡及裝置

Wi-Fi

使用 Wi-Fi，您可以在無線接入點 (AP) 範圍內高速瀏覽互聯網。 使用 Wi-Fi 享用無線互聯網，而不會收取額外費用。

連接至 Wi-Fi 網絡

要於手機上使用 Wi-Fi，您需要存取無線存取點或「熱點」。 一些存取點乃開放的存取點，您只需簡單連接便可。 其他存取點乃隱藏或使用保安功能；在連接它們前必須先設定您的手機。

要延長電池壽命，請在不使用 Wi-Fi 時將其關閉。

注意：如您脫離了 Wi-Fi 區域或將Wi-Fi 設置為**關閉**，您的移動網絡供應商可能會向您收取額外的移動數據費用。

開啟 Wi-Fi 並連接至 Wi-Fi 網絡

1 點按 [O] > > **應用程式**標籤 > **設定** > **網絡**標籤 > **Wi-Fi**。
2 將 **Wi-Fi** 設定為 **開啟**以開啟並搜尋可使用的 Wi-Fi 網絡。
3 再次點擊 Wi-Fi 功能表以查看已啟用或附近可用的 Wi-Fi 網絡。
   - 已加密的網絡旁邊會有一個鎖形圖示。
4 點按一個網絡進行連接。
   - 如該網絡已加密，手機會提示您輸入密碼或其他憑證。（請向您的網絡管理員查詢詳情）
5 狀態欄上的圖示會顯示 Wi-Fi 狀態。

藍牙

在大部分手機上，您可以透過執行相應應用程式，而非從藍牙功能表，使用藍牙傳送資料。

注意：
- LG 並不會對經藍牙無線功能傳送或接收資料而造成的資料遺失、攔截或誤用負責。
- 隨時確保透過信任且安全的裝置分享與接收您的資料。 若是裝置之間有障礙物，可能需要縮短可運行的距離。
- 某些裝置（特別是經由藍牙 SIG 測試許可的裝置）可能會與您的手機不相容。

開啟藍牙並與藍牙裝置配對您的手機

您必需先將裝置跟另一部機器配對，才可將兩者連接。

1 點按 [○] > > **應用程式**標籤 > **設定** > **網絡**標籤 > 將**藍牙**設定為**開啟**。
2 再次點按**藍牙**功能表。 您將看見顯示您手機及搜尋裝置的選項。 點按**搜尋**以檢視藍牙範圍內的裝置。
3 從列表中選擇您想配對的裝置。

配對成功後，您的裝置就會連接到該裝置。

備註：某些裝置，特別是耳機或免提車內套件，可能設有固定的藍牙 PIN 碼，例如 0000。 如其他裝置設定 PIN 碼，系統將提示您輸入。

經由藍牙無線功能發送資料

1 從適當的應用程式或**下載**中選擇檔案或項目，如通訊錄、日曆事件或媒體檔案。
2 選擇經藍牙傳送資料的選項。

備註：選擇選項的方式會因資料類型而有所差異。

3 搜尋和配對已啟動藍牙的裝置。

透過藍牙無線功能接收資料

1 點按 [○] > > **應用程式**標籤 > **設定** > **網絡**標籤 > 將**藍牙**設定為**開啟**。
2 再次點按**藍牙**功能表，並勾選螢幕頂部的核取方塊，以在其他裝置顯示您的手機。

注意：要選擇您裝置顯示的時間長短，點按 > **可見性逾時**。

3 選擇**接受**以確認您願意從該裝置接收資料 。

享手機的數據連接

USB 共享網絡及可攜式 Wi-Fi 熱點在沒有可用的無線網絡連線可用時是個非常好的功能。您可以透過 USB 線（USB 共享網絡）與單一電腦共享手機的流動數據連接。 您亦可同時與多於一部裝置分享您手機的數據連接。將您的手機作為一個可攜式 Wi-Fi 熱點。

當手機正共享數據連接，狀態欄會顯示圖示，而通知欄內也會顯示進行中的通知。

有關共享網絡及可攜式熱點的最新資訊，包括受支援的操作系統及其他詳情，請瀏覽 http://www.android.com/tether。

要將手機的數據連接以可攜式 Wi-Fi 熱點的形式分享

1 點按 [O] > > **應用程式**標籤 > **設定** > **網絡**標籤 > **網絡共享和網絡** > **Wi-Fi 熱點**切換為啟動狀態。
2 輸入密碼並點按**儲存**。

提示！ 如您的電腦運行的為 Windows 7 或最近發行的 Linux 版本（如 Ubuntu），您將無需為共享網絡而預備您的電腦。 不過，如您正使用較舊的 Windows 版本或其他作業系統，您可能需要預備您的電腦以經 USB 建立網絡連線。 有關支援 USB 共享網絡的操作系統及其設定方式的最新資訊，請瀏覽 http://www.android.com/tether。

要重新命名或保護可攜式熱點

您可以更改手機 Wi-Fi 網絡名稱 (SSID)，並保護手機的 Wi-Fi 網絡。

1 點按 [O] > > **應用程式**標籤 > **設定** > **網絡**標籤 > **網絡共享和網絡** > **Wi-Fi 熱點**。
2 點按**設定 Wi-Fi 熱點**。
   - 會開啟**設定 Wi-Fi 熱點**的對話方塊。
   - 您可以更改其他裝置於掃瞄 Wi-Fi 網絡時看見的**Wi-Fi 名稱 (SSID)**。
   - 您亦可點按**安全**功能表，使用預先共用金鑰 (PSK) 設定 Wi-Fi 受保護存取 2 (WPA2) 的網絡。
   - 如果您點按 **WPA2 PSK** 安全選項，密碼欄會新增至**設立 Wi-Fi 熱點**的對話方塊上。 如果您輸入密碼，使用電腦或其他裝置連接至手機的熱點時則需要輸入該密碼。 您可點按**安全**功能表內的**開啟**，從 Wi-Fi 網絡移除安全性。
3 點按**儲存**。

注意！ 如果您將安全選項設定為開啟，您不能阻止他人於未經授權下使用網上服務，並可能造成額外收費。 要避免未經授權的使用，我們建議您啟用安全選項。

Wi-Fi Direct

Wi-Fi Direct 支援連接 Wi-Fi 功能裝置而無需接入點。 由於 Wi-Fi Direct 需要使用電量較高，建議您使用 Wi-Fi Direct 功能時，將手機插入電源插座。 事先檢查 Wi-Fi 和 Wi-Fi Directed 網絡連接，確保使用者已連接至相同網絡。

SmartShare

您可在媒體匣、音樂應用程式等輕鬆使用 SmartShare 功能。

透過各種裝置盡享一切內容

您可以使用各種裝置分享您手機的內容。
點按 分享音樂中的內容。

Play/Beam

Play：您可透過電視、藍牙揚聲器或其他裝置播放內容。
Beam：您可向支援藍牙及 SmartShare Beam 的裝置傳送內容。

- SmartShare Beam: 透過 Wi-Fi Direct 快速傳送內容。

< Play >

< Beam >

盡享附近裝置的內容

您可透過媒體匣、音樂應用程式盡享附近裝置（**如電腦、NAS（網路附屬存儲裝置）、手機**）的內容。

連接裝置

在同一 Wi-Fi 網絡下連接您的裝置及其他由 DLNA 支援的裝置

搜尋其他裝置

1 點按附近裝置，然後您會看見支援 DLNA 的裝置。
2 連接至該裝置以檢視內容。

使用 USB 纜線進行 PC 連接

了解如何於 USB 連接模式中以USB 纜線將您的裝置連接到 PC。

使用 USB 大容量儲存模式傳音樂、相片及影片

1 使用 USB 數據線將手機連接到 PC。
2 如您並未於 PC 上安裝LG Android 平台驅動程式，您將需手動更改設定。 向下滑動狀態欄再選取**媒體裝置 (MTP)** 選項。
3 現在您可於 PC 上檢視大容量儲存內容及傳輸檔案。

與 Windows Media Player 同步

確保電腦已安裝 Windows Media Player。

1 使用 USB 數據線將手機連接至已安裝 Windows Media Player 的 PC。
2 選擇**媒體裝置 (MTP)** 選項。 連接完成後，電腦會出現彈出式視窗。
3 開啟 Windows Media Player 以同步音樂檔案。
4 在彈出式視窗編輯或輸入您的裝置名稱（如有需要）。
5 選擇並拖放要同步列表的音樂檔案。
6 開啟同步。

- 必須符合以下要求以完成與 Windows Media Player 的同步。

項目	要求
OS	Microsoft Windows XP SP2、Vista 或更高版本
Window Media Player 版本	Windows Media Player 10 或更高版本

通話功能

撥打電話

1 點按 開啟小鍵盤。
2 使用鍵盤輸入號碼 要刪除數字，點按 。
3 點按 以撥打電話。
4 要結束通話，點按**結束**圖示 。

提示！ 要在撥打國際電話時輸入「+」，點按並按住 0+ 。

從通訊錄中撥打電話

1 點按 以開啟通訊錄。
2 捲動聯絡人列表，或點按**搜尋通訊錄**以輸入您想致電的聯絡人名稱的首數個字母。
3 在列表中點按您想致電的 。

調節通話音量

如要在通話期間調整通話音量，按下手機後方的音量提高及降低鍵。

通話期間撥打第二個電話

1 進行第一個通話時，點按 > **新增 通話**，然後撥打號碼。 您亦可點按**通話記錄**以轉至最近撥出號碼列表或點按**通訊錄**搜尋通訊錄並選擇您想進行通話的聯絡人。
2 點按 以撥打電話。
3 兩個通話均會在通話螢幕中顯示。 您的原來通話會被鎖定及保留。
4 點按顯示的號碼，以在通話之間切換。 或點按 **合併通話**以開始電話會議。
5 如要結束進行中的通話，點按**結束**，或按 ，並向下滑動通知列，然後選擇**結束通話**圖示 。

注意：您撥打的每一個通話均需收費。

檢視通話記錄

在桌面點按 並選擇**通話記錄**標籤。
檢視所有已撥、已接和未接來電的完整清單。

提示！
- 點按任何通話記錄項目，檢視通話的日期、時間和持續時間。
- 點按 ，然後點按刪除全部以刪除所有記錄項目。

通話設定

您可設定由供應商所提供如來電轉接及其他特別功能等的手機通話設定。

1 於桌面，點按 。
2 點按 。
3 點按**通話設定**並選擇您想進行調整的選項。

通訊錄

新增通訊錄至您的手機並與您的 Google 帳號或其他支援通訊錄同步的帳號同步。

搜尋通訊錄

1 點按 以開啟通訊錄。
2 點按**搜尋通訊錄**，使用鍵盤輸入該聯絡人姓名。

新增通訊錄

1 點按 ，輸入新聯絡人的號碼，然後點按 。 點按**新增至通訊錄** > **新增通訊錄**。
2 如您想將圖片新增至新聯絡人，點按圖像區域。
選擇**拍照**或**從媒體匣中選取**。
3 點按聯絡資訊類別，然後輸入聯絡人的詳情。
4 點按**儲存**。

最愛通訊錄

您可將常用的聯絡人分類為您的最愛。

新增聯絡人至您的最愛

1 點按 以開啟通訊錄。
2 點按聯絡人以檢視詳情。
3 點按聯絡人名稱右上角的星號。 星號將會變為黃色。

從最愛移除聯絡人

1 點按 以開啟通訊錄。
2 點按**最愛**標籤，然後選擇聯絡人以檢視詳細資料。
3 點按聯絡人名稱右面的黃色星號。 星號會變為原來的顏色並聯絡人將從我的最愛移除。

建立群組

1 點按 以開啟通訊錄。
2 點按**群組**然後點按 。 選擇**新群組**。
3 為新群組輸入一個名稱。 您可為新建立的群組設定鈴聲。
4 點按**儲存**以儲存群組。

注意：若要刪除某群組，指定給該群組的聯絡人將不會遺失。 他們仍將保留在您的通訊錄中。

訊息

手機將文字訊息和多媒體訊息結合在一個易用的功能表中。

警告：LG 訊息應該設定至預設的 SMS 應用程式中。 如沒有設定，部分的訊息功能將會受到限制。

發送訊息

1 點按桌面上的 ，然後點按 以開啟空白訊息。
2 在**收件者**一欄中輸入聯絡人名稱或聯絡人號碼。 當您輸入該聯絡人名稱時，會顯示匹配的聯絡人。 您可點按建議的收件者。 您可新增多於一個聯絡人。

備註：向每個聯絡人所發送的訊息將被個別收取費用。

3 點按**訊息**欄位並開始撰寫訊息。
4 點按 以開啟選項功能表。 選擇**快捷訊息**、**插入表情符號**、**排程傳送**、**新增主旨**及**捨棄**。

提示！ 您可點按 圖示以將您想分享的檔案附加至訊息。

5 點按**發送**以發送訊息。
6 螢幕會顯示回覆。 當您檢視及發送更多訊息，便會建立一個訊息串連。

警告：

- 160 個字元的限制可能會依國家/地區而有所不同，取決於語言及文字訊息的編碼方式。
- 如您新增圖像、影片或音頻檔案至一個文字訊息，它會自動轉換為多媒體訊息，而您亦會被收取相應費用。

訊息串連方塊

與另一方交換的訊息（文字訊息、多媒體訊息）可按時間順序顯示，讓您方便地查看對話總覽。

更改訊息設定

您手機的訊息設置是您可立即發送訊息。 您可因應您的喜好更改設定。

- 點按桌面上的**訊息**圖示，點按 ⋮，然後按**設定**。

電子郵件

您可使用電子郵件應用程式以從例如 Gmail 服務等讀取電子郵件。 電子郵件應用程式支援以下帳號類型：POP3、IMAP 及 Exchange。
您的服務供應商或管理員系統可提供您所需的帳號設定。

管理電郵帳號

於首次開啟**電子郵件**應用程式時，設置精靈將開啟以助您設置電子郵件帳號。
於初始設置後，電子郵件會顯示您收件匣的內容。

要新增其他電郵帳號：

- 點按 [O] > > **應用程式**標籤 > **電子郵件** > 點按 > **設定** > **新增帳號**。

要更改電子郵件設定：

- 點按 [O] > > **應用程式**標籤 > **電子郵件** > 點按 > **設定** > **一般帳號**。

要刪除電子郵件：

- 點按 [O] > > **應用程式**標籤 > **電子郵件** > 點按 > **設定** > 點按 > **移除帳號** > 選擇要移除的帳號 > **移除** > 選擇**是**。

處理帳號資料夾

點按 [O] > > **應用程式**標籤 > **電子郵件** > 點按 然後選擇 **資料夾**。
每個帳戶設有收件匣、寄件匣、已發送及草稿資料夾。 您可能會有更多資料夾，視乎您的帳戶服務供應商所支援的功能而定。

編寫及發送電子郵件

要編寫及發送訊息

1. 在**電郵**應用程式，點按 。
2. 輸入將會收到訊息的收件者的地址。 於輸入文字時，會從您的通訊錄建議符合地址。以分號分隔多個地址。
3. 點按 以新增副本/密件副本，如有需要，點按 以附加檔案。
4. 輸入訊息的文字。
5. 點按 。

提示！ 當新電子郵件到達您的收件匣時，會以聲音或震動進行通知。

相機

開啟相機應用程式，請按 [ ] > [ ] > **應用程式**標籤 > [ ]。

了解取景器

1. **閃光燈** – 選擇 [ ]、[ ] 或 [ ]。
2. **切換鏡頭** – 在後方相機鏡頭和正面相機鏡頭之間做切換。
3. **拍攝模式** – 選擇**標準**、**動態調和 (HDR)**、**超廣角**、 **連環拍攝**、**人面優化**、**時間捕捉拍攝**或**運動**。
4. **設定** - 點按此圖示以開啟設定功能表。
5. **影片模式** – 點按並向下滑動此圖示以切換至影片模式。
6. **擷取鍵** – 點按以拍攝。
7. **媒體匣** - 點按以觀賞您最後拍攝的相片。 此讓您可於相機模式時進入媒體匣並檢視已儲存相片。

注意：於拍攝相片前請確保相機鏡頭清潔。

使用進階設定

在取景器，點按 ⚙ 以開啟進階選項。 於拍攝相片前請確保相機鏡頭清潔。

	要拍攝相片 ，說出以下字詞：Cheese、Smile、Whisky、Kimchi 或 LG。
	決定並控制進入影片的亮度。
	點按以選擇對焦模式。
W6M	選擇相片解像度。 如您選擇高解像度，相片大小將會增加，這代表您可於記憶體中儲存較少相片 。
	ISO 等級決定相機的光線感應器的感光度。 ISO 等級越高，相機對光線越敏感。當您在光線較暗環境下拍照且無法使用補光燈時，此功能非常有用。
AWB	可以設定白平衡。
	可以設定色彩效果。
	設定於按下拍攝鍵後延遲快門。 此功能最適合自拍時使用。
	啟動此功能以使用手機的地理標簽。 **注意：**此功能只可於 GPS 功能啟用或連結網絡時提供。
	選擇快門音。
	設定音量鍵以用作擷取或縮放。
	選擇儲存裝置以儲存圖像。
	打開說明指南，了解功能的運作方式。
	還原所有相機的預設設定。

相機

提示！
- 當您退出相機後，某些設定將返回預設，例如白平衡、色彩效果、計時器及拍攝模式。 拍攝下一張相片前，請先檢查這些設定。
- 設定功能表疊於取景器上，因此當您更改相片品質的設定，您會在設定功能表背後看見預覽圖像的更改。

快速拍照

1 開啟**相機**應用程式，將鏡頭對準您想拍攝的主體。
2 對焦方框將顯示於取景器中心。 您亦可點按螢幕中任何地方以進行對焦。
3 當對焦方塊變藍，則表示相機對焦完成。
4 點按 以拍攝相片。

使用時間捕捉拍攝模式

設定相機在點按 前拍攝五張連續相片，以捕捉錯過的時刻。
1 開啟**相機**應用程式。
2 點按 > **時間捕捉拍攝**。
3 點按 以拍攝相片。
4 要檢視拍攝相片前的一刻，請點按相機螢幕底部的圖像縮圖。
5 選擇您想保留的圖片，然後點按螢幕最上的 。

當拍攝相片後

在相機螢幕底部點按圖像縮圖以檢視您最後拍攝的相片。

	點按以編輯相片。
	點按以立即拍攝新相片。
	點按以將相片發送至其他人或通過社交網絡服務分享相片。

	點按以刪除相片。

提示！ 如您擁有於手機上建立的 SNS 帳號，您可於 SNS 社群分享相片。

注意：如在漫遊期間下載多媒體訊息，則可能需額外收費。

視像攝錄機

了解取景器

1. **閃光燈** – 選擇 、 或 。
2. **切換鏡頭** – 在後置相機鏡頭與前置相機鏡頭之間切換。
3. **設定** - 點按此圖示以開啟設定功能表。
4. **相機模式** – 點按並向上滑動此圖示，以切換至相機模式。
5. **錄製影片鍵** – 點按以開始錄製影片。
6. **媒體匣** - 點按以觀看您最後錄製的影片。 此讓您可於影片模式時進入媒體匣並檢視已儲存影片。

提示！
於錄製影片時，將兩隻手指置於螢幕上並捏緊以使用縮放功能。

使用進階設定

使用取景器，點按 ⚙ 以開啟所有進階選項。

FHD	點按以設定正錄製影片的大小（像素）。
	決定及控制進入鏡頭的亮度。 您可滑動亮度指標：向「-」滑動使影片較暗，或向「+」滑動使影片較亮。
AWB	可以設定白平衡。
	可以設定色彩效果。
	啟動此功能以使用手機的地理標簽。 **注意：**此功能只可於 GPS 功能啟用或連結網絡時提供。
	設定音量鍵以用作錄製或縮放。
	選擇儲存裝置以儲存影片 。
	打開說明指南，了解功能的運作方式。
	還原所有相機的預設設定。

錄製短片

1 開啟**相機**應用程式並滑動**視像攝錄機模式**按鈕。
2 視像攝錄機的取景器會在螢幕上顯示。
3 握住手機，將鏡頭對準拍攝影片的對象。
4 按一下 ● 以開始錄製。
5 REC將於取景器出現，而計時器會顯示影片錄製的長度。
6 點按螢幕上的 ■ 以停止錄製。

提示！

- 點按即可在錄製影片時拍攝圖片。
- 點按即可在錄製影片時暫停。

錄製影片後

透過取景器，在螢幕底部點按影片縮圖，檢視最近拍攝的影片。

	點按以立即拍攝另一段影片。
	點按以將影片發送至其他人或通過社交網絡服務分享影片。
	點按以刪除影片。
	輕按以獲取更多選項。

注意：如在漫遊期間下載多媒體訊息，則可能需額外收費。

Knock Code

當螢幕鎖定時，您可以正確地輕敲指定區域以解除鎖定螢幕。

啟用 Knock Code 功能

1 點按 [ ] > [ ] > **應用程式**標籤 > **設定** > **顯示**標籤 > **鎖定螢幕** > **選擇螢幕鎖定** > Knock Code。

2 然後會開啟指南畫面，引導您選擇解除鎖定次序。 您必須新增一個備份 PIN 碼以作保障，以防您忘記您的解鎖圖形。

QuickMemo+

QuickMemo+ 讓您可建立備忘錄及擷取螢幕截圖。擷取螢幕並進行繪畫，然後以 QuickMemo+ 與家人及朋友分享。

1 點按並向下滑動狀態欄，然後點按 [ ]。

2 從**筆型**、**色彩**、**橡皮擦**選擇所需功能表選項，然後建立備忘錄。

3 點按編輯功能表的 以連同當前螢幕儲存備忘錄。 若要隨時結束 QuickMemo+，請點按 ◁ 。

注意：使用 QuickMemo+ 期間，請使用指尖。 請勿使用指甲。

使用 QuickMemo+ 選項

使用 QuickMenu 時，您可輕鬆使用 QuickMemo+ 選項。

	復原或重新執行。
	輸入文字。
	選擇筆型、厚度、透明和顏色。
	刪除已建立的備忘錄。
	將備忘錄與目前畫面一同儲存至**QuickMemo+**或**媒體匣**。
	點按以選擇**分享**及**紙張樣式**。

檢視已儲存的 QuickMemo+

點按**媒體匣**並選擇 QuickMemo+ 相簿。

QSlide

從任何螢幕加入日曆及更多工具作為您螢幕內的一個視窗。

1		點按以離開 QSlide 並返回至完整視窗。
2		點按以調整透明度。
3		點按以結束 QSlide。
4		點按以調整大小。

1 觸控並向下滑動狀態欄 > 點擊 Qslide 應用程式或當使用支援 QSlide 的應用程式時，點擊 。 功能將持續以小視窗顯示於螢幕上。
2 您可以撥打電話、瀏覽網站或選擇其他電話選項。 當透明度欄並未全滿 時，您亦可使用及點按小視窗下的螢幕 。

注意：QSlide 可同時支援最多兩個視窗。

QuickRemote

QuickRemote 讓您的手機化身成家用電視及機頂盒的通用遙控器。

1 輕觸並向下滑動狀態欄，然後點按 > **新增遠端**。

或者

點按 > > **應用程式**標籤 > QuickRemote > 點按 。

2 選擇裝置的類型和品牌，然後按照螢幕上的說明設定裝置。

3 觸控並向下滑動狀態欄，並使用 QuickRemote 功能。

點按**功能表鍵** ⋮，以選擇**編輯遙控器名稱**、**移動遙控**、**刪除遙控**、**設定**及**說明**。

注意：QuickRemote 與普通遙控的紅外線 (IR) 訊號的操作方式相同。 使用 QuickRemote 功能時，請注意不要遮蓋手機頂部的紅外線感應器。 視乎型號、製造商或服務供應商而定，此功能可能無法支援。

多媒體

媒體匣

開啟**媒體匣**應用程式以檢視圖片和影片的相簿。

1 點按 [○] > > **應用程式**標籤 > **媒體匣**。
您可管理並與媒體匣分享所有圖像及影片檔案。

注意：
- 視乎手機的軟件而定，可能不支援部分檔案格式。
- 視乎檔案編碼而定，某些檔案或不能正常播放。

檢視圖片

啟動媒體匣將顯示可提供的資料夾。 當其他應用程式如電子郵件等保存圖片時，下載資料夾會自動建立以存放該圖片。 同樣地，當擷取螢幕截圖時，會自動建立螢幕截圖資料夾。選擇資料夾以開啟。

圖片會以建立日期排序顯示於資料夾。 選擇圖片以進行全螢幕檢視。 向左或右捲動以檢視下一個或上一個圖像。

放大及縮小

使用以下方法以放大圖像：
- 於任何位置點按兩次以放大。
- 於任何位置將手指分開以放大。 捏緊以縮小或點按兩次以重新放大。

播放影片

影片檔案的 圖示將顯示於預覽中。 選擇影片進行觀看並點按 。 影片應用程式將隨即啟動。

編輯相片

檢視相片時，點按 。

刪除相片/影片

使用以下方法：
- 於資料夾中，點按 並以勾選方式選擇相片/影片，然後點按**刪除**。
- 觀看相片時，點按 。

設定為牆紙

檢視相片時，點按 ⋮ > **將影像設定為**以將圖片設定為牆紙或通訊錄相片。

注意：
- 視乎裝置軟件而定，某些檔案格式並不支援。
- 如果檔案大小超過可用的記憶體，則在開啟檔案時會發生錯誤。

影片

手機配備內置影片播放器，可讓您播放所有最愛的影片。 要存取影片播放器，點按 > **應用程式**標籤 > **媒體匣**。

播放影片

1 點按 > **應用程式**標籤 > **媒體匣**。

2 選擇要播放的影片。

1 ⏸ / ▶	點按以暫停/恢復影片播放。
2 ⏩	點按即可快轉 10 秒。
3 ⏪	點按即可倒轉 10 秒。
4 🔊	點按即可控制影片音量。

❺ /	點按即可鎖定/解除鎖定影片畫面。
❻	點按可設置圖片到您的最愛。
❼	點按以使用 QSlide。
❽	點按以使用 SmartShare 功能分享您的影片。
❾	點按以存取螢幕比例、字幕、分享、設定或詳細資訊。

音樂

手機配備內置音樂播放器，可讓您播放所有最愛的曲目。 如要存取音樂播放器，點按 > > **應用程式**標籤 > **音樂**。

播放歌曲

1 點按 > > **應用程式**標籤 > **音樂**。
2 點按**歌曲**。
3 選擇要播放的歌曲。

1	II / ▶	點按以暫停/繼續播放。
2	⏭	點按以播放的下一首曲目。 觸控並按住以快進。
3	⏮	點按以重新開始播放目前曲目，或播放的上一首曲目。 觸控並按住以倒轉。
4	🔈	點按以顯示音量滑動欄，然後在滑動欄調節播放音量。
5		點按以設定聲音效果。
6		點按以使用 SmartShare 功能分享您的音樂。
7	★	點按以新增歌曲至您的最愛。
8	☰	點按以開啟目前播放列表。
9	⤮	點按以隨機模式播放目前播放列表（以隨機順序播放曲目）。

10		點按以切換重複播放模式，以重複播放所有歌曲、重複播放目前歌曲或關閉重複播放。

要在聆聽音樂時調節音量，按手機左方的向上及向下音量鍵。
點按並按住列表上的任何歌曲， **播放**、**新增至播放列表**、**刪除**、**分享**、**設為鈴聲**、**詳細資料**及**搜尋**選項將會顯示。

新增音樂檔案至手機

開始傳輸音樂檔至手機：

- 使用媒體裝置 (MTP) 傳輸音樂。
- 從無線網絡下載。
- 將手機同步至電腦
- 通過接收檔案。

FM 收音機

您的手機備有內置 FM 收音機，只要作出適當調校，即可隨時隨地收聽您最喜愛的電台。

注意：您需要插入耳機才可收聽收音機。 請將之插入耳機插孔。

實用程式

定鬧鐘

1 點按 ○ > > **應用程式**標籤 > **時鐘** > **鬧鐘** > ＋。
2 設定鬧鐘後，手機會讓您知道距離鬧鐘響起還剩下多少時間。
3 設定**重複**、**暫停時間**、**鬧鐘響時震動**、**鬧鐘提示音**、**鬧鐘音量**、**自動應用程式啟動器**、**拼圖鎖**及**備忘錄**。
4 點按**儲存**。

注意：如要在鬧鐘列表畫面上更改鬧鐘設定，點按**功能表鍵** ⋮ 並選擇**設定**。

使用計算機

1 點按 ○ > > **應用程式**標籤 > **計算機**。
2 觸控數字鍵以輸入數字。
3 對於簡單計算，請點按所需的功能（+、－、×、÷），然後按「=」。
4 如要檢查記錄，請點按 ⋮，然後選擇**計算記錄**。
5 如要進行更複雜的計算，點按 ⋮，選擇**科學計算機**，然後選擇 sin、cos、tan、log 等。

新增事件至日曆

1 點按 ○ > > **應用程式**標籤 > **日曆**。
2 您可在螢幕中找到不同的日曆檢視類型（日、星期、月、年份、議事日程）。
3 點按您想新增事件的日期並點按 ＋。
4 點按**事件名稱**然後輸入事件名稱。
5 點按**位置**以進入地點。 檢查日期，並輸入事件開始及完結的時間。
6 若要重複鬧鐘，請設定**重複**，如有需要亦可設定**提醒類型**。
7 點按**儲存**，將事件儲存至日曆。

語音備忘錄

使用語音備忘錄錄製語音備忘錄或其他聲音檔案。

錄製聲音或語音

1 點按 ○ > > **應用程式**標籤 > **語音備忘錄**。
2 點按 ● 開始錄音。
3 點按 ■ 以結束錄音。
4 點按 ▶ 以聆聽錄音。

注意：點按 ≡ 以存取您的錄音集。 您可聆聽已儲存的錄音。 可供錄音時間可能與實際錄音有所不同。

工作

此工作可使用 MS Exchange 帳戶同步處理。 您可在 MS Outlook 或 MS Office Web Access 中建立工作、重新編輯和刪除工作。

同步處理 MS Exchange

1 在桌面中，點按 ○ > > **應用程式**標籤 > **設定**。
2 點按**一般**標籤 > **帳號及同步處理** > **新增帳號**。
3 點按 Microsoft Exchange 以建立電郵地址和密碼。
4 請確認您已勾選同步工作。

注意：視乎電郵伺服器，可能不支援 MS Exchange。

ThinkFree 檢視器

ThinkFree 檢視器是專業的流動辦公室解決方案，讓使用者隨時隨地透過流動裝置輕鬆檢視不同類型的辦公室文件，包括 Word、Excel 和 PowerPoint 檔案。

點按 [O] > > **應用程式**標籤 > **ThinkFree 檢視器**。

檢視檔案

手機用戶現在可以直接在流動裝置上輕易檢視各式各樣的檔案類型，包括 Microsoft Office 文件和 Adobe PDF。 使用 ThinkFree Office 檢視器檢視文件時，物件和編排會保持與原始文件相同。

Google+

使用此功能以通過 Google 的社交網絡服務與人們保存聯繫。

- 點按 [O] > > **應用程式**標籤 > **Google** > **Google+**。

注意：此功能可能因應地區或服務供應商而未能提供。

語音搜尋

使用此功能以語音搜尋網頁。

1 點按 [O] > > **應用程式**標籤 > **語音搜尋**。
2 當**現在請講話**出現於畫面時說出關鍵字或字詞。 從出現的建議關鍵字中進行選擇。

注意：此功能可能因應地區或服務供應商而未能提供。

下載

使用此功能以查看已通過應用程式下載的檔案。

- 點按 [O] > > **應用程式**標籤 > **下載**。

注意：此功能可能因應地區或服務供應商而未能提供。

LG SmartWorld

LG SmartWorld 提供各式各樣的豐富內容 - 遊戲、應用程式、牆紙及鈴聲 - 讓 LG 手機使用者盡享多姿多采的「流動生活」體驗。

如何從手機進入 LG SmartWorld

1 點按 [○] > > **應用程式**標籤 > 點按 圖示以存取 **LG SmartWorld**。
2 點按登入並輸入LG SmartWord 的電子郵件及密碼。 如您尚未註冊，點按註冊以接收您的 LG SmartWorld 會籍。
3 下載想要的內容。

附註： 如果沒有 圖示該怎麼辦？
1 使用手機網絡瀏覽器，存取 LG SmartWorld (www.lgsmartworld.com) 並選擇您的國家/地區。
2 下載 LG SmartWorld 應用程式。
3 執行並安裝已下載的檔案。
4 點按 圖示以存取 LG SmartWorld。

如何使用 LG SmartWorld

- 參與 LG SmartWorld 每月推廣。

	搜尋內容。
	以類別搜尋內容（例如：遊戲、教育、娛樂等。）

- 嘗試使用簡易的「**功能表**」按鍵，快速尋找您正在找尋的內容。
  設定 - 設定設定檔及顯示。
  登入 – 設定您的電子郵件及密碼。
- 也嘗試其他實用的功能吧。（內容詳細資料螢幕）

注意：LG SmartWorld 或未能在所有運營商或國家中提供。

網絡功能

互聯網

使用此功能以瀏覽互聯網。 無論您身在何處，有何需求，瀏覽器可讓您快速、盡情享受遊戲、音樂、新聞、運動和娛樂資訊，並直接在手機上載入更多內容。

注意： 連接到這些服務和下載內容需繳交額外費用。 請向網絡供應商諮詢收費詳情。

1 點按 [O] > [⊞] > **應用程式**標籤 > **互聯網**。

使用網絡工具列

用手指點按並向上滑動以開啟工具列。

⇦	點按以返回前一頁。
⇨	點按以前往您在目前頁面後連接的一頁。 此等同當您按 [◁] 返回上一頁的相反操作方式。
⌂	點按以前往桌面。
⊞	點按以新增新視窗。
★	點按以存取書簽。

檢視網頁

點按地址欄，如網址並點按**跳至**。

開啟頁面

如要前往新頁面，點按 [1] > [+]。

要前往其他網頁，點按 [2]，向上或向下捲動並點按頁面以進行選擇。

以語音搜尋網站

點按地址欄，點按 🎤，說出關鍵字，然後從所出現的建議關鍵字進行選擇。

注意：此功能可能因應地區或服務供應商而未能提供。

書簽

如要將目前網頁新增為書簽，點按 > **新增至書簽** > **確定**。
要開啟已新增書簽的網頁，點按 並進行選擇。

歷史記錄

點按 > **記錄**以從近期瀏覽的網頁列表中開啟網頁。

Chrome

使用 Chrome 以搜尋資訊及瀏覽網頁。

1 點按 > > **應用程式**標籤 > Chrome。

注意：此功能可能因應地區或服務供應商而未能提供。

檢視網頁

點按地址欄然後輸入網址或搜尋範圍。

開啟頁面

如要前往新頁面，點按 > New tab。

設定

此節提供您可使用手機的系統設定功能表更改的項目總覽。

要存取設定功能表：

點按 [○] > 點按並按住 [□] > **系統設定**。

- 或者 -

點按 [○] > [⊞] > **應用程式**標籤 > **設定**。

網絡

<Wi-Fi>

Wi-Fi – 開啟 Wi-Fi 以連接可使用的 Wi-Fi 網絡。

提示！ 如何取得 MAC 位址

若要在某些設有 MAC 過濾器的無線網絡建立連線，您需要把手機的 MAC 位址輸入到路由器。

您可於以下使用者介面找到 MAC 位址：點按 [○] > [⊞] > **應用程式**標籤 > **設定** > **網絡**標籤 > **Wi-Fi** > [⋮] > **進階的 Wi-Fi** > **MAC 位址**。

<藍牙>

開啟或關閉藍牙無線功能以使用藍牙。

<流動數據>

顯示數據使用並設定流動數據限制。

<通話>

您可設置手機的通話設定，例如來電轉接及服務供應商提供的特別功能。

留言信箱 – 讓您選擇您服務供應商的語音信箱服務。

固定撥號 – 開啟並編譯可從您的手機撥出的號碼列表。 需要使用 PIN2 ，您可以向網絡商索取此 PIN2 。 僅可從手機撥出固定撥號列表包含的號碼。

來電快顯視窗 – 使用相機及影片時顯示來電快顯快顯訊息

拒接來電 – 讓您設定拒接來電功能。 您可選擇來電拒接模式或拒接通話。

用訊息拒絕 – 當您想拒接來電時，使用此功能可以快速發送訊息。

隱私保護工具 – 隱藏來電的致電人名稱及號碼。

來電轉接 – 選擇當忙碌時、無人接聽或無訊號時轉駁所有通話。

自動接聽 – 設定時間後，已連接的免提裝置會自動接聽來電。 選擇**關閉**、**1 秒**、**3 秒**及 **5 秒**。

連接震動 – 於另一方接聽來電時手機震動。

儲存未知號碼 – 通話後將未知號碼新增至通訊錄。

電源鍵結束通話 – 允許您結束通話。

通話限制 – 鎖定來電、撥出或國際通話。

通話時間 – 檢視最後通話、撥出通話、來電及所有通話的通話時間。

其他設定 – 您可變更以下設定：

來電顯示：選擇是否在撥出的電話中顯示您的電話號碼。

來電等候：如已啟動來電等候，當您在通話中接到來電，手機便會通知您（視乎您的網絡供應商而定）。

<共用與連線>

NFC – NFC（近距離無線通訊）是一種無線連接技術，使兩部裝置在幾吋的連接範圍內可傳輸數據。 啟動手機的 NFC 功能後，您的手機可以與其他已啟動 NFC 的裝置交換數據，或讀取海報、貼紙及其他產品智能標記上的資訊。

Android Beam – 開啟此功能時，只要將裝置貼近另一支援近距離通訊 (NFC) 裝置，即可傳送應用程式內容。例如，您可以傳送瀏覽器頁面、YouTube 影片、聯絡人等。 只需將兩部裝置貼近（通常為背面相對）然後點按螢幕。 應用程式會決定需要傳送的項目.。

SmartShare Beam – 開啟以透過 SmartShare Beam 從 LG 手機或平板電腦接收多媒體內容。

媒體伺服器 – 允許您與附近兼容 DLNA 的裝置共享多媒體內容。

LG PC Suite – 勾選此方框即可透過 Wi-Fi 連接使用 LG PC Suite。 請注意，Wi-Fi 網絡應透過 Wi-Fi 連接為 LG PC Suite 進行連接。

<網絡共享和網絡>

USB 網絡連線 – 連接 USB 線與電腦共享互聯網連接。

Wi-Fi 熱點 – 您亦可使用手機，提供流動寬頻連線。 建立熱點並分享連接。

藍牙數據連線 – 不論是否於分享互聯網連線的情況下均可設定手機。

說明 – 點選以檢視關於USB 網絡連線、Wi-Fi 熱點及藍牙數據連線功能的說明資訊。

飛航模式 – 切換至飛航模式後，所有無線通訊會被停用。

備註：使用加密儲存前，必須設定螢幕鎖定 PIN 或密碼。

流動網絡 – 設定數據漫遊、網絡模式和運營商及存取點名稱 (APNs) 等的選擇。

VPN – 顯示您以前配置的虛擬專用網絡（VPN）列表。 允許您新增不同類型的 VPN。

聲音

<基本>

聲音設定檔 – 您可以選擇聲音、僅震動或勿干擾。

音量 – 調整手機的音量設定以配合您的需要及環境。

震動強度 – 讓您可為來電及通知設定震動強度。

<鈴聲 & 震動>

鈴聲 – 設定來電的鈴聲。 您亦可以點按螢幕右上角的 + 以新增鈴 聲。

通知聲音 – 設定通知音。 您亦可以點按螢幕右上角的 + 以新增通知 音。

聲音與振動 – 勾選以設定手機收到來電時有鈴聲及振動。

震動類型 – 讓您設定來電震動類型。

<通知>

勿干擾 – 設定您的手機不顯示通知的時間及模式。 選擇自所有、只限優先或 無。

僅優先級 – 設定為只限優先時可使用特定功能。 鬧鐘永遠優 先。 從 設有日曆活動的應用程式、來電、新訊息或允許的通訊錄中選擇。

日 程表 – 即使設定為所有，只有優先的通知可重複顯示。

鎖定螢幕 – 於鎖定螢幕設定顯示或隱藏所有通知。

應用程式 – 設定應用程式通知。 選擇無以不顯示應用程式通知，重 要性以顯示優先於其他應用程式的通知，請勿打擾僅顯示優先的通 知。

<進階設定>

點選震動 – 點選主頁觸摸按鈕及與撥號盤時震動。

音效 – 可設定以下音效。

撥號鍵盤觸控音 – 勾選以於使用撥號鍵盤時播放音效。

輕觸聲音 – 勾選以於作出螢幕選擇時播放音效。

螢幕鎖定聲音 – 勾選以於鎖定及解鎖螢幕時播放音效。

訊息 / 通話聲音通知 – 開啟讓您的裝置大聲讀出來電者資訊和訊息。

顯示

<桌面>

設定**選擇主頁**、**主題**、**牆紙**、**螢幕效果**、**允許主頁螢幕循環**、**主頁備份與還原**、**說明**。

<鎖定螢幕>

選擇螢幕鎖定 – 設定螢幕鎖定類型以保護手機安全。 開啟一系列畫面，以指導您繪畫螢幕解鎖圖形。 設定**無**、**揮動**、**Knock Code**、**圖形**、**PIN 碼**或**密碼**。

如果您已啟用圖形鎖類型，當您開啟手機或螢幕時，系統會要求您畫出解鎖圖形以解鎖螢幕。

Smart Lock – 設定何時使用信任的裝置（藍牙裝置 或 NFC）或信任的臉孔自動為電話解鎖。 當鎖定畫面設定為 Knock Code、圖形、PIN 及密碼，就可以使用這項功能。

注意：要啓動這個功能，必須開啓智能鎖定。
設定 > 一般 > 安全 > Trust agents > Smart Lock。

螢幕效果 – 設定螢幕效果選項。 從**輕粒子**、**向量圓圈**、**馬賽克**及**蘇打**。

注意：如螢幕鎖定設定為圖形，名稱可能會改變。

牆紙 – 設定您的鎖定畫面牆紙。 從**媒體匣**或**牆紙圖庫中選擇**。
捷徑 – 讓您更改**滑動**鎖定螢幕**的捷徑**。
遺失手機的通訊錄資訊 – 選擇是否在鎖定螢幕上顯示擁有者資訊，以及自訂擁有者資訊。
鎖定時計 – 設定螢幕逾時後自動鎖定的時間。
電源按鈕立即鎖定 – 勾選以在按下電源/鎖定鍵時立即鎖定螢幕。 此設定覆蓋安全鎖計時器的設定。

<主頁觸摸按鈕>

按鈕組合 – 拖動圖示重新安排桌面觸控按鈕。 您可有最多 5 個桌面 觸控按鈕。
顏色 – 設定桌面觸控按鈕的背景顏色。 選擇白色或黑色。.

<字體>

字體類型 – 設定手機及功能表使用的字體類型。
字體大小 – 設定手機及功能表顯示的字體大小。

<其他螢幕設定>

亮度 – 調節螢幕亮度。 為享有最佳的電池性能，請使用最暗的舒適亮度。
自動旋轉螢幕 – 勾選以設定手機根據手機方向（縱向或橫向）而自動旋轉螢幕。
螢幕逾時 – 設定螢幕逾時的時間。
智慧螢幕 – 勾選以在裝置偵測到您的眼睛看著螢幕時，防止螢幕逾時。

<進階設定>

螢幕關閉效果 – 設定螢幕關閉效果。 選擇**復古電視**、**黑洞**或**淡出**。

休眠模式 – 點按切換以切換為開啟或關閉。 開啟讓手機在插在機座時及/或充電時的休眠期間顯示已設定的螢幕保護。 選擇**時鐘**、Google Photos。

一般

<語言與輸入裝置>

使用語言與輸入設定以選擇您手機文字的語言，包括您新增至字典的字詞，並設定您的螢幕鍵盤。

< 位置 >

如要開啟定位服務，您的電話會使用 GPS、Wi-Fi 和流動網絡決定您大概的所在位置。

模式 – 設定位置模式為 **高精度**、**省電**或**僅裝置感應器**。

<帳號及同步處理>

允許應用程式在背景中同步資料，而不論您是否啟動它們。 取消勾選此設定會幫助節省電量，同時亦會降低（但不會消除）數據用量。

<協助工具>

您可使用**協助工具**設定，以設定已安裝到手機的可存取性外掛程式。

<單手操作>

撥號鍵盤 – 勾選後，您可將撥號鍵盤移至裝置的左邊或右邊。 只需點按箭頭，即可將其移至另一邊。

LG 鍵盤 – 勾選後，您可將鍵盤移至裝置的左邊或右邊。 只需點按箭頭，即可將其移至另一邊。

鎖定螢幕 – 勾選後，您可將 PIN 鎖定螢幕鍵盤移至裝置的左邊或右邊。 只需點按箭頭，即可將其移至另一邊。

說明 – 顯示關於單手操作的資訊。

<快速鍵>

當螢幕關閉或鎖定時，按住音量鍵以快速存取應用程式。 點按螢幕右上角的快速鍵 以切換**開啟**或**關閉**。

<安全>

加密手機 – 讓您可加密手機上的資料，以保安全。 每次開機時，您需要輸入 PIN 碼或密碼以解鎖手機。

加密 SD 卡儲存器 – 讓您加密在手機上的 SD 卡資料，以確保安全。

設定 SIM 卡鎖定 – 設定 SIM 卡鎖定或更改 SIM 卡 PIN 碼。

密碼鍵入為可見 – 輸入密碼時，顯示上一個輸入的字元。

裝置管理員 – 查看或撤銷裝置管理員

未知的來源 – 安裝非 Play Store 應用程式的預設設定。

確認應用程式 – 在安裝可能會造成危害的應用程式之前禁止或警告。

儲存裝置類型 - 查看儲存裝置。

可信認證 – 顯示受信任的 CA 憑證。

從儲存裝置中安裝 – 選擇安裝加密憑證。

清除憑證 – 移除所有憑證。

Trust agents – 選擇可於解鎖螢幕上使用的應用程式。

螢幕固定 – 讓應用程式只可於輸入螢幕 PIN 碼時使用。

可以使用的應用程式 – 讓應用程式檢視您的手機的應用程式使用資訊。

<訪客模式>

如您需要將手機借給他人，您可以限制顯示的應用程式。

<手勢>

螢幕開啟/關閉 – 勾選以啟用開啟螢幕，以開啟或關閉螢幕。 快速點按兩下螢幕中心以開啟。 點按兩下狀態欄、桌面的空白位置或鎖定螢幕以關閉螢幕。 為達至最佳效果，使用啟螢幕時請勿移動手機。

靜音來電 – 勾選後，翻轉手機，即可將來電靜音。

延後或停止鬧鐘 – 勾選後，只需翻轉手機，即可延後或停止鬧鐘。

暫停影片 – 勾選後，只需翻轉手機，即可暫停正在播放的影片。

說明 – 開啟關於如何使用裝置的手勢功能的說明指南。

運動感應器校正 – 改善傾斜的精準度及感應器的速度。

<QuickWindow case>

啟動後即可享用特別功能，例如在使用 QuickWindow case 時可於小型視窗上觀看音樂、天氣及時鐘。

<日期及時間>

使用**日期及時間**設定以設定顯示日期的方式。 您還可以使用這些設定來設置您自己的時間和時區，而不只是從流動網絡獲得當前時間。

<儲存裝置>

內存空間 – 檢視內部儲存佔用。

SD 卡 – 檢視 SD 卡的所有可用空間。 點按解除安裝 SD 卡以安全移除。 如您希望刪除 SD 卡上的所有資料，請清除 SD 卡。

<電池>

電池資訊

充電資訊會顯示於電池圖案上，連同剩餘充電量百分比及其狀態。

電池使用狀況 – 顯示使用最多電量的組件及應用程式。

狀態列之電量百分比 – 勾選以在狀態欄的電池圖示旁顯示電池存量百分比。

省電

點按省電模式按鍵以將其切換 至開啟或關閉。點按省電模式以存取以下設定：

省電 – 設定自動啟動省電模式的電池存量百分比。 選擇**啟動省電模式**或 **限制後臺應用程式**。

說明 – 點按以檢視節省電量的提示。

<應用程式>

檢視及管理應用程式。

< 預設訊息應用程式 >

將**訊息**或 Hangouts 設定為預設應用程式。

<備份與重設>

更改設定以管理設定和數據。

備份我的數據 – 設定為在 Google 伺服器上備份您的設定及應用程式數據。

備份帳號 – 設定以備份您的帳號。

自動還原功能 - 設定當應用程式重新安裝在裝置時，還原您的設定及應用程式數據。

LG Backup 服務 – 為裝置上的所有資料備份，以便於數據遺失或取代時可進行還原。

重設為原廠設定 – 將設定重設為原廠預設值並刪除您的所有數據。 如果您用此方法重設您的手機，您會被提示重新輸入您第一次啟動 Android 時所輸入的訊息。

<正在列印>

允許您使用連接至與 Android 裝置相同 Wi-Fi 網絡的印表機，列印某些畫面的內容（如 Chrome 顯示的網頁）。

<關於手機>

檢視法律資訊及檢查手機狀態和軟件版本。

PC 軟件 (LG PC Suite)

「LG PC Suite」電腦軟件助您透過 USB 纜線及 Wi-Fi 將裝置連接至電腦。 連接後，您可以在電腦使用手機的功能。

使用「LG PC Suite」電腦軟件，您可以...

- 在電腦管理並播放媒體內容（音樂、電影、圖片）。
- 向裝置發送多媒體內容。
- 在裝置及電腦上同步數據（日曆、通訊錄及書簽）。
- 備份裝置的應用程式。
- 更新裝置的軟件。
- 從裝置播放電腦的多媒體內容。
- 於裝置上備份及建立並編輯備忘錄

注意：您可使用應用程式的說明功能表，了解如何使用「LG PC Suite」電腦應用程式。

安裝「LG PC Suite」電腦軟件

「LG PC Suite」電腦軟件可從 LG 的網頁下載。

1 移至 www.lg.com，然後選擇所需國家/地區。
2 前往**支援** > **手機支援** > **LG 手機** > **選擇型號**
或
前往**支援** > **手機** > 選擇型號。
3 點擊**使用者手冊及下載**的 **PC 同步處理**，然後點擊**下載**以下載「LG PC Suite」PC 軟件。

「LG PC Suite」PC 軟件的系統需求

- 作業系統：Windows XP (Service pack 3) 32 位元、Windows Vista、Windows 7、Windows 8
- CPU：1GHz 或以上處理器
- 記憶體：512MB 或以上 RAM
- 顯示卡：1024 x 768 解像度、32 位元色彩或以上
- HDD：500 MB 或以上可用磁碟空間（視乎儲存的數據量，可能需要更多可用磁碟空間。）
- 軟體需求：LG 內置驅動程式、Windows Media Player 10 以上版本

備註：LG 內置 USB 驅動程式

安裝「LG PC Suite」電腦軟件時，需要 LG 內置 USB 驅動程式，以連接 LG 裝置和電腦並自動安裝。

將裝置同步至電腦

裝置及電腦的資料可透過「LG PC Suite」電腦軟件輕鬆同步，簡易便利。 通訊錄、日程表及書簽均可作同步處理。

程序如下：

1 將裝置連接到電腦。（使用 USB 線或 Wi-Fi 連接。）
2 將會顯示**選取 USB 連接方法**，然後選擇 **LG 軟體**。
3 連接後，執行程式，然後從畫面左方的類別選擇裝置部分。
4 按**個人資訊**進行選擇。
5 選擇要同步內容的取方塊，然後按**同步**按鈕。

注意：要與電腦同步您的手機，您需要於電腦上安裝 LG PC Suite。 請參閱之前頁數以安裝 LG PC Suite。

將通訊錄從舊裝置移至新裝置

1 使用電腦同步程式，將通訊錄以 CSV 檔案格式從舊裝置匯出至電腦。
2 先在電腦上安裝「LG PC Suite」。 執行該程式，並使用 USB 線將 Android 行動手機連接到電腦。
3 在頂部功能表中，選擇**裝置** > **匯入至裝置** > **匯入通訊錄**。
4 可選擇檔案類型和要匯入檔案的彈出式視窗就會顯示。
5 在彈出式視窗中，點擊**選擇檔案**，Windows Explorer 就會顯示。
6 選擇要在 Windows Explorer 中匯入的聯絡人檔案，然後點擊**開啟**。
7 按一下**確定**。
8 可讓您在裝置和新聯絡人資料中連結聯絡人的**對應欄位**彈出式視窗就會顯示。
9 如果在電腦聯絡人和裝置聯絡人之間出現衝突，請在 LG PC Suite 中做出必要的選擇或修改。
10 點擊**確定**。

手機軟件更新

從互聯網更新 LG 手機軟件

如需更多有關此功能的資訊，請瀏覽 http://www.lg.com/common/index.jsp → 選擇國家/地區及語言。

此功能允許您無須親臨服務中心，即可輕鬆透過互聯網將手機韌體更新為較新版本。 LG 為您的手機推出較新版本的韌體時，此功能才可使用。

手機韌體更新要求用戶加倍留意整個更新過程。請確保繼續進行前，已檢查所有在每一個步驟出現的說明和備註。 請注意，更新期間若移除 USB 數據線，有可能對您的手機造成嚴重損害。

注意：LG 保留權利，可酌情決定只為選定型號提供韌體更新，並不保證所有手機型號均有韌體的較新版本。

透過空中下載 (OTA) 進行 LG 手機軟件更新

此功能讓您無須連接 USB 數據線，亦能輕鬆透過 OTA 將手機軟件更新為較新版本。 LG 為您的手機推出較新版本的韌體時，此功能才可使用。

您應該先在手機上檢查軟件版本：**設定** > **一般**標籤 > **關於手機** > **更新中心** > **軟體更新** > **現在檢查更新**。

備註：內部手機儲存空間的個人資料（包括 Google 帳戶及任何其他帳戶的資訊、系統 / 應用程式數據及設定、任何已下載的應用程式及 DRM 授權），可能會在更新手機軟件的程序期間遺失。 因此，LG 建議您先備份個人資料，才更新手機軟件。 LG 對於個人資料的任何遺失概不責任。

備註：此功能視網路服務供應商、地區或國家而定。

有關本使用者指南

- 使用裝置前，請細心閱讀本手冊。 此可確保您安全及正確運用手機。
- 本指南中某些圖像及螢幕截圖可能與出現於您手機上的有所不同。
- 您的內容可能與最終產品、或來自服務網絡或供應商的軟件有所不同，此內容可能隨時作出更改而不另行通知。 如要獲取本手冊的最新版本，請前往 www.lg.com 瀏覽 LG 網站。
- 手機應用程式及功能可能因應國家、地區或硬件規格而有所不同。 因使用由非 LG 開發的應用程式而導致任何效能問題，LG 概不負責。
- 因編輯出廠設定或修改操作系統軟件而導致的效能或不兼容問題，LG 概不負責。 於任何情況下嘗試對操作系統作出自行改動可導致裝置或應用程式無法運作。
- 於裝置中的軟件、音效、牆紙、圖像及其他媒體乃被授權作為有限度使用。 如您抽取及使用這些項目作為商業用途，則可能已侵犯版權法。 作為用戶，您需要對於非法使用媒體負上全部責任。
- 於使用數據服務例如訊息、上載及下載、自動同步或使用位置服務時可能被收取額外費用。 如要避免產生額外收費，請選擇符合所需的數據計劃。 聯絡您的服務供應商以獲取更額外詳細資料。

Trademarks

- LG 及 LG 標誌乃 LG Electronics 的註冊商標。
- 所有其他商標與版權均屬於其擁有者。

DivX HD

關於 DivX 影片：DivX® 是 Rovi Corporation 的子公司 DivX, LLC 建立的數位影片格式。這是通過嚴格測試可播放 DivX 影片的 DivX Certified® 官方認證裝置。如需進一步資訊以及可用來轉檔成 DivX 影片的軟體工具，請造訪 divx. com。

關於 DivX 隨選影片：此 DivX Certified® 裝置必須註冊，才能播放所購買的 DivX 隨選 (VOD) 影片。若要取得註冊碼，請在裝置設定選單中尋找 DivX VOD 區段。有關如何完成註冊的進一步資訊，請移至 vod.divx.com。

DivX Certified® 可播放畫質高達 720p 的 DivX® 影片，包括付費內容。

DivX®、DivX Certified® 和相關標誌是 Rovi Corporation 或其子公司的商標，經授權許可使用。

Dolby Digital Plus

Dolby Laboratories 授權製造。 Dolby、Dolby Digital Plus 及 double-D 符號乃 Dolby Laboratories 的商標。

注意：開放源碼軟件

若要取得 GPL、LGPL、MPL 或其他公開來源授權的相應原始碼，請瀏覽 http://opensource.lge.com/

所有授權條款、免責聲明及通知均可連同原始碼一同下載。

配件

這些配件可搭配手機使用。（下列配件為可選購配件。）

旅行充電器

立體聲耳機

快速入門指南

數據線

電池

注意：

- 只可使用原裝 LG 配件。
- 若不使用原裝 LG 配件，則保養可能失效。
- 配件可能會視乎不同地區而有所不同。

疑難排解

本章節列出一些使用手機時可能遇上的問題。 您可能需要就某些問題聯絡您的服務供應商，但多數問題均可輕易自行修正。

訊息	可能起因	可用解決方法
SIM 卡錯誤	手機內無 SIM 咭，或不正確地插入 SIM 咭。	確保已正確地插入 SIM 卡。
無網絡連接/失去網絡	訊號較弱或您位於運營商網絡服務範圍外。	移近窗邊或移至空曠範圍。 檢查網絡供應商的覆蓋範圍。
	網絡商套用新服務。	檢查 SIM 卡是否多於 6~12 個月。 如是者，請前往網絡供應商的就近分店更換 SIM 咭。 請聯絡您的服務供應商。
代碼不相符	要更改安全密碼，您需要重新輸入以確認新的安全密碼。	如您忘記密碼，請聯絡您的服務供應商。
	您所輸入的兩個密碼並不相符。	
並無可設定應用程式	服務供應商不支援此功能，或需要註冊使用此功能。	請聯絡您的服務供應商。

訊息	可能起因	可用解決方法
無法撥打電話	撥號錯誤	未授權新網絡。
	新 SIM 卡已插入。	請檢查新的限制。
	已達預付費用上限。	聯絡您的服務供應商，或使用 PIN2 重設限額。
手機無法啟動	按開/關鍵時間太快。	按住開啟/關閉鍵至少兩秒。
	電池並無充電。	為電池充電。 檢查螢幕上的充電指示器。
充電錯誤	電池並無充電。	為電池充電。
	外界溫度太高或太低。	確保於正常溫度下為手機充電。
	接觸不良	檢查充電器是否正常，以及是否正確地連接至手機。
	無電壓	將充電器插入不同的插座。
	充電器故障	更換充電器。
	使用不當充電器	請只使用原裝 LG 配件。
號碼不允許	固定撥號功能已開啟。	檢查設定功能表並關閉功能。
無法接收/發送文字訊息和圖片	記憶體已滿	刪除手機的部分訊息。

疑難排解

訊息	可能起因	可用解決方法
無法開啟檔案	不支援的檔案格式	檢查支援的檔案格式。
接收來電時，螢幕並無開啟。	距離感應器問題	如您使用保護邊或保護殼，請確保其並無遮蓋距離感應器四周位置。 確保距離感應器附近並無任何障礙物。
沒有聲音	震動模式	檢查聲音功能表的設定狀態以確保您並非使用震動或靜音模式。
死機或停止運作。	軟件間歇性問題	透過網站嘗試進行軟件更新。

常見問題解答

類別 子類別	問題	解答
藍牙 藍牙 裝置	透過藍牙可以使用哪些功能？	您可以連接藍牙音訊裝置，例如立體聲/單聲度耳機或車用配件。 另外，當 FTP 伺服器連接到兼容裝置時您可分享儲存在儲存媒體中的內容。
資料 通訊錄 備份	我應如何備份通訊錄？	通訊錄資料可以在您的手機與 Gmail™ 之間同步。
資料 同步	可否設定使用 Gmail 進行單向同步？	僅可以進行雙向同步。
資料 同步	可否同步全部電子郵件資料夾？	收件匣會自動同步。 您可點按**功能表鍵** ⋮ 以檢視其他資料夾，然後點按**資料夾**以選擇資料夾。
Google™ 服務 Gmail 登入	每當我想存取 Gmail，是否也需要登入 Gmail？	當您已登入 Gmail 後，無需再次登入。
Google™ 服務 Google 帳戶	可否篩選電郵？	不可以，手機不支援電郵篩選。
手機功能 電郵	編寫電郵時，如果我執行其他應用程式會發生什麼？	您的電郵會自動被儲存為草稿。
手機功能 鈴聲	如果我需要使用 MP3 檔案作為鈴聲，是否有檔案大小限制？	沒有檔案大小限制。
手機功能 訊息時間	我的手機沒有顯示 24 小時以上的訊息接收時間。如何查看時間？	開啟對話，按住所需訊息。 然後點按**詳細 資料**。

類別 子類別	問題	解答
手機功能 導航	可否在手機上安裝其他導航應用程式？	可以安裝和使用所有 Play Store™ 上可提供的應用程式以及與硬體兼容的應用程式。
手機功能 同步	可否從我全部的電郵帳戶同步通訊錄？	僅可同步 Gmail 和 MS Exchange 伺服器（公司電郵伺服器）中的通訊錄。
手機功能 等候與暫停	能否使用號碼中的等候與暫停來儲存聯絡人？	如果您傳輸的聯絡人在號碼中存有 W & P 功能，則無法使用該等功能。 您需要重新儲存每個號碼。 如何使用等候與暫停儲存： 1. 從桌面按**手機**圖示 。 2. 撥號後點按 **功能表鍵** 。 3. 點按**新增 2 秒暫停功能**或**新增等待功能**。
手機功能 安全	手機有什麼安全性功能？	您可設定手機於被存取或使用前要求輸入解鎖圖形。
手機功能 解鎖 圖形	我如何建立解鎖圖形？	1. 從桌面按**最近使用的應用程式鍵** 。 2. 點按**系統設定** > **顯示**標籤 > **鎖定螢幕**。 3. 點按**選擇螢幕鎖定** > **圖形**。 首次進行此步驟時，將會出現關於建立解鎖圖形的簡短教程。 4. 繪畫圖形一次以設定，然後再繪畫一次以確認。 **使用圖形鎖定需注意事項。** 請記住您所設定的解鎖圖形，這是非常重要的。 如果錯誤輸入圖形的次數達到 5 次，您將無法存取您的手機。 您有 5 次輸入解鎖圖形、PIN 或密碼的機會。 如果您已使用全部 5 次機會，您可在 30 秒後再次嘗試。（或如您預設備份 PIN 碼，您可使用備份 PIN 碼以解鎖圖形。

類別 子類別	問題	解答
手機功能 解鎖 圖形	如果我忘記了解鎖圖形而且沒有在手機上建立 Google 帳戶，我應該怎麼辦？	**如果您忘記了您的圖形：** 如果您已用手機登入 Google 帳號，但 5 次輸入錯誤的解鎖圖形，點按位於螢幕底部的忘記解鎖圖形按鍵。 然後，您需要登入您的 Google 帳戶以解鎖您的手機。 如您沒有無於手機上建立 Google 帳號或您已忘記該帳號，您需進行硬性重新設定。 **注意：若執行出廠設定，所有用戶應用程式及用戶數據將被刪除。 請記住先備份所有重要的數據，才進行原廠重設。**
手機功能 記憶體	記憶體已滿時我會被告知嗎？	是，您將會收到通知。
手機功能 語言支援	我可否更改手機語言？	手機具有雙語功能。 若要變更語言： 1. 從桌面點按**最近使用的應用程式鍵** □ ，然後點按**系統設定**。 2. 點按**一般**標籤 > **語言與輸入裝置** > **語言**。 3. 點按所需語言。
手機功能 VPN	我如何設定 VPN？	VPN 存取設定根據公司而有所不同。 若要從手機設定 VPN 存取，您必須從供應商的網絡管理員取得詳細資料。
手機功能 螢幕逾時	我的螢幕在 15 秒後關閉了。 我如何變更背景燈關閉的時間？	1. 從桌面按**最近使用的應用程式鍵** □ 。 2. 點按**系統設定** > **顯示**標籤。 3. 點按**螢幕逾時**。 4. 點按所需的螢幕背景燈逾時時間。
手機功能 Wi-Fi 及流動網絡	當 Wi-Fi 及流動網絡均為可用時，手機將會使用哪一項服務？	使用數據時，您的手機將預設為 Wi-Fi 連接（如果手機的 Wi-Fi 連接設定為開啟）。 不過，手機切換服務時您將不會收到通知。 若要知道正在使用哪一個數據連線服務，檢視螢幕上方的流動網絡或 Wi-Fi 圖示。

常見問題解答

類別 子類別	問題	解答
手機功能 桌面	可否從桌面移除應用程式？	可以。 只需點按並按住圖示，直至畫面右上方出現垃圾桶圖示。 然後，不要放開手指，將圖示拖放至垃圾桶。
手機功能 應用程式	我下載了一個應用程式，它導致大量錯誤發生。 我如何移除它？	1. 從桌面按**最近使用的應用程式鍵** □。 2. 點按**系統設定** > **一般標**籤 > **應用程式** > **已下載**。 3. 點按應用程式，然後點按**解除安裝**。
手機功能 充電器	可否在沒有安裝所需 USB 驅動程式的情況下透過 USB 數據線為手機充電？	可以，不論有否安裝所需驅動程式，手機亦能透過 USB 數據線充電。
手機功能 鬧鐘	可否在鬧鐘使用音樂檔案？	可以。 在鬧鐘設定中，選擇歌曲作為鬧鐘提示音。
手機功能 鬧鐘	如手機已關機，我的鬧鐘會否響鬧？	不會，不支援此功能。
手機功能 鬧鐘	如果鈴聲音量設定為震動，我仍會聽到鬧鐘 響鬧嗎？	即使在此情況，您的鬧鐘仍被設定為響鬧。
恢復的方法 硬性重新設定（出廠設定）	如何無法存取手機的設定功能表，應如何執行出廠設定？	如您的手機並無還原至其原始狀態，請使用強制重新設定（原廠設定）以初始化手機。

简体中文

用户手册

- 屏幕显示和说明可能与手机实物上看到的不同。
- 本手册中的部分内容可能不适用于您的手机，具体视您手机的软件和服务提供商而定。 本指南的所有信息如有更改，恕不另行通知。
- 此手机采用触摸屏键盘，不适合视障人士使用。
- 版权所有 ©2015 LG Electronics, Inc。保留所有权利。 LG 和 LG 徽标是 LG 集团及其相关实体的注册商标。 所有其他商标是其各自所有者的财产。
- Google™、Google Maps™、Gmail™、YouTube™、Hangouts™ 和 Play Store™ 是 Google, Inc. 的商标。

目录

关于安全有效使用手机的准则..... 5

重要注意事项..... 10

开始了解您的手机..... 14
- 手机概览..... 14
- 安装 SIM 卡和电池..... 16
- 充电..... 18
- 使用存储卡..... 19
- 屏幕锁定和解锁..... 20

主屏..... 21
- 触摸屏提示..... 21
- 主屏..... 21
  - 扩展主屏..... 22
  - 自定义主屏..... 22
- 返回到最近使用的应用程序..... 23
- 通知面板..... 23
  - 打开通知面板..... 24
  - 状态栏上的指示器图标..... 25
- 屏上键盘..... 26
  - 输入带注音的字母..... 26

Google 帐户设置..... 27
- 设置您的 Google 帐户..... 27

连接到网络和设备..... 28
- WLAN..... 28
  - 连接 WLAN 网络..... 28
  - 打开 WLAN 并连接 WLAN 网络..... 28
- 蓝牙..... 28
- 享手机的数据连接..... 29
- WLAN Direct..... 30
- SmartShare..... 31
- 体验附近设备上的内容..... 31
- 使用 USB 数据线的 PC 连接..... 32

通话..... 33
- 拨打电话..... 33
- 呼叫联系人..... 33
- 调节通话音量..... 33
- 拨打第二个电话..... 33
- 查看通话记录..... 34
- 通话设置..... 34

联系人..... 35
- 搜索联系人..... 35
- 添加新联系人..... 35
- 按收藏夹归类联系人..... 35
- 创建群组..... 36

信息..... 37
- 发送信息..... 37
- 线程框..... 37
- 更改信息设置..... 37

电子邮件..... 38
- 管理电子邮件帐户..... 38
- 使用帐户文件夹..... 38
- 撰写和发送电子邮件..... 38

相机..... 39
- 了解取景器..... 39
- 使用高级设置..... 40
- 快速拍照..... 41
- 使用时间捕捉拍摄模式..... 41
- 拍照后..... 41

摄像机..... 43
- 了解取景器..... 43
- 使用高级设置..... 44

快速录制视频 44
录制视频后 45

功能 46
轻敲代码 46
QuickMemo+ 46
使用 QuickMemo+ 选项 47
查看保存的 QuickMemo+ 47
QSlide 48
Quick遥控 48

多媒体 50
图片库 50
查看图片 50
播放视频 50
编辑照片 50
删除照片/视频 50
设置为墙纸 51
视频 51
播放视频 51
音乐 52
播放歌曲 52
将音乐文件添加至手机 53
FM 收音机 54

实用工具 55
置闹钟 55
使用计算器 55
将事件添加到日程表中 55
录音机 56
录制声音或语音 56
任务 56
ThinkFree 查看器 57
Google+ 57
语音搜索 57
下载 57
LG SmartWorld 58
如何从手机访问 LG SmartWorld ... 58
如何使用 LG SmartWorld 58

网络 59
互联网 59
使用 Web 工具栏 59
查看网页 59
打开网页 59
使用语音搜索网络 60
书签 60
历史记录 60
Chrome 60
查看网页 60
打开网页 60

设置 61
网络 61
声音 63
显示 64
常规 65

PC 软件 (LG PC Suite) 69

手机软件更新 71
手机软件更新 71

关于此用户手册 72
关于此用户手册 72
商标 72
DivX HD 72
Dolby Digital Plus 73

目录

配件..... 74

故障排除..... 75

常见问题解答..... 78

关于安全有效使用手机的准则

请阅读以下简单的准则。 违反这些准则可能造成危险或者触犯法律。

如果发生故障，设备内置的软件工具会收集故障记录。

此工具仅收集特定于故障的数据，如信号强度、呼叫突然掉线时的 cell ID position 和加载的应用程序。 该记录仅用于帮助确定故障原因。 该类记录已加密，如果您需要将退回设备以进行维修，仅 LG 授权维修中心可查看它们。

暴露在射频能量之下

无线电波暴露和“特定吸收率”(SAR) 信息。

此款 LG-D620k 型手机已设计为遵守有关适用的无线电波暴露安全要求。 此要求基于相关的科学准则，其中包括为确保所有人员（无论年龄和健康状况）安全而设计的安全裕量。

- 无线电波暴露准则采用一种称为“特定吸收率”(SAR) 的测量单位。 SAR 测试是在所有用到的频带中以手机的最高认可功率电平进行发射时使用标准化方法执行的。
- 不同的 LG 手机型号可能有不同的 SAR 能级，但它们均符合相关的无线电波暴露准则。
- 国际非游离辐射防护委员会 (ICNIRP) 建议的 SAR 上限值为：每 10g 重的人体组织吸收的能量平均值不超过 2 W/kg。
- 经对该型号手机进行的测试得知，人耳能够承受的最高 SAR 值为 0.336 W/kg（10 克），戴在身体上时，其值为 0.332 W/kg（10 克）。
- 本设备在靠近耳朵的正常使用位置使用或放置在距人体至少 1.5 厘米的位置时符合 RF 暴露标准。 当使用便携盒、皮带夹或皮套进行身体佩戴操作时，不得包含金属并且产品应至少距身体 1.5 厘米。 为了发送数据文件或信息，此设备需要高质量的网络连接。 在某些情况下，数据文件或信息的发送可能被延迟，直到有这样的连接可用。 确保遵照以上间隔距离说明直到完成发送。

产品保养和维护

警告

仅使用经核准为用于此特定手机型号的电池、充电器和配件。 使用任何其它类型可能导致适用于此手机的许可或保修失效，并可能造成危险。

- 不要拆解本机。 当需要维修时，请将手机送往合格的服务技术人员处。
- 保修（由 LG 决定）可能包括使用新的或返修的更换部件或板，只要其功能与更换的部件等效。

- 远离诸如电视、收音机或个人计算机之类的电器。
- 远离诸如暖气片或厨灶之类的热源。
- 小心不要让手机摔落。
- 不要让手机受到机械振动或撞击。
- 在任何有特殊条例要求的区域关闭手机。 例如，请勿在医院使用手机，因为它可能影响敏感的医疗装置。
- 手机充电时，请勿用湿手操作手机。 这可能会导致电击或手机严重受损。
- 请勿在靠近易燃物体的位置充电，因为手机可能因加热而引发火灾。
- 使用干布清洁手机外壳（不要使用如苯、稀释剂或酒精之类的溶剂）。
- 如果手机置于柔软物体之上，请不要充电。
- 应将手机放在完全通风的位置充电。
- 不要在烟雾或灰尘过多的环境中使用或存放手机。
- 不要将手机放在信用卡或卡式车票旁边，它可能会影响磁条上的信息。
- 不要用尖锐物体敲击屏幕，这可能会损坏手机。
- 不要将手机暴露在液体或潮气中。
- 谨慎使用诸如耳机之类的配件。 在不必要的情况下，不要触摸天线。
- 请勿使用、触摸或试图取下或修复破碎或破裂的玻璃。 由于滥用或误用造成的玻璃显示屏损坏不在保修范围内。
- 本手机为正常使用过程中会发热的电子设备。 在缺乏足够通风的条件下过长时间直接接触皮肤时，可能导致不舒服或轻微灼伤。 因此，在操作的过程中或之后立即处理您的手机时，应特别小心。
- 如果手机变湿，请立即拔下其电源插头，并让它完全晾干。 切勿试图使用烤炉、微波炉或电吹风等外部热源加快干燥处理。
- 潮湿手机内的液体会改变手机内产品标签的颜色。 由于接触液体而对设备造成的损坏不在保修范围内。

有效的手机操作

电子设备

所有手机都可能受到干扰，这种干扰会对性能造成影响。

- 在未经允许的情况下，不得在医疗装置附近使用手机。 不要将手机放在心脏起搏点上，即胸前的口袋内。
- 手机可能会对某些助听器造成干扰。

- 微弱的干扰可能会影响电视、收音机、个人计算机等。
- 如果可能，请在介于 0ºC 与 40ºC 温度之间使用手机。将手机放置在过低或过高的温度的环境下可能会导致损坏、故障、甚至爆炸

行车安全

查阅有关在驾驶时使用手机的本地法律法规。

- 不要在驾驶时使用手持式手机。
- 将注意力完全集中在驾驶上。
- 如果行驶条件需要，请在拨打或接听电话之前将车辆驶离道路并停车。
- 射频能量可能影响车辆内的电子系统，例如立体声音响、安全设备等。
- 当车辆配备气囊时，不要让安装的便携式的无线设备阻挡气囊。 这样做可能因性能不当而导致气囊无法释放或导致严重受伤。
- 如果您在外出时使用耳机收听音乐，请确保将音量设置为合理的音量级别，以便注意周围的情况。 在靠近马路时，尤其要注意这一点。

防止损伤您的听力

为防止听力可能受损，请勿长时间高音量倾听。

如果您长时间置于高音环境中，那么您的听力可能会遭到伤害。 因此，我们建议您在开机或关机时不要将手机置于耳边。 同时，我们还建议您将音乐和通话音量设置为合理的音量级别。

- 使用耳机时，如果您不能听到附近的人说话，或者坐在您旁边的人能听到您在听的内容，则将音量调低。

注意:耳机声音压力过大可能导致听力受损。

关于安全有效使用手机的准则

玻璃部分

手机部分为玻璃制。 如果手机摔落到坚硬表面或受到强烈撞击，玻璃会破碎。 如果玻璃破碎，请勿触摸或尝试取出玻璃碎片。 停止使用手机，在授权的服务提供商处更换玻璃。

爆破区域

不要在正进行爆破的地区使用手机。 请依照有关限制，并遵守任何规章或规定。

易爆环境

- 不要在加油站内使用手机。
- 不要在靠近燃料或化学制品处使用手机。
- 不要在放有手机和配件的车厢内运输或存放可燃气体、液体或爆炸品。

在飞机上

无线设备可能对飞机造成干扰。

- 登机前，请关机。
- 未经机务人员允许，不得在地面上使用手机。

儿童

将手机放在儿童接触不到的安全地方。 手机中包含细小零件，如果脱落可能导致窒息危险。

紧急电话

并非在所有手机网络中均可使用紧急电话。 因此，您不应仅依赖于手机的紧急呼叫功能。请向本地的服务提供商核准。

电池信息及保养

- 您无需在再次充电前对电池进行完全放电。 与其它电池系统不同，本机电池不具有可能影响电池性能的记忆效应。
- 只能使用 LG 电池和充电器。 LG 充电器设计为最大程度地延长电池使用寿命。
- 不要拆解电池或将其短路。
- 当电池不再提供合乎要求的性能时，请更换电池。 在需要更换之前，电池组可以反复充电数百次。
- 如果很长一段时间都没用过电池，请将电池再次进行充电以保持最佳使用状态。
- 不要将电池充电器暴露在直射阳光下，也不要在诸如浴室之类的高湿环境中使用。
- 不要将电池存放在过热或过冷的地方，这可能损害电池的性能。
- 如果用不适当的电池进行替换，可能会有爆炸危险。
- 请按制造商的说明处置用过的电池。 如果可能，请循环使用电池。 不要象处理家用废物一样处理电池。
- 如果要更换电池，请将其携带至 LG Electronics 授权服务点或经销商处以寻求帮助。
- 手机充好电后，请务必将充电器从墙上插座拔下，以避免不必要的耗电。
- 实际的电池寿命将取决于网络配置、产品设置、使用方式、电池和环境条件。
- 确保没有细尖的物体，如动物牙齿、指甲等进入手机内触碰电池。 这可能引发火灾。

确认声明

特此，LG Electronics宣布此 LG-D620k产品符合指令 1999/5/EC的核心要求和其它相关规定。 有关《确认声明》的副本，请访问 http://www.lg.com/global/declaration

重要注意事项

使用手机前，请阅读本用户指南！

请检查以查看本节是否介绍了您手机遇到的任何问题，然后再将手机拿去维修或者致电给服务代表。

1. 手机内存

当手机内存可用空间小于 10% 时，您的手机无法收到新信息。 您需要检查手机内存并删除一些数据（如应用程序或信息），以有更多内存可用。

卸载应用程序：

1 按 [O] > [⊞] > **应用程序**选项卡 > **设置** > **常规**选项卡 > **应用程序**。
2 所有应用程序都显示后，请滚动并选择要卸载的应用程序。
3 轻触**卸载**。

2. 优化电池使用寿命

通过禁用无需在后台持续运行的功能来延长电池电量可支持的时间。 您可以监视应用程序和系统资源如何消耗电池电量。

延长手机电池的使用寿命：

- 如果您未使用无线电通信，请关闭它。 如果不使用 WLAN、蓝牙或 GPS，请将其关闭。
- 调低屏幕亮度，设置较短的屏幕待机时间。
- 关闭 Gmail、日历、联系人及其他应用程序的自动同步。
- 您下载的一些应用程序可能会消耗电池电量。
- 使用下载的应用程序时，检查电池电量水平。

检查电池电量水平：

- 按 [O] > [⊞] > **应用程序**选项卡 > **设置** > **常规选**项卡 > **关于手机** > **电量使用情况**。

电池状态（正在充电或正在放电）和电池电量（充电百分比）显示在屏幕顶部。

监视并控制电池电量的使用情况：

- 按 [O] > [⊞] > **应用程序**选项卡 > **设置** > **常规选项卡** > **关于手机** > **电量使用情况** > **电量使用情况**。

电池使用时间将显示在屏幕上。 它告诉您自上次连接到电源以来的时间，或者连接到电

源后在电池电源上运行的时间。 屏幕上还显示了使用电池电源的应用程序或服务，从最大量到最小量。

3. 安装开源应用程序和操作系统之前

⚠ **警告**

如果安装并使用非制造商提供的操作系统，可能导致手机无法正常工作。 此外，您的手机也不再享受保修。

⚠ **警告**

为保护您的手机和个人数据，请只从信任的来源（如 Play Store™）下载应用程序。 如果手机上存在未正确安装的应用程序，手机可能无法正常工作，甚至可能发生严重错误。 您必须从手机中卸载那些应用程序及其所有关联的数据和设置。

4. 使用解锁图案

设置保护手机的解锁图案。 按 [O] > [⋯] > **应用程序**选项卡 > **设置** > **显示**选项卡 > **锁定屏幕** > **选择屏幕锁定** > **图案。** 此时将打开一个屏幕，指导您如何绘制屏幕解锁图案。 您必须创建一个备份 PIN 以作为安全措施，以免忘记了解锁图案。

注意：设置解锁图案之前，请先创建一个 Google 帐户，并记住创建图案锁定时设置的备份 PIN。

⚠ **警告**

使用图案锁定时的预防措施。

请务必记住您设置的解锁图案。 如果有 5 次使用不正确的图案，您将无法访问您的手机。 您有 5 次机会输入解锁图案、PIN 或密码。 如果您用完 5 次机会，需等待 30 秒方可再次尝试。

在无法记起解锁图案、PIN 或密码时：

<如果您忘记图案>

若要在手机上登录 Google 帐户，但连续 5 次输错图案，请轻触**忘记了图案？** 按钮（屏幕底部）。 随后，您需要使用 Google 帐户登录或输入创建图案锁定时设置的备份 PIN。如果未在手机上创建 Google 帐户或者忘记了备份 PIN，则需要执行硬重置。

<如果您忘记 PIN 或密码>

如果您忘记 PIN 或密码，您需要进行一次硬重置。

注意：如果执行硬重置，所有用户应用程序和用户数据都将被删除。

备注：如果您未登录 Google 帐户且忘记了解锁图案，您需要输入备份 PIN。

5. 打开和切换应用程序

多任务可在 Android 中轻松实现，您可同时运行多个应用程序。 打开其他应用程序之前，无需退出当前应用程序。 使用多个打开的应用程序，并在这些应用程序之间切换。Android 管理各个应用程序、根据需要停止和启动应用程序，从而确保闲置应用程序不会不必要地耗费资源。

1 轻触**近期任务键** □。 屏幕将显示最近使用的应用程序列表。
2 轻触要访问的应用程序。 这不会停止在手机后台运行的上一个应用程序。 确保在使用应用程序后轻触**返回键** ◁ 退出。

- 要停止应用程序，从最近的应用程序列表中轻触**任务管理器**，然后轻触**停止**或**全部停止**。
- 要从最近的应用程序列表中删除应用程序，向左或向右滑动应用程序预览。 要清除所有应用程序，轻触**全部清除**。

6. 媒体设备（MTP）传输音乐、照片和视频

1 按 ○ > ⋯ > **应用程序**选项卡 > **设置** > **常规**选项卡 > **存储**以查看存储媒体。
2 使用 USB 数据线将手机连接到 PC。
3 向下滑动状态栏，然后选择**媒体设备（MTP）**选项。
4 打开 PC 上的存储文件夹。 您可查看 PC 上的大容量存储内容，并能在 PC 和设备存储文件夹之间相互传输文件。

7. 向上持握手机

将手机像普通手机一样竖直持握。 您的手机具有内置天线。 请注意不要刮伤或损坏手机背面，这可能影响性能。

拨打/接听电话或发送/接收数据时，避免持握天线所处的手机下部。 这样做可能会影响通话质量。

8. 屏幕冻结时

如果屏幕冻结或您尝试操作时手机无响应：

卸下电池，将它重新插入，然后打开手机。 如果这仍不起作用，请联系服务中心。

开始了解您的手机

手机概览

听筒

近程传感器

主屏键
从任何屏幕返回到主屏。

返回键
- 返回上一个屏幕。
- 使用后退出应用程序。

前置相机镜头

近期任务键
显示近期使用的应用程序。如果您触摸并按住该键，将打开可用选项菜单。

备注：近程传感器
在接听及拨打电话时，若手机位于耳旁，一旦感应到物体，此近程传感器将自动关闭背景灯并锁定触摸屏。 这样有助于延长电池寿命，并避免在通话期间无意中激活触摸屏。

警告
在手机上放置重物或坐在手机上可能会损坏手机的 LCD 屏幕及触摸屏的功能。 不要在 LCD 近程传感器上使用保护膜。 这可能会影响传感器的感应度。

警告

注意不要损坏手机上的 NFC 触控点，这是 NFC 天线的一部分。

安装 SIM 卡和电池

在开始浏览新手机之前，您需要先进行设置。 插入 SIM 卡和电池。

1 要卸下电池盖，请用一只手紧握手机。 再用另一隻手，如图中的拇指手取下电池覆盖。

2 将 SIM 卡滑入插槽中，如图所示。 确保卡的金色接触区域面朝下。

3 对齐手机与电池上的金色接触区域 (1)，向下按电池直到卡入到位 (2)，以插入电池。

4 在电池仓上对齐电池盖 (1)，向下按直到其卡入到位 (2)。

充电

第一次使用电池前，请为电池充电。 使用充电器为电池充电。 可以通过 USB 数据线将设备连接到计算机，使用计算机为设备充电。

警告

只能使用 LG 许可的充电器、电池和电缆。 使用未获许可的充电器或电缆时，可能导致充电延迟或有关于充电缓慢的消息弹出。 未获许可的充电器或电缆还可导致电池爆炸或损坏设备，相应后果不属于 LG 保修范围。

充电器接口位于手机底部。 插入充电器并插入电流插座。

备注：
- 第一次充电时必须为电池完全充电，这样可以延长电池使用寿命。
- 手机正在充电时不要打开后盖。

使用存储卡

本手机支持使用容量高达 32 GB 的 microSD™ 或 microSDHC™ 存储卡。 这些存储卡专为手机和其他超小型设备而设计，非常适合于存储可在手机上使用的音乐、程序、视频和照片等各种媒体文件。

插入存储卡：
将存储卡插入插槽。 确保金色接触区域面朝下。

安全地取出存储卡：
点触 > **应用程序**选项卡 > **设置** > **常规选项卡** > **存储** > **卸载 SD 卡**。

备注：
- 请仅使用与手机兼容的存储卡。 使用不兼容的内存卡可能损坏卡、卡中存储的数据和手机。
- 因为设备使用 FAT32，任何给定文件的最大大小为 4 GB。

警告
请勿在手机开机时插入或取出存储卡。 这样做可能会损坏存储卡以及手机，并且存储卡上存储的数据也可能会损坏。

格式化存储卡：
如果已格式化存储卡，您可以开始使用。 如果没有，您必须先对其进行格式化才能使用。

备注：格式化卡时，卡上的所有文件将被删除。

1 点触 以打开应用程序列表。
2 滚动并点触**设置** > **常规选项卡** > **存储**。
3 点触**卸载 SD 卡**。
4 点触**清除 SD 卡** > **清除 SD 卡** > **清除全部内容**。
5 如果设置了图案锁定，请输入图案锁定，然后选择**清除全部内容**。

备注：如果存储卡中包含内容，由于格式化后将删除所有文件，所以文件夹结构会有所不同。

屏幕锁定和解锁

如果您在一段时间内未使用手机，屏幕将自动关闭和锁定。 这有助于防止意外点触，节省电池电量。

不使用手机时，按**电源/锁定键** 可锁定手机。

如果在您锁定屏幕时有程序正在运行，它们可能在锁定模式下继续运行。 建议在进入锁定模式前退出所有程序以避免不必要的费用（例如，打电话、网络访问和数据通信）。

要唤醒手机，请按**电源/锁定键** 。 将显示“锁定”屏幕。 点触并向任意方向滑动锁定屏幕即可解锁主屏。 您最后查看的屏幕将会打开。

主屏

触摸屏提示

以下是关于如何浏览手机的一些提示。

轻触或点触 – 手指轻触一下，即可选择项目、链接、屏上键盘的快捷方式和字母。

点触并按住 – 点触并按住项目，方法是轻触屏幕上的某个项目，并且在动作发生前不抬起手指。 例如，要打开一个联系人的可用选项，请在“联系人”列表中点触并按住联系人，直至打开上下文菜单。

拖动 – 点触项目并短暂按住，不要抬起手指，在屏幕上移动手指，直至达到目标位置。在主屏上，可拖动项目进行重新定位。

滑动 – 滑动的方法是手指轻触屏幕后不要停顿（因而避免拖动项目），在屏幕表面迅速移动。 例如，将屏幕向上或向下滑动可滚动浏览列表，或从左向右滑动浏览不同的主屏（反之亦然）。

轻触两次 – 轻触两次可放大网页或地图。 例如，快速轻触两次网页的局部，可调整局部来适应屏幕的宽度。 查看图片时，您还可轻触两次，即可放大或缩小。

双指缩放 – 使用浏览器或地图时，或者在浏览图片时，将食指和拇指并拢或张开，即可放大或缩小。

旋转屏幕 – 可通过多个应用程序和菜单将屏幕的方向调整为设备的实际方向。

备注：
- 要选择项目，请轻触图标中心位置。
- 无需大力按，触摸屏非常敏感，轻轻点触即可。
- 使用指尖轻触所需选项。 请注意不要触碰到任何其他键。

主屏

主屏是许多应用程序和功能的起点，使您可以添加应用程序快捷方式、Google 小工具等项目，从而直接访问信息和应用程序。 这是默认的画布，可从任何菜单中轻触 ○ 访问。

主屏

状态栏
显示手机的状态信息，包括时间、信号强度、电池状态以及通知图标。

小工具
小工具是独立应用程序，可以通过应用程序屏幕或在主屏或扩展主屏上访问。 与快捷方式不同，小工具显示为屏幕应用程序。

应用程序图标
轻触图标（应用程序、文件夹等）以打开并使用。

位置指示灯
指示您正在查看的主屏画布。

快速键区
可让您一键访问任何主屏画布上的功能。

扩展主屏

操作系统提供多个主屏画布，为添加图标、小工具等提供更大的空间。

▶ 在主屏上向左或向右滑动手指。

自定义主屏

您可以通过添加应用程序、小工具或更改墙纸来自定义主屏。

在主屏上添加项目

1 点触并按住主屏的空白部分。
2 在“添加模式”菜单中，选择要添加的项目。 您会在主屏上看到此添加的项目。
3 将它拖到您想要的位置，然后抬起手指。

提示！ 要将应用程序图标添加到主屏，请在“应用程序”菜单上点触并按住要添加的应用程序。

从主屏中移除项目

▶ 主屏 > 点触并按住要移除的图标 > 将其拖到 删除。

将某个应用程序添加为快速键

▶ 从应用程序菜单或主屏上，点触并按住应用程序图标并将其拖动到快速键区域。

从快速键区域删除应用程序

▶ 点触并按住目标快速键并将其拖动至 删除。

备注： **应用程序**键无法删除。

在主屏上自定义应用程序图标

1 点触并按住应用程序图标直至将其从当前位置解锁。 然后将其拖放到屏幕上。 将在应用程序的右上角显示编辑图标 。
2 再次轻触应用程序图标并选择所需的图标设计和大小。
3 轻触**确定**以保存更改。

返回到最近使用的应用程序

1 轻触 □。 屏幕将显示最近使用的应用程序列表。
2 轻触某个图标以打开其应用程序。 或轻触 ◁ 以返回上一个屏幕。

通知面板

通知可提醒您接收到新信息、日历事件和闹钟，以及正在进行的事件，如正在通话。当收到通知时，屏幕顶部将出现其图标。 未读通知的图标会显示在左侧，WLAN 强度或电池电量等系统图标会显示在右侧。

备注： 可用选项可能会因地区或服务提供商而异。

打开通知面板

从状态栏向下滑动可打开通知面板

快速切换区域

轻触每个快速切换键以将其打开/关闭。 点触并按住此键以访问其功能设置菜单。 要查看更多切换键，请向左或向右滑动。 轻触 以删除、添加或重新设定切换键。

QSlide 应用程序

轻触 QSlide 应用程序以将其打开，在屏幕上显示为小窗口。 轻触 以删除、添加或重新设定 QSlide 应用程序。

通知

列出了当前通知，每个通知都带有简短的说明。 轻触通知以查看。

轻触以清除所有通知。

要关闭通知面板，请点触此标签并将其向屏幕顶部方向拖动。

状态栏上的指示器图标

指示器图标显示在屏幕顶部的状态栏上，可报告未接来电、新信息、日历事件、设备状态等。

屏幕顶部显示的图标可提供有关设备状态的信息。 下表仅列示了最常见的图标。

图标	说明	图标	说明
	未插入 SIM 卡		铃声静音
	无可用网络信号		已打开振动模式
	已打开飞行模式		电池已充满电
	已连接到 WLAN 网络		电池正在充电
	已连接有线耳机		手机已通过 USB 数据线与 PC 连接
	正在通话		正在下载数据
	未接来电		正在上传数据
	蓝牙开启		已打开 GPS
	NFC 开启		正在同步数据
	系统警告		收到新 Gmail 消息
	闹钟已设置		收到新 Hangouts 消息
	收到新语音邮件		选择输入法

	收到新文本消息信		WLAN 热点已激活
	当前正在播放歌曲		

备注：图标在状态栏中的位置可能会因功能或服务而异。

屏上键盘

您可以使用屏上键盘输入文本。 在您需要输入文本时，屏上键盘会自动显示在屏幕上。要手动显示键盘，只需轻触要输入文本的文本字段。

使用键盘并输入文本

轻触一次以使键入的下一字母变为大写字母。 轻触两次表示全部为大写字母。

点击切换到字母和符号键盘。

轻触以输入空格。

轻触以新建一行。

轻触以删除上一字符。

输入带注音的字母

当选择法语或西班牙语作为文本输入语言时，您可以输入特殊的法语或西班牙语字符（如“á”）。

例如，要输入“á”，请点触并按住“a”键，直到放大键变大并显示其他语言的字符。然后，选择所需特殊字符。

Google 帐户设置

首次打开手机时，您有机会激活网络，登录 Google 帐户，并选择要如何使用某些 Google 服务。

设置您的 Google 帐户

- 从提示的设置屏幕登录 Google 帐户。

  或者

- 按 [○] > > **应用程序**选项卡 > 选择一个 Google 应用程序（如 Gmail） > 点击 **知道了** > 选择添**加电子邮件地址**以创建新帐户或添加帐户。

一旦在手机上设置了 Google 帐户，您的手机将自动与网络上的 Google 帐户同步。

您的联系人、Gmail 信息、日历事件和来自网络上这些应用程序和服务的其他信息将与您的手机同步 （这将取决于您的同步设置。）

登录后，您可在手机上使用 Gmail™ 收发邮件和利用 Google 服务。

连接到网络和设备

WLAN

使用 WLAN，您可在无线接入点 (AP) 覆盖区内高速访问互联网。 使用 WLAN 尽情享受无线互联网，而且无需额外付费。

连接 WLAN 网络

要在手机上使用 WLAN，您需要访问无线接入点或“热点”。 一些接入点已打开，您只需连接即可。 其他接入点处于隐藏状态或使用安全功能，因此您必须配置手机才能进行连接。

禁用不使用的 WLAN，以延长电池使用寿命。

备注：如果您在 WLAN 区域之外，或者将 WLAN 设为**关**，则您的移动运营商可能为移动数据使用收取额外的费用。

打开 WLAN 并连接 WLAN 网络

1 轻触 [○] > 应用程序**选项卡** > **设置** > **网络**选项卡 > **WLAN**。
2 将 **WLAN** 设置为**开启**，将其打开，开始扫描可用的 WLAN 网络。
3 再次轻触 WLAN 菜单，查看范围内的有效 WLAN 网络列表。
   - 锁图标表示受到安全保护的网络。
4 轻触某个网络进行连接。
   - 如果网络受到安全保护，您会收到提示，要求输入密码或其他凭据。 （请咨询网络管理员获取详细信息）
5 状态栏显示了可指明 WLAN 状态的图标。

蓝牙

与大多数手机不同，您可以通过运行对应的应用程序而不是通过蓝牙菜单，来使用蓝牙发送数据。

备注：
- LG 对经蓝牙无线功能发送或接收的数据的丢失、拦截或误用不承担任何责任。
- 随时确保您与之共享和接收数据的设备可靠且安全。 如果设备间存在障碍物，则需要缩短操作距离。
- 某些未经 Bluetooth SIG 测试或认可的设备可能与您的设备不兼容。

打开蓝牙，将手机与蓝牙设备配对

您必须将您的设备与另一设备配对方可与其连接。

1 按 [ ] > [ ] > **应用程序**选项卡 > **设置** > **网络**选项卡 > 将**蓝牙**设置为**开**。
2 再次轻触**蓝牙**菜单。 您将看到将手机设为可见的选项和搜索设备的选项。 现在轻触**搜索**以查看蓝牙范围内的设备。
3 从列表中选择您要配对的设备。

一旦配对成功，您的设备将连接到另一个设备。

备注：有些耳机或免提式车载套件设备可能有固定的蓝牙 PIN，如 0000。 如果配对设备有 PIN，系统会提示您输入 PIN。

使用蓝牙无线功能发送数据

1 从相应的应用程序或**下载**中选择文件或项目，如联系人、日历事件或媒体文件。
2 选择选项以通过蓝牙发送数据。

备注：选择选项的方法可能会因数据类型的不同而有所变化。

3 搜索并配对已启用蓝牙的设备。

使用蓝牙无线功能接收数据

1 按 [ ] > [ ] > **应用程序**选项卡 > **设置** > **网络**选项卡 > 将**蓝牙**设为**开**。
2 再次点击**蓝牙**菜单，勾选屏幕顶部的复选框，以使您的手机在其他设备上可见。

备注：要选择您的设备可见的时间长度，请轻触 [ ] > **可见超时**。

3 选择**接收**以确认您愿意接收来自该设备的数据。

享手机的数据连接

在没有无线连接可用时，USB 绑定和便携式 WLAN 热点功能非常有用。 您可以通过 USB 数据线（USB 绑定）将您手机的移动数据连接与一台电脑共享。 通过将手机变为便携式 WLAN 热点，您可以一次与多个设备共享手机的数据连接。

当手机共享其数据连接时，状态栏中将出现一个图标，同时通知抽屉中将出现持续的通知。

有关绑定和便携式热点的最新信息，包括支持的操作系统及其他详细信息，请访问 http://www.android.com/tether。

将手机的数据连接共享为便携式 WLAN 热点

1 按 [O] > [⊞] > **应用程序**选项卡 > **设置** > **网络**选项卡 > **绑定 & 网络** > **WLAN 热点**开关以激活。
2 输入密码并轻触**保存**。

提示！ 如果您的计算机运行 Windows 7 或部分 Linux 风格的最新分发（例如 Ubuntu），通常无需准备计算机进行绑定。 但是，如果运行的是较早版本的 Windows 或其他操作系统，则可能需要先准备您的计算机，才能通过 USB 建立网络连接。 如需获得有关哪种操作系统支持 USB 绑定以及如何配置它们的最新信息，请访问 http://www.android.com/tether。

重命名或确保您的便携式热点安全

您可以更改手机 WLAN 网络名称 (SSID) 的名称并确保其 WLAN 网络的安全。

1 按 [O] > [⊞] > **应用程序**选项卡 > **设置** > **网络**选项卡 > **绑定 & 网络** > **WLAN 热点**。
2 轻触**设置 WLAN 热点**。
   - 这将打开**设置 WLAN 热点**对话框。
   - 您可以更改**WLAN 名称 (SSID)**，这将是其他设备在扫描 WLAN 网络时看到的名称。
   - 您也可以轻触**安全性**菜单，使用预共享密钥 (PSK) 来为网络配置 WLAN 保护访问 2 (WPA2) 安全性。
   - 如果点触 **WPA2 PSK** 安全性选项，则密码字段将会添加到**设置 WLAN 热点**对话框中。如果输入密码，您将需要在将手机的热点与电脑或其他设备连接时输入密码。 您可以在**安全性**菜单中点触**打开**，以从 WLAN 网络中删除安全性。
3 轻触**保存**。

注意！ 如果将安全性选项设为“开放”，则不可避免其他人在未经授权的情况下使用在线服务并可能产生额外收费。 为避免未授权使用，最好保持激活安全性选项。

WLAN Direct

WLAN Direct 支持启用了 WLAN 的设备之间无需借助接入点而直接连接。 因为 WLAN Direct 十分耗电，所以建议您在使用 WLAN Direct 功能时将手机连接至电源插座。 提前检查您的 WLAN & WLAN Directed 网络，确保用户已连接到相同的网络。

SmartShare

您可以在图片库、音乐应用程序等中轻松使用 SmartShare 功能。

使用不同设备享用我手机中的内容。
使用各种设备体验内容。
轻触 可以音乐中共享内容。

播放/发送
播放：您可以通过 TV、蓝牙扬声器等播放内容。
无线收发：您可以将内容发送至支持蓝牙和 SmartShare Beam 的设备。
- SmartShare Beam: 通过 WLAN Direct 可快速传输内容。

体验附近设备上的内容

您可以在图片库、音乐应用程序中欣赏附近设备（例如 PC.NAS、手机）的内容。

连接设备

将您的设备连接到相同的 WLAN 网络中其他 DLNA 支持的设备。

搜索其他设备

1 轻触“附近设备”，就可以看到 DLNA 支持的设备。
2 连接到设备即可查看内容。

使用 USB 数据线的 PC 连接

了解在 USB 连接模式下，如何使用 USB 数据线将您的设备与 PC 相连。

使用 USB 大容量存储模式传输音乐、照片和视频

1 使用 USB 数据线将手机连接到 PC。
2 如果您未在 PC 上安装 LG Android 平台驱动程序，则需要手动更改设置。 向下滑动状态栏，然后选择**媒体设备 (MTP)** 选项。
3 现在，您可以在 PC 中查看大容量存储内容，然后传输文件。

与 Windows Media Player 同步

确保 Windows Media Player 已安装在您的 PC 上。

1 使用 USB 数据线将手机连接到安装有 Windows Media Player 的 PC。
2 选择**媒体设备 (MTP)** 选项。 连接后，PC 上显示弹出窗口。
3 打开 Windows Media Player 以同步音乐文件。
4 在弹出窗口中编辑或输入设备的名称（如有必要）。
5 选中并拖动所需音乐文件至同步列表。
6 开始同步。

• 要与 Windows Media Player 同步，必须满足以下要求。

项目	要求
操作系统	Microsoft Windows XP SP2、Vista 或更高
Window Media Player 版本	Windows Media Player 10 或更高版本

通话

拨打电话

1 轻触 以打开键盘。
2 使用键盘输入号码。 要删除数字，请轻触 。
3 轻触 以拨打电话。
4 要结束通话，请轻触**结束**图标 。

提示！ 要输入“+”以拨打国际电话，请点触并按住 0+ 。

呼叫联系人

1 轻触 以打开联系人。
2 滚动浏览联系人列表，或轻触**搜索联系人**，输入您要呼叫的联系人的前几个字母。
3 在列表中，轻触 以呼叫。

调节通话音量

要在通话期间调节通话音量，请使用手机后侧的音量调高和调低键。

拨打第二个电话

1 在第一个通话过程中，轻触 > **添加 通话**，然后拨号。 您还可通过轻触**通话记录**转至最近拨出的号码，也可轻触**联系人**来搜索联系人并选择要呼叫的联系人。
2 轻触 以拨打电话。
3 此时呼叫屏幕上显示两个呼叫。 初始呼叫被锁定，通话方进入保持状态。
4 轻触显示的数字可在不同的通话间切换。 或轻触 **合并通话**进行多方通话。
5 要结束当前通话，请轻触**结束**或按 向下滑动通知栏，然后选择**结束通话**图标 。

备注：您需要对每通电话付费。

查看通话记录

在主屏上，轻触 并选择**通话记录**选项卡。
查看所有拨电、已接来电和未接来电的完整列表。

提示！
- 轻触任意通话记录条目，以查看通话日期、时间和时长。
- 轻触 ，然后轻触全部删除以删除所有记录项目。

通话设置

您可以配置通话设置（如呼叫转移）以及运营商提供的其他特殊功能。

1 在主屏上，轻触 。
2 轻触 。
3 轻触**通话设置**，然后选择要调整的选项。

联系人

在手机上添加联系人，并将其与 Google 帐户或其他支持联系人同步的帐户中的联系人同步。

搜索联系人

1 轻触 以打开联系人。
2 轻触**搜索联系人**，使用键盘输入联系人姓名。

添加新联系人

1 轻触 ，输入新联系人号码，然后轻触 。 轻触**添加至联系人** > **新建联系人**。
2 如果您想为新联系人添加图片，请轻触图像区域。
从**拍照**选择或**从图片库选择**。
3 轻触联系人信息类别，并输入有关联系人的详细信息。
4 轻触**保存**。

按收藏夹归类联系人

您可以按收藏夹归类经常呼叫的联系人。

将联系人添加到收藏夹

1 轻触 以打开联系人。
2 轻触联系人以查看其详细信息。
3 轻触联系人姓名右角的星号。 星号会变成黄色。

从收藏夹列表中删除联系人

1 轻触 以打开联系人。
2 轻触**收藏夹**选项卡，选择一个联系人以查看其详细信息。
3 轻触联系人姓名右角的黄色星号。 星号变为灰色，联系人已从收藏夹中删除。

创建群组

1 轻触 以打开联系人。
2 依次轻触**群组** **。** 选择**新建群组**。
3 为新群组输入名称。 您也可以为新建群组设置一个铃声。
4 轻触**保存**以保存群组。

备注：如果您删除一个群组，分配至该群组的联系人不会被删除。 他们将保留在您的电话本中。

信息

您的手机将短信和彩信结合到一个直观易用的菜单中。

警告： LG 信息应设置为默认短信应用程序。 如果没有，信息功能将受限。

发送信息

1 轻触主屏上的 图标，然后轻触 打开空白信息。
2 在**收件人**字段中输入联系人姓名或电话号码。 随着您输入联系人姓名，匹配的联系人将会显示。 您可以轻触建议的收件人。 您可添加多个联系人。

备注：您将按每个收件人每条文本信息付费。

3 轻触**信息**字段并开始编写信息。
4 轻触 以打开“选项”菜单。 从以下选项中选择：**快速消息**、**插入表情符号**、**发送日程表**、**添加主题和**放弃。

提示！ 您可以轻触 图标以附加想要在信息中共享的文件。

5 轻触**发送**以发送信息。
6 屏幕上会显示回复。 当您查看并发送附加信息时，将创建信息会话。

警告：
- 160 个字符的限制在不同国家/地区有所不同，具体取决于语言和短信编码方式。
- 如果在短信中添加图像、视频或音频文件，则短信将自动转换为彩信，您需要支付相应费用。

线程框

与另一方交换的信息（短信、彩信）将以时间顺序显示，以便您方便查看对话概述。

更改信息设置

已预定义手机信息设置，因此您可以立即发送信息。 您可以根据喜好更改设置。
- 轻触主屏上的**信息**图标，然后轻触 和**设置**。

电子邮件

您可以使用电子邮件应用程序阅读 Gmail 等服务的电子邮件。 电子邮件应用程序支持以下帐户类型：POP3、IMAP 和 Exchange。
您的服务提供商或系统管理员可提供您需要的帐户设置。

管理电子邮件帐户

首次打开**电子邮件**应用程序时，将打开一个设置向导，帮助您设置电子邮件帐户。
在初始设置后，电子邮件显示收件箱的内容。

添加另一个电子邮件帐户：

- 按 [O] > [应用程序] > **应用程序**选项卡 > **电子邮件** > 轻触 [⋮] > **设置** > [+] **添加帐户。**

更改电子邮件帐户的设置：

- 按 [O] > [应用程序] > **应用程序**选项卡 > **电子邮件** > 轻触 [⋮] > **设置** > **常规设置**。

删除电子邮件帐户：

- 按 [O] > [应用程序] > **应用程序**选项卡 > **电子邮件** > 轻触 [⋮] > **设置** > 轻触 [⋮] > **删除帐户** > 选择要删除的帐户 > **删除** > 选择**是。**

使用帐户文件夹

按 [O] > [应用程序] > **应用程序**选项卡 > **电子邮件** > 轻触 [⋮] 再选择**文件夹**。
每个帐户均具有收件箱、发件箱、已发送和草稿箱文件夹。 取决于您帐户的服务提供商支持的功能，您可能具有其他文件夹。

撰写和发送电子邮件

要撰写和发送邮件

1 在**电子邮件**应用程序中，轻触 [✉]。
2 输入邮件目标收件人的地址。 输入文字时，匹配的地址将从您的联系人中建议。 用分号分隔多个地址。
3 轻触 [⋮] 以添加抄送和密件抄送，并在需要时轻触 [📎] 以附加文件。
4 输入邮件的正文。
5 轻触 [➢]。

提示！ 当新电子邮件到达“收件箱”时，您将通过声音或振动收到通知。

相机

要打开“照相机”应用程序，按 [ ] > [ ] > **应用程序**选项卡 > [ ]。

了解取景器

1. **闪光灯** – 从**关闭**、**打开**、**自动** 中选择。
2. **切换相机** – 在后置相机镜头与前置相机镜头之间切换。
3. **拍摄模式** – 从**正常**、**全景**、**动态音调** (HDR)、**连环拍摄**、**人面优化**、**时间捕捉拍摄**或**运动**中选择。
4. **设置** – 轻触此图标可以打开设置菜单。
5. **视频模式** – 轻触并向下滑动此图标以切换到视频模式。
6. **捕获按钮** – 轻触以拍照。
7. **图片库** – 轻触以查看最近拍摄的照片。 您可以访问“我的文档”并查看相机模式下保存的照片。

备注：拍照前，请确保相机镜头清洁干净。

使用高级设置

从取景器中轻触 ⚙ 以打开高级选项。 通过滚动浏览列表，您可以更改相机设置。

	要拍照，说出以下词语之一：Cheese、Smile、Whisky、Kimchi 或 LG。
	定义并控制进入照片的光量。
	轻触以选择对焦模式。
W6M	选择照片分辨率。 如果您选择高分辨率，文件大小会增大，这意味着内存中可存放的照片数量会减少。
	ISO 评级决定相机的光传感器的感光性。 ISO 越高，相机感光性能越好。 在您无法使用闪光灯而光线较差的条件下，此功能很有用。
AWB	提高不同光照条件下的颜色质量。
	对图片应用艺术效果。
	设置按下拍摄按钮后的延迟。 如果要为自己拍摄照片，此功能是理想之选。
	激活以使用手机基于位置的服务。 **备注：**此功能仅在激活 GPS 或连接网络后可用。
	选择快门声音。
	将音量键设为是否用于拍摄或变焦。
	选择存储介质以保存图片。
	打开帮助指南以了解某功能的操作方式。
	恢复所有相机默认设置。

提示！

- 退出相机时，部分设置将返回默认值，如白平衡、色彩效果、计时器和拍摄模式。 拍摄下一张照片之前，请先查看这些设置。
- 设置菜单层叠在取景器之上。因此，当您更改照片颜色或质量元素时，您将在“设置”菜单下预览到图像更改效果。

快速拍照

1 打开**相机**应用程序，将镜头对准要拍摄的物体。
2 对焦框将显示在取景器屏幕的中心。 您还可轻触屏幕上的任何位置以对焦特定点。
3 对焦框变蓝时，表示相机已对好焦。
4 轻触 以拍照。

使用时间捕捉拍摄模式

轻触 之前，连续拍摄五张照片以将相机设为捕获错过的瞬间。

1 打开**相机**应用程序。
2 轻触 > **时间捕捉拍摄**。
3 轻触 拍照。
4 要查看拍摄照片之前的瞬间，轻触相机屏幕底部的图像缩略图。
5 选择要保留的照片，然后轻触屏幕顶部的 。

拍照后

轻触“照相机”屏幕底部的图像缩略图以查看拍摄的上一张照片。

	轻触可编辑此照片。
	轻触可以立即拍摄其它照片。
	轻触即可发送照片给他人或通过社交网络服务共享照片。

	轻触以删除照片。

提示！ 如果您在手机上设置了 SNS 帐户，您可以向 SNS 社区共享您的照片。

备注：漫游时如果下载了彩信，可能会额外收费。

摄像机

了解取景器

1. **闪光灯** – 从**关闭**、**打开**、**自动** 中选择。
2. **切换相机** – 在后置相机镜头与前置相机镜头之间切换。
3. **设置** – 轻触此图标可以打开设置菜单。
4. **相机模式** – 轻触并向上滑动此图标以切换到相机模式。
5. **开始录制** – 轻触可开始视频录制。.
6. **图片库** – 轻触以查看最近录制的视频。 您可以访问“图片库”并查看视频模式下保存的视频。

提示！
录制视频时，将两根手指放在屏幕上并缩放手指，即可使用缩放功能。

使用高级设置

使用取景器，轻触 ⚙ 以打开所有高级选项。

FHD	轻触以设置正在录制的视频的大小（以像素为单位）。
	定义并控制进入镜头的光量。 沿滚动条滑动亮度指示器，滑向“-”将调低视频亮度，滑向“+”将调高视频亮度。
AWB	提高不同光照条件下的颜色质量。
	选择要对新视图使用的色调。
	激活以使用手机基于位置的服务。 **备注：**此功能仅在激活 GPS 或连接网络后可用。
	将音量键设为是否用于录制或变焦。
	选择要保存视频的存储。
	打开帮助指南以了解某功能的操作方式。
	恢复所有相机默认设置。

快速录制视频

1 打开**相机**应用程序并滑动**视频模式**按钮。
2 屏幕上将显示摄像机的取景器。
3 拿稳手机，将镜头对准您要摄像的物体。
4 轻触 ● 一次，开始录制。
5 取景器的顶部左角有红灯闪烁，计时器显示视频长度。
6 轻触屏幕上的 ■ 停止录制。

提示！

- 轻触以在录制视频过程中拍摄图像。
- 轻触以暂停录制视频。

录制视频后

在取景器中，轻触屏幕底部的视频缩略图以查看最近拍摄的视频。

	轻触以立即录制其他视频。
	轻触即可发送视频给他人或通过社交网络服务共享视频。
	轻触以删除视频。
	点击查看更多选项。

备注：漫游时如果下载了彩信，可能会额外收费。

轻敲代码

您可以在屏幕关闭时通过轻触正确的区域和顺序来解除屏幕锁定。

激活轻敲代码功能

1 按 [O] > [⊞] > **应用程序**选项卡 > **设置** > **显示**选项卡 > **锁定屏幕** > **选择屏幕锁定** > **轻敲代码。**

2 这将打开一个屏幕，该屏幕将指导您如何选择解锁顺序。 您必须创建一个备份 PIN 码以作为安全措施，以免忘记解锁顺序。

QuickMemo+

通过 QuickMemo+，您可创建备忘录和捕捉屏幕截图。捕捉屏幕截图，在上面画图，并使用 QuickMemo+ 与亲朋好友分享。

1 点触并向下滑动状态栏，然后轻触 [Q]。

2 从**笔型**、**颜色**、**橡皮擦**中选择所需菜单选项，然后创建备忘录。

3 在“编辑”菜单中轻触 以使用当前屏幕保存备忘录。 任何时候想退出 QuickMemo+，只需轻触 ◁ 即可。

备注：使用 QuickMemo+ 时请使用指尖。 不要使用指甲。

使用 QuickMemo+ 选项

使用 QuickMemo+ 时，您可轻松使用 QuickMenu 选项。

	取消操作或重新操作。
	使用复杂的概念功能。
	选择笔型和颜色。
	清除创建的备忘录。
	使用当前屏幕将备忘录保存在**图片库**或**QuickMemo+** 中。
	选项：点击以为备忘录选择**共享**、**纸张样式**。

查看保存的 QuickMemo+

轻触**图片库**，并选择QuickMemo+相册。

QSlide

在任何屏幕上，以屏幕窗口形式显示记事本、日历等。

1		轻触以退出 QSlide 并返回全屏模式。
2		轻触以调整透明度。
3		轻触以结束 QSlide。
4		轻触以调整大小。

1 点触并向下滑动状态栏 > 轻触 Qslide 应用程序，或者在使用支持 QSlide 的应用程序时，轻触 。 此功能将在屏幕上持续显示为小窗口。

2 您可以拨打电话、浏览网页或选择其他手机选项。 当透明度栏未满 时，也可以使用和轻触小窗口下方的屏幕。

备注：QSlide 最多可同时支持两个窗口。

Quick遥控

Quick遥控将您的手机变成家庭电视和 DVD/蓝光的万能遥控器。

1 点触并向下滑动状态栏，然后点击 > **添加远程**。

或者

轻触 > > **应用程序**选项卡> **Quick遥控** > 轻触 。

2 选择设备类型和品牌，再按照屏幕上的说明配置设备。

3 点触并向下滑动状态栏，然后使用 QuickRemote 功能。

轻触**菜单键** ⋮ 以选择**编辑遥控器名称**、**移动遥控器**、**删除遥控器**、**编辑房间**、**设置**和**帮助**。

备注：QuickRemote 的工作方式与普通遥控器控制红外 (IR) 信号相同。 当您使用 QuickRemote 功能时，注意不要遮盖手机顶部的红外传感器。 某些型号、制造商或服务公司可能不支持此功能。

多媒体

图片库

打开**图片库**应用程序以查看您的图片和视频专辑。

1 按 [O] > > **应用程序**选项卡 > **图片库**。
可以使用图片库管理和共享所有图片和视频文件。

备注：
- 某些文件格式不受支持，具体取决于设备已安装的软件。
- 某些文件可能无法正常播放，具体取决于它们的编码方式。

查看图片

启动图片库后，会显示可用的文件夹。 当另一个应用程序（如电子邮件）保存一张图片，会自动创建下载文件夹以包含图片。 同样，抓拍屏幕后，会自动创建抓拍图片文件夹。选择一个文件夹并打开它。

图片按创建日期显示在文件夹中。 选择一张要全屏查看的图像。 向左或向右滚动以查看下一张或上一张图像。

放大和缩小

使用以下一种方法放大图像：
- 在任何位置轻触两下以放大。
- 在任何位置划开两根手指可放大。 收拢手指可缩小，或轻触两下可返回。

播放视频

视频文件在预览时显示 图标。 选择一个将观看的视频，再轻触 。 视频应用程序会启动。

编辑照片

查看照片时，轻触 。

删除照片/视频

使用以下一种方法：
- 在文件夹中，轻触 ，再通过勾选选择照片或视频，最后轻触**删除**。
- 查看照片时，轻触 。

设置为墙纸

查看照片时，轻触 ⋮ > **将图像设置为**以将图像设置为壁纸或将其分配给联系人。

备注：
- 某些文件格式不受支持，具体取决于设备的软件。
- 如果文件大小超过可用内存，打开文件时可能会发生错误。

视频

您的手机拥有内置的视频播放器，可让您播放所有喜爱的视频。 要访问视频播放器，请点触 > **应用程序**选项卡 > **图片库**。

播放视频

1 点触 > **应用程序**选项卡 > **图片库**

2 选择您要播放的视频。

1 ❚❚ / ▶	点触可以暂停/恢复视频播放。
2 ▶▶	点触可以前进 10 秒。
3 ◀◀	点触可以后退 10 秒。
4 🔊	点触可以管理视频音量。
5 🔓 / 🔒	点触可以锁定视频屏幕或为其解锁。

❻ ★	轻触以在播放视频过程中拍摄图像。
❼	点触可以使用 QSlide。
❽	轻触以使用 SmartShare 功能共享视频。
❾ ⋮	轻触可访问屏幕比例、字幕、分享、设置或详细信息。

音乐

手机拥有内置的音乐播放器，可让您播放所有喜爱的曲目。 要访问音乐播放器，请按 [○] > > **应用程序**选项卡 > **音乐**。

播放歌曲

1 按 [○] > > **应用程序**选项卡 > **音乐**。
2 轻触**歌曲**。
3 选择您要播放的歌曲。

1	II / ▶	轻触以暂停/恢复播放。
2	⏭	轻触可跳到专辑、播放列表或随机曲目中的下一曲目。 轻触并按住可快进。
3	⏮	轻触可重新开始播放当前曲目或跳至专辑、播放列表或随机曲目中的上一曲目。 轻触并按住可后退。
4	🔈	轻触以显示音量滑动条，然后通过滑动条调整播放音量。
5		轻触可设至音效。
6		轻触以使用 SmartShare 功能共享音乐。
7	★	轻触可将歌曲添加至收藏夹。
8		轻触可打开当前播放列表。
9	⤮	轻触以采用随机播放模式（按随机顺序播放曲目）播放当前的播放列表。
10	⟲	轻触以切换至重复播放模式，以重复播放所有歌曲、重复播放当前歌曲或关闭重复。

要在聆听音乐时更改音量，请按手机左侧的上下音量键。

点触并按住列表中的任何歌曲。 这将显示**播放**、**添加至播放列表**、**共享**、**设为铃声**、**删除**、**详细信息**和**搜索**选项。

将音乐文件添加至手机

开始时将音乐文件传输至手机：

- 使用媒体设备 (MTP) 传输音乐。
- 从无线 Web 下载。
- 将手机与计算机同步。
- 通过蓝牙接收文件。

FM 收音机

手机内置了 FM 收音机，因此您在路上也能转到喜爱的电台并收听无线广播。

备注：要收听收音机，您需要插入耳机。 将耳机插入耳机插孔。

实用工具

置闹钟

1 按 ○ > > **应用程序**选项卡 > **时钟** > **闹钟** > +。
2 在设置闹钟后，您的手机会提示您与闹钟时间相距多久。
3 设置**重复**、**再响间隔**、**闹钟响时振动**、**闹钟声音**、**闹钟音量**、**自动应用程序启动器**、**拼图锁**和**备忘录**。
4 轻触**保存**。

备注：要更改闹钟列表屏幕上的闹钟设置，请轻触**菜单键** ⋮，然后选择**设置**。

使用计算器

1 按 ○ > > **应用程序**选项卡 > **计算器**。
2 轻触数字键输入数字。
3 对于简单的计算，请轻触要执行的函数（+、–、x 或 ÷），然后点触 =。
4 要查看历史记录，点触 ⋮ 并选择**计算历史记录**。
5 对于更复杂的计算，点触 ⋮，选择**科学计算器**，然后选择 sin、cos、tan、log 等。

将事件添加到日程表中

1 按 ○ > > **应用程序**选项卡 > **日历**。
2 在屏幕上，您可以发现日历的不同视图类型（日、周、月、年、日程）。
3 轻触要添加事件的日期，再轻触 +。
4 轻触**事件名称**，然后输入事件名称。
5 轻触**位置**，然后输入位置。 查看日期并输入事件开始和结束的时间。
6 如果要重复闹钟，请设置**重复**，并必要时设置**提醒**。
7 轻触**保存**以在日历中保存事件。

录音机

使用录音机录制录音机或其他音频文件。

录制声音或语音

1 按 ○ > > **应用程序**选项卡 > **录音机**。
2 轻触 ● 以开始录音。
3 轻触 ■ 以结束录音。
4 轻触 ▶ 收听录音。

备注：轻触 ☰ 可访问相册。 您可以收听保存的录音。 可用的录音时间可能会因实际录音时间而异。

任务

可使用 MS Exchange 帐户同步此任务。 您可在 MS outlook 或 MS Office Outlook Web Access 中创建、修改或删除任务。

同步 MS Exchange

1 在主屏上按 ○ > > **应用程序**选项卡 > **设置**。
2 轻触**常规**选项卡 > **帐户与同步** > **添加帐户**。
3 轻触 **Microsoft Exchange** 以创建电子邮件地址和密码。
4 确保选中“同步任务”。

备注：根据电子邮件服务器，可能不支持 MS Exchange。

ThinkFree 查看器

ThinkFree 查看器是专业的移动办公解决方案，让用户可使用移动设备随时随地方便地查看各种类型的办公文档，包括 Word、Excel 和 PowerPoint 文件。

按 [O] > > **应用程序**选项卡 > **ThinkFree 查看器。**

查看文件

现在，移动用户可在移动设备上轻松查看各种文件类型，包括 Microsoft Office 文档和 Adobe PDF。 使用 ThinkFree 查看器查看文档时，对象和布局与原始文档类似。

Google+

使用此应用程序可与他人通过 Google 社交网络服务保持联系。

- 按 [O] > > **应用程序**选项卡 > **Google+。**

备注：此应用程序可能无法使用，具体取决于您所在的地区或您的服务提供商。

语音搜索

通过此应用程序，可使用语音搜索网页。

1 按 [O] > > **应用程序**选项卡 > **语音搜索**。
2 当**开始语音**出现在屏幕上时，说一个关键词或词组。 从显示的关键词建议中选择一项。

备注：此应用程序可能无法使用，具体取决于您所在的地区或您的服务提供商。

下载

使用此应用程序可查看您通过此应用程序下载的具体文件。

- 按 [O] > > **应用程序**选项卡 > **下载内容**。

备注：此应用程序可能无法使用，具体取决于您所在的地区或您的服务提供商。

LG SmartWorld

LG SmartWorld 提供了琳琅满目的精彩内容（游戏、应用程序、壁纸和铃声），将让 LG 手机用户有机会体验到更丰富的“移动生活”。

如何从手机访问 LG SmartWorld

1 按 [O] > [⋮⋮⋮] > **应用程序**选项卡 > 轻触 [LG] 图标以访问 **LG SmartWorld**。
2 轻触“登录”，然后输入您在 LG SmartWorld 的 ID/密码。 如果您还未注册，轻触“注册”以接收您的 LG SmartWorld 会员资格。
3 下载所需的内容。

备注：如果没有 [LG] 图标怎么办？
1 使用手机网络浏览器访问 LG SmartWorld (www.lgworld.com)，并选择您所在的国家/地区。
2 下载 LG SmartWorld 应用程序。
3 运行和安装下载的文件。
4 轻触 [LG] 图标以访问 LG SmartWorld。

如何使用 LG SmartWorld

- 参加 LG SmartWorld 每月的促销活动。

🔍	搜索内容。
⋮	按类别查找内容（如游戏、教育、娱乐等）。

- 尝试使用简单的**菜单**按钮，迅速找到您正在寻找的功能。
  设置 – 设置情景模式和显示。
  登录 – 设置您的 ID 和密码。
- 还可以试用其他有用功能。 （内容详细资料屏幕）

备注：您所在国家/地区可能无法使用 LG SmartWorld。

网络

互联网

使用此应用程序浏览互联网。 浏览器为您提供了一个涵盖游戏、音乐、新闻、体育、娱乐等更多内容的缤纷世界，您可以快速、直接地通过手机访问。畅行无阻、精彩无限。

备注：连接这些服务并下载内容时，可能会产生额外费用。 查看网络提供商要求的数据付费。

1 按 [○] > [⋯] > **应用程序**选项卡> **互联网**。

使用 Web 工具栏

轻触并用手指将其向上滑动以打开。

⇦	轻触可返回上一页。
⇨	轻触可前进到当前页之后的下一页。 这正好与轻触 [◁] 的效果相反，按此键将转到上一页。
⌂	轻触可返回主页。
⊞	轻触可添加新窗口。
☆	轻触可访问书签。

查看网页

点触地址栏，输入网址，再点触**开始**。

打开网页

要转至新页面，请轻触 [1] > [+]。

要转至另一个网页，请点触 [2]，向上或向下滚动，再点触网页以选择它。

网络

使用语音搜索网络

轻触地址字段，轻触 ，说一个关键字，然后选择显示的建议关键字之一。

备注：此功能可能无法使用，具体取决于您所在的地区或您的服务提供商。

书签

要对当前网页添加书签，请轻触 > **添加到书** > **确定**。
要打开一个带书签的网页，请点触 ，再选择其中一项。

历史记录

点触 > **历史记录**以从最近访问的网页列表中打开一个网页。

Chrome

使用 Chrome 可搜索信息和浏览网页。

1 按 > > **应用程序**选项卡 > Chrome。

备注：此应用程序可能无法使用，具体取决于您所在的地区和您的服务提供商。

查看网页

点触地址栏，再输入一个网址或搜索标准。

打开网页

要转至新页面，请轻触 > **新标签页**。

设置

此节将提供项目概览，您可以使用手机的系统设置菜单更改此项目。

访问设置菜单：

按 [O] > 轻触并按住 [□] > **系统设置**。

- 或 -

按 [O] > [⊞] > **应用程序**选项卡 > **设置**。

网络

<WLAN>

WLAN – 打开 WLAN 以连接到可用的 WLAN 网络。

提示！ 如何获取 MAC 地址

要使用 MAC 筛选器在某些无线网络中建立连接，您需要在路由器中输入手机的 MAC 地址。

您可以在下列用户界面中找到 MAC 地址：按 [O] > [⊞] > **应用程序**选项卡 > **设置** > **网络**选项卡 > **WLAN** > [⋮] > **高级 WLAN** > **MAC 地址**。

<蓝牙>

打开或关闭蓝牙无线功能以使用蓝牙。

<移动数据>

显示数据使用情况并设置移动数据范围。

<通话>

配置通话设置（例如呼叫转移）以及运营商提供的其他特殊功能。

语音邮件 – 您可以选择运营商的语音邮件服务。

固定拨号 – 打开并汇集一个号码列表，可从手机拨打此列表中的号码。 您需要提供 PIN2 码，此代码由运营商提供。 仅可以使用手机拨打此号码列表中的号码。

来电弹出窗口 – 当您使用相机和视频时会显示来电弹出窗口

拒接来电 – 允许您设置拒接来电功能。 从来电拒接模式或“拒接呼叫”中选择。

拒接后发送信息 – 拒接来电时，可使用此功能快速发送一条信息。

来电隐藏 – 隐藏主叫方姓名和来电号码。

呼叫转接 – 选择是转接所有通话、线路忙时转接、无人接听时转接，还是无信号时转接。

自动应答 – 设置在连接的免提设备自动接听来电前的时间。 从“**停用**”、“**1 秒**”、“**3 秒**”和“**5 秒**”中进行选择。

接听振动 – 当对方接听电话后，您的手机会振动。
保存未知号码 – 通话后将未知号码添加至联系人。
按“电源”按钮结束通话 – 可供您选择结束通话。
呼叫限制 – 锁定接听来电、拨出电话或国际电话。
通话时间 – 查看通话时间，包括“最后通话”、“已拨电话”、“来电”和“所有通话”。
其他设置 – 允许您更改以下设置：
本机号码：选择是否要在拨出电话时显示您的号码。
来电等待：如果激活了来电等待功能，在通话过程中，手机将提醒您有新来电（取决于网络提供商）。

<共享与连接>

NFC – NFC（近场通讯）是一项无线技术，当两个对象彼此相距几英寸时，可在二者之间进行数据传输。 当您启用手机上的 NFC 时，手机可与其他支持 NFC 的设备交换数据，或从内置有智能标签的海报、贴纸及其他产品读取信息。
Android Beam – 启用此功能时，您可以通过将多台设备紧紧握在一起，将应用程序内容播送至其它具有 NFC 功能的设备。 例如，您可以播送浏览器页面内容、YouTube 视频、联系人等更多信息。 只需使设备在一起（一般采用背靠背的方式）并点触屏幕即可。 此应用程序将确定播送的内容。
SmartShare Beam – 打开以通过 SmartShare Beam 接收来自 LG 手机或平板电脑的多媒体内容。
媒体服务器 – 可让您与附近的 DLNA 兼容设备共享手机的多媒体内容。
LG PC 套件 – 选中此复选框可在有 WLAN 连线时使用 LG PC 套件。 请注意，应通过 WLAN 连接将 WLAN 网络连接至 LG PC Suite。

<绑定与网络>

USB 绑定 – 连接 USB 数据线，与计算机共享互联网连接。
WLAN 热点 – 您也可以使用手机来提供移动宽带连接。 创建热点，共享连接。
蓝牙绑定 – 可让您设置手机，无论您是否在共享互联网连接。
帮助 – 轻触以查看有关 USB绑定、WLAN 热点和蓝牙绑定功能的帮助信息。
飞行模式 – 切换为飞行模式之后，将禁用所有无线连接。

备注：您必须设置锁定屏幕 PIN 或密码才能使用凭据存储。

移动网络 – 为数据漫游、网络模式和运营商、接入点名称 (APN) 等设置选项。
VPN – 显示您之前配置的虚拟专用网 (VPN) 的列表。 允许您添加不同类型的 VPN。

声音

<基本>
声音模式 – 选择“声音”、“仅振动”或“请勿打扰”。
音量 – 调节手机的音量设置，以适合您和环境的需要。
振动强度 – 允许您设置来电、通知和触摸反馈的振动强度。

<铃声 & 振动>
铃声 – 设置通话的铃声。 您也可以通过点触屏幕右上角 + 来添加铃声。
通知声音 – 设置通知声音。 您也可以通过轻触屏幕右上角的 + 来添加通知声音。
声音和振动 – 勾选以将手机设为接到来电时既响铃又振动。
振动类型 – 允许您设置来电的振动类型。从快速、快速重复、持续振动、标准或滴答声中选择。

<通知>
请勿打扰 – 设置手机不提示来电通知的时间和模式。 从全部、仅优先或无中选择。
  仅优先级 – 仅允许某些优先功能提示。 闹钟总是优先。 从具有日历事件、来电、新信息或允许的联系人的应用程序中选择。
  日程表 – 即便设置为全部，仍然仅重复提示优先通知。
锁定屏幕 – 设置在锁定屏幕上显示或隐藏全部通知。
应用程序 – 设置应用程序发出的通知。 选择“无”不显示应用程序发出的任何通知，选择“优先”以先于其他通知显示优先通知，选择“请勿打扰”时可以设置“仅优先”。

<高级设置>
点击振动 – 勾选以在点击主页触摸按钮以及其他用户界面互动期间振动。
音效 – 点击以设置拨号盘按键音、触摸声音和屏幕锁定声音。
  拨号盘触摸声音 – 勾选以在使用拨号盘时播放铃声。
  触摸音 – 勾选以进行屏幕选择时发出声音。
  屏幕锁定提示音 – 勾选以在锁定和解锁屏幕时播放声音。
信息/呼叫语音通知 – 如果启用，您的设备将可以自动接听来电和消息事件。

显示

<主屏>

设置**选择主页**、**主题**、**壁纸**、**屏幕点击效果**、**允许主屏幕循环**、**主页备份与还原**、**帮助**。

<锁定屏幕>

选择屏幕锁定 – 设置屏幕锁定类型以保护手机。 打开一组屏幕，它们可指导您绘制屏幕解锁图案。 设置**无**、**滑动**、**轻敲代码**、**图案**、 PIN 或**密码**。

如果在打开手机或唤醒屏幕时已启用图案锁定类型，系统会提示您绘出解锁图案以解锁屏幕。

Smart Lock – 通过受信任的设备（蓝牙设备或 NFC ）或受信任的面部来设置自动解锁手机。 该功能在锁定屏幕设置为轻敲代码、图案、PIN 和密码其中之一时可用。

备注： 必须开启智能锁定才可激活此功能。
设置 > **常规** > **安全性** > Trust agents > Smart Lock。

屏幕滑动效果 – 设置屏幕滑动效果选项。 **轻粒子**、**矢量圆圈**、**马赛克**和**苏打**。

备注： 如果屏幕锁定设为“图案”，屏幕点击效果将变为图案效果。

壁纸 – 设置锁定屏幕壁纸。 从**图片库**或**壁纸图库**中进行选择。
快捷方式 – 允许您更改**滑动**锁定屏幕上的快捷方式。
丢失手机的联系人信息 – 在锁定屏幕上显示丢失手机的联系人信息。.
锁定计时器 – 设置屏幕超时后屏幕自动锁定前的时间。
电源按钮立即锁定 – 勾选后，可在按下电源/锁定键后立即锁定屏幕。 此设置将覆盖安全锁定计时器设置。

<主页触摸按钮>

按钮组合 – 拖动一个图标重新安排主页触摸按钮。 最多可以有 5 个主页触摸按钮。
颜色 – 设置主页触摸按钮的背景色。 从白色和黑色中进行选择。

<字体>

字体类型 – 设置手机和菜单使用的字体类型。
字体大小 – 设置手机和菜单中显示的字体大小。

<其他屏幕设置>

亮度 – 调整屏幕的亮度。 为获得最佳电池性能，使用最暗的舒适亮度。
自动旋转屏幕 – 勾选以将手机设为根据手机方向（纵向或横向）自动旋转屏幕。

屏幕超时 – 设置屏幕超时之前的时间。
智能屏幕 – 勾选以防止在设备检测到您的双眼看着屏幕时屏幕超时。

<高级设置>
屏幕关闭效果 – 设置屏幕关闭效果。 从**复古电视**、**黑洞**和**淡出**中选择。
互动屏保 – 轻触互动屏保开关以打开或关闭此功能。 如果打开，设备屏幕保护程序将在手机处于睡眠模式（插接和/或充电）时显示。 从**时钟**和**Google 相册**中选择。

常规

<语言和输入设备>
使用语言和输入设置为手机上的文本选择语言以及配置屏上键盘（包括已添加到词典中的文字）。

<位置>
打开位置服务，您的手机将使用 GPS、WLAN 和移动网络确定您的大概位置。
模式 – 从**高精度**、**省电**和**仅设备传感器**中设置位置模式。

<帐户与同步>
允许应用程序在后台同步数据，无论您当前是否正在使用。 取消选择此设置可节省电池电量并减少（而非消除）数据使用。

<辅助工具>
使用**辅助工具**可配置您在手机上安装的辅助功能插件。
<单手操作>
拨号键盘 – 勾选可向设备右侧或左侧移动拨号键盘。 只需轻触箭头便可将其移至一侧或另一侧。
LG 键盘 – 勾选可向设备右侧或左侧移动键盘。 只需轻触箭头便可将其移至一侧或另一侧。
锁定屏幕 – 勾选可向设备右侧或左侧移动 PIN 锁定屏幕键盘。 只需轻触箭头便可将其移至一侧或另一侧。
帮助 – 显示关于单手操作的信息。

< 快速鍵 >
當螢幕關閉或鎖定時，按住音量鍵以快速存取應用程式。 點按螢幕右上角的快速鍵 ⊙ I 以切換**開啟**或**關閉**。

<安全性>

加密手机 – 允许加密手机数据以保护安全性。 您需要在每次开机时输入 PIN 或密码才能解密手机。

加密 SD 卡存储 – 使您可以为安全加密手机上的 SD 卡数据。

设置SIM卡锁定 – 设置 SIM 卡锁定或更改 SIM 卡的 PIN。

密码键入时可见 – 在您键入密码时，显示隐藏的密码的最后一个字符。

手机管理器 – 查看或停用手机管理器。

未知源 – 将设置默认为安装非 Play Store 应用程序。

验证应用程序 – 安装可能引起危害的应用程序之前进行禁用或警告。

存储器类型 – 受硬件支持。

可信凭据 – 显示可信 CA 证书。

从存储器开始安装 – 选择并安装已加密的证书。

清除凭据 – 删除所有证书。

Trust agents – 选择可在不解锁屏幕的情况下使用的应用程序。

屏幕固定 – 允许应用程序成为在您固定应用程序屏幕时所使用的唯一应用程序。

可以使用的应用程序 – 允许应用程序查看您手机上的应用程序使用信息。

<访客模式>

当您将手机借给其他人时，您可以限制要显示的应用程序。

<手势>

屏幕已开启/关闭 – 勾选以启用 KnockON，以便打开和关闭屏幕。 快速双击中心屏幕将打开屏幕。 双击状态栏、主屏幕上的空白区域或锁定屏幕将关闭屏幕。 为获得最佳效果，请勿在使用 KnockON 功能时移动手机。

将来电静音 – 勾选可翻转手机以将来电静音。

暂停或关闭闹钟 – 勾选后，只需翻转设备便可暂停或停止闹钟。

暂停视频 – 勾选后，只需翻转设备便可暂停当前播放的视频。

帮助 – 打开关于如何使用设备手势功能的帮助指南。

运动传感器校准 – 可让您提高倾斜精确度和感应器速度。

<QuickWindow 窗口>

激活可在使用 QuickWindow 窗口时以小视图显示音乐、天气和时钟等功能。

<日期和时间>

使用**日期和时间**设置可设置日期的显示方式。 您还可使用这些设置来设置自己的时间和时区，而非从移动网络获取当前时间。

<存储>

内部存储器 – 查看内部存储器使用情况。

SD 卡 – 检查 SD 卡总可用空间。 点触删除存储卡以安全移除。 如果要删除 SD 卡上的所有数据，请清除 SD 卡。

<电量使用情况>

电池信息

电池图上将显示电池电量信息，此外还将显示剩余电量百分比及电池状态。

电池使用情况 – 显示使用电池电量最多的组件和应用程序。 点击某个条目以查看更多详情。

状态栏上的电池电量百分比 – 勾选以在电池图标旁边的状态栏上显示电池使用量百分比。

省电

轻触省电开 关以打开或关闭此功能。 轻触省电可访问以下设置：

省电 – 设置将自动开启省电功能的电池电量百分比。 选择**开启省电模**式**和限制后台应用程序**。

帮助 – 轻触以查看关于省电提示的信息。

<应用程序>

查看并管理应用程序。

<默认消息应用程序>

将**信息**或**环聊**设置为默认应用程序。

<备份与重置>

更改设置以管理您的设置和数据。

备份我的数据 – 设为将您的设置和应用程序数据备份至 Google 服务器。

备份帐户 – 设为备份您的帐户。

自动还原 – 设置为在您的设备上重新安装应用程序时恢复您的设置和应用程序数据。

LG 备份服务 – 备份设备上的所有信息并在出现数据丢失或更换时进行恢复。

重置出厂数据 – 将您的设置重置为出厂默认值，然后删除所有数据。 如果以此方式重置手机，首次启动 Android 时，将提示您重新输入相同的信息。

<正在打印>

您可以将某些屏幕的内容（如 Chrome 浏览器显示的网页）通过打印机打印，此打印机须与您的 Android 设备连接的 WLAN 网络相同。

〈关于手机〉

查看法律信息，检查手机状态和软件版本。

PC 软件 (LG PC Suite)

“LG PC Suite”PC 软件是一种可帮助您使用 USB 数据线和 WLAN 将设备连接到 PC 的程序。 连接后，您可以在 PC 上使用设备的功能。

借助“LG PC Suite”PC 软件，您可以...

- 在 PC 上管理和播放媒体内容（音乐、电影、图片）。
- 将多媒体内容发送到设备。
- 同步设备和 PC 间的数据（日程表、联系人、书签）。
- 备份设备中的应用程序。
- 更新设备中的软件。。
- 在您的设备上播放 PC 中的多媒体内容。
- 在设备中备份、创建和编辑备忘录。

备注：您可使用应用程序中的“帮助”菜单，查找如何使用“LG PC Suite”PC 软件。

安装“LG PC Suite”PC 软件

可以从 LG 网页下载“LG PC Suite”PC 软件。

1 转到 www.lg.com，选择您所在的国家/地区。
2 转至**支持** > **手机支持** > **LG 手机** > **选择型号**
   或
   转至**支持** > **手机** > 选择型号。
3 单击**手册与下载**中的 **PC 同步**，然后单击 **WINDOW PC 同步下载**，下载“LG PC Suite”PC 软件。

“LG PC Suite”PC 软件的系统要求

- 操作系统：Windows XP (Service pack 3) 32 位、Windows Vista、Windows 7、Windows 8
- CPU: 1 GHz 或更高处理器
- 内存：512 MB 或更高 RAM
- 图形卡：1024 x 768 分辨率，32 位色彩或更高
- 硬盘：500 MB 或更多的可用硬盘空间（根据要存储数据的容量，可能需要更多的可用硬盘空间。）
- 所需软件：LG 集成的驱动程序、Windows Media Player 10 或更高版本

备注：LG 集成的 USB 驱动程序

需要使用 LG 集成的 USB 驱动程序连接 LG 设备和 PC，并且该驱动程序将在安装“LG PC Suite”PC 软件时自动安装。

PC 软件 (LG PC Suite)

将设备与 PC 同步

为便于您的使用，可以根据轻松将设备与 PC 中的数据与“LG PC Suite”PC 软件同步。您可同步日程表、联系人和书签。

步骤如下：

1 将设备连接到 PC。 （使用 USB 数据线或 WLAN 连接。）
2 **此**时将出现选择 USB 连接方法，然后选择 **LG 软件**。
3 连接后，运行程序，然后从屏幕左侧的类别中选择设备部分。
4 单击**个人信息**进行选择。
5 选择要同步内容的复选框，然后单击**同步**按钮。

备注：要将手机与 PC 同步，需要在 PC 上安装 LG PC Suite。 请参阅先前页面以安装 LG PC Suite。

将旧设备上的联系人移至新设备

1 使用 PC 同步程序将联系人作为 CSV 文件从旧设备导出到 PC。
2 首先在 PC 上安装“LG PC Suite”。 运行程序，并使用 USB 数据线将您的 Android 手机连接到 PC。
3 在顶层菜单中，选择**设备** > **导入设备** > **导入联系人**。
4 此时会出现一个弹出窗口，可供选择文件类型和要导入的文件。
5 在弹出窗口中，单击**选择文件**，此时会出现 Windows Explorer。
6 在 Windows Explorer 中选择要导入的联系人文件，然后单击**打开**。
7 单击**确定**。
8 此时会出现一个**字段映射**弹出窗口，可链接至设备中的联系人和新联系人数据。
9 如果 PC 联系人和设备联系人中的数据出现冲突，请在 LG PC Suite 中做出必要选择或修改。
10 单击**确定**。

手机软件更新

从互联网的 LG 手机软件更新

有关使用此功能的更多信息，请访问 http://www.lg.com/common/index.jsp →，选择您所在的国家/地区和语言。

此功能帮助您方便地从互联网将手机固件更新为最新版本，而无需访问服务中心。 只有当 LG 为您的设备提供了更新的固件版本时，此功能才可用。

由于手机固件更新要求用户高度重视更新过程的时长，因此在继续执行操作之前，请确保留意每一个步骤中出现的所有说明和提示。 请注意，在升级过程中移除 USB 数据线或取出电池将严重损坏您的手机。

备注：LG 保留根据自行判断决定固件更新仅可用于指定型号的权利，不保证所提供的固件更新版本可供所有手机型号使用。

通过空中下载 (OTA) 的 LG 手机软件更新

此功能使您可以通过 OTA 方便地将手机的软件更新为较新的版本，而无需连接 USB 数据线。 只有当 LG 为您的设备提供了更新的固件版本时，此功能才可用。

首先，您应在手机上检查软件版本：**设置** > **常规**选项卡 > **关于手机** > **更新中心** > **软件更新** > **现在检查更新**。

备注：手机内存中的您的个人数据（包括有关您 Google 帐户、其他任何帐户、您的系统和应用程序数据及设置、下载的任何应用程序和 DRM 许可信息）可能会在手机软件的更新过程中遗失。 因此，LG 建议您在更新手机软件之前，先备份个人数据。 对于任何个人数据的遗失，LG 概不负责。

备注：此功能取决于网络服务提供商、所在区域或国家/地区。

关于此用户手册

- 使用设备前，请仔细阅读本手册。 阅读本手册后，您可安全无误地使用手机。
- 本指南手册中提供的一些图像和抓拍图片在您的手机上显示可能不同。
- 您的内容可能与最终产品或者服务提供商或运营商提供的软件有所不同。内容如有更改，如不另行通知。 要获取本手册的最新版本，请访问 LG 网站 www.lg.com。
- 您手机的应用程序和各自的功能可能因国家/地区或硬件规格不同而有所差异。 因使用 LG 之外的提供商开发的应用程序而导致任何性能问题，LG 概不负责。
- 因编辑注册表设置或修改操作系统软件而导致性能或不兼容问题，LG 概不负责。 一旦尝试自定义操作系统，即可能导致设备或设备的应用程序无法正常运作。
- 仅可限制性地使用您手机提供的软件、音频、墙纸、图像和其他多媒体。 如果您将这些材料抽取一部分或整体用于商业或其他用途，您可能会侵犯版权法。 此时用户会因非法使用媒体而承担相应的全部法律责任。
- 发送信息、上传下载、自动同步或使用定位服务等数据服务可能会造成额外费用。 为避免额外费用，请选择一项适合您自身需求的数据计划。 联系您的服务提供商以获取更多详细信息。

商标

- LG 和 LG 徽标是 LG Electronics 的注册商标。
- 所有其他商标和版权是其各自所有者的财产。

DivX HD

关于 DIVX 视频：DivX® 是由 Rovi Corporation 的子公司 DivX，LLC 创建的数字视频格式。这是一个官方的DivX Certified® 设备，已通过严格的测试确认可播放 DivX 视频。请访问 divx.com 网站获取更多信息以及用于将文件转换为 DivX 视频的软件工具。

关于 DIVX 视频点播：本 DivX Certified® 认证设备注册后才能播放所购买的 DivX 视频点播 (VOD) 电影。要获得注册代码，请在设备设置菜单中找到 DivX VOD 区域。请访问 vod.divx.com 网站，详细了解如何完成注册。

通过 DivX Certified® 认证、可播放 DivX® 视频，最高可达 HD 720p，包括付费内容。

DivX®、DivX Certified® 和相关徽标是 Rovi Corporation 或其子公司的商标，均为授权使用。

Dolby Digital Plus

由 Dolby Laboratories 许可生产。 Dolby、Dolby Digital Plus 和 double-D 符号是 Dolby Laboratories 的商标。

注意： 开源软件

要获取 GPL、GPL、MPL 及其他开源证书下的相应源代码，请访问
http://opensource.lge.com/
可使用源代码下载所有相关许可条款、声明和通知。

配件

以下配件可与您的手机一起使用。 **（以下配件为可选配件。）**

旅行适配器

立体声耳机

快速入门指南

数据线

电池

备注：

- 务必使用正品 LG 配件。
- 否则可能导致保修失效。
- 配件可能根据国家/地区有所不同。

故障排除

本章列出了您在使用手机过程中可能遇到的一些问题。 有些问题可能需要您致电服务提供商，但大多数问题您可自行解决。

消息	可能原因	可行解决措施
SIM 卡错误	手机中没有安装 SIM 卡或 SIM 卡插入不正确。	请确保正确插入 SIM 卡。
没有网络连接/网络断开	信号弱，或者您在运营商网络范围之外。	将手机移到窗边或开放的区域中。 检查网络运营商覆盖地图。
	运营商应用了新服务。	检查 SIM 卡使用时间是否超过 6~12 个月。 如果超过，请在最近的网络提供商处更换 SIM 卡。 请与服务提供商联系。
代码不匹配	要更改安全码，您需要在此输入以确认新代码。	如果忘记代码，请联系您的服务提供商。
	两次输入的代码不匹配。	
无应用程序可供设置	服务提供商不支持或需要注册。	请与服务提供商联系。
无法拨打电话	拨号错误	新网络未获得授权。
	已插入新 SIM 卡。	查看新的限制。
	达到预付费上限。	与服务提供商联系或重新设置 PIN 2 的限制。

故障排除

消息	可能原因	可行解决措施
手机无法打开	按开/关键时间过短。	请按开/关键至少两秒钟。
	电池未充电。	为电池充电。 检查显示屏上的充电指示灯。
充电错误	电池未充电。	为电池充电。
	外部温度太热或太冷。	确保手机在正常温度下充电。
	触点问题	检查充电器以及与手机的连接。
	无电压	将充电器插入其他插座。
	充电器故障	更换充电器。
	错误充电器	请仅使用原装 LG 配件。
不允许使用号码	已打开固定拨号功能。	检查“设置”菜单并关闭该功能。
无法接收/发送短信和照片	内存已满	删除手机中的部分信息。
文件无法打开	不受支持的文件格式	检查受支持的文件格式。
我收到来电时，屏幕未打开。	近程传感器问题	如果使用保护带或保护套，请确保其未盖住近程传感器周围的区域。 确保近程传感器周围的区域干净。

消息	可能原因	可行解决措施
无声音	振动模式	检查声音菜单的设置状态以确保您不处于振动或静音模式下。
挂机或死机	间歇性软件问题	尝试通过网站执行软件更新。

常见问题解答

类别 子类别	问	答
BT 蓝牙 设备	蓝牙能提供哪些功能	您可以连接立体声/单声道耳机或车载套件等蓝牙音频设备。 另外，FTP 服务器连接至兼容设备时，您可以共享存储在存储媒体中的内容。
数据 联系人 备份	如何备份联系人？	联系人数据可以在您的耳机与 Gmail™ 之间同步。
数据 同步	是否可以设置与 Gmail 的单向同步？	只提供双向同步。
数据 同步	是否可以同步所有电子邮件文件夹？	收件箱会自动同步。 您可通过轻触**菜单键** ⋮ 并选择**文件夹**以选中一个文件夹，查看其他文件夹。
Google™ 服务 Gmail 登录	我是否需要在每次访问 Gmail 时均需要登录 Gmail？	一旦登录 Gmail，无需再次登录。
Google™ 服务 Google 帐户	是否可以过滤电子邮件？	否，不支持通过手机过滤电子邮件。
手机功能 电子邮件	在编写电子邮件时如果执行另一应用程序会发生什么情况？	您的电子邮件将自动保存为草稿。
手机功能 铃声	使用 MP3 文件作为铃声时是否有文件大小限制？	没有文件大小限制。
手机功能 信息时间	如果收到的信息超过 24 小时，则手机将不显示此信息的收到时间。 我如何才能查看时间？	打开会话，点触并按住所需信息。 然后轻触**详细信息**。

类别 子类别	问	答
手机功能 导航	是否可以在我的手机上安装其他导航应用程序？	在 Play Store™ 上可用并且与硬件兼容的任何应用程序均可安装和使用。
手机功能 同步	是否可以从我的所有电子邮件帐户同步我的联系人？	仅可同步 Gmail 和 MS Exchange 服务器（公司电子邮件服务器）联系人。
手机功能 等待和暂停	是否可以在保存联系人时对号码中使用等待和暂停功能？	如果您传输的联系人的号码使用了等待和暂停功能，则您无法使用这些功能。 您需要重新保存每个号码。 如何使用等待和暂停功能进行保存？ 1. 在主屏上轻触**手机**图标 。 2. 拨打号码，然后轻触**菜单键** 。 3. 轻触**添加两秒暂停**或**添加等待**。
手机功能 安全	手机有什么安全功能？	您可以将手机设为在访问或使用手机前需要输入解锁图样。
手机功能 解锁 图样	如何创建解锁图样？	1. 在主屏中，点触并按住 **最近运行的应用程序键** 。 2. 轻触**系统设置** > **显示**选项卡 > **锁定屏幕**。 3. 轻触**选择屏幕锁定** > **图案**。 第一次这样做时，将显示有关创建解锁图样的简短指南。 4. 通过画出图样一次，然后再画一次确认进行设置。 **使用图样锁定时的预防措施。** 请务必记住您设置的解锁图案。 如果有 5 次使用不正确的图样，您将无法访问手机。您有 5 次机会输入解锁图样、PIN 或密码。 如果您用完 5 次机会，需等待 30 秒方可再次尝试。 （或者，如果预设了备份 PIN，您可使用备份 PIN 码解锁图样。）

类别 子类别	问	答
手机功能 解锁 图样	在忘记解锁图样并且未在手机上创建我的 Google 帐户时该怎么办？	**如果您忘记图样：** 若要在手机上登录 Google 帐户，但连续 5 次输错图案，请轻触“忘记图案”按钮。 随后，您需要使用 Google 帐户登录才能将手机解锁。 如果未在手机上创建 Google 帐户或者忘记了该帐户，则需要执行硬重置。 **注意：如果执行恢复出厂设置，将删除所有用户应用程序和用户数据。 在执行恢复出厂设置之前，请记得备份任何重要数据。**
手机功能 内存	内存已满时我是否会知道？	是，您将收到通知。
手机功能 语言支持	是否可以更改手机语言？	手机具有多语言功能。 更改语言： 1. 在主屏中，点触并按住 **最近运行的应用程序键** □，然后轻触**系统设置**。 2. 轻触**常规**选项卡 > **语言和输入** > **语言**。 3. 轻触所需的语言。
手机功能 VPN	如何设置 VPN？	VPN 访问配置根据每个公司而有所不同。要从手机配置 VPN 访问，您必须从公司的网络管理员获得详细信息。
手机功能 屏幕超时	我的屏幕仅 15 秒后便关闭。 如何更改关闭背景灯的时间量？	1. 在主屏中，点触并按住 **最近运行的应用程序键** □。 2. 轻触**系统设置** > **显示**选项卡。 3. 轻触**屏幕超时**。 4. 轻触首选屏幕背景灯超时时间。

类别 子类别	问	答
手机功能 WLAN 和移动网络	在 WLAN 和移动网络均可用时，我的手机将使用哪个服务？	在使用数据时，您的手机可默认为 WLAN 连接（如果手机上的 WLAN 连接设为“开”）。 但是，在手机从一个服务切换到另一服务时将不发出通知。 要知道正在使用哪个数据连接，请查看屏幕顶部的移动网络或 WLAN 图标。
手机功能 主屏	是否可以从主屏删除应用程序？	是。 只需触摸并按住此图标，直到屏幕右上方出现垃圾桶图标。 然后，在不抬起手指的情况下，将图标拖到垃圾桶。
手机功能 应用程序	我下载了一个应用程序，但其导致了许多错误。如何删除它？	1. 在主屏中，点触并按住 **最近运行的应用程序键** □。 2. 轻触**系统设置** > **常规** 选项卡 > **应用程序** > **已下载**。 3. 轻触应用程序，然后轻触**卸载**。
手机功能 充电器	是否可以在未安装所需 USB 驱动程序的情况下通过 USB 数据线为手机充电？	可以，无论是否安装了必要的驱动程序，此手机均可以通过 USB 数据线充电。
手机功能 闹钟	我是否可以将音乐文件用作闹钟铃声？	是。 在闹钟设置中，选择用作闹钟铃声的歌曲。
手机功能 闹钟	如果手机关闭，还可听见我的闹钟吗？	否，不支持此功能。
手机功能 闹钟	如果我的“铃声音量”设为“振动”，我能否听到闹钟？	闹钟设定为即使在这些情况下也可听到。
恢复解决方案 硬重置（恢复出厂设置）	如果无法访问手机的设置菜单，如何执行恢复出厂设置？	如果手机未恢复到原始条件，请使用硬重置（恢复出厂设置）初始化手机。

ENGLISH

User Guide

- Screen displays and illustrations may differ from those you see on actual phone.
- Some of the contents of this guide may not apply to your phone, depending on the software and your service provider. All information in this document is subject to change without notice.
- This handset is not suitable for people who have a visual impairment due to the tap screen keyboard.
- Copyright ©2015 LG Electronics, Inc. All rights reserved. LG and the LG logo are registered trademarks of LG Group and its related entities. All other trademarks are the property of their respective owners.
- Google™, Google Maps™, Gmail™, YouTube™, Hangouts™ and Play Store™ are trademarks of Google, Inc.

Table of contents

Guidelines for safe and efficient use 5

Important notice 11

Getting to know your phone.....15
Phone overview.....15
Installing the SIM card and battery 17
Charging your phone 19
Using the memory card 20
Locking and unlocking the screen 21

Your Home screen.....22
Touch screen tips 22
Home screen.....22
Extended home screen.....23
Customizing the Home screen 23
Returning to recently-used applications.....24
Notifications panel.....24
Opening the notifications panel.....25
Indicator icons on the Status Bar.....26
On-screen keyboard.....27
Entering accented letters.....27

Google account setup.....28
To set up your Google account.....28

Connecting to Networks and Devices.....29
Wi-Fi 29
Connecting to Wi-Fi networks 29
Turning Wi-Fi on and connecting to a Wi-Fi network.....29
Bluetooth 30
Sharing your phone's data connection.....31
Wi-Fi Direct.....32
SmartShare.....32
Enjoying the content from Nearby devices.....33
PC connections with a USB cable 33

Calls 35
Making a call 35
Calling your contacts.....35
Adjusting the in-call volume 35
Making a second call 35
Viewing your call logs.....36
Call settings 36

Contacts.....37
Searching for a contact 37
Adding a new contact.....37
Favourites contacts 37
Creating a group 38

Messaging.....39
Sending a message.....39
Threaded box 39
Changing your message settings.....40

E-mail.....41
Managing an email account 41
Working with account folders 41
Composing and sending email.....41

Camera.....42
Getting to know the viewfinder.....42
Using the advanced settings.....43
Taking a quick photo 44
Using Time catch shot mode 44
Once you've taken a photo 45

Video camera 46

Getting to know the viewfinder 46
Using the advanced settings.....47
Recording a quick video 47
After recording a video 48

Function 49
Knock Code.....49
QuickMemo+ 49
Using the QuickMemo+ options.....50
Viewing the saved QuickMemo+ 50
QSlide 51
QuickRemote 52

Multimedia 54
Gallery 54
Viewing pictures 54
Playing videos.....54
Editing photos.....54
Deleting photos/videos 54
Setting as wallpaper.....55
Videos.....55
Playing a video 55
Music.....56
Playing a song 56
Add music files to your phone.....58
FM Radio 58

Utilities 59
Setting your alarm.....59
Using your calculator.....59
Adding an event to your calendar 59
Voice Recorder.....60
Recording a sound or voice 60
Tasks 60
ThinkFree Viewer.....61
Google+ 61
Voice Search 61
Downloads.....61
LG SmartWorld.....62
How to Get to LG SmartWorld from Your Phone 62
How to use LG SmartWorld.....62

The Web 63
Internet 63
Using the Web toolbar 63
Viewing webpages 63
Opening a page 63
Searching the web by voice 64
Bookmarks 64
History 64
Chrome.....64
Viewing webpages 64
Opening a page 64

Settings 65
Networks 65
Sound 67
Display.....68
General 69

PC software (LG PC Suite) 73

Phone software update 75
Phone software update.....75

About this user guide 76
About this user guide 76
Trademarks.....76
DivX HD.....76
Dolby Digital Plus 77

Table of contents

Accessories.....78

Troubleshooting 79

FAQ 82

Guidelines for safe and efficient use

Please read these simple guidelines. Not following these guidelines may be dangerous or illegal.

Should a fault occur, a software tool is built into your device that will gather a fault log.

This tool gathers only data specific to the fault, such as signal strength, cell ID position in sudden call drop and applications loaded. The log is used only to help determine the cause of the fault. These logs are encrypted and can only be accessed by an authorized LG Repair centre should you need to return your device for repair.

Exposure to radio frequency energy

Radio wave exposure and Specific Absorption Rate (SAR) information.

This mobile phone model LG-D620k has been designed to comply with applicable safety requirements for exposure to radio waves. These requirements are based on scientific guidelines that include safety margins designed to assure the safety of all persons, regardless of age and health.

- The radio wave exposure guidelines employ a unit of measurement known as the Specific Absorption Rate (SAR). Tests for SAR are conducted using standardised methods with the phone transmitting at its highest certified power level in all used frequency bands.
- While there may be differences between the SAR levels of various LG phone models, they are all designed to meet the relevant guidelines for exposure to radio waves.
- The SAR limit recommended by the International Commission on Non-Ionizing Radiation Protection (ICNIRP) is 2 W/kg averaged over 10g of tissue.
- The highest SAR value for this model phone tested for use at the ear is 0.336 W/kg (10g) and when worn on the body is 0.332 W/Kg (10g).
- This device meets RF exposure guidelines when used either in the normal use position against the ear or when positioned at least 1.5 cm away from the body. When a carry case, belt clip or holder is used for body-worn operation, it should not contain metal and should position the product at least 1.5 cm away from your body. In order to transmit data files or messages, this device requires a quality connection to the network. In some cases, transmission of data files or messages may be delayed until such a connection is available. Ensure the above separation distance instructions are followed until the transmission is completed.

Guidelines for safe and efficient use

Product care and maintenance

WARNING

Only use batteries, chargers and accessories approved for use with this particular phone model. The use of any other types may invalidate any approval or warranty applying to the phone and may be dangerous.

- Do not disassemble this unit. Take it to a qualified service technician when repair work is required.
- Repairs under warranty, at LG's discretion, may include replacement parts or boards that are either new or reconditioned, provided that they have functionality equal to that of the parts being replaced.
- Keep away from electrical appliances such as TVs, radios and personal computers.
- The unit should be kept away from heat sources such as radiators or cookers.
- Do not drop.
- Do not subject this unit to mechanical vibration or shock.
- Switch off the phone in any area where you are required to by special regulations. For example, do not use your phone in hospitals as it may affect sensitive medical equipment.
- Do not handle the phone with wet hands while it is being charged. It may cause an electric shock and can seriously damage your phone.
- Do not charge a handset near flammable material as the handset can become hot and create a fire hazard.
- Use a dry cloth to clean the exterior of the unit (do not use solvents such as benzene, thinner or alcohol).
- Do not charge the phone when it is on soft furnishings.
- The phone should be charged in a well ventilated area.
- Do not subject this unit to excessive smoke or dust.
- Do not keep the phone next to credit cards or transport tickets; it can affect the information on the magnetic strips.
- Do not tap the screen with a sharp object as it may damage the phone.
- Do not expose the phone to liquid or moisture.
- Use accessories like earphones cautiously. Do not touch the antenna unnecessarily.
- Do not use, touch or attempt to remove or fix broken, chipped or cracked glass. Damage to the glass display due to abuse or misuse is not covered under the warranty.
- Your phone is an electronic device that generates heat during normal operation. Extremely prolonged, direct skin contact in the absence of adequate ventilation may result in discomfort or minor burns. Therefore, use care when handling your phone during or immediately after operation.

- If your phone gets wet, immediately unplug it to dry off completely. Do not attempt to accelerate the drying process with an external heating source, such as an oven, microwave or hair dryer.
- The liquid in your wet phone, changes the color of the product label inside your phone. Damage to your device as a result of exposure to liquid is not covered under your warranty.

Efficient phone operation

Electronics devices

All mobile phones may receive interference, which could affect performance.

- Do not use your mobile phone near medical equipment without requesting permission. Avoid placing the phone over pacemakers, for example, in your breast pocket.
- Some hearing aids might be disturbed by mobile phones.
- Minor interference may affect TVs, radios, PCs etc.
- Use your phone in temperatures between 0ºC and 40ºC, if possible. Exposing your phone to extremely low or high temperatures may result in damage, malfunction, or even explosion.

Road safety

Check the laws and regulations on the use of mobile phones in the area when you drive.

- Do not use a hand-held phone while driving.
- Give full attention to driving.
- Pull off the road and park before making or answering a call if driving conditions so require.
- RF energy may affect some electronic systems in your vehicle such as car stereos and safety equipment.
- When your vehicle is equipped with an air bag, do not obstruct with installed or portable wireless equipment. It can cause the air bag to fail or cause serious injury due to improper performance.
- If you are listening to music whilst out and about, please ensure that the volume is at a reasonable level so that you are aware of your surroundings. This is of particular importance when near roads.

Guidelines for safe and efficient use

Avoid damage to your hearing

To prevent possible hearing damage, do not listen at high volume levels for long periods.

Damage to your hearing can occur if you are exposed to loud sound for long periods of time. We therefore recommend that you do not turn on or off the handset close to your ear. We also recommend that music and call volumes are set to a reasonable level.

- When using headphones, turn the volume down if you cannot hear the people speaking near you, or if the person sitting next to you can hear what you are listening to.

NOTE: Excessive sound pressure from earphones and headphones can cause hearing loss

Glass Parts

Some parts of your mobile device are made of glass. This glass could break if your mobile device is dropped on a hard surface or receives a substantial impact. If the glass breaks, do not touch or attempt to remove it. Stop using your mobile device until the glass is replaced by an authorised service provider.

Blasting area

Do not use the phone where blasting is in progress. Observe restrictions and follow any regulations or rules.

Potentially explosive atmospheres

- Do not use your phone at a refueling point.
- Do not use near fuel or chemicals.
- Do not transport or store flammable gas, liquid or explosives in the same compartment of your vehicle as your mobile phone or accessories.

In aircraft

Wireless devices can cause interference in aircraft.

- Turn your mobile phone off before boarding any aircraft.
- Do not use it on the ground without permission from the crew.

Children

Keep the phone in a safe place out of the reach of small children. It includes small parts which may cause a choking hazard if detached.

Emergency calls

Emergency calls may not be available on all mobile networks. Therefore you should never depend solely on your phone for emergency calls. Check with your local service provider.

Battery information and care

- You do not need to completely discharge the battery before recharging. Unlike other battery systems, there is no memory effect that could compromise the battery's performance.
- Use only LG batteries and chargers. LG chargers are designed to maximise the battery life.
- Do not disassemble or short-circuit the battery.
- Replace the battery when it no longer provides acceptable performance. The battery pack may be recharged hundreds of times before it needs replacing.
- Recharge the battery if it has not been used for a long time to maximise usability.
- Do not expose the battery charger to direct sunlight or use it in high humidity, such as in the bathroom.
- Do not leave the battery in hot or cold places, as this may deteriorate battery performance.
- There is risk of explosion if the battery is replaced with an incorrect type.
- Dispose of used batteries according to the manufacturer's instructions. Please recycle when possible. Do not dispose as household waste.
- If you need to replace the battery, take it to the nearest authorised LG Electronics service point or dealer for assistance.

Guidelines for safe and efficient use

- Always unplug the charger from the wall socket after the phone is fully charged to save unnecessary power consumption of the charger.
- Actual battery life will depend on network configuration, product settings, usage patterns, battery and environmental conditions.
- Make sure that no sharp-edged items such as animal's teeth or nails, come into contact with the battery. This could cause a fire.

DECLARATION OF CONFORMITY

Hereby, **LG Electronics** declares that this **LG-D620k** product is in compliance with the essential requirements and other relevant provisions of Directive **1999/5/EC**. A copy of the Declaration of Conformity can be found at **http://www.lg.com/global/declaration**

Important notice

Please read this before you start using your phone!

Please check to see whether any problems you encountered with your phone are described in this section before taking the phone in for service or calling a service representative.

1. Phone memory

When there is less than 10% of space available in your phone memory, your phone cannot receive new messages. You need to check your phone memory and delete some data, such as applications or messages, to make more memory available.

To uninstall applications:

1 Tap [ ] > > **Apps** tab > **Settings** > **General** tab > **Apps**.
2 Once all applications appear, scroll to and select the application you want to uninstall.
3 Tap **Uninstall**.

2. Optimizing battery life

Extend your battery's power by turning off features that you don't have to run constantly in the background. You can monitor how applications and system resources consume battery power.

Extending your phone's battery life:

- Turn off radio communications when you are not using. If you are not using Wi-Fi, Bluetooth or GPS, turn them off.
- Reduce screen brightness and set a shorter screen timeout.
- Turn off automatic syncing for Gmail, Calendar, Contacts and other applications.
- Some applications you have downloaded may reduce battery power.
- While using downloaded applications, check the battery charge level.

To check the battery power level:

- Tap [ ] > > **Apps** tab > **Settings** > **General** tab > **About phone** > **Battery.**

The battery status (charging or discharging) and battery level (percentage charged) is displayed at the top of the screen.

To monitor and control how battery power is being used:

- Tap [ ] > > **Apps** tab > **Settings** > **General** tab > **About phone** > **Battery > Battery usage**.

Battery usage time is displayed on the screen. It tells you how long it has been since you last connected your phone to a power source or, if currently connected, how long the phone was last running on battery power. The screen shows the applications or services using battery power, listed in order from the greatest to smallest amount used.

3. Before installing an open source application and OS

WARNING

If you install and use an OS other than the one provided by the manufacturer it may cause your phone to malfunction. In addition, your phone will no longer be covered by the warranty.

WARNING

To protect your phone and personal data, only download applications from trusted sources, such as Play Store™. If there are improperly installed applications on your phone, the phone may not work normally or a serious error may occur. You must uninstall those applications and all associated data and settings from the phone.

4. Using an unlock pattern

Set an unlock pattern to secure your phone. Tap [ ] > > **Apps** tab > **Settings** > **Display** tab > **Lock screen** > **Select screen lock** > **Pattern**. This opens a screen that will guide you through how to draw a screen unlock pattern. You have to create a Backup PIN as a safety measure in case you forget your unlock pattern.

Caution: Create a Google account before setting an unlock pattern and remember the Backup PIN you created when creating your pattern lock.

⚠ WARNING

Precautions to take when using pattern lock.

It is very important to remember the unlock pattern you set. You will not be able to access your phone if you use an incorrect pattern 5 times. You have 5 opportunities to enter your unlock pattern, PIN or password. If you have used all 5 opportunities, you can try again after 30 seconds.

When you can't recall your unlock Pattern, PIN or Password:

< If you have forgotten your pattern >

If you logged in to your Google account on the phone but failed to enter the correct pattern 5 times, tap the **Forgot pattern?** button at the bottom of the screen. You are then required to log in with your Google Account or you have to enter the Backup PIN which you entered when creating your Pattern Lock.

If you have not created a Google account on the phone or you forgot Backup PIN, you have to perform a hard reset.

< If you have forgotten your PIN or Password >

If you forget your PIN or Password, you will need to perform a hard reset.

Caution: If you perform a hard reset, all user applications and user data will be deleted.

NOTE: If you have not logged into your Google Account and have forgotten your Unlock Pattern, you will need to enter your Backup PIN.

5. Opening and switching applications

Multi-tasking is easy with Android, you can keep more than one application running at the same time. There is no need to quit an application before opening another one. Use and switch between several open applications. Android manages each application, stopping and starting them as needed to ensure that idle applications don't consume resources unnecessarily.

1 Touch the **Recent Apps Key** [□]. A list of recently used applications will be displayed.

2 Tap the application you want to access. This does not stop the previous app running in the background on the phone. Make sure to tap **Back Key** [◁] to exit an app after using it.

- To stop applications, tap **Task Manager** from the recent apps list, then tap **Stop** or **Stop all**.
- To remove an app from the recent apps list, swipe the app preview to the left or right. To clear all apps, tap **Clear all**.

6. Transferring music, photos and videos using Media device (MTP)

1 Tap [ ] > > **Apps** tab > **Settings** > **General** tab > **Storage** to check out the storage media.
2 Connect the phone to your PC using the USB cable.
3 Slide down the status bar and select the **Media device (MTP)** option.
4 Open the memory folder on your PC. You can view the mass storage content on your PC and transfer the files from PC to Device memory folder or vice versa.

7. Hold your phone upright

Hold your cell phone vertically, as you would a regular phone. Your phone has an internal antenna. Be careful not to scratch or damage the back of the phone, as this may affect performance.

When making/receiving calls or sending/receiving data, avoid holding the lower part of the phone where the antenna is located. Doing so may affect call quality.

8. When the screen freezes

If the screen freezes or the phone does not respond when you try to operate it:

Remove the battery, reinsert it, then turn the phone on. If it still does not work, please contact the service center.

Getting to know your phone

Phone overview

NOTE: Proximity sensor

When receiving and making calls, the proximity sensor automatically turns the backlight off and locks the touch screen by sensing when the phone is near your ear. This extends battery life and prevents you from unintentionally activating the touch screen during calls.

⚠WARNING

Placing a heavy object on the phone or sitting on it can damage the LCD and touch screen functions. Do not cover the LCD proximity sensor with protective film. This could cause the sensor to malfunction.

Getting to know your phone

WARNING

Be careful not to damage the NFC touch point on the phone, which is part of the NFC antenna.

Installing the SIM card and battery

Before you can start exploring your new phone, you'll need to set it up. To insert the SIM card and battery.

1 To remove the battery cover, hold the phone firmly in one hand. With your other hand, lift off the battery cover with your thumbnail as shown in figure.

2 Slide the SIM card into its slot as shown in the figure. Make sure the gold contact area on the card is facing downwards.

3 Insert the battery into place by aligning the gold contacts on the phone and the battery (1) and pressing it down until it clicks into place (2).

4 Align the battery cover over the battery compartment (1) and press it down until it clicks into place (2).

Charging your phone

Charge the battery before using it for the first time. Use the charger to charge the battery. A computer can be also used to charge the device by connecting them via the USB cable.

WARNING

Use only LG-approved chargers, batteries, and cables. When using unapproved chargers or cables, it may cause battery charging delay or pop-up message regarding slow charging. Or, unapproved chargers or cables can cause the battery to explode or damage the device, which are not covered by the warranty.

The charger connector is at the bottom of the phone. Insert the charger and plug it into an electrical outlet.

NOTE:
- The battery must be fully charged initially to improve battery lifetime.
- Do not open the back cover while your phone is charging.

Using the memory card

Your phone supports the use of microSD™ or microSDHC™ memory cards of up to 32 GB capacity. These memory cards are specifically designed for mobile phones and other ultra-small devices, and are ideal for storing media-rich files such as music, programs, videos, and photographs for use with your phone.

To insert a memory card:

Insert the memory card into the slot. Make sure the gold contact area is facing downwards.

To safely remove the memory card:

Touch > **Apps** tab > **Settings** > **General** tab > **Storage** > **Unmount SD card**.

NOTE:

- Use only compatible memory cards with your phone. Using incompatible memory cards may damage the card and data stored on the card, as well as the phone.
- As the device uses FAT32, the maximum size for any given file is 4 GB.

WARNING

Do not insert or remove the memory card when the phone is ON. Doing so may damage the memory card as well as your phone, and the data stored on the memory card may become corrupt.

To format the memory card:

Your memory card may already be formatted. If it isn't, you must format it before you can use it.

NOTE: All files on your memory card are deleted when it is formatted.

1 Touch to open the application list.
2 Scroll and touch **Settings** > **General** tab > **Storage**.
3 Touch **Unmount SD card**.
4 Touch **Erase SD card** > **Erase SD card** > **Erase everything**.
5 If you have set a pattern lock, input the pattern lock then select **Erase everything**.

NOTE: If there is content on your memory card, the folder structure may be different after formatting, as all the files will have been deleted.

Locking and unlocking the screen

If you do not use the phone for a while, the screen will be automatically turned off and locked. This helps to prevent accidental taps and saves battery power.

When you are not using the phone, press the **Power/Lock key** to lock your phone.

If there are any programs running when you lock your screen, they may be still running in Lock mode. It is recommended that you exit all programs before entering Lock mode to avoid unnecessary charges (e.g. phone calls, web access and data communications).

To wake up your phone, press the **Power/Lock key**. The Lock screen will appear. Touch and slide the Lock screen in any direction to unlock your Home screen. The last screen you viewed will open.

Your Home screen

Touch screen tips

Here are some tips on how to navigate on your phone.

Tap or touch – A single finger tap selects items, links, shortcuts and letters on the on-screen keyboard.

Touch and hold – Touch and hold an item on the screen by tapping it and not lifting your finger until an action occurs. For example, to open a contact's available options, touch and hold the contact in the Contacts list until the context menu opens.

Drag – Touch and hold an item for a moment and then, without lifting your finger, move your finger on the screen until you reach the target position. You can drag items on the Home screen to reposition them.

Swipe or slide – To swipe or slide, quickly move your finger across the surface of the screen, without pausing when you first tap it (so you don't drag an item instead). For example, you can slide the screen up or down to scroll through a list, or browse through the different Home screens by swiping from left to right (and vice versa).

Double-tap – Double-tap to zoom on a webpage or a map. For example, quickly double-tap a section of a webpage to adjust that section to fit the width of the screen. You can also double-tap to zoom in and out while viewing the picture.

Pinch-to-Zoom – Use your index finger and thumb in a pinching or spreading motion to zoom in or out when using the browser or Maps, or when browsing pictures.

Rotate the screen – From many applications and menus, the orientation of the screen adjusts to the device's physical orientation.

NOTE:

- To select an item, tap the center of the icon.
- Do not press too hard; the tap screen is sensitive enough to pick up a light, yet firm tap.
- Use the tip of your finger to tap the option you want. Be careful not to tap any other keys.

Home screen

The Home screen is the starting point for many applications and functions, and it allows you to add items like application shortcuts, or Google widgets to give you instant access to information and applications. This is the default canvas and accessible from any menu by tapping ○.

Status Bar

Shows phone's status information including the time, signal strength, battery status, and notification icons.

Widget

Widgets are self-contained applications that can be accessed through the Apps screen or on the Home screen or an extended home screen. Unlike a shortcut, the Widget appears as an on-screen application.

Application Icons

Tap an icon (application, folder, etc.) to open and use it.

Location Indicator

Indicates which Home screen canvas you are viewing.

Quick Key Area

Provides one-touch access to the function in any home screen canvas.

Extended home screen

The operating system provides multiple Home screen canvases to provide more space for adding icons, widgets, and more.

- ▶ Slide your finger left or right across the Home screen.

Customizing the Home screen

You can customize your Home screen by adding apps, widgets or changing wallpapers.

To add items on your Home screen

1. Touch and hold the empty part of the Home screen.
2. In the Add Mode menu, select the item you wish to add. You will then see this added item on the Home screen.
3. Drag it to the desired location and lift your finger.

Your Home screen

TIP! To add an application icon to the Home screen from the Apps menu, touch and hold the application you want to add.

To remove an item from the Home screen

- Home screen > touch and hold the icon you want to remove > drag it to Remove.

To add an app as a Quick key

- From the Apps menu or on the Home screen, touch and hold an application icon and drag it to the Quick key area.

To remove an app from the Quick key area

- Touch and hold the desired quick key and drag it to Remove.

NOTE: **Apps** key cannot be removed.

To customize apps icons on the Home screen

1. Touch and hold an application icon until it is unlocked from its current position. Then drop it on the screen. The editing icon will appear in the upper right corner of the application.
2. Tap the application icon again and select the desired icon design and size.
3. Tap **OK** to save the change.

Returning to recently-used applications

1. Touch . A list of recently used applications will be displayed.
2. Tap an icon to open the application. Or tap to return to your previous screen.

Notifications panel

Notifications alert you the arrival of new messages, calendar events, and alarms, as well as to ongoing events, such as when you are on a call.

When a notification arrives, its icon appears at the top of the screen. Icons for pending notifications appear on the left, and system icons such as Wi-Fi or battery strength shown on the right.

NOTE: The available options may vary depending on the region or service provider.

Opening the notifications panel

Swipe down from the status bar to open the notifications panel.

Quick Toggle Area

Tap each quick toggle key to turn it on/off. Touch and hold the key to access the settings menu of the function. To see more toggle keys, swipe left or right. Tap to remove, add, or rearrange toggle keys.

QSlide apps

Tap a QSlide app to open as a small window on your screen. Tap to remove, add, or rearrange QSlide apps.

Notifications

The current notifications are listed, each with a brief description. Tap a notification to view it.

Tap to clear all the notifications.

To close the notifications panel, touch and drag the tab toward the top of the screen.

Your Home screen

Indicator icons on the Status Bar

Indicator icons appear on the status bar at the top of the screen to report missed calls, new messages, calendar events, device status and more.

The icons displayed at the top of the screen provide information about the status of the device. The icons listed in the table below are some of the most common ones.

Icon	Description	Icon	Description
	No SIM card inserted		Do not disturb
	No network signal available		Vibrate mode is on
	Airplane mode is on		Battery fully charged
	Connected to a Wi-Fi network		Battery is charging
	Wired headset connected		Phone is connected to PC via USB cable
	Call in progress		Downloading data
	Missed call		Uploading data
	Bluetooth is on		GPS is on
	NFC is on		Data is synchronizing
	System warning		New Gmail message available
	An alarm is set		New Hangouts message available

	New voicemail available		Choose input method
	New text or multimedia message		Wi-Fi hotspot is active
	A song is currently playing		

NOTE: The icons location in the status bar may differ according to the function or service.

On-screen keyboard

You can enter text using the on-screen keyboard. The on-screen keyboard appears automatically on the screen when you need to enter text. To manually display the keyboard, simply tap a text field where you want to enter text.

Using the keypad & entering text

Tap once to capitalize the next letter you type. Double-tap for all caps.

Tap to switch to the symbols keyboard.

Tap to enter a space.

Tap to create a new line.

Tap to delete the previous character.

Entering accented letters

When you select French or Spanish as the text entry language, you can enter special French or Spanish characters (e.g. "á").

For example, to input "á", touch and hold the "a" key until the zoom-in key grows bigger and displays characters from different languages.

Then select the special character you want.

Google account setup

When you first turn on your phone, you have the opportunity to activate the network, to sign into your Google Account and select how you want to use certain Google services.

To set up your Google account

- Sign into a Google Account from the prompted set-up screen.

  OR

- Tap [ ] > > **Apps** tab > select a Google application, such as **Gmail** > Tap **GOT IT** > select **Add an email address** to create a new account.

Once you have set up your Google account on your phone, your phone automatically synchronizes with your Google account on the Web.

Your contacts, Gmail messages, Calendar events and other information from these applications and services on the Web are synchronized with your phone. (This will depend on your synchronization settings.)

After signing in, you can use Gmail™ and take advantage of Google services on your phone.

Connecting to Networks and Devices

Wi-Fi

With Wi-Fi, you can use high-speed Internet access within the coverage of the wireless access point (AP). Enjoy wireless Internet using Wi-Fi, without extra charges.

Connecting to Wi-Fi networks

To use Wi-Fi on your phone, you need to access a wireless access point or 'hotspot'. Some access points are open and you can simply connect to them. Others are hidden or use security features; you must configure your phone to be able to connect to them.

Turn off Wi-Fi when you're not using it to extend the life of your battery.

NOTE: If you are out of the Wi-Fi zone or have set Wi-Fi to **OFF**, additional charges may be applied by your mobile operator for mobile data use.

Turning Wi-Fi on and connecting to a Wi-Fi network

1 Tap [ ] > > **Apps** tab > **Settings** > **Networks** tab > **Wi-Fi**.

2 Set **Wi-Fi** to **ON** to turn it on and start scanning for available Wi-Fi networks.

3 Tap the Wi-Fi menu again to see a list of active and in-range Wi-Fi networks.
- Secured networks are indicated by a lock icon.

4 Tap a network to connect to it.
- If the network is secured, you are prompted to enter a password or other credentials. (Ask your network administrator for details)

5 The status bar displays icons that indicate Wi-Fi status.

Bluetooth

You can use Bluetooth to send data by running a corresponding application, but not from the Bluetooth menu as on most other mobile phones.

NOTE:
- LG is not responsible for the loss, interception or misuse of data sent or received via the Bluetooth wireless feature.
- Always ensure that you share and receive data with devices that are trusted and properly secured. If there are obstacles between the devices, the operating distance may be reduced.
- Some devices, especially those that are not tested or approved by Bluetooth SIG, may be incompatible with your device.

Turning on Bluetooth and pairing up your phone with a Bluetooth device

You must pair your device with another device before you connect to it.

1 Tap [ ] > > **Apps** tab > **Settings** > **Networks** tab > set **Bluetooth** to **ON**.
2 Tap the **Bluetooth** menu again. You will see the option to make your phone visible and option to search devices. Now tap **Search** to view the devices in the Bluetooth Range.
3 Choose the device you want to pair with from the list.

Once the paring is successful, your device will connect to the other device.

NOTE: Some devices, especially headsets or hands-free car kits, may have a fixed Bluetooth PIN, such as 0000. If the other device has a PIN, you will be asked to enter it.

Send data using the Bluetooth wireless feature

1 Select a file or item, such as a contact, calendar event or media file, from an appropriate application or from **Downloads**.
2 Select the option for sending data via Bluetooth.

NOTE: The method for selecting an option may vary by data type.

3 Search for and pair with a Bluetooth-enabled device.

Receive data using the Bluetooth wireless feature

1 Tap [ ] > > **Apps** tab > **Settings** > **Networks** tab > set **Bluetooth** to **ON**.

2 Tap the **Bluetooth** menu again and mark the checkbox at the top of the screen to make your phone visible to other devices.

NOTE: To select the length of time that your device will be visible, tap > **Visibility timeout**.

3 Select **Accept** to confirm that you are willing to receive data from the device.

Sharing your phone's data connection

USB tethering and portable Wi-Fi hotspot are great features when there are no wireless connections available. You can share your phone's mobile data connection with a single computer via a USB cable (USB tethering). You can also share your phone's data connection with more than one device at a time by turning your phone into a portable Wi-Fi hotspot.

When your phone is sharing its data connection, an icon appears in the status bar and as an ongoing notification in the notifications drawer.

For the latest information about tethering and portable hotspots, including supported operating systems and other details, visit http://www.android.com/tether.

To share your phone's data connection as a portable Wi-Fi hotspot

1 Tap > > **Apps** tab > **Settings > Networks** tab > **Tethering & networks** > **Wi-Fi hotspot** switch to activate.

2 Enter a password and tap **Save**.

TIP! If your computer is running Windows 7 or a recent distribution of some flavours of Linux (such as Ubuntu), you will not usually need to prepare your computer for tethering. But, if you are running an earlier version of Windows or another operating system, you may need to prepare your computer to establish a network connection via USB. For the most current information about which operating systems support USB tethering and how to configure them, visit http://www.android.com/tether.

To rename or secure your portable hotspot

You can change the name of your phone's Wi-Fi network name (SSID) and secure its Wi-Fi network.

1 Tap > > **Apps** tab > **Settings** > **Networks** tab > **Tethering & networks** > **Wi-Fi hotspot**.

2 Tap **Set up Wi-Fi hotspot**.

- The **Set up Wi-Fi hotspot** dialogue box will open.

- You can change the **Wi-Fi name (SSID)** that other devices see when scanning for Wi-Fi networks.
- You can also tap the **Security** menu to configure the network with Wi-Fi Protected Access 2 (WPA2) security using a pre-shared key (PSK).
- If you touch the **WPA2 PSK** security option, a password field is added to the **Set up Wi-Fi hotspot** dialogue box. If you enter a password, you will need to enter that password when you connect to the phone's hotspot with a computer or other device. You can set **Open** in the **Security** menu to remove security from your Wi-Fi network.

3 Tap **Save**.

ATTENTION! If you set the security option as Open, you cannot prevent unauthorised usage of online services by other people and additional charges may be incurred. To avoid unauthorized usage, you are advised to keep the security option active.

Wi-Fi Direct

Wi-Fi Direct supports a direct connection between Wi-Fi enabled devices without an access point. Due to the high battery usage of Wi-Fi direct, it is recommended that you plug your phone into a power outlet while using the Wi-Fi Direct feature. Check your Wi-Fi & Wi-Fi Directed network in advance and make sure the users are connected to the same network.

SmartShare

You can use the SmartShare feature easily in the Gallery, Music apps, etc.

Enjoying content via a variety devices

You can share your phone's content with a variety devices. Tap to share the contents in the Music.

Playing/Sending

Play: You can play the content via a TV, a Bluetooth speaker or etc.

Beam: You can send the content to the device of Bluetooth and SmartShare Beam supported.

- **SmartShare Beam:** Transferring the content feature fast via Wi-Fi Direct.

< Play >

< Beam >

Enjoying the content from Nearby devices

You can enjoy the content from nearby devices (i.e. PC.NAS, Mobile) in the **Gallery**, **Music** app.

Connecting devices

Connect your device and other devices supported by DLNA in the same Wi-Fi network.

Searching other devices

1 Tap Nearby devices, then you can see the DLNA-supported devices.
2 Connect to the device to view the content.

PC connections with a USB cable

Learn to connect your device to a PC with a USB cable in USB connection modes.

Transferring music, photos and videos using the USB mass storage mode

1 Connect your phone to a PC using a USB cable.
2 If you haven't installed the LG Android Platform Driver on your PC, you will need to manually change the settings. Slide down the status bar and select the **Media device (MTP)** option.
3 You can now view the mass storage content on your PC and transfer the files.

Synchronize with Windows Media Player

Ensure that Windows Media Player is installed on your PC.

1. Use the USB cable to connect the phone to a PC on which Windows Media Player has been installed.
2. Select the **Media device (MTP)** option. When connected, a pop-up window will appear on the PC.
3. Open Windows Media Player to synchronize music files.
4. Edit or enter your device's name in the pop-up window (if necessary).
5. Select and drag the music files you want to the sync list.
6. Start synchronization.

- The following requirements must be satisfied to synchronize with Windows Media Player.

Items	Requirement
OS	Microsoft Windows XP SP2, Vista or higher
Window Media Player version	Windows Media Player 10 or higher

Calls

Making a call

1 Tap to open the keypad.
2 Enter the number using the keypad. To delete a digit, tap the .
3 Tap to make a call.
4 To end a call, tap the **End** icon .

TIP! To enter "+" to make international calls, touch and hold 0+.

Calling your contacts

1 Tap to open your contacts.
2 Scroll through the contact list or enter the first few letters of the contact you want to call by tapping **Search contacts**.
3 In the list, tap you want to call.

Adjusting the in-call volume

To adjust the in-call volume during a call, use the Volume up and down keys on the back of the phone.

Making a second call

1 During your first call, tap > **Add call** and dial the number. You can also go to the recently dialled numbers list by tapping **Call logs** or can search contacts by tapping **Contacts** and selecting the contact you want to call.
2 Tap to make the call.
3 Both calls are displayed on the call screen. Your initial call is locked and put on hold.
4 Tap the displayed number to toggle between calls. Or tap **Merge calls** to start a conference call.
5 To end active calls, tap **End** or tap and slide the notification bar down and select the **End call** icon .

NOTE: You are charged for each call you make.

Viewing your call logs

On the Home screen, tap and choose the **Call logs** tab.
View a complete list of all dialled, received and missed calls.

TIP!
- Tap any call log entry to view the date, time and duration of the call.
- Tap , then tap **Delete all** to delete all the recorded items.

Call settings

You can configure phone call settings such as call forwarding, as well as other special features offered by your carrier.

1 On the Home screen, tap .
2 Tap .
3 Tap **Call settings** and choose the options that you wish to adjust.

Contacts

Add contacts to your phone and synchronize them with the contacts in your Google account or other accounts that support contact syncing.

Searching for a contact

On the Home screen

1 Tap to open your contacts.
2 Tap **Search contacts** and enter the contact name using the keyboard.

Adding a new contact

1 Tap , enter the new contact's number, then tap . Tap **Add to Contacts** > **New contact**.
2 If you want to add a picture to the new contact, tap the image area.
Choose from **Take photo**, **Select from Gallery**.
3 Tap a category of contact information and enter the details about your contact.
4 Tap **Save**.

Favourites contacts

You can classify frequently called contacts as favourites.

Adding a contact to your favourites

1 Tap to open your contacts.
2 Tap a contact to view its details.
3 Tap the star to the right corner of the contact's name. The star will turn yellow color.

Removing a contact from your favourites list

1 Tap to open your contacts.
2 Tap the **Favorites** tab, and choose a contact to view its details.
3 Tap the yellow color star to the right corner of the contact's name. The star turns grey color and the contact is removed from your favourites.

Creating a group

1 Tap to open your contacts.
2 Tap **Groups** and tap . Select **New group**.
3 Enter a name for the new group. You can also set a ringtone for the newly created group.
4 Tap **Save** to save the group.

NOTE: If you delete a group, the contacts assigned to that group will not be lost. They will remain in your contacts.

Messaging

Your phone combines SMS and MMS into one intuitive, easy-to-use menu.

WARNING: LG message should be set up to default SMS app. If not, some message functions will be limited.

Sending a message

1 Tap on the Home screen and tap to open a blank message.

2 Enter a contact name or contact number in the **To** field. As you enter the contact name, matching contacts will appear. You can tap a suggested recipient. You can add more than one contact.

NOTE: You will be charged for a text message for every person to whom you send the message.

3 Tap the **Enter message** field and begin composing your message.

4 Tap to open the Options menu. Choose from **Quick message, Insert smiley, Schedule sending, Add subject** and **Discard.**

TIP! You can tap the icon to attach the file, that you want to share with message.

5 Tap **Send** to send your message.

6 Responses will appear on the screen. As you view and send additional messages, a message thread is created.

WARNING:

- The 160-character limit may vary from country to country, depending on the language and how the SMS is coded.
- If an image, video or audio file is added to an SMS message, it is automatically converted into an MMS message and you are charged accordingly.

Threaded box

Messages (SMS, MMS) exchanged with another party can be displayed in chronological order so that you can conveniently see an overview of your conversation.

Changing your message settings

Your phone message settings are pre-defined, so you can send messages immediately. You can change the settings according to your preferences.

- Tap the **Messaging** icon on the Home screen, tap ⋮ and then tap **Settings**.

E-mail

You can use the E-mail application to read emails from services like Gmail. The E-mail application supports the following account types: POP3, IMAP and Exchange.

Your service provider or system administrator can provide you with the account settings you need.

Managing an email account

The first time you open the **E-mail** application, a set-up wizard opens to help you to set up an email account. After the initial set-up, E-mail displays the contents of your inbox.

To add another email account:

- Tap > > **Apps** tab > **E-mail** > tap > **Settings** > **Add account**.

To change an email account's settings:

- Tap > > **Apps** tab > **E-mail** > tap > **Settings** > **General settings**.

To delete an email account:

- Tap > > **Apps** tab > **E-mail** > tap > **Settings** > tap > **Remove account** > Select the account to delete > **Remove** > select **Yes**.

Working with account folders

Tap > > **Apps** tab > **E-mail** > tap and select **Folders**.

Each account has an Inbox, Outbox, Sent and Drafts folder. Depending on the features supported by your account's service provider, you may have additional folders.

Composing and sending email

To compose and send a message

1. While in the **E-mail** application, tap the .
2. Enter an address for the message's intended recipient. As you enter text, matching addresses will be proposed from your Contacts. Separate multiple addresses using semicolons.
3. Tap the to add a Cc/Bcc and tap to attach files, if required.
4. Enter the text of the message.
5. Tap .

TIP! When a new email arrives in your Inbox, you will be notified by a sound or vibration.

Camera

To open the Camera application, tap [ ] > > **Apps** tab > .

Getting to know the viewfinder

1. **Flash** – Choose from **Off** , **On** , **Auto** .
2. **Swap camera** – Switch between the rear–facing camera lens and the front–facing camera lens.
3. **Shot mode** – Choose from **Normal, Dynamic tone (HDR), Panorama**, **Continuous shot**, **Beauty shot, Time catch shot** or **Sports**.
4. **Settings** – Tap this icon to open the settings menu.
5. **Video mode** – Tap and slide down this icon to switch to video mode.
6. **Capture button** – Tap to take a photo.
7. **Gallery** – Tap to view the last photo you captured. This enables you to access your gallery and view saved photos while in camera mode.

NOTE: Please ensure the camera lens is clean before taking pictures.

Using the advanced settings

In the viewfinder, tap ⚙ to open the advanced options. You can change the camera settings by scrolling through the list.

	To take a photo, say one of the following words: Cheese, Smile, Whiskey, Kimchi or LG.
	Defines and controls the amount of sunlight entering the photo.
	Tap to select the focus mode.
W6M	Selects photo resolution. If you choose high resolution, file size will increase, which means you will be able to store fewer photos in the memory.
	The ISO rating determines the sensitivity of the camera's light sensor. The higher the ISO, the more sensitive the camera. This is useful in darker conditions when you cannot use the flash.
AWB	Improves color quality in various lighting conditions.
	Applies artistic effects to your pictures.
	Sets a delay after the capture button is pressed. This is ideal if you want to be in the photo.
	Activate this to use your phone's location-based services. **NOTE:** This function is available when the GPS function is active or connected network.
	Selects a shutter sound.
	Set the Volume Key whether to use for the capture or zoom.
	Select storage to save images.
	Opens the help guide to know how a function operates.
	Restores all camera default settings.

TIP!

- When you exit the camera, some settings return to their defaults, such as white balance, color effect, timer and shot mode. Check these before you take your next photo.
- The setting menu is superimposed over the viewfinder, so when you change photo color or quality elements, you will see a preview of the changed image behind the Settings menu.

Taking a quick photo

1 Open the **Camera** application and point the lens toward the subject your want to photograph.
2 Focus boxes will appear in the center of the viewfinder screen. You can also tap anywhere on the screen to focus on that spot.
3 When the focus box turns blue, the camera has focused on your subject.
4 Tap to capture the photo.

Using Time catch shot mode

Sets the camera to capture missing moments by taking five sequential pictures before is tapped.

1 Open the **Camera** application.
2 Tap MODE > **Time catch shot**.
3 Tap to take a picture.
4 To view the moments just before the picture was taken, tap the image thumbnail at the bottom of the Camera screen.
5 Select the pictures that you want to keep, then tap at the top of the screen.

Once you've taken a photo

Tap the image thumbnail at the bottom of the Camera screen to view the last photo you took.

	Tap to edit the photo.
	Tap to take another photo immediately.
	Tap to send your photo to others or share it via social network services.
	Tap to delete the photo.

TIP! If you have an SNS account set up on your phone, you can share your photo with your SNS community.

NOTE: Additional charges may apply when MMS messages are downloaded while roaming.

Video camera

Getting to know the viewfinder

1. **Flash** – Choose from **Off**, **On**, **Auto**.
2. **Swap camera** – Switch between the rear–facing camera lens and the front-facing camera lens.
3. **Settings** – Tap this icon to open the settings menu.
4. **Camera mode** – Tap and slide up this icon to switch to camera mode.
5. **Start recording** – Tap to start recording a video.
6. **Gallery** – Tap to view the last video you recorded. This enables you to access your gallery and view your saved videos while in video mode.

TIP!
When recording a video, place two fingers on the screen and pinch to use the Zoom function.

Using the advanced settings

Using the viewfinder, tap ⚙ to open all the advanced options.

FHD	Tap to set the size (in pixels) of the video you are recording.
	Defines and controls of the amount of sunlight entering the lens. Slide the brightness indicator along the bar towards "-" for a lower brightness video or towards "+" for a higher brightness video.
AWB	Improves color quality in various lighting conditions.
	Choose a colour tone to use for your new view.
	Activate this to use your phone's location-based services. **NOTE:** This function is available when the GPS function is active or connected network.
	Set the Volume Key whether to use for the record or zoom.
	Select storage to save videos.
	Opens the help guide to know how a function operates.
	Restores all camera default settings.

Recording a quick video

1 Open the **Camera** application and slide the **Video mode** button.
2 The video camera viewfinder appears on the screen.
3 Holding the phone, point the lens towards the subject you wish to capture in your video.
4 Tap ● once to start recording.
5 A red light will appear at the top left corner of the viewfinder with a timer showing the length of the video.
6 Tap ■ on the screen to stop recording.

Video camera

TIP!

– Tap to capture an image during recording a video.

– Tap to pause recording a video.

After recording a video

In the viewfinder, tap the video thumbnail at the bottom of the screen to view the last video you took.

	Tap to record another video immediately.
	Tap to send your video to others or share it via social network services.
	Tap to delete the video.
	Tap for more options.

NOTE: Additional charges may apply when MMS messages are downloaded while roaming.

Function

Knock Code

You can unlock the screen when screen is off by taping the correct area and sequence.

To activate Knock Code feature

1 Tap [ ] > [ ] > **Apps** tab > **Settings** > **Display** tab > **Lock screen** > **Select screen lock** > **Knock Code.**

2 This opens a screen that will guide you through how to select the unlock sequence. You have to create a Backup PIN as a safety measure in case you forget your unlock sequence.

QuickMemo+

The **QuickMemo+** allows you to create memos and capture screen shots.Capture screens, draw on them and share them with family and friends with QuickMemo+.

1 Touch and slide the status bar downward and tap [ ].

2 Select the desired menu option from **Pen type**, **Colour**, **Eraser** and create a memo.

Function

3 Tap in the Edit menu to save the memo with the current screen. To exit QuickMemo+ at any time, tap .

NOTE: Please use a fingertip while using the QuickMemo+. Do not use your fingernail.

Using the QuickMemo+ options

You can easily use the QuickMenu options when using the QuickMemo+.

	Undo or Redo.
	Use complex concept function.
	Select the pen type and the colour
	Erase the memo that you created.
	Save the memo with the current screen in the **QuickMemo+** or **Gallery**.
	Option: Tap to choose **Share** or **Paper style** for the memo.

Viewing the saved QuickMemo+

Tap **Gallery** and select the **QuickMemo+** album.

QSlide

From any screen, bring up a calendar and more as a window inside your screen.

1		Tap to exit the QSlide and return to full window.
2		Tap to adjust transparency.
3		Tap to end the QSlide.
4		Tap to adjust the size.

1 Touch and slide the status bar downwards > tap QSlide apps or while using applications that support QSlide, tap . The function will be continuously displayed as a small window on your screen.

2 You can make a call, browse the Web, or choose other phone options. You can also use and tap the screen under the small windows when the transparency bar is not full .

NOTE: The QSlide can support up to two windows at the same time.

QuickRemote

QuickRemote turns your phone into a Universal Remote for your home TV and DVD/Blue-ray.

1 Touch and slide the status bar downwards and tap > **ADD REMOTE.**

OR

Tap > > **Apps** tab > **QuickRemote** > tap .

2 Select the type and brand of device, then follow the on-screen instructions to configure the device(s).

3 Touch and slide the status bar downwards and use QuickRemote functions.

Tap the **Menu key** to select **Magic Remote setting, Edit remote name, Move remote, Delete remote, Settings** and **Help.**

NOTE: The QuickRemote operates the same way as an ordinary remote control infrared (IR) signals. Be careful not to cover the infrared sensor at the top of the phone when you use the QuickRemote function. This function may not be supported depending on the model, the manufacturer or service company.

Multimedia

Gallery

Open the **Gallery** application to view albums of your pictures and videos.

1 Tap [ ] > > **Apps** tab > **Gallery**.
You can manage and share all your image and video files with Gallery.

NOTE:
- Some file formats are not supported, depending on the software installed on the device.
- Some files may not play properly, depending on how they are encoded.

Viewing pictures

Launching Gallery displays your available folders. When another application, such as Email, saves a picture, the download folder is automatically created to contain the picture. Likewise, capturing a screenshot automatically creates the Screenshots folder. Select a folder to open it.

Pictures are displayed by creation date in a folder. Select a picture to view it full screen. Scroll left or right to view the next or previous image.

Zooming in and out

Use one of the following methods to zoom in on an image:
- Double-tap anywhere to zoom in.
- Spread two fingers apart on any place to zoom in. Pinch to zoom out, or double-tap to return.

Playing videos

Video files show the icon in the preview. Select a video to watch it and tap . The Videos application will launch.

Editing photos

When viewing an photo, tap .

Deleting photos/videos

Use one of the following methods:
- In a folder, tap and select photos/videos by ticking, and then tap on **Delete**.
- When viewing a photo, tap .

Setting as wallpaper

When viewing a photo, tap ⋮ > **Set image as** to set the image as wallpaper or assign to a contact.

NOTE:

- Some file formats are not supported, depending on the device software.
- If the file size exceeds the available memory, an error can occur when you open files.

Videos

Your phone has a built-in video player that lets you play all of your favorite videos. To access the video player, touch > **Apps** tab > **Gallery**.

Playing a video

1 Touch > **Apps** tab > **Gallery**.

2 Select the video you want to play.

1 ❚❚ / ▶	Touch to pause/resume video playback.
2 ▶▶	Touch to go 10 seconds forward.
3 ◀◀	Touch to go 10 seconds backward.
4 🔊	Touch to manage the video volume.

5 /	Touch to lock/unlock a video screen.
6	Touch to set the picture to your Favorites folder.
7	Touch to use QSlide.
8	Tap to share your video via the SmartShare function.
9	Tap to access Screen ratio, Subtitles, Share, Trim, Settings or Details.

Music

Your phone has a built-in music player that lets you play all your favorite tracks. To access the music player, tap > > **Apps** tab > **Music**.

Playing a song

1 Tap > > **Apps** tab > **Music**.
2 Tap **Songs**.
3 Select the song you want to play.

1	II / ▶	Tap to pause/ resume playback.
2	⏭	Tap to skip to the next track in the album, playlist, or shuffle. Touch and hold to fast forward.
3	⏮	Tap to restart the current track or skip to the previous track in the album, playlist, or shuffle. Touch and hold to rewind.
4	🔈	Tap to display the Volume slider bar, then adjust the playback volume on the slider bar.
5		Tap to set audio effects.
6		Tap to share your music via the SmartShare funtion.
7	★	Tap to add the song to your favourites.
8		Tap to open the current playlist.
9	⤮	Tap to play the current playlist in shuffle mode (tracks are played in random order).

10		Tap to toggle through the repeat modes to repeat all songs, repeat current song, or repeat off.

To change the volume while listening to music, press the up and down volume keys on the left-hand side of the phone.

Touch and hold any song in the list. The **Play, Add to playlist, Delete, Share, Set as ringtone, Details** and **Search** options will be displayed.

Add music files to your phone

Start by transferring music files to your phone:

- Transfer music using Media device (MTP).
- Download from the wireless Web.
- Synchronize your phone to a computer.
- Receive files via Bluetooth.

FM Radio

Your phone has a built-in FM Radio so you can tune in to your favorite stations and listen on the go.

NOTE: You need to use your headphones to listen to the radio. Insert it into the headphone jack.

Utilities

Setting your alarm

1 Tap ○ > > **Apps** tab > **Clock** > **Alarms** > .
2 After you set the alarm, your phone lets you know how much time is left before the alarm will go off.
3 Set **Repeat**, **Snooze duration**, **Alarm with vibration**, **Alarm sound, Alarm volume, Auto app starter, Puzzle lock** and **Memo**.
4 Tap **Save**.

NOTE: To change alarm settings in the alarm list screen, tap the **Menu key** and select **Settings**.

Using your calculator

1 Tap ○ > > **Apps** tab > **Calculator**.
2 Tap the number keys to enter numbers.
3 For simple calculations, tap the function you want to perform (+, –, x or ÷) followed by =.
4 To check the history, touch and select the **Calculation history**.
5 For more complex calculations, touch and select the **Scientific calculator,** then choose sin, cos, tan, log etc.

Adding an event to your calendar

1 Tap ○ > > **Apps** tab > **Calendar**.
2 On the screen, you can find the different view types for the Calendar (Day, Week, Month, Year, Agenda).
3 Tap on the date for which you wish to add an event and tap .
4 Tap **Event name** and enter the event name.
5 Tap **Location** and enter the location. Check the date and enter the time you wish your event to start and finish.
6 If you wish to repeat the alarm, set **REPEAT** and set **REMINDERS**, if necessary.
7 Tap **Save** to save the event in the calendar.

Voice Recorder

Use the voice recorder to record voice memos or other audio files.

Recording a sound or voice

1 Tap ○ > > **Apps** tab > **Voice Recorder**.
2 Tap ● to begin recording.
3 Tap ■ to end the recording.
4 Tap ▶ to listen to the recording.

NOTE: Tap ☰ to access your album. You can listen to the saved recording. The available recording time may differ from actual recording time.

Tasks

This task can be synchronized with MS Exchange account. You can create task, revise it and delete it in MS outlook or MS Office Outlook Web Access.

To Synchronize MS Exchange

1 From the Home Screen, Tap ○ > > **Apps** tab > **Settings**.
2 Tap **General** tab > **Accounts & sync** > **Add account**.
3 Tap **Microsoft Exchange** to create Email address and Password.
4 Make sure if you checkmark Sync task.

NOTE: MS Exchange may not be supported depending on email server.

ThinkFree Viewer

ThinkFree Viewer is a professional mobile office solution that lets users conveniently view various types of office documents, including Word, Excel and PowerPoint files, anywhere or anytime, using their mobile devices.

Tap [O] > > **Apps** tab > **ThinkFree Viewer**.

Viewing files

Mobile users can now easily view a wide variety of file types, including Microsoft Office documents and Adobe PDF, right on their mobile devices. When viewing documents using ThinkFree Viewer, the objects and layout remain the similar in the original documents.

Google+

Use this application to stay connected with people via Google's social network service.

- Tap [O] > > **Apps** tab > **Google+.**

NOTE: This application may not be available depending on the region or service provider.

Voice Search

Use this application to search webpages using voice.

1 Tap [O] > > **Apps** tab > **Voice Search**.

2 Say a keyword or phrase when **Speak now** appears on the screen. Select one of the suggested keywords that appear.

NOTE: This application may not be available depending on the region or service provider.

Downloads

Use this application to see what files have been downloaded through the applications.

- Tap [O] > > **Apps** tab > **Downloads**.

NOTE: This application may not be available depending on the region or service provider.

LG SmartWorld

LG SmartWorld offers an assortment of exciting content - games, applications, wallpaper and ringtones - giving LG phone users the chance to enjoy richer "Mobile Life" experiences.

How to Get to LG SmartWorld from Your Phone

1 Tap [ ] > > **Apps** tab > tap the icon to access **LG SmartWorld**.
2 Tap Sign in and enter ID/PW for LG SmartWorld. If you have not signed up yet, tap Register to receive your LG SmartWorld membership.
3 Download the content you want.

NOTE: What if there is no icon?

1 Using a mobile Web browser, access LG SmartWorld (www.lgworld.com) and select your country.
2 Download the LG SmartWorld App.
3 Run and install the downloaded file.
4 Access LG SmartWorld by tapping the icon.

How to use LG SmartWorld

- Participate in monthly LG SmartWorld promotions.

	Search content.
	Find content by category (e.g. Games, Education, Entertainment etc).

- Try the easy "**Menu**" buttons to find what you're looking for fast.
  Settings – Set Profile and Display.
  Sign in – Set your ID and Password.
- Try other useful functions as well. (Content Detail screen)

NOTE: LG SmartWorld may not be available from all carriers or in all countries.

The Web

Internet

Use this application to browse the Internet. Browser gives you a fast, full-color world of games, music, news, sports, entertainment and much more, right on your mobile phone wherever you are and whatever you enjoy.

NOTE: Additional charges apply when connecting to these services and downloading content. Check data charges with your network provider.

1 Tap [ ] > > **Apps** tab > **Internet**.

Using the Web toolbar

Tap slide it downwards with your finger to open.

	Tap to go back one page.
	Tap to go forward one page, to the page you connected to after the current one. This is the opposite of what happens when you tap [ ], which takes you to the previous page.
	Tap to go to the Home page.
	Tap to add a new window.
	Tap to access bookmarks.

Viewing webpages

Tap the address field, enter the web address and tap **Go**.

Opening a page

To go to new page, tap > .

To go to another webpage, tap , scroll up or down, and tap the page to select it.

The Web

Searching the web by voice

Tap the address field, tap , speak a keyword, and then select one of the suggested keywords that appear.

NOTE: This feature may not be available depending on the region or service provider.

Bookmarks

To bookmark the current webpage, tap > **Add to bookmarks** > **OK**.
To open a bookmarked webpage, tap and select one.

History

Tap > **History** to open a webpage from the list of recently-visited webpages.

Chrome

Use Chrome to search for information and browse webpages.

1 Tap > > **Apps** tab > **Chrome**.

NOTE: This application may not be available, depending on your region and service provider.

Viewing webpages

Tap the Address field, and then enter a web address or search criteria.

Opening a page

To go to a new page, tab > **New tab**.

Settings

This section provides an overview of items you can change using your phone's System settings menus.

To access the Settings menu:

Tap [O] > touch and hold [□] > **System settings**.

- or -

Tap [O] > [Apps icon] > **Apps** tab > **Settings**.

Networks

< Wi-Fi >

Wi-Fi – Turns on Wi-Fi to connect to available Wi-Fi networks.

TIP! How to obtain the MAC address

To set up a connection in some wireless networks with MAC filters, you may need to enter the MAC address of your phone in the router.

You can find the MAC address in the following user interface: tap [O] > [Apps icon] > **Apps** tab > **Settings** > **Networks** tab > **Wi-Fi** > [⋮] > **Advanced Wi-Fi** > **MAC address**.

< Bluetooth >

Turn the Bluetooth wireless feature on or off to use Bluetooth.

< Mobile data >

Displays the data usage and set mobile data usage limit.

< Call >

Configure phone call settings such as call forwarding and other special features offered by your carrier.

Voicemail – Allows you to select your carrier's voicemail service.

Fixed dialing numbers – Turn on and compile a list of numbers that can be called from your phone. You'll need your PIN2, which is available from your operator. Only numbers within the fixed dial list can be called from your phone.

Incoming voice call pop-up – Display incoming voice call popup when using camera and videos.

Call reject – Allows you to set the call reject function. Choose from Call reject mode or Reject calls from.

Decline with message – When you want to reject a call, you can send a quick message using this function.

Privacy keeper – Hides the caller name and number for an incoming call.

Call forwarding – Choose whether to divert all calls when the line is busy, when there is no answer or when you have no signal.

Auto answer – Set the time before a connected hands-free device automatically answers an incoming call. Choose from **Off**, **1 sec**, **3sec** and **5 sec**.

Connection vibration – Vibrates your phone when the other party answers the call.

Save unknown numbers – Add unknown numbers to contacts after a call.

Power key ends call – Allows you to select your end call.

Call barring – Lock incoming, outgoing or international calls.

Call duration – View the duration of calls including Last call, Outgoing calls, Incoming calls and All calls.

Additional settings – Allows you to change the following settings:

Caller ID: Choose whether to display your number in an outgoing call.

Call waiting: If call waiting is activated, the handset will notify you of an incoming call while you are on a call (depending on your network provider).

< Share & connect >

NFC – NFC (Near Field Communication) is a wireless technology that enables data transmission between two objects when they are brought within a few inches of each others. When you enable NFC on your phone, your phone can exchange data with other NFC-enabled devices or read information from smart tags embedded in posters, stickers, and other products.

Android Beam – When this feature is turned on, you can beam app contents to another NFC-capable device by holding the devices close together. For example, you can beam Browser pages, YouTube videos, contacts, and more. Just bring the devices together (typically back to back) and then touch your screen. The app determines what gets beamed.

SmartShare Beam – Turn on to receive multimedia content via SmartShare Beam from LG phones or tablets.

Media server – Allows you to share the phone's multimedia content with nearby DLNA-compatible devices.

LG PC Suite – Check this to use LG PC Suite with your Wi-Fi connection. Please note that Wi-Fi network should be connected to LG PC Suite via a Wi-Fi connection.

< Tethering & networks >

USB tethering – Connect the USB cable to share the internet connection with the computer.

Wi-Fi hotspot – You can also use your phone to provide a mobile broadband connection. Create a hotspot and share your connection.

Bluetooth tethering – Allows you to set your phone whether you are sharing the Internet connection or not.

Help – Tap to view help information on the USB tethering, Wi-Fi hotspot and Bluetooth tethering functions.

Airplane mode – After switching to Airplane mode, all wireless connections are disabled.

NOTE: You must set a lock screen PIN or Password before you can use credential storage.

Mobile networks – Set options for data roaming, network mode & operators, access point names (APNs) etc.

VPN – Displays the list of Virtual Private Networks (VPNs) that you've previously configured. Allows you to add different types of VPNs.

Sound

< BASIC >

Sound profile – Choose Sound, Vibrate only or Interruptions.

Volume – Adjust the phone's volume settings to suit your needs and your environment.

Vibrate strength – Allows you to set the vibrate strength for calls, notifications.

< RINGTONES & VIBRATIONS >

Ringtone – Set the ringtone for calls. You can also add a ringtone by tapping + at the top right corner of the screen.

Notification sound – Set the notification sound. You can also add a notification sound by tapping + at the top right corner of the screen.

Sound with vibration – Checkmark to set the phone to vibrate in addition to the ringtone when you receive calls.

Vibration type – Allows you to set the vibration type for incoming calls. Choose from Long Lasting, Rapid, Short repeated, Standard or Ticktock.

< NOTIFICATIONS >

Interruptions – Set a time and mode when your phone doesn't let you know about notifications coming in. Choose from All, Priority only or None.

- **PRIORITY ONLY** – Allow certain features to interrupt when Priority only. Alarms always have priority. Choose from Apps with Calendar events, Incoming calls, New messages, or Allowed contacts.
- **SCHEDULE** – Only notification with priority interrupt on repeat even when set to all.

Lock screen – Set to Show all notifications, Hide sensitive only, Hide all notifications on the lock screen.

Apps – Set notification from Apps. Choose from None to show no notifications form the Apps, and Priority to show notifications with priority on top of others and when Interruptions set to Priority only.

< ADVANCED SETTINGS >

Vibrate on tap – Checkmark to vibrate when tapping the Home touch buttons and during other UI interactions.

Sound effects – Tap to set the dialpad touch sounds, touch sounds, and screen lock sound.

Dialpad touch sounds – Checkmark to play tones while using dialpad.

Touch sound – Checkmark to play sound when making screen selection.

Screen lock sound – Checkmark to play sound when locking and unlocking the screen.

Message/call voice notifications – To read out the incoming call and the message event automatically.

Display

< Home screen >

Set the **Select Home**, **Theme, Wallpaper, Screen swipe effect, Allow Home screen looping, Home backup & restore, Help.**

< Lock screen >

Select screen lock – Set a screen lock type to secure your phone. Opens a set of screens that guide you through drawing a screen unlock pattern. Set **None, Swipe, Knock Code, Pattern, PIN** or **Password**.

If you have enabled a Pattern lock type when you turn on your phone or wake up the screen, you will be asked to draw your unlock pattern to unlock the screen.

Smart Lock – Set when to automatically unlock phone by Trusted devices (BT device or NFC), Trusted places or Trusted face. This function is available when the Lock screen is set to one of the Knock Code, Pattern, PIN and Settings Password.

NOTE: To use this feature, Smart Lock must be On.
Settings > General > Security > Trust agents > Smart Lock.

Screen swipe effect – Sets the screen swipe effect options. Choose from **Light particle, Vector circle, Mosaic** and **Soda**.

NOTE: Screen swipe effect becomes Pattern effect if the screen lock is set to Pattern.

Wallpaper – Sets your Lock screen wallpaper. Select it from **Gallery** or **Wallpaper gallery**.

Shortcuts – Allows you to change the shortcuts on the **Swipe** Lock screen.

Contact info for lost phone – Select whether to display the owner information on the lock screen and customize the owner information.

Lock timer – Sets the amount of time before the screen automatically locks after the screen has timed-out.

Power button instantly locks – Checkmark to instantly lock the screen when the Power/Lock Key is pressed. This setting overrides the Security lock timer setting.

< Home touch buttons >

Button combination – Drag an icon to rearrange Home touch buttons. You can have up to 5 Home touch buttons.

Color – Sets the background color for the Home touch buttons. Select it from White and Black.

< FONT >

Font type – Sets the type of font used for the phone and menus.

Font size – Sets the size of the font displayed in the phone and menus.

< OTHER SCREEN SETTINGS >

Brightness – Adjusts the brightness of the screen. For best battery performance, use the dimmest comfortable brightness.

Auto-rotate screen – Checkmark to set the phone to automatically rotate the screen based on the phone orientation (portrait or landscape).

Screen timeout – Sets the amount of time before the screen times out.

Smart screen – Checkmark to keep the screen from timing-out when the device detects your eyes looking at the screen.

< ADVANCED SETTINGS >

Screen-off effect – Sets the screen-off effect. Choose from **Retro TV**, **Black hole** and **Fade out**.

Daydream – Tap the Daydream switch to toggle it On or Off. On allows the set screensaver to be displayed when the phone is sleeping while docked and/or charging. Choose from **Clock** and **Google Photos**.

General

< Language & input >

Use the Language & input settings to select the language for the text on your phone and to configure the on-screen keyboard, including words you've added to its dictionary.

< Location >

Turn on location service, your phone determines your approximate location using GPS, Wi-Fi and mobile networks.

Mode – Set the location mode from **High accuracy**, **Battery saving** and **Device sensors only**.

< Accounts & sync >

Permits applications to synchronize data in the background, whether or not you are actively working in them. Deselecting this setting can save battery power and lower (but not eliminate) data usage.

< Accessibility >

Use the **Accessibility** settings to configure accessibility plug-ins you have installed on your phone.

< One-handed operation >

Dial keypad – Checkmark to enable you move the dial keypad to the right or left side of the device. Simply tap the arrow to move it to one side or the other.

LG keyboard – Checkmark to enable you move the keyboard to the right or left side of the device. Simply tap the arrow to move it to one side or the other.

Lock screen – Checkmark to enable you move the PIN Lock screen keypad to the right or left side of the device. Simply tap the arrow to move it to one side or the other.

Help – Displays information regarding one-handed operation.

< Shortcut key >

Get quick access to apps by pressing and holding the volume keys when screen is off or locked. Tap the Shortcut key switch at the top right corner of the screen to toggle it **On** or **Off**.

< Security >

Encrypt phone – Allows you to encrypt data on the phone for security. You will be required to enter a PIN or password to decrypt your phone each time you power it on.

Encrypt SD card storage – Allows you to encrypt SD card data on the phone for security.

Set up SIM card lock – Set up SIM card lock or change the SIM card PIN.

Password typing visible – Show the last character of the hidden password as you type.

Phone administrators – View or deactivate phone administrators.

Unknown source – Default setting to install non-Play store applications.

Verify apps – Disallow or warn before installation of apps that may cause harm.

Storage type – Hardware-backed.

Trusted credentials – Display trusted CA certificates.

Install from storage – Choose to install encrypted certificates.

Clear credentials – Remove all certificates.

Trust agents – Select apps to use without unlocking the screen.

Screen pin – Allow an app to be the only one used when you pin the screen of an app.

App usage access – Allow apps to view the usage information of apps on your phone.

< Guest mode >

When you lend your phone to others, you can limit the applications to be displayed.

< Gestures >

Screen on/off – Checkmark to enable KnockON to turn the screen on and off. Quickly double-tap center screen to turn it on. Double-tap the Status Bar, an empty area on the Home screen, or the Lock screen to turn the screen off. For the best results, do not move the phone while using the KnockON feature.

Silence incoming calls – Checkmark to enable you to flip the phone to silence incoming calls.

Snooze or stop alarm – Checkmark to enable you to simply flip the device to snooze or stop the alarm.

Pause video – Checkmark to enable you to simply flip the device to pause the currently playing video.

Help – Opens a help guide on how to use the Gestures features of your device.

Motion sensor calibration – Allows you to improve the accuracy of the tilt and speed of the sensor.

< QuickWindow case >

Activate to make features, such as music, weather, and clock, available in small view when using the QuickWindow case.

< Date & time >

Use **Date & time** settings to set how dates will be displayed. You can also use these settings to set your own time and time zone rather than obtaining the current time from the mobile network.

< Storage >

INTERNAL STORAGE – View the internal storage usage.

SD CARD – Check total available SD card space. Touch Unmount SD card for safe removal. Erase SD card if you want to delete all data from the SD card.

< Battery >

BATTERY INFORMATION

The Battery charge information is shown on a battery icon along with the percentage of the remaining charge and its status.

Battery usage – Shows which components and applications are using the most battery power.

Battery percentage on status bar – Checkmark to display the battery level percentage on the Status Bar next to the battery icon.

BATTERY SAVER

Tap the Battery saver switch to toggle it On or Off. Tap Battery saver to access the following settings:

Battery saver – Sets the battery charge percent level that will automatically turn on Battery saver. Choose from **Turn Battery saver on** and **Restrict apps in background**.

Help – Tap to view help information on the battery saver tips.

< Apps >

View and manage your applications.

< Default message app >

Set **Messaging** or **Hangouts** as default app.

< Backup & reset >

Change the settings for managing your settings and data.

Back up my data – Set to backup your settings and application data to the Google server.

Backup account – Set to backup your account.

Automatic restore – Set to restore your settings and application data when the applications are reinstalled on your device.

LG Backup service – Backs up all information on the device and restores it in the event of data loss or replacement.

Factory data reset – Reset your settings to the factory default values and delete all your data. If you reset the phone this way, you are prompted to re-enter the same information as when you first started Android.

< Printing >

Allows you to print the content of certain screens (such as web pages displayed in Chrome) to a printer connected to the same Wi-Fi network as your Android device.

< About phone >

View legal information and check your phone status and software version.

PC software (LG PC Suite)

"LG PC Suite" PC software is a program that helps you connect your device to a PC via a USB cable and Wi-Fi. Once connected, you can use the functions of your device from your PC.

With your "LG PC Suite" PC Software, You Can...

- Manage and play your media contents (music, movie, picture) on your PC.
- Send multimedia contents to your device.
- Synchronizes data (schedules, contacts, bookmarks) in your device and PC.
- Backup the applications in your device.
- Update the softwares in your device.
- Play multimedia contents of your PC from your device.
- Backup and create and edit the memos in your device

NOTE: You can use the Help menu from the application to find out how to use your "LG PC Suite" PC software.

Installing "LG PC Suite" PC Software

"LG PC Suite" PC software can be downloaded from the webpage of LG.

1 Go to www.lg.com and select a country of your choice.

2 Go to **Support** > **MOBILE SUPPORT** > **LG Mobile Phones** > **Select the Model**
or
Go to **Support** > **Mobile** > Select the Model.

3 Click **PC SYNC** from **MANUALS & DOWNLOAD** and click **DOWNLOAD** to download "LG PC Suite" PC software.

System Requirements for "LG PC Suite" PC software

- OS: Windows XP (Service pack 3) 32bit, Windows Vista, Windows 7, Windows 8
- CPU: 1 GHz or higher processors
- Memory: 512 MB or higher RAMs
- Graphic card: 1024 x 768 resolution, 32 bit color or higher
- HDD: 500 MB or more free hard disk space (More free hard disk space may be needed depending on the volume of data stored.)
- Required software: LG integrated drivers, Windows Media Player 10 or later

NOTE: LG Integrated USB Driver

LG integrated USB driver is required to connect an LG device and PC and is installed automatically when you install "LG PC Suite" PC software application.

PC software (LG PC Suite)

Synchronizing your Device to a PC

Data from your device and PC can be synchronized easily with "LG PC Suite" PC software for your convenience. Contacts, schedules and bookmarks can be synchronized.

The procedure is as follows:

1. Connect your device to PC. (Use a USB cable or Wi-Fi connection.)
2. The **Select USB connection method** will appear, then select **LG software**.
3. After connection, run the program and select the device section from the category on the left side of the screen.
4. Click **Personal information** to select.
5. Select the checkbox of contents to synchronize and click the **Sync** button.

NOTE: To synchronize your phone with your PC, you need to install LG PC Suite onto your PC. Please refer to previous pages to install LG PC Suite.

Moving contacts from your Old Device to your New Device

1. Export your contacts as a CSV file from your old device to your PC using a PC sync program.
2. Install "LG PC Suite" on the PC first. Run the program and connect your Android mobile phone to the PC using a USB cable.
3. On the top menu, select **Device** > **Import to device** > **Import contacts**.
4. A popup window to select the file type and a file to import will appear.
5. On the popup, click the **Select a file** and Windows Explorer will appear.
6. Select the contacts file to import in Windows Explorer and click the **Open**.
7. Click **OK**.
8. A **Field mapping** popup to link the contacts in your device and new contacts data will appear.
9. If there is a conflict between the data in your PC contacts and device contacts, make the necessary selections or modifications in LG PC Suite.
10. Click **OK**.

Phone software update

LG Mobile phone software update from the Internet

For more information about using this function, please visit http://www.lg.com/common/index.jsp → select your country and language.

This feature allows you to conveniently update the firmware on your phone to a newer version from the Internet without needing to visit a service center. This feature will only be available if and when LG makes a newer firmware version available for your device.

Because the mobile phone firmware update requires the user's full attention for the duration of the update process, please make sure you check all instructions and notes that appear at each step before proceeding. Please note that removing the USB data cable during the upgrade may seriously damage your mobile phone.

NOTE: LG reserves the right to make firmware updates available only for selected models at its own discretion and does not guarantee the availability of the newer version of the firmware for all handset models.

LG Mobile Phone software update via Over-the-Air (OTA)

This feature allows you to conveniently update your phone's software to a newer version via OTA, without connecting using a USB data cable. This feature will only be available if and when LG makes a newer firmware version available for your device.

You should first check the software version on your mobile phone: **Settings** > **General** tab > **About phone** > **Update Center** > **Software Update** > **Check now for update**.

NOTE: Your personal data from internal phone storage—including information about your Google account and any other accounts, your system/application data and settings, any downloaded applications and your DRM licence—might be lost in the process of updating your phone's software. Therefore, LG recommends that you backup your personal data before updating your phone's software. LG does not take responsibility for any loss of personal data.

NOTE: This feature depends on your network service provider, region and country.

About this user guide

- Before using your device, please carefully read this manual. This will ensure that you use your phone safely and correctly.
- Some of the images and screenshots provided in this guide may appear differently on your phone.
- Your content may differ from the final product, or from software supplied by service providers or carriers, This content may be subject to change without prior notice. For the latest version of this manual, please visit the LG website at www.lg.com.
- Your phone's applications and their functions may vary by country, region, or hardware specifications. LG cannot be held liable for any performance issues resulting from the use of applications developed by providers other than LG.
- LG cannot be held liable for performance or incompatibility issues resulting from registry settings being edited or operating system software being modified. Any attempt to customize your operating system may cause the device or its applications to not work as they should.
- Software, audio, wallpaper, images, and other media supplied with your device are licensed for limited use. If you extract and use these materials for commercial or other purposes, you may be infringing copyright laws. As a user, you are fully and entirely responsible for the illegal use of media.
- Additional charges may be applied for data services, such as messaging, uploading and downloading, auto-syncing, or using location services. To avoid additional charges, select a data plan that is suitable for your needs. Contact your service provider to obtain additional details.

Trademarks

- LG and the LG logo are registered trademarks of LG Electronics.
- All other trademarks and copyrights are the property of their respective owners.

DivX HD

ABOUT DIVX VIDEO: DivX® is a digital video format created by DivX, LLC, a subsidiary of Rovi Corporation. This is an official DivX Certified® device that has passed rigorous testing to verify that it plays DivX video. Visit divx.com for more information and software tools to convert your files into DivX videos.

ABOUT DIVX VIDEO-ON-DEMAND: This DivX Certified® device must be registered in order to play purchased DivX Video-on-Demand (VOD) movies. To obtain your registration code, locate the DivX VOD section in your device setup menu. Go to vod.divx.com for more information on how to complete your registration.

DivX Certified® to play DivX® video up to HD 720p, including premium content.
DivX®, DivX Certified® and associated logos are trademarks of Rovi Corporation or its subsidiaries and are used under license.

Dolby Digital Plus

Manufactured under license from Dolby Laboratories. Dolby, Dolby Digital Plus, and the double-D symbol are trademarks of Dolby Laboratories.

Notice: Open Source Software

To obtain the corresponding source code under GPL, LGPL, MPL and other open source licences, please visit http://opensource.lge.com/

All referred licence terms, disclaimers and notices are available for download with the source code.

Accessories

These accessories are available for use with the your phone. **(Items described below may be optional.)**

Travel adaptor

Stereo headset

Quick Start Guide

Data cable

Battery

NOTE:

- Always use genuine LG accessories.
- Failure to do this may void your warranty.
- Accessories may vary in different regions.

Troubleshooting

This chapter lists some problems you might encounter when using your phone. Some problems require you to call your service provider, but most are easy to fix yourself.

Message	Possible causes	Possible corrective measures
SIM card error	There is no SIM card in the phone or it is inserted incorrectly.	Make sure that the SIM card is correctly inserted.
No network connection/ Dropped network	Signal is weak or you are outside the carrier network.	Move toward a window or into an open area. Check the network operator coverage map.
	Operator applied new services.	Check whether the SIM card is more than 6~12 months old. If so, change your SIM card at your network provider's nearest branch. Contact your service provider.
Codes do not match	To change a security code, you will need to confirm the new code by re-entering it.	If you forget the code, contact your service provider.
	The two codes you have entered do not match.	
No applications can be set	Not supported by service provider or registration required.	Contact your service provider.

Troubleshooting

Message	Possible causes	Possible corrective measures
Calls not available	Dialling error	New network not authorized.
	New SIM card inserted.	Check for new restrictions.
	Pre-paid charge limit reached.	Contact service provider or reset limit with PIN2.
Phone cannot be switched on	On/Off key pressed too briefly.	Press the On/Off key for at least two seconds.
	Battery is not charged.	Charge battery. Check the charging indicator on the display.
Charging error	Battery is not charged.	Charge battery.
	Outside temperature is too hot or cold.	Make sure phone is charging at a normal temperature.
	Contact problem	Check the charger and its connection to the phone.
	No voltage	Plug the charger into a different socket.
	Charger defective	Replace the charger.
	Wrong charger	Use only original LG accessories.

Message	Possible causes	Possible corrective measures
Number not allowed	The Fixed dialling number function is on.	Check the Settings menu and turn the function off.
Impossible to receive / send SMS & photos	Memory full	Delete some messages from your phone.
Files do not open	Unsupported file format	Check the supported file formats.
The screen does not turn on when I receive a call.	Proximity sensor problem	If you use a protection tape or case, make sure it has not covered the area around the proximity sensor. Make sure that the area around the proximity sensor is clean.
No sound	Vibration mode	Check the settings status in the sound menu to make sure you are not in vibration or silent mode.
Hangs up or freezes	Intermittent software problem	Try to perform a software update via the website.

FAQ

Category Sub-Category	Question	Answer
BT Bluetooth Devices	What are the functions available via Bluetooth	You can connect a Bluetooth audio device such as a Stereo/Mono headset or Car Kit. Also, when the FTP server is connected to a compatible device, you can share content stored on the storage media.
Data Contacts Backup	How can I backup Contacts?	The Contacts data can be synchronized between your phone and Gmail™.
Data Synchronization	Is it possible to set up one-way sync with Gmail?	Only two-way synchronization is available.
Data Synchronization	Is it possible to synchronize all email folders?	The Inbox is automatically synchronized. You can view other folders by tapping the **Menu Key** ⋮ and select **Folders** to choose a folder.
Google™ Service Gmail Log-In	Do I have to log into Gmail whenever I want to access Gmail?	Once you have logged into Gmail, no need to log into Gmail again.
Google™ Service Google Account	Is it possible to filter emails?	No, email filtering is not supported via the phone.
Phone Function Email	What happens when I execute another application while writing an email?	Your email will automatically be saved as a draft.

Category Sub-Category	Question	Answer
Phone Function Ringtone	Is there a file size limitation for when I want to use MP3 file as ring tone?	There is no file size limitation.
Phone Function Message Time	My phone does not display the time of receipt for messages older than 24 hrs. How can I view the time?	Open the conversation and touch and hold the desired message. Then tap **Details**.
Phone Function Navigation	Is it possible to install another navigation application on my phone?	Any application that is available at Play Store™ and is compatible with the hardware can be installed and used.
Phone Function Synchronisation	Is it possible to synchronize my contacts from all my email accounts?	Only Gmail and MS Exchange server (company email server) contacts can be synchronized.
Phone Function Wait and Pause	Is it possible to save a contact with Wait and Pause in the numbers?	If you transferred a contact with the W & P functions saved into the number, you will not be able to use those features. You will need to re-save each number. How to save with Wait and Pause: 1. From the Home screen, tap the **Phone** icon . 2. Dial the number, then tap the **Menu Key** . 3. Tap **Add 2-sec pause** or **Add wait**.
Phone Function Security	What are the phone's security functions?	You are able to set the phone to require that an Unlock Pattern be entered before the phone can be accessed or used.

Category Sub-Category	Question	Answer
Phone Function Unlock Pattern	How do I create the Unlock Pattern?	1. From the Home screen, tap and hold the **Recent Apps Key** ☐. 2. Tap **System settings** > **Display** tab > **Lock screen**. 3. Tap **Select screen lock** > **Pattern**. The first time you do this, a short tutorial about creating an Unlock Pattern will appear. 4. Set up by drawing your pattern once, and once again for confirmation. **Precautions to take when using the pattern lock.** It is very important to remember the unlock pattern you set. You will not be able to access your phone if you use an incorrect pattern five times. You have five chances to enter your unlock pattern, PIN or password. If you have used all 5 opportunities, you can try again after 30 seconds. (Or, if you preset the backup PIN, you can use the backup PIN code to unlock the pattern.)

Category Sub-Category	Question	Answer
Phone Function Unlock Pattern	What should I do if I forget the unlock pattern and I didn't create my Google account on the phone?	**If you have forgotten your pattern:** If you logged into your Google account on the phone but failed to enter the correct pattern 5 times, tap the forgot pattern button. You are then required to log in with your Google account to unlock your phone. If you have not created a Google account on the phone or you have forgotten it, you will have to perform a hard reset. **Caution: If you perform a factory reset, all user applications and user data will be deleted. Please remember to backup any important data before performing a factory reset.**
Phone Function Memory	Will I know when my memory is full?	Yes, you will receive a notification.
Phone Function Language Support	Is it possible to change my phone's language?	The phone has multilingual capabilities. To change the language: 1. From the Home screen, tap and hold the **Recent Apps Key** ☐ and tap **System settings**. 2. Tap **General** tab > **Language & input** > **Language.** 3. Tap the desired language.
Phone Function VPN	How do I set up a VPN?	VPN access configuration is different for each company. To configure VPN access from your phone, you must obtain the details from your company's network administrator.

FAQ

Category Sub-Category	Question	Answer
Phone Function Screen time out	My screen turns off after only 15 seconds. How can I change the amount of time for the backlight to turn off?	1. From the Home screen, tap and hold the **Recent Apps Key** ☐. 2. Tap **System settings** > **Display** tab. 3. Tap **Screen timeout**. 4. Tap the preferred screen backlight timeout time.
Phone Function Wi-Fi & mobile network	When Wi-Fi and mobile network are both available, which service will my phone use?	When using data, your phone may default to the Wi-Fi connection (if Wi-Fi connectivity on your phone is set to On). However, there will be no notification when your phone switches from one to the other. To know which data connection is being used, view the mobile network or Wi-Fi icon at the top of your screen.
Phone Function Home screen	Is it possible to remove an application from the Home screen?	Yes. Just touch and hold the icon until the dustbin icon appears at the top right hand side of the screen. Then, without lifting your finger, drag the icon to the trash can.
Phone Function Application	I downloaded an application and it causes a lot of errors. How do I remove it?	1. From the Home screen, tap and hold the **Recent Apps Key** ☐. 2. Tap **System settings** > **General** tab > **Apps** > **DOWNLOADED**. 3. Tap the application, then tap **Uninstall**.
Phone Function Charger	Is it possible to charge my phone using a USB data cable without installing the necessary USB driver?	Yes, the phone will be charged by the USB cable regardless of whether the necessary drivers are installed or not.
Phone Function Alarm	Can I use music files for my alarm?	Yes. In the Alarm clock setting, select the song as the Alarm sound.

Category Sub-Category	Question	Answer
Phone Function Alarm	Will my alarm be audible if the phone is turned off?	No, this is not supported.
Phone Function Alarm	If my ringer volume is set to Vibrate, will I hear my alarm?	Your alarm is programmed to be audible even in these scenarios.
Recovery Solution Hard Reset (Factory Reset)	How can I perform a factory reset if I can't access the phone's setting menu?	If your phone does not restore to its original condition, use a hard reset (factory reset) to initialize it.

LG

Life's Good

PRINTED WITH SOY INK™

CE0168