Additional Information

Specification

Power consumption	Refer to the main label.
AC adapter	• Model : DA-50F25 • Manufacturer : Asian Power Devices Inc. • Input : 100 - 240 V ~ 50 - 60 Hz 1.5 A Max. • Output : 25 V ⎓ 2 A
Dimensions (W x H x D)	Approx. 890 mm x 55 mm x 85 mm With foot
Bus Power Supply (USB)	5 V ⎓ 500 mA
Amplifier (Total RMS Output power)	420 W RMS

Design and specifications are subject to change without notice.

Rear Surround sound

Wireless Rear Speakers Kit included for real surround sound.(SPJ4-S)

OPEN SOURCE SOFTWARE NOTICE INFORMATION

To obtain the source code under GPL, LGPL, MPL, and other open source licenses, that is contained in this product, please visit http://opensource.lge.com.

In addition to the source code, all referred license terms, warranty disclaimers and copyright notices are available for download.

LG Electronics will also provide open source code to you on CD-ROM for a charge covering the cost of performing such distribution (such as the cost of media, shipping and handling) upon email request to opensource@lge.com. This offer is valid for three (3) years from the date on which you purchased the product.

HDMI HIGH-DEFINITION MULTIMEDIA INTERFACE

LG Life's Good

ENGLISH

SIMPLE MANUAL

Wireless Sound Bar

Please read this manual carefully before operating your set and retain it for future reference.
To view the instructions of advanced features, visit http://www.lg.com and then download Owner's Manual.
Some of the content in this manual may differ from your unit.

MODEL
SJ4R

MFL69710479


www.lg.com

Copyright © 2017 LG Electronics. All Rights Reserved



Front Panel

The buttons are located on the rear.




⏻/I ····· Standby / On

F ····· Selects Function

– + ····· Adjusts Volume

Rear Panel



DC IN ····· Connect to the AC adapter

OPTICAL IN ····· Connect to an Optical device

PORTABLE IN ····· Connect to a Portable device

USB ····· Connect to a USB device

HDMI OUT (TV ARC) ····· Connect to a TV

HDMI IN ····· Connect to HDMI out on a device

1 Subwoofer Connection

Place the wireless subwoofer near the speaker and follow steps below.

1. Connect the power cord of wireless subwoofer and sound bar to the outlet.
2. Turn on the main unit :


   The sound bar and wireless subwoofer will be **automatically** connected. The subwoofer's green LED turns on.

Subwoofer Connection Manually

If the subwoofer does not make sound, try to connect manually.

1. Press **Pairing** button on the rear of the wireless subwoofer.
   - The green LED on the rear of wireless subwoofer blinks quickly.
2. Turn on the main unit.
3. Pairing is completed.
   - The green LED on the rear of wireless subwoofer turns on.

Keep the sound bar and the subwoofer away from the device (ex. wireless router, microwave oven, etc.) over 1 m to prevent wireless interference.




2 TV Connection

Connect with the Sound Bar and TV using Optical (Ⓐ) or HDMI ARC (Ⓑ).


Ⓐ Optical Connection

1. Connect the sound bar to the TV using Optical cable.
2. Set up [External Speaker (Optical)] on your TV setting menu.



Ⓑ HDMI(ARC) Connection


1. Connect the sound bar to the TV using HDMI cable.
2. Set up [External Speaker (HDMI ARC)] on your TV setting menu.



- HDMI connection is unavailable if your TV does not support HDMI ARC.
- If this unit is connected by OPTICAL and ARC at the same time, the ARC signal is a high priority.

Additional Device Connection

1. Connect to the external device as follows.



2. Set the input source by pressing **F** on the remote control or unit repeatedly.

Remote control



ASC/BASS BLAST/CINEMA: Selects the sound effect.

REAR LEVEL +/-: Adjusts the volume level of rear speakers. (For rear speakers)

WOOFER LEVEL +/-: Adjusts the volume level of subwoofer.

AUTO POWER ON/OFF: Automatically turns on by an input source.

Replacement of battery

