Ceiling Cassette
Multi type Air Conditioner
OWNER'S MANUAL

- Please read carefully and thoroughly this manual before operating this unit.
- Contact the authorized SVC man for repair or maintenance of this unit.
- Contact the installer for installation of this unit.
- The appliance is not intended for use by young children or infirm persons without supervision.
- Young children should be supervised to ensure that they do not play with the appliance.

MODEL: Ceiling Cassette
Multi type
Air-Conditioner

Prior to installation of this air-conditioning unit must be submitted for approval by the utility service which provides electricity (EN 61000-3-3/3-11).

Safety Precautions
Warning 2
Caution 3

Operating Instructions
Name and Function of Remote Controller 4
Optional Function 5
Set the Current Time and a day of the Week.....6
Weekly Timer.....7
Holiday Setting 8
Timer Setting 8
Operation Mode 9
Operation Procedure 9
Child Lock Function(optional).....15
Operation Details 16
Self-diagnosis Function 16

Care and Maintenance
Indoor unit.....17
Outdoor unit.....17
Not used for long time.....18

Troubleshooting Tips
Before You Call For Service 19

Safety precautions

To prevent injury to the user or other people and property damage, the following instructions must be followed.

■ Incorrect operation due to ignoring of instruction will cause harm or damage. The seriousness is classified by the following indications.

⚠ WARNING

This symbol indicates the possibility of death or serious injury.

⚠ CAUTION

This symbol indicates the possibility of injury or damage to properties only.

⚠ WARNING

■ **Do not install, remove and reinstall the unit by yourself.**
- Improper installation will cause water leakage, electrical shock, or fire. Please consult authorized dealer or specialist for the installation work. Please note fault caused by improper installation is not covered by warranty.
- Unit must be installed in an easily accessible area. Any additional cost required to hire a special equipment to service the unit will be the responsibility of the customer.

⚠ WARNING

Do not damage or [illegible]
- It will cause electrical shock or fire.
- If the supply cord is damaged, it must be replaced by the manufacturer or its service agent or a similarly qualified person in order to avoid a hazard.

Do not operate switch with wet
- It may cause electrical shock.

Plug in the power cord
- Otherwise, it will cause electrical shock or fire due to heat generation.

Do not operate or stop the [illegible]
- It will cause electrical shock or fire due to heat generation.

Do not insert your finger or [illegible]
- Since the fan rotates at high speed, this may cause an injury or damage the unit.

Do not expose [illegible] in to
- This could damage your health.

When an abnormality (smell or warning, etc.)
- If the unit continues to be operated in an abnormal condition, it may cause a fire, trouble, etc. In this case, consult your dealer.

Repair or relocation should not be done by
- If this is done in correctly, it may cause a fire, electric shock, injury by dropping of the unit, water leakage, etc. Consult your dealer.

CAUTION

- Contact the authorized Service technician for repair or maintenance of this unit.
- Contact the installer for installation of this unit.
- The air conditioner is not intended for use by young children or infirm persons without supervision.
- Young children should be supervised to ensure that they do not play with the air conditioner.

⚠ CAUTION



- Water may enter the unit and degrade the insulation. It may cause an electric shock.



- An oxygen shortage may occur.



- Since the fan rotates at high speed during operation, it may cause an injury.



- This could injure the pet or plant.



- It may cause a fire or deformation of the cabinet.



- The unit may drop or fall down and cause an injury.



- It may cause imperfect combustion.



- It may cause an injury.



- It may cause an injury through dropping or falling down.



- In the cooling mode, if it is operated in a room with high humidity (80%r.h. or more) for a long time, water condensed in the air conditioner may drop and may wet and spoil furniture, etc.



- It may case an injury, etc. by falling down.



- Do not use this air conditioner to preserve precision devices, food, animal, plants and art objects.
  It may cause deterioration of quality, etc.



- If will cause electrical shock or fire.



- It may cause an injury.



- It will cause an injury by the rotating blower.

Operating Instructions

Name and Function of Remote Controller



A Operation display
Displays the operation conditions.

B On/Off Button
Operation starts when this button is pressed, and stops when the button is pressed again.

C Set Temperature Button
Used to set the temperature when the desired temperature is obtained.

D FAN Operation Button
Used to circulate room air without cooling or heating.

E Fan Speed Button
Used to set the desired fan speed.

F Operation Mode Selection Button
Used to select the operation mode.
- Auto Operation Mode. (except heat pump model)
- Cooling Operation Mode.
- Soft Dry Operation Mode.
- Heating Operation Mode. (except cooling model)

G Timer Set Button
Used to set the timer when the desired time is obtained.

H Timer Cancel Button
Used to cancel the timer.

I Auto Swing Button
Used to swing up and down.

J Room Temperature Checking Button
Used to check the room temperature.

K Program Button
Used to set the weekly timer.

L Week Button
Used to set a day of the week.

M Holiday Button
Used to set a holiday of the week.

N Time Set Button
Used to set the time of the day and change the time in the weekly timer Function.

O Set and Clear Button
Used to set and clear the weekly timer.

P Reset Button
Used to set the current time and clear the setting time.

Optional Function

• WIRELESS REMOTE CONTROLLER

This air-conditioner is equipped with wired remote controller basically. But if you want to be available with wireless remote controller, you pay for it.

Remote Controller

Signal transmitter

Transmits the signals to the signal receptor.



- A **FAN Operation Button**
  Used to circulate room air without cooling or heating
- B **Cooling Operation Button**
- C **Soft Dry Operation Button**
  Used to dehumidify without overcooling.
- D **Heating Operation Button**
  (Heat pump model only)
- E **Timer Set Button**
  Used to set the timer when the desired time is obtained.
  Then the wired remote controller is set to 24 hours by an hour but the wireless remote controller is set to 7 hours by an hour. Therefore, if you want to set over 7 hours, use the wired remote controller.
- F **Fan Speed Button**
  Used to set the desired fan speed.
- G **Auto Swing Button**
  Used to swing up and down.
- H **On/Off Button**
  Operation starts when this button is pressed, and stops when the button is pressed again.
- I **Set Temperature Button**
  Used to set the temperature when the desired temperature is obtained.
- J **Auto Operation Button**(except heat pump model)

CAUTION

of handling the Remote Controller

- Aim at the signal receptor on the wired remote controller so as to operate.
- The remote control signal can be received at a distance of up to about 7m.
- Be sure that there are no obstructions between the remote controller and the signal receptor.
- Do not drop or throw the remote controller.
  Do not place the remote controller in a location exposed to direct sunlight, or near the heating unit, or any other heat source.
- Block a strong light over the signal receptor with a curtain or etc. so as to prevent the abnormal operation. (ex:electronic quick start, ELBA, inverter type fluorescent lamp)

• AIR-FILTER CHECKING FUNCTION(OPTIONAL)

It will display in the remote controller display when an air filter is polluted.
Then clean the air-filter for reference to this Manual (page 17).
Press the "Set and clear Button" and the "Room Temperature Checking Button" simultaneously after cleaning the air filter.

Set the Current Time and a day of the Week

1 Press the ' Hour ' button.

Each time the button is pressed, the number is changed from 00 to 23.
You can set the number of the current hour.





2 Press the ' Min ' button.

Each time the button is pressed, the number is increased from 00 to 59.
You can set the number of the current minute.





3 Press ' Week ' button.

Each time the button is pressed, a day of the week is shifted from sunday to saturday.
You can set the day of the week.





4 Press the ' ● RESET ' button.

If you want to reset the current time and a day of the week, click the Reset button.





Weekly Timer

1 Press the Program button.

The remote controller is displayed like below. Then ' Program set ', ' Sun ' and '01' is blinked.





2 Press the ' Week ' button.

Select Monday.



3 Change the timer setting until the desired time is set.



For Example, the air-conditioner is turned on from 6 to 8 and from 13 to 22 .



Holiday Setting

If it is a holiday in this week, you may set a holiday.

1. Press the Program button.



2. Press the Week button.
   Select the Tuesday.



3. Press the Holiday button.



Then the remote controller will be displayed ' Tue '.
The outside rectangular means holiday.



Timer Setting

1. Press the Timer button.



2. Change the timer setting until the desired time is set.



3. If you want to cancel the timer setting, press the Cancel button.



Operation Mode



(Heat Pump Model)



(Cooling Model)

Operation Procedure

1st On/Off Button

2nd Operation Mode Selection Button

3rd Room Temperature Setting Button

4th Indoor Fan Speed Selection Button



Cooling Operation Mode

1 Press the On/Off Button.



2 Select Cooling Operation.

Press the Operation Mode Selection Button.
Each time the button is pressed, the operation mode is shifted in the arrow direction.





3 Set the temperature lower than the room temperature.



- The temperature can be set within a range of 18℃ ~ 30℃ by 1℃ .



4 Set the fan speed.



- Select the fan speed in three steps
  - high, low, medium.
- The display shows high fan speed.
- Each time the button is pressed, the fan speed mode is shifted.

⁄BSoft Dry Operation Mode

This mode dehumidifies without overcooling.

1 Press the On/Off Button.



2 Select Soft Dry Operation.

Press the operation Mode Selection Button.
Each time the button is pressed, the operation mode is shifted in the arrow direction.





3 During Dry Operation.

- The indoor fan speed is automatically set to the low, so the shift of the indoor fan speed is impossible because of already being set to the best speed for Dry Operation by Micom Control.

Heating Operation Mode (Heat pump model only)

1 Press the On/Off Button.



2 Select Heating Operation.

Press the Operation Mode Selection Button.
Each time the button is pressed, the operation mode is shifted in the arrow direction.



3 Set the temperature.



- The temperature can be set within a range of 16℃~30℃ by 1℃.



To raise the Temperature.

To lower the Temperature.

4 Set the fan speed.



- Select the fan speed in three steps
  - high, low, medium.
- The display shows high fan speed
- Each time the button is pressed, the fan speed mode is shifted.

5 This air-conditioner is set to the hot start control in order not to discharge the cold air during the heating operation. This time, the remote controller indicates 'Preheat'.



6 If the outdoor temperature is too low during the heating operation, this air-conditioner is set to the defrosting operation and the remote controller indicates 'Defrost'.



Auto Operation Mode (Cooling model only)

1 Press the On/Off Button.



2 To select **Auto Operation**, press the Operation Mode Selection button.
Each time the button is pressed, the operation mode is shifted in the direction of the arrow.



3 Set the temperature upper or lower than the standard temperature.
The temperature can be set within a range of -2 ~ 2 by 1 level.



(This indication will be shifted to the initial Auto Mode Display state after 4 seconds.)



During Auto Operation:

❑ You can switch the indoor fan speed.

FAN Operation

1 Press the On/Off Button.



2 Press FAN Operation Button.



3 Each time Indoor Fan Speed button is pressed, the fan speed mode is shifted in the arrow direction.



- Fan speed is high.
- Fan speed is low.
- Fan speed is medium.

⁄F AUTO SWING BUTTON



1 Press the On/Off button. (Confirm the unit on operation.)	**2** Press the Auto Swing button then the horizontal louvers swing up and down automatically.	**3** Press again the Auto Swing button to cancel the Auto Swing mode.

Child Lock Function(optional)

This is the Function that any children cannot used to the air-conditioner.

Operation procedure



1 ***To set the Child-Lock Function***

Press the Timer button and Minute Set button for three seconds. Then the operation mode shift to child lock mode and it is displayed ' CL ' in the operation display. When you press any button in this time, the remote controller is not converted to any selected mode and the ' CL ' is displayed in the remote controller for about three seconds. But the Room Temperature function is operated in spite of child lock mode.

2 ***To cancel the Child-Lock Function***

Press the Timer button and Minute Set button for three seconds. Then the child-lock mode is cancelled and the preselected mode is displayed in the remote controller.

Operation Details

• Cooling Operation Mode

When the room temperature is higher than the set temperature, it operates in cooling mode at the set temperature, the set fan speed, and then it will be in automatically turn off when the room temperature reaches the set temperature +0.5℃.



■ : SETTING FAN SPEED ⦿ : LOW COOL OPERATION ★ : COMP ON ◈ : COMP OFF

Helpful information

Airflow speed and cooling capacity.
The cooling capacity indicated in the specification is the value when the fan speed is set to high, and the capacity will be lower at low or medium fan speed.
High fan speed is recommended when you wish to cool the room quickly.



Self-diagnosis Function

'CH' will flash in the remote controller display when a problem occurs. Then please contact your dealer.

Care and maintenance of the air conditioner

Indoor Unit

Grille, Case and Remote Control

❒ Turn the system off before cleanining, To clean, wipe with a soft, dry cloth. Do not use bleach or abrasives.

NOTE:
Supply power must be disconnected before cleaning the indoor unit.



Air Filters

The air filters behind the front grille should be checked and cleaned once every 2 weeks or more often if neccessary.



■ Never use any of the followings:
- Water hotter than 40℃. Could cause deformation and/or discoloration.
- Volatile substances. Could damage the surfaces of the air conditioner.



1 Remove the Air filters.
■ Take hold of the tab and pull slightly forward to remove the filter.

⚠ CAUTION

When the air filter is to be removed, do not touch the metal parts of the indoor unit.
It may cause an injury.

2 Clean dirt from the air filter using a vacuum cleaner or washing with water.
■ If dirt is conspicuous, wash with a neutral detergent in lukewarm water.
■ If hot water (50℃ or more) is used, it may be deformed.

3 After washing with water, dry well in the shade.
■ Do not expose the air filter to direct sunlight or heat from a fire when drying it.

4 Install the air filter.

Outdoor Unit

The heat exchanger coils and panel vents of the outdoor unit should be checked regularly. If clogged with dirt or soot, the heat exchanger and panel vents may be professionally steam cleaned.

NOTE:
Dirty or clogged coils will reduce the operating efficiency of the system and cause higher operating costs.



When the air conditioner is not GOING to be used for a long time.

1 **Operate the air conditioner at the following settings for 2 to 3 hours.**
- Type of operation: Fan operation mode.(Refer to page 14.)
- This will dry out the internal mechanisms.

2 **Turn off the breaker.**

⚠ CAUTION

Turn off the breaker when the air conditioner is not going to be used for a long time.

Dirt may collect and may cause a fire.

Helpful information

The air filters and your electiric bill.
If the air filters become clogged with dust, the cooling capacity will drop, and 6% of the electricity used to operate the air conditioner will be wasted.

1 **Clean the air filter and install it in the indoor unit.**
(Refer to page 17 for cleaning it.)

2 **Check that the air inlet and outlet of the indoor/outdoor unit are not blocked.**

3 **Check that the ground wire is connected correctly. It may be connect to the indoor unit side.**

This is not good for the health and wastes electricity.

Do not let direct sunshine enter the room when the air conditioner is in operation.

Adjust the vertical and horizontal airflow direction to ensure a uniform temperature in the room.

Avoid opening doors and windows as much as possible to keep the cool air in the room.

Blockages in the air filter reduce the airflow and lower cooling and dehumidifying effects. Clean at least once every two weeks.

Since windows are kept closed, it is a good idea to open them and ventilate the room now and then.

Before you call for service...

Troubleshooting Tips! Save time and money!

Check the following points before requesting repairs or service.... If the malfunction persist, please contact your dealer.



- Have you made a mistake in timer operation?
- Has the fuse blown or has the circuit breaker been tripped?



- Check that this is not a damp smell exuded by the walls, carpet, furniture or cloth items in the room.



- Condensation occurs when the airflow from the air conditioner cools the warm room air.



- This is the protector of the mechanism.
- Wait about three minutes and operation will begin.



- Is the air filter dirty? See air filter cleaning instructions.
- The room may have been very hot when the room air conditioner was first turned on. Allow time for it to cool down.
- Has the temperature been set incorrectly?
- Are the indoor unit's air inlet or outlet vents obstructed?



- For a noise that sounds like water flowing.
  -This is the sound of freon flowing inside the air conditioner unit.
- For a noise that sounds like the compressed air releasing into atmosphere.
  -This is the sound of the dehumidifying water being processed inside the air conditioning unit.



- This sound is generated by the expansion/constriction of the front panel, etc. due to changes of temperature.



- Are the batteries depleted?
- Are the batteries inserted in the opposite (+) and (-) directions?