This unit has been engineered and manufactured to ensure your personal safety, however improper use may result in potential electrical shock or fire hazards. In order to allow the proper operation of all safeguards incorporated in this monitor, observe the following basic rules for its installation, use, and servicing.

On Safety

Use only the power cord supplied with the unit. In case you use another power cord, make sure that it is certified by the applicable national standards if not being provided by the supplier. If the power cable is faulty in any way, please contact the manufacturer or the nearest authorized repair service provider for a replacement.

The power supply cord is used as the main disconnection device. Ensure that the socket-outlet is easily accessible after installation.

Operate the monitor only from a power source indicated in the specifications of this manual or listed on the monitor. If you are not sure what type of power supply you have in your home, consult with your dealer.

Overloaded AC outlets and extension cords are dangerous. So are frayed power cords and broken plugs. They may result in a shock or fire hazard. Call your service technician for replacement.

Do not Open the Monitor.
- There are no user serviceable components inside.
- There are Dangerous High Voltages inside, even when the power is OFF.
- Contact your dealer if the monitor is not operating properly.

To Avoid Personal Injury :
- Do not place the monitor on a sloping shelf unless properly secured.
- Use only a stand recommended by the manufacturer.
- Do not try to roll a stand with small casters across thresholds or deep pile carpets.

To Prevent Fire or Hazards:
- Always turn the monitor OFF if you leave the room for more than a short period of time. Never leave the monitor ON when leaving the house.
- Keep children from dropping or pushing objects into the monitor's cabinet openings. Some internal parts carry hazardous voltages.
- Do not add accessories that have not been designed for this monitor.
- During a lightning storm or when the monitor is to be left unattended for an extended period of time, unplug it from the wall outlet.
- Do not bring magnetic devices such as magnets or motors near the picture tube.

On Installation

Do not allow anything to rest upon or roll over the power cord, and do not place the monitor where the power cord is subject to damage.

Do not use this monitor near water such as near a bathtub, washbowl, kitchen sink, laundry tub, in a wet basement, or near a swimming pool.
Monitors are provided with ventilation openings in the cabinet to allow the release of heat generated during operation. If these openings are blocked, built-up heat can cause failures which may result in a fire hazard. Therefore, NEVER:

- Block the bottom ventilation slots by placing the monitor on a bed, sofa, rug, etc.
- Place the monitor in a built-in enclosure unless proper ventilation is provided.
- Cover the openings with cloth or other material.
- Place the monitor near or over a radiator or heat source.

On Cleaning

- Unplug the monitor before cleaning the face of the monitor screen.
- Use a slightly damp (not wet) cloth. Do not use an aerosol directly on the monitor screen because overspray may cause electrical shock.

On Repacking

- Do not throw away the carton and packing materials. They make an ideal container in which to transport the unit. When shipping the unit to another location, repack it in its original material.

- **Before setting up the monitor, ensure that the power is turned off to the monitor, computer system, and other attached devices.**
- **Carefully set the monitor face-down with the underside facing you.**

Connecting the Tilt/Swivel stand

1. Align the hooks on the tilt/swivel stand with the matching slots in the base of the monitor.
2. Insert the hooks into slots.
3. Slide the tilt/swivel stand toward the front of the monitor until the latches click into the locked position.

NOTE

- This illustration depicts the general model of connection. Your monitor may differ from the items shown in the picture.



Using the Computer

1. Connect the signal cable. When mated, tighten the thumbscrews to secure the connection.
2. Connect the power cord into a properly power outlet that is easily accessible and close to the monitor.

NOTE

- This is a simplified representation of the rear view.
- This rear view represents a general model; your monitor may differ from the view as shown.



Front Panel Controls



Control		Function
1	**Power Button**	Use this button to turn the monitor on or off.
2	**Power (DPMS) Indicator**	This Indicator lights up green when the monitor operates normally. If the monitor is in DPM (Energy Saving) mode, this indicator color changes to amber.
3	**MENU (or OSD) Button**	Use this button to enter or exit the on screen display.
4	**▲▼/◀ ▶ Buttons**	Use these buttons to choose or adjust items in the on screen display.
5	**SELECT (or SET) Button**	Use this button to enter a selection in the on screen display.

Control Direct Access Function





4 ▶ **Button** Bring up Contrast adjustment

▲ **Button** Bring up Brightness adjustment

The Contrast and Brightness functions are also available in the On Screen Display (OSD) menu.

◀ **Button** Brings up the clearness of the image : *letters, pictures or moving pictures.*

For seeing letters

For seeing pictures or the photographs

For seeing moving pictures

6 **AUTO adjustment function**

When adjusting your display settings, always press the **AUTO** button before entering the On Screen Display(OSD). This will automatically adjust your display image to the ideal settings for the current screen resolution size (display mode).

The best display mode is **1600 x 1200**.

7 **INPUT**

Use this button to make Dsub or BNC connector active. This feature is used when two computers are connected to the display. The default setting is Dsub. The LED is turned on for the D-sub connector and is turned off for the BNC connector.

Screen Adjustment

Making adjustments to the image size, position and operating parameters of the monitor is quick and easy with the On Screen Display Control system. A short example is quick and easy given below to familiarize you with the use of the controls. The following section is an outline of the available adjustments and selections you can make using the OSD.

NOTE

- Allow the monitor to stabilize for at least 30 minutes before making image adjustments.

To make adjustments in the On Screen Display, follow these steps:

- **Case 1**

MENU → ▲ ▼ → SELECT → ▲ ▼ ◀ ▶ → SELECT → MENU

- **Case 2**

OSD → ▲ ▼ → SET → ▲ ▼ ◀ ▶ → SET → OSD

1. Press the **MENU (or OSD) Button**, then the main menu of the OSD appears.
2. To access a control, use the ▲ or ▼ **Buttons**. When the icon you want becomes highlighted, press the **SELECT (or SET) Button**.
3. Use the ▲ ▼ / ◀ ▶ **Buttons** to adjust the item to the desired level.
4. Accept the changes by pressing the **SELECT (or SET) Button**.
5. Exit the OSD by pressing the **MENU (or OSD) Button**.

The following table indicates all the On Screen Display control, adjustment, and setting menus.

Main menu	Sub menu			Reference
BRIGHTNESS/ CONTRAST	Brightness		●	To adjust the brightness and contrast of the screen
	Contrast		●	
POSITION	V Position		●	To adjust the position of the screen
	H Position		●	
SIZE	V Size		●	To adjust the size of the screen
	H Size		●	
SHAPE	Tilt		●	To adjust the shape of the screen
	Side Pincushion		●	
	S Pincushion Balance		●	
	Parallelogram		●	
	Trapezoid		●	
	H Corner			
	Top Corner		●	
	Bottom Corner		●	
	Recall		●	
	Zoom		●	
	H Linearity		●	
	V Linearity		●	
	Recall		●	
RGB COLOR	PRESET	6500K	●	To customize the color of the screen
		9300K	●	
	Temp		●	
	R/G/B(User Color)		●	

● : Adjustable

NOTE

■ The order of icons may differ depending on the model (A10~A14).

Main menu	Sub menu			Reference
SETUP	Video Level		●	To customize the screen status for a user's operating environment
	Language		●	
	OSD Time			
	OSD Position		●	
	Reset		●	
	Clamp		●	
SPECIAL	Degauss		●	To improve the clarity and stability of the screen
	Natural Color		●	
	Auto Sizing		●	
	Sharpness		●	
	Moire	H Moire	●	
		V Moire	●	
	Purity		●	
	Convergence		●	
● : Adjustable				

NOTE

▪ The order of icons may differ depending on the model (A10~A14).

You were introduced to the procedure of selecting and adjusting an item using the OSD system. Listed below are the icons, icon names, and icon descriptions of the all items shown on the Menu.

To adjust the brightness and contrast of the screen



Brightness
To adjust the brightness of the screen.

Contrast
To adjust the contrast of the screen.

To adjust the position of the screen



Vertical Position
To move image up and down.

Horizontal Position
To move image left and right.

To adjust the size of the screen



Vertical Size
To adjust image height.

Horizontal Size
To adjust image width.

To adjust the shape of the screen







Tilt
To correct image rotation.

Side Pincushion
To correct a concave or convex bowing of the image.

Side Pincushion Balance
To correct the balance of both sides bowing.

Parallelogram
To correctly adjust the skew of the image.

Trapezoid
To correct geometric distortion.

H Corner*
Top Corner*
Bottom Corner*
To correct an irregular distortion of the displayed image.

Recall*
You can use this function to reload the modified parameters for screen display operation, as specified by the user after purchase: *Side Pincushion, Side Pincushion Balance, Parallelogram, Trapezoid , H Corner, Top Corner, Bottom Corner (These recalled options may differ depending on the mode selected: Preset, User, or New).*

Zoom*
To simultaneously adjust horizontal and vertical size of the image.

* This function is available for designated models only.
PAGE A8

To adjust the shape of the screen



H. Linearity*
To adjust the horizontal width of edge of the image.

V. Linearity*
To adjust the vertical width of edge of the image.

Recall*
You can use this function to reload the modified parameters for screen display operation, as specified by the user after purchase: *Zoom, H/V Linearity (These recalled options may differ depending on the mode selected: Preset, User, or New).*

* This function is available for designated models only. PAGE A8

To customize the color of the screen



PRESET **6500K/ 9300K**
Select the screen color.
• 6500K: Slightly reddish white.
• 9300K: Slightly bluish white.

TEMP Select the screen temperature which you prefer among reddish or bluish or any color in between.

RED
GREEN
BLUE Set your own color levels.

On Screen Display(OSD) Selection and Adjustment

To customize the screen status for a user's operating environment





VIDEO LEVEL This item is used to select the monitor's input signal level. The normal level used for most PCs is 0.7V.
If the screen becomes suddenly washed-out or blurred, please select 1.0V and try again.

LANGUAGE To choose the language in which the control names are displayed.
OSD Menus are available in 11 languages: English, German, French, Spanish, Italian, Swedish, Finnish, Portuguese, Korean, Chinese and Russian.

OSD TIME* Set the OSD time, i.e. the length of time a menu will remain on-screen before it shuts off automatically. Adjust the time to 5, 10, 20, 30 or 60 seconds.

OSD POSITION* To adjust position of the OSD window on the screen.

RESET* Return to all factory default settings except "LANGUAGE, BRIGHTNESS, CONTRAST": *Tilt, Color 9300K, Video Level, OSD Time, OSD Position, Moire, Convergence (These reset options may differ depending on the mode selected: Preset, User, or New).*

CLAMP* In case of input SOG (Sync On Green) Video Signal, the back raster will appear green. Then, to select the SOG (Sync On Green) in the clamp, it goes back to the original back raster.

* This function is available for designated models only. PAGE A9

To improve the clarity and stability of the screen





DEGAUSS To manually demagnetize the screen to avoid showing incorrect images or colors.

NATURAL COLOR* This is have the real color of the image.

AUTO SIZING* This will automatically adjust your display image to the ideal settings for the current screen resolution size (display mode).

SHARPNESS* This is to adjust the clearness of the screen.
It is recommended to use this to see movies or moving picture.

MOIRE This item allows you to reduce the degree of moire. (Moire is caused by interference Horizontal Scan Line with the periodical dot screen). It is normally OFF(H:0/V:0).
The moire adjustments may affect the focus of the screen.
Moire adjustments may shake slightly while the moire reduction function is on.

PURITY* Use to adjust the purity on the screen if the color appears uneven.

CONVER-GENCE* This is to adjust the alignment of red and blue fields.

* This function is available for designated models only. PAGE A9

Check the following before calling for service.

No image appears

◉ **Is the power cord of the monitor connected?**	• Check and see if the power cord is connected properly to the power outlet.
◉ **Is the power indicator light on?**	• Press the Power button.
◉ **Is the power on and the power indicator green?**	• Adjust the brightness and the contrast.
◉ **Is the power indicator amber?**	• If the monitor is in power saving mode, try moving the mouse or pressing any key on the keyboard to bring up the screen.
◉ **Do you see an "OUT OF FREQUENCY" message on the screen?**	• This message appears when the signal from the PC (video card) is out of horizontal or vertical frequency range of the monitor. See the 'Specifications' section of this manual and configure your monitor again.
◉ **Do you see a "SELF DIAGNOSITICS" message on the screen?**	• This message appears when the signal cable between your PC and your monitor is not connected. Check the signal cable and try again. In case of using the BNC connector, this message also appears in the DPM mode. Check the signal cable or press any key on the keyboard to bring up the screen.

The screen is flickering

◉ **Is the vertical frequency less than 70Hz or is your monitor set to the interlaced mode?**	• Set the vertical frequency to 72Hz or higher, and consult the video card user manual for instructions on converting to a non-interlaced mode. (You can set this option under the Display icon of the Control Panel.)
◉ **Do you have any magnetic material such as adapter, or high-voltage line near to your monitor?**	• Remove magnetic sources, such as power adapters, speakers, or high-voltage lines, away from the monitor.
◉ **Do you hear a "~ding" sound while the monitor is flickering?**	• Use the normal degaussing function. This function clears the screen and reduces any screen blur that may occur due to the surrounding magnetic field. The screen may flicker for about 5 seconds, accompanied by a "~ding" sound.

The screen color is not normal

◉ Do you see basic discoloration (16 colors)?	• Set the color depth to 256 colors or higher: use 'Control Panel' → 'Display' → 'Settings' → 'Color Palette'
◉ Is the screen color unstable or monochrome?	• Check the connection of the signal cable. Or pull out the video card of the PC and insert it again.
◉ Do you see two fine horizontal lines on the screen?	• Two fine horizontal lines may be visible on the screen. This is not a fault or defect of the moitor and is normal for all aperture grille type displays. The fine lines are the shadows of Damper Wires which are used to reduce the susceptibility of the CRT's aperture grille to shock or vibration.
◉ Do you see a partial blurring on the screen?	• This happens due to interference from surrounding magnetic fields, as created when speakers, steel structures, or high-voltage lines are placed near the monitor. Remove any such materials from the immediate vicinity and use the DEGAUSS icon on the screen adjustment menu to fix the screen.

I see an after-image on the screen

◉ Do you see the after-image even when you turn off the monitor?	• A premature aging of the monitor pixels may cause the prolonged display of a single image on the screen. Be sure to use a screen saver to maximize the service life of the monitor.

I see waves on the screen

◉ Do you see the wave directly on the screen?	• This occurs in inverse proportion to the screen focus, which can be caused by a particular frequency or video card. Brighten the screen and use the 'MOIRE' icon on the screen adjustment menu to adjust the screen.

Have you installed the monitor driver?

◉ Have you installed the monitor driver?	• Be sure to install the monitor driver from the monitor driver CD (or diskette) that comes with your monitor. Or, you can also download the driver from our web site: http://www.lge.com.

Picture Tube	22 inches (20 inches viewable), Natural Flat Tube 90 degree deflection 0.24mm Grille pitch ARAS(Anti-Reflective Anti-Static) coating	
Sync Input	Horizontal Freq.	30 - 124kHz (Automatic)
	Vertical Freq.	50 - 160Hz (Automatic)
	Input Form	Separate TTL, Positive/Negative CompositeTTL, Positive/Negative SOG(Sync On Green)
	Signal Input	15 pin D-Sub / 5 BNC Connector
Video Input	Input Form	Separate, RGB Analog, 0.7Vp-p/75 ohm, Positive
	Resolution(max)	2048 x 1536@75Hz
Plug&Play	DDC 1/2B	
Power Consumption	Normal	≤ 115W(130W)
	Stand-by/Suspend	≤ 8W(20W)
	Power Off	≤ 3W(18W) *( ) : with USB
Dimensions &Weight (with tilt/ swivel stand)	Width	50.3cm / 19.8 inches
	Height	50.9 cm / 20.4 inches
	Depth	47.7 cm / 18.8 inches
	Net	31.3 kg (69.0 lbs)
Power Input	AC 100-240V 50/60Hz 2.0A	
Environmental Conditions	Operating Conditions	
	Temperature	5˚C to 35 ˚C
	Humidity	10 % to 90 % non-Condensing
	Storage Conditions	
	Temperature	-20˚C to 60 ˚C
	Humidity	5 % to 90 % non-Condensing
	Attached( ), Detached (O)	
Signal cable	Attached( ), Detached (O)	
	Attached or Detached	
	TCO99	

Preset Modes (Resolution)

	Display Modes (Resolution)		Horizontal Freq. (kHz)	Vertical Freq. (Hz)
1	VESA	640 x 480	31.47	60
2	VESA	800 x 600	53.68	85
3	VESA	1024 x 768	60.02	75
4	VESA	1024 x 768	68.68	85
5	VESA	1280 x 1024	79.98	75
6	VESA	1280 x 1024	91.15	85
7	VESA	1600 x 1200	93.75	75
8	VESA	1600 x 1200	106.25	85
9	VESA	2048 x 1536	121.95	75

Using the BNC connectors with other types of video cards. Follow the example that fits your needs.

1. In case of using a composite sync on green video signal(Sync On Green):
Connect each R,G and B video signals to BNC receptacles on the back of the monitor.



2. In case of using an external composite sync signal:
Connect each R, G and B video signals and composite sync signal to the BNC receptacles on the rear panel.



* Varies according to model.

3. In case of using a separate horizontal and vertical sync signal:
Connect each R, G and B video signals and the horizontal and vertical sync signal to BNC receptacles on rear panel.



* Varies according to model.

NOTE
- This package does not include the BNC connectors but you can purchase them at your local computer stores.
- This monitor does not support the DDC function, if you use the 5 BNC connectors with other types of video cards.

HD : Horizontal Drive
VD : Vertical Drive
COMP : Composite

USB (Universal Serial Bus) is an innovation in connecting your different desktop peripherals conveniently to your computer. By using the USB, you will be able to connect your mouse, keyboard, and other peripherals to your monitor instead of having to connect them to your computer. This will give you greater flexibility in setting up your system. USB allows you to connect a chain of up to 120 devices on a single USB port; and you can "hot" plug (attach them while the computer is running) or unplug them while maintaining the Plug and the Plug auto detection and configuration. This monitor has an integrated BUS-powered USB hub, allowing up to 4 other USB devices to be attached it.

USB connection

1. Connect the upstream port of the monitor to the downstream port of the USB compliant PC or another hub using the USB cable. (Computer must have a USB port)
2. Connect the USB compliant peripherals to the downstream ports of the monitor.

- This is a simplified representation of the rear view.



To ***USB downstream port*** of the USB compliant PC or another hub cable

- This is a simplified representation of the side view.



USB downstream Ports connect the cables from USB compliant peripherals-such as keyboard, mouse, etc

NOTE

- To activate the USB hub function, the monitor must be connected to a USB compliant PC(OS) or another hub with the USB cable(enclosed).
- When connecting the USB cable, check that the shape of the connector at the cable side matches the shape at the connecting side.
- Even if the monitor is in a power saving mode, USB compliant devices will function when they are connected the USB ports(both the upstream and downstream) of the monitor.

USB Specifications

USB standard	Rev. 1.1 complied BUS-powered hub
Downstream power supply	500mA for each (MAX)
	12 Mbps (full), 1.5 Mbps (low)
	1 Upstream port / 4 Downstream ports

IMPORTANT: These USB connectors are not designed for use with high-power USB devices such as a video camera, scanner, etc. LGE recommends connecting high-power USB devices directly to the computer