LG
Life's Good

OWNER'S MANUAL

# DVD Receiver System

Please read this manual carefully before operating your set and retain it for future reference.

FOR THE WARRANTY TERMS & CONDITIONS, PLEASE REFER TO BACK COVER OF THIS MANUAL.

**MODEL**
HT44S (HT44S, SH85S-F/ W)

P/NO : MFL63284290

HT805S-D0_BGBRLL_ENG_4290.indd 1 2010-03-02 ¿ÀÈÄ 3:40:57

# 1 Safety Information




CAUTION: TO REDUCE THE RISK OF ELECTRIC SHOCK DO NOT REMOVE COVER (OR BACK) NO USER-SERVICEABLE PARTS INSIDE REFER SERVICING TO QUALIFIED SERVICE PERSONNEL.



This lightning flash with arrowhead symbol within an equilateral triangle is intended to alert the user to the presence of uninsulated dangerous voltage within the product's enclosure that may be of sufficient magnitude to constitute a risk of electric shock to persons.



The exclamation point within an equilateral triangle is intended to alert the user to the presence of important operating and maintenance (servicing) instructions in the literature accompanying the product.

**WARNING**: TO PREVENT FIRE OR ELECTRIC SHOCK HAZARD, DO NOT EXPOSE THIS PRODUCT TO RAIN OR MOISTURE.

**WARNING**: Do not install this equipment in a confined space such as a book case or similar unit.




**CAUTION**: This product employs a Laser System. To ensure proper use of this product, please read this owner's manual carefully and retain it for future reference. Shall the unit require maintenance, contact an authorized service center.

Use of controls, adjustments or the performance of procedures other than those specified herein may result in hazardous radiation exposure.

To prevent direct exposure to laser beam, do not try to open the enclosure. Visible laser radiation when open. DO NOT STARE INTO BEAM.

**CAUTION**: The apparatus shall not be exposed to water (dripping or splashing) and no objects filled with liquids, such as vases, shall be placed on the apparatus.

**CAUTION concerning the Power Cord**

Most appliances recommend they be placed upon a dedicated circuit;

That is, a single outlet circuit which powers only that appliance and has no additional outlets or branch circuits. Check the specification page of this owner's manual to be certain. Do not overload wall outlets. Overloaded wall outlets, loose or damaged wall outlets, extension cords, frayed power cords, or damaged or cracked wire insulation are dangerous. Any of these conditions could result in electric shock or fire. Periodically examine the cord of your appliance, and if its appearance indicates damage or deterioration, unplug it, discontinue use of the appliance, and have the cord replaced with an exact replacement part by an authorized service center. Protect the power cord from physical or mechanical abuse, such as being twisted, kinked, pinched, closed in a door, or walked upon. Pay particular attention to plugs, wall outlets, and the point where the cord exits the appliance. To disconnect power from the mains, pull out the mains cord plug. When installing the product, ensure that the plug is easily accessible.

**Disposal of your old a ppliance**



1. When this crossed-out wheeled bin symbol is attached to a product it means the product is covered by the European Directive 2002/96/EC.
2. All electrical and electronic products should be disposed of separately from the municipal waste stream via designated collection facilities appointed by the government or the local authorities.
3. The correct disposal of your old appliance will help prevent potential negative consequences for the environment and human health.
4. For more detailed information about disposal of your old appliance, please contact your city office, waste disposal service or the shop where you purchased the product.

CE LG Electronics hereby declares that this/these product(s) is/are in compliance with the essential requirements and other relevant provisions of Directive 2004/108/EC, 2006/95/EC, and 2009/125/EC.

European representative :

LG Electronics Service Europe B.V. Veluwezoom 15, 1327 AE Almere, The Netherlands (Tel : +31–(0)36–547–8888)

**WARNING**: Do not install this equipment in a confined space such as a book case or similar unit.

**CAUTION**: Do not block any ventilation openings. Install in accordance with the manufacturer's instructions.

Slots and openings in the cabinet are provided for ventilation and to ensure reliable operation of the product and to protect it from overheating.
The openings should be never be blocked by placing the product on a bed, sofa, rug or other similar surface. This product should not be placed in a built-in installation such as a bookcase or rack unless proper ventilation is provided or the manufacturer's instruction have been adhered to.

This device is equipped with a portable battery or accumulator.

**Safe way to remove the battery or the battery from the equipment:**

Remove the old battery pack, follow the steps in reverse order than the assembly. To prevent contamination of the environment and bring on possible threat to human and animal health, the old battery or the battery put in the appropriate container at designated collection points. Do not dispose of batteries or battery together with other waste. It is recommended that you use local, free reimbursement system batteries and accumulators.

The battery shall not be exposed to excessive heat such as sunshine, fire or the like.

## Copyrights

It is forbidden by law to copy, broadcast, show, broadcast via cable, play in public, or rent copyrighted material without permission. This product features the copy protection function developed by Macrovision. Copy protection signals are recorded on some discs. When recording and playing the pictures of these discs picture noise will appear. This product incorporates copyright protection technology that is protected by U.S. patents and other intellectual property rights. Use of this copyright protection technology must be authorized by Macrovision, and is intended for home and other limited viewing uses only unless otherwise authorized by Macrovision. Reverse engineering or disassembly is prohibited.

CONSUMERS SHOULD NOTE THAT NOT ALL HIGH DEFINITION TELEVISION SETS ARE FULLY COMPATIBLE WITH THIS PRODUCT AND MAY CAUSE ARTIFACTS TO BE DISPLAYED IN THE PICTURE. IN CASE OF 525 OR 625 PROGRESSIVE SCAN PICTURE PROBLEMS, IT IS RECOMMENDED THAT THE USER SWITCH THE CONNECTION TO THE 'STANDARD DEFINITION ' OUTPUT. IF THERE ARE QUESTIONS REGARDING OUR TV SET COMPATIBILITY WITH THIS MODEL 525p AND 625p UNIT, PLEASE CONTACT OUR CUSTOMER SERVICE CENTER.

You have to set the disc format option to [Mastered] in order to make the discs compatible with the LG players when formatting rewritable discs. When setting the option to Live File System, you cannot use it on LG players.

(Mastered/ Live File System : Disc format system for Windows Vista)

**POWER:** This unit operates on a mains supply of 200-240V~, 50/60Hz.

**WIRING:** This unit is supplied with a BSI 1363 approved 13 amp mains plug, fused at 5 amp. When replacing the fuse always use a 5 amp BS 1362, BSI or ASTA approved type. Never use this plug with the fuse cover omitted. To obtain a replacement fuse cover contact your dealer. If the type of plug supplied is not suitable for the mains sockets in your home, then the plug should be removed and a suitable type fitted. Please refer to the wiring instructions below:

**WIRING:** A mains plug removed from the mains lead of this unit must be destroyed. A mains plug with bared wires is hazardous if inserted in a mains socket. Do not connect either wire to the earth pin, marked with the letter E or with the earth symbol ⏚ or coloured green or green and yellow. If any other plug is fitted, use a 5 amp fuse, either in the plug, or at the distribution board.

**IMPORTANT:** The wires in this mains lead are coloured in accordance with the following codes:

**- BLUE: NEUTRAL, BROWN: LIVE -** As the colours of the wires in the mains lead of this unit may not correspond with the coloured marking identifying the terminals in your plug, proceed as follows: The wire which is coloured blue must be connected to the terminal which is marked with the letter N or coloured black. The wire which is coloured brown must be connected to the terminal which is marked with the letter L or coloured red.

1
2
3
4
5
6
7

# Contents


## Safety Information

2 CAUTION

## Preparation

8 Unique Features
8 Accessories
9 Introduction
9 Playable Discs
9 About the ⃠ Symbol Display
9 Symbol Used in this Manual
9 Regional Codes
10 Playable file Requirement
11 Remote control
13 Front panel
14 Rear panel

## Installation

15 Attaching the speakers to the unit
16 Connections to Your TV
16 Component Video Connection
17 HDMI Out Connection
18 Video Connection
18 SCART Connection
19 Resolution Setting
19 Video Output Resolution
20 Optional Equipment Connection
20 AUX IN Connection
20 AUDIO (PORT. IN) In Connection
20 Listening to music from your portable player or external device
21 USB Connection
22 OPTICAL IN connection
22 Antenna Connection
23 Adjust the setup settings
23 OSD Initial language settings
23 To display and exit the Setup menu
24 Language
24 Display
25 Audio
26 Lock (Parental Control)
27 Others

## Operation

28 Using the Home Menu
28 Basic Operations
29 Other Operations
29 Displaying Disc Information on-screen
30 To display the DVD Menu
30 To display the DVD title
30 1.5 times speed playback
30 Screen Saver
30 Starting play from selected time
30 Resume playback
31 Marked Playback

31 Changing subtitle code page
32 Viewing a PHOTO file
32 Options while viewing a photo
33 Sleep Timer Setting
33 Dimmer
33 Turn off the sound temporarily
33 Last Scene Memory
33 System Select - Optional
33 Adjust the speaker level settings

34 **Radio Operations**
34 Presetting the Radio Stations
34 Deleting all the saved stations
34 Deleting a saved station
34 Improving poor FM reception
35 Seeing information about a radio station

36 **Sound adjustment**
36 Setting the surround mode

37 **Advanced Operations**
37 Recording to USB

## Maintenance

38 **Notes on Discs**
38 **Handling the Unit**

## Troubleshooting

39 **Troubleshooting**

## Appendix

40 **Language Codes**
41 **Area Codes**
42 **Trademarks and Licenses**
43 **Specifications**

## Warranty

44 **Warranty**

# 2 Preparation



## Unique Features

### Portable In

Listens to music from your portable device. (MP3, Notebook, etc)

### USB Direct Recording

Records music from CD to your USB device.

### Full HD up-scaling

Views Full HD picture quality with simple setup.

### Home Theater Speaker ez Setup

listens sound form TV, DVD and Digital device with vivid 2.1 or 2.0 ch mode.

## Accessories

Please check and identify the supplied accessories.



Remote control (1)



Battery (1)



FM antenna (1)



Speaker cables (3)

# Introduction

## Playable Discs

This unit plays DVD±R/RW and CD-R/RW that contains audio titles, DivX, MP3, WMA and/or JPEG files. Some DVD±RW/DVD±R or CD-RW/CD-R cannot be played on this unit due to the recording quality or physical condition of the disc, or the characteristics of the recording device and authoring software.

| | |
|---|---|
| DVD VIDEO | DVD-VIDEO (8 cm / 12 cm disc)<br>Discs such as movies that can be purchased or rented. |
| DVD R | DVD±R (8 cm / 12 cm disc)<br>Video mode and finalized only |
| DVD RW | DVD-RW (8 cm / 12 cm disc)<br>Video mode and finalized only |
| RW DVD+R | DVD+R: Video mode only<br>Supports the double layer disc also |
| RW DVD+ReWritable | DVD+RW (8 cm / 12 cm disc)<br>Video mode and finalized only |
| COMPACT disc DIGITAL AUDIO | Audio CD: Music CDs or CD-R/CD-RW in music CD format that can be purchased. |

## About the ⃠ Symbol Display

" ⃠ " may appear on your TV display during operation and indicates that the function explained in this owner's manual is not available on that disc.

## Symbol Used in this Manual

| | |
|---|---|
| All discs and file listed below | ALL |
| MP3 files | MP3 |
| DVD and finalized DVD±R/RW | DVD |
| WMA files | WMA |
| DivX files | DivX |
| Audio CDs | ACD |
| JPG files | JPG |

**NOTE**

Indicates special notes and operating features.

**TIP**

Indicates tip and hints for making the task easier.

**CAUTION**

Indicates cautions for preventing possible damages from abuse.

## Regional Codes

This unit has a regional code printed on the rear of the unit. This unit can play only DVD discs labeled same as the rear of the unit or "ALL".

- Most DVD discs have a globe with one or more numbers in it clearly visible on the cover. This number must match your unit's regional code or the disc cannot play.
- If you try to play a DVD with a different regional code from your unit, the message "Check Regional Code" appears on the TV screen.

# Playable file Requirement

### MP3/ WMA music file requirement

MP3/ WMA file compatibility with this unit is limited as follows :

- Sampling frequency : within 32 to 48 kHz (MP3), within 32 to 48 kHz (WMA)
- Bit rate : within 32 to 320 kbps (MP3), 40 to 192 kbps (WMA)
- Support Version : v2, v7, v8, v9
- Maximum files : Under 999
- File extensions : ".mp3"/ ".wma"
- CD-ROM file format : ISO9660/ JOLIET
- We recommend that you use Easy-CD Creator, which creates an ISO 9660 file system.

### Photo file requirement

Photo file compatibility with this unit is limited as follows :

- Max pixel in width : 2760 x 2048 pixel
- Maximum files : Under 999
- Some discs may not operate due to a different recording format or the condition of disc.
- File extensions: ".jpg"
- CD-ROM file format : ISO9660/ JOLIET

### DivX file requirement

DivX file compatibility with this unit is limited as follows :

- Available resolution: within 720x576 (W x H) pixels.
- The file name of the DivX subtitle should be entered within 45 characters.
- If there is impossible code to express in the DivX file, it may be displayed as " _ " mark on the display.
- Frame rate : less than 30 fps.
- If the video and audio structure of recorded files is not interleaved, either video or audio is outputted.
- Playable DivX file : ".avi", ".mpg", ".mpeg", ".divx"
- Playable Subtitle format : SubRip (*.srt/ *.txt), SAMI (*.smi), SubStation Alpha (*.ssa/ *.txt), MicroDVD (*.sub/ *.txt), SubViewer 2.0 (*.sub/ *.txt), Vobsub (*.sub)
- Playable Codec format : "DIVX3.xx", "DIVX4. xx", "DIVX5.xx", "MP4V3", "3IVX".
- Playable Audio format : "AC3", "PCM", "MP3", "WMA".
- Sampling frequency : within 32 to 48 kHz (MP3), within 32 to 48 kHz (WMA)
- Bit rate : within 32 to 320 kbps (MP3), 40 to 192 kbps (WMA)
- For Discs formatted in Live file system, you can not it on this unit.
- If the name of movie file is different from that of the subtitle file, during playback of a DivX file, subtitle may not be display.
- If you play a DivX file differ from DivXspec, it may not operate normally.

# Remote control

Remote control




• • • • • • • • • • • **1** • • • • • • • • • • •

**RADIO&INPUT**: Changes input sources.

**MARKER :** Marks play list.

**POWER** : Switches the unit ON or OFF.

**OPEN/CLOSE** : Opens and closes the disc Drawer.

**SLEEP** : Sets the System to turn off automatically at a specified time. (Dimmer : The display window will be darken by half.)

**INFO/DISPLAY** : Accesses On-Screen Display.

**HOME**: Displays the [Home] menu.

**DISC MENU** : Accesses the menu on a DVD disc.

• • • • • • • • • • • **2** • • • • • • • • • • •

∧/∨/</> (up/ down/ left/ right): Used to navigate on-screen displays.

**PRESET** (+/-) : Selects programme of Radio.

**TUNING -/+** : Tunes in the desired radio station.

**ENTER** : Acknowledges menu selection. Presetting the radio stations.

**RETURN** : Moves backwards in the menu or exits the setup menu.

**TITLE** : If the current DVD title has a menu, the title menu appears on the screen. Otherwise, the disc menu may not appear.

• • • • • • • • • • • **3** • • • • • • • • • • •

**SKIP** : Goes to next or previous chapter/ track/ file.

**SCAN** : Searchs backward or forward.

**STOP** : Stops playback or recording.

**PLAY**, **MONO/STEREO** : Starts playback. Selects Mono/ Stereo.

**PAUSE/STEP** : Pauses playback.

**Put the batteries into the remote control.**

Make sure for the + (plus) and – (minus) on the batterise to be matched on the remote control.

## Remote control




• • • • • • • • • • 4 • • • • • • • • • •

**SPEAKER LEVEL**: Sets the sound level of desired speaker.

**SOUND EFFECT**: Selects a sound effect mode.

**VOL -/+ (Volume) :** Adjusts speaker volume.

**OPTICAL**: Changes input source to optical directly.

**MUTE :** Mutes the sound.

• • • • • • • • • • 5 • • • • • • • • • •

**0-9 numerical buttons :** Selects numbered options in a menu.

**CLEAR :** Removes a number when setting the password.

**REPEAT :** Selects a play mode. (Repeat/ Random)

• • • • • • • • • • 6 • • • • • • • • • •

**TV Control buttons :** Controls the TV. (LG TV only)

● **REC** : USB Direct Recording.

★ : This button is not available.

**RDS** : Radio Data System.

**PTY** : Views the various displays of the RDS.

**Controlling the TV.**

You can control the sound level, input source, and power switching of LG TVs as well. Hold POWER (TV) and press PR/CH (∧/∨) button repeatedly until the TV turns on or off.

# Front panel






**1** ⏻/I (POWER)
Switches the unit ON or OFF.

**2** Disc Tray

**3** Display window
Shows the current status of the unit.

**4** **VOLUME**
Adjusts speaker volume.

**5** **F** (FUNCTION)
Changes the input source or function.

**6** I◄◄ / ►►I (SKIP)
Go to next or previous file/track/chapter.
Searches backward or forward (Press and hold)
Tunes in the desired radio station.

**7** ■ (STOP)
Stops playback.

**8** ►/II (PLAY / PAUSE)
Starts playback.
Pause playback temporarily, press again to exit pause mode.

**9** ⏏ (OPEN/CLOSE)
Opens or closes the disc tray.

**10** USB Port
Connect a USB device.

**11** PORT. IN
Connect to a portable player with audio outputs.

# Rear panel






**1** Power cord

**2** Speakers connectors
Connect the speaker cables.

**3** Cooling Fan

**4** Antenna Connector
FM- Connects the FM wired antenna

**5** SCART connetcor

**6** VIDEO OUT
Connects to a TV with video inputs.

**7** HDMI OUT (type A)
Connects to TV with HDMI inputs.
(Interface for digital audio and video)

**8** OPTICAL IN
Connects to optical audio equipment.

**9** COMPONENT VIDEO (Y PB PR)OUTPUT
(PROGRESSIVE SCAN)
Connects to a TV with Y PB PR inputs.

**10** AUX (L/R) INPUT
Connects to an external source with 2 channel audio outputs.

# 3 Installation

## Attaching the speakers to the unit

**1.** Connect the wires to the unit.
Match each wire's colored band to the same colored connection terminal on the rear of the unit. To connect the cable to the unit, press each plastic finger pad to open the connection terminal. Insert the wire and release the finger pad.



Connect the black end of each wire to the terminals marked -(minus) and the other end to the terminals marked + (plus).

**2.** Connect the wires to the speakers.
Connect the other end of each wire to the correct speaker according to the color coding:

| Color | Speaker | Position |
|---|---|---|
| Orange | Sub woofer | Any front position |
| Red | Front | Front right |
| White | Front | Front left |

To connect the cable to the speakers, press each plastic finger pad to open the connection terminals on the base of each speaker. Insert the wire and release the finger pad.

**CAUTION**

Be careful to make sure children not to put their hands or any objects into the *speaker duct.
*Speaker duct: A hall for plentiful bass sound on speaker cabinet (enclosure).

# Connections to Your TV

Make one of the following connections, depending on the capabilities of your existing equipment.

**NOTE**

- Depending on your TV and other equipment you wish to connect, there are various ways you could connect the unit. Use only one of the connections described in this manual.
- Please refer to the manuals of your TV, Stereo System or other devices as necessary to make the best connections.
- Make sure the unit is connected directly to the TV. Tune the TV to the correct video input channel.
- Do not connect your unit via your VCR. The image could be distorted by the copy protection system.

## Component Video Connection

Connect the COMPONENT VIDEO OUTPUT (PROGRESSIVE SCAN) jacks on the unit to the corresponding input jacks on the TV using component cables.

You can hear the sound through the system's speakers.

Component Connection



## HDMI Out Connection

If you have a HDMI TV or monitor, you can connect it to this unit using a HDMI cable. Connect the HDMI OUT jack on the unit to the HDMI IN jack on a HDMI compatible TV or monitor.
Set the TV's source to HDMI (refer to TV's Owner's manual).

HDMI Connection




### TIP

- You can fully enjoy digital audio and video signals together with this HDMI connection.
- When you use HDMI connection, you can change the resolution for the HDMI output. (Refer to "Resolution Setting" on page 19.)

### NOTE

- If a connected HDMI device does not accept the audio output of the unit, the HDMI device 's audio sound may be distorted or may not output.
- When you connect a HDMI or DVI compatible device make sure of the following:
  - Try switching off the HDMI/DVI device and this unit. Next, switch on the HDMI/DVI device and leave it for around 30 seconds, then switch on this unit.
  - The connected device's video input is set correctly for this unit.
  - The connected device is compatible with 720x480i (or 576i), 720x480p (or 576p), 1280x720p,1920x1080i or 1920x1080p video input.
- Not all HDCP-compatible HDMI or DVI devices will work with this unit.
  - The picture will not be displayed properly with non-HDCP device.
  - This unit does not playback and TV screen is changed to black or green screen or the snow noise may occur on the screen.
- If there is noise or lines on the screen, please check the HDMI cable and usea higher version cable than 1.2A HDMI cable.

### CAUTION

- Changing the resolution when the connection has already been established may result in malfunctions. To solve the problem, turn off the unit and then turn it on again.
- When the HDMI connection with HDCP is not verified, TV screen is changed to black or green screen or the snow noise may occur on the screen. In this case, check the the HDMI connection, or disconnect the HDMI cable.

## Video Connection

Connect the VIDEO OUT jack on the unit to the video in jack on the TV using a video cable.

You can hear the sound through the system's speakers.

Video Connection




## SCART Connection

Connect the SCART jack on the unit to the SCART in jack on the TV using a SCART cable.

You can hear the sound through the system's speakers.

SCART Connection



## Resolution Setting

The unit provides several output resolutions for HDMI OUT and COMPONENT VIDEO OUT jacks. You can change the resolution using [Setup] menu.

1. Press **HOME**.
2. Use </> to select the [Setup] and press **ENTER**. The [Setup] menu appears.




3. Use ∧/∨ to select [Display] option then press > to move to the second level.
4. Use ∧/∨ to select the [Resolution] option then press > to move to the third level.
5. Use ∧/∨ to select the desired resolution then press **ENTER** to confirm your selection.

**NOTE**

If your TV does not accept the resolution you have set on the player, you can set resolution to 480p (or 576p) as follows:

Press ■ **(STOP)** for more than 5 seconds.

# Video Output Resolution

Displayed resolution in display window and outputted resolution may different according to connection type.

[HDMI OUT]: 1080p, 1080i, 720p and 480p (or 576p) and 480i (or 576i)

[COMPONENT VIDEO OUT]: 480p (or 576p) and 480i (or 576i)

[VIDEO OUT]: 480i (or 576i)

[SCART] : 480i (or 576i)

# Optional Equipment Connection

## AUX IN Connection

Connect an Output of auxiliary device to the AUX (L/R) INPUT Connector.

AUX IN Connection




**NOTE**

If your TV has only one output for audio (mono), connect it to the left (white) audio jack on the unit.

## AUDIO (PORT. IN) In Connection

Connect an output of portable device (MP3 or PMP etc) to the AUDIO (PORT. IN) input connector.

PORT.IN Connection




## Listening to music from your portable player or external device

The unit can be used to play the music from many types of portable player or external devices.

1. Connect the portable player to the PORT.IN(PORTABLE IN) connector of the unit.

   Or

   Connect the external device to the AUX connector of the unit.
2. Turn the power on by pressing ⏻ **(POWER)**.
3. Select the PORTABLE or AUX (L/R) INPUT function by pressing ⇥ **RADIO&INPUT**.
4. Turn on the portable player or external device and start it playing.

## USB Connection

Connect the USB port of USB Memory (or MP3 player, etc.) to the USB port on the front of the unit.

USB Connection



Removing the USB Device from the unit

1. Choose a different function mode or press **STOP** (■) twice in a row.
2. Remove the USB device from the unit.

### Compatible USB Devices

- MP3 Player : Flash type MP3 player.
- USB Flash Drive : Devices that support USB2.0 or USB1.1.
- The USB function of this unit does not support some USB devices.

### USB device requirement

- Devices which require additional program installation connected to a computer, are not supported.
- Do not extract the USB device while in operation.
- For a large capacity USB, it may take longer than a few minute to be searched.
- To prevent data loss, back up all data.
- If you use a USB extension cable or USB hub, the USB device is not recognized.
- Using NTFS file system is not supported. (Only FAT(16/32) file system is supported.)
- This unit is not supported when the total number of files is 1 000 or more.
- External HDD, Card readers, Locked devices, or hard type usb devices are not supported.
- USB port of the unit cannot be connected to PC. The unit can not be used as a storage device.

## OPTICAL IN connection

Connect an optical output of Unit (or Digital Device etc) to the OPTICAL IN connector.

OPTICAL IN Connection




## Home theater speaker ez setup

Listen to sound from TV, DVD and Digital Device with 2.1 or 2 ch mode. Even in power off mode, if you press **OPTICAL**, then power is on and automatically changed to AUX OPT mode.

1. Connect the unit's OPTICAL IN jack to jack on optical out of your TV (or Digital Device etc.).
2. Select the AUX OPT by using the **OPTICAL**. To select the AUX OPT directly
3. Listen sound with 2.1 or 2 ch speaker.
4. To escape from AUX OPT by using the **OPTICAL**.
   Function is retuned to previous one.

# Antenna Connection

Connect the supplied FM antenna for listening to the radio.

Connect the FM Wire antenna to the FM antenna connector.

Antenna Connection




**NOTE**

Be sure to fully extend the FM wire antenna.
After connecting the FM wire antenna, keep it as horizontal as possible.

# Adjust the setup settings

By using the Setup menu, you can make various adjustments to items such as picture and sound.
You can also set a language for the subtitles and the Setup menu, among other things. For details on each Setup menu item, see pages 23 to 27.

## OSD Initial language settings

During the first use of this unit, the initial language setup menu appears on your TV screen. You must complete initial language selection before using the unit. English will be selected as the initial language.

1. Press ⏻ **(POWER)** to turn the unit on. The language setup menu will appear on the screen.




2. Use ∧ ∨ < > to select a language then press ⊙ **ENTER**.
The confirm menu will appear.




3. Use < > to select the [Enter] then press ⊙ **ENTER** to finish the language setup.

## To display and exit the Setup menu

1. Press **HOME**.
Displays the [Home] Menu.




2. Select an [Setup] by using < >.
3. Press ⊙ **ENTER**.
Displays the [Setup]
4. Press **HOME** or **RETURN** to exit in the [Setup] Menu.

**About help menu for Setup**

| Menu | Buttons | Operation |
|---|---|---|
| ▲▼ **Move** | ∧ ∨ | Moving to another menu. |
| ◀ **Move** | < | Moving to previous level. |
| ▶ **Move** | > | Moving to next level or selecting menu. |
| **Close** | **RETURN** | To exit the [Setup] menu or [ 2.1 Speaker setup]. |
| ⊙ **Select** | ⊙ **ENTER** | To confirm menu. |

## Language

### Menu Language

Select a language for the Setup menu and then on screen display.

### Disc Audio / Disc Subtitle / Disc Menu

Select the language you prefer for the audio track (disc audio), subtitles, and the disc menu.

**[Original]**
Refers to the original language in which the disc was recorded.

**[Other]**
To select another language, press numeric buttons and then ⊙ **ENTER** to enter the corresponding 4-digit number according to the language code list on the page 40. If you enter the wrong language code, press **CLEAR**.

**[Off (for Disc Subtitle)]**
Turn off Subtitle.

## Display

### TV Aspect

Select which screen aspect to use based on the shape of your TV screen.

**[4:3]**
Select when a standard 4:3 TV is connected.

**[16:9]**
Select when a 16:9 wide TV is connected.

### Display Mode

The Display Mode setting works only when the TV Aspect mode is set to 4:3.

**[Letterbox]**
Displays a wide picture with bands on the upper and lower portions of the screen.

**[Panscan]**
Automatically displays the wide picture on the entire screen and cuts off the portions that do not fit. (If the disc/file is not compatible with Pan Scan, the picture is displayed at Letterbox ratio.)

### TV Output Select

Select an option according to the TV connection type.

**[RGB]**
When your TV is connected with the SCART jack.

**[YPbPr]**
When your TV is connected with the COMPONENT/ PROGRESSIVE SCAN jacks on the unit.

### Resolution

Sets the output resolution of the Component and HDMI video signal. Refer to "Resolution Setting" for details about the resolution (page 19).

**[Auto]**
If the HDMI OUT jack is connected to TVs providing display information (EDID), automatically selects the resolution best suited to the connected TV. If the COMPONENT VIDEO OUT is only connected, this changes the resolution to 480i (or 576i) as default resolution.

**[1080p]**
Outputs 1080 lines of progressive video.

**[1080i]**
Outputs 1080 lines of interlaced video.

**[720p]**
Outputs 720 lines of progressive video.

**[480p (or 576p)]**
Outputs 480 (or 576) lines of progressive video.

**[480i (or 576i)]**
Outputs 480 (or (576) lines of interlaced video.

## Audio

### 2.1 Speaker setup

Make the following settings for the built-in 2.1 channel surround decoder.

1. Select [2.1 Speaker setup] on the [Audio] menu.
2. Press ⊙ **ENTER**.
   The [2.1 Speaker setup] appears.




3. Use < > to select the desired speaker.
4. Adjust options using ∧ ∨ < > buttons.
5. Returns to the previous menu by pressing ↶ **RETURN**.

**[Speaker selection]**
Select a speaker that you want to adjust.

**NOTE**

Certain speaker settings are prohibited by the Dolby Digital licensing agreement.

**[Size]**
Since the speaker settings are fixed, you cannot change the settings.

**[Volume]**
Press < > to adjust the output level of the selected speaker.

Front L/R : 0 ~ -5
SubWoofer : 5 ~ -5

**[Distance]**
If you connect speakers to your unit, setting the Distance lets the speakers to know how far the sound has to travel to reach your set listening point. This allows the sound from each speaker to reach the listener at the same time. Press < > to adjust the Distance of the selected speaker.

**[Test]**
Select [Speaker Test Start] by using the ∧ ∨ and press ⊙ **ENTER**. Press ⊙ **ENTER** again to stop. Adjust the volume to match the volume of test signals memorized in the system.

### DRC (Dynamic Range Control)

Make the sound clear when the volume is turned down (Dolby Digital only). Set to [On] for this effect.

### Vocal

Select [On] to mix karaoke channels into normal stereo.

This function is effective for multi-channel karaoke DVDs only.

### HD AV Sync

Sometimes Digital TV encounters a delay between picture and sound. If this happens you can compensate by setting a delay on the sound so that it effectively 'waits' for the picture to arrive: this is called HD AV Sync. Use ∧ ∨ (on the remote control) to scroll up and down through the delay amount, which you can set at anything between 0 and 300m sec.



## Lock (Parental Control)

### Initial Setting the Area Code:

When you use this unit for the first time, you have to set the Area Code.

1. Select the [Lock] menu and then press >.
2. Press >.
   To access the [Lock] options, you must input the password you have created. Input a password and press ⊙ **ENTER**. Enter it again and press ⊙ **ENTER** to verify. If you make a mistake before pressing ⊙ **ENTER**, press **CLEAR**.
3. Select the first character using ∧ ∨ buttons.
4. Press ⊙ **ENTER** and select the second character using ∧ ∨ buttons.
5. Press ⊙ **ENTER** to confirm your Area code selection.

### Rating

Blocks playback of rated DVDs based on their contents. Not all discs are rated.

1. Select [Rating] on the [Lock] menu then press >.
2. Input a password and press ⊙ **ENTER**.
3. Select a rating from 1 to 8 using the ∧ ∨ buttons.

**[Rating 1-8]**
Rating one (1) has the most restrictions and rating eight (8) is the least restrictive.

**[Unlock]**
If you select unlock, parental control is not active and the disc plays in full.

4. Press ⊙ **ENTER** to confirm your rating selection.

### Password

You can enter or change password.

1. Select [Password] on the [Lock] menu and then press >.
2. Press ⊙ **ENTER**.
3. Input a password and press ⊙ **ENTER**.

   To change the password, press ⊙ **ENTER** when the [Change] option is highlighted. Input a password and press ⊙ **ENTER**. Enter it again and press ⊙ **ENTER** to verify.
4. Press ⌂ **HOME** to exit the menu.

**NOTE**

If you forget your password, you can clear it using the following steps:

1. Select the [Setup] menu on the [Home] menu.
2. Input the 6-digit number "210499" and press ⊙ **ENTER**. The password is cleared.

### Area Code

Enter the code of the area whose standards were used to rate the DVD video disc, based on the list on page 41.

1. Select [Area Code] on the [Lock] menu then press >.
2. Input a password and press ⊙ **ENTER**.
3. Select the first character using ∧ ∨ buttons.
4. Press ⊙ **ENTER** and select the second character using ∧ ∨ buttons.
5. Press ⊙ **ENTER** to confirm your Area code selection.

## Others

### DivX VOD

We provide you with the DivX® VOD (Video On Demand) registration code that allows you to rent and purchase videos using the DivX® VOD service.

For more information, visit www.divx.com/vod.

Press ⊙ **ENTER** when [DivX(R) VOD] is highlighted and you can view the registration code of the unit.

**NOTE**

All the downloaded videos from DivX VOD can only be played back on this unit.

# 4 Operation

## Using the Home Menu

1. Press **HOME**.
   Displays the [Home] menu.




2. Select an option by using < >.
3. Press **ENTER** then selected option menu.

[Music] – Displays [MUSIC] menu.

[Movie] – Start video media's playback or displays the [MOVIE] menu.

[Photo] – Displays [PHOTO] menu.

[Setup] – Displays the [Setup] menu.

**NOTE**

You can not select the [Music], [Movie] or [Photo] option when the USB device is not connected or a disc is not inserted.

## Basic Operations

1. Insert the disc by using the **OPEN/CLOSE** or Connect the USB device to the USB port.
2. Press **HOME**.
   Displays the [Home] Menu.
3. Select an option by using < >.
   If you select the [Movie], [Photo] or [Music] option when you connect up to two devices, it appears as belows. Select a media then press **ENTER**.




4. Press **ENTER** then selected option menu.

**NOTE**

- For the most Audio CD and DVD-ROM discs, playback starts automatically.
- The unit plays only music file contained in the USB storage device or disc automatically.

| To | Do this |
|---|---|
| Stop | Press ■ **(STOP)** |
| Playback | Press ▶ **(PLAY)**, **MONO/ STEREO**. |
| Pause | Press ❚❚ **(PAUSE/STEP)**. |
| Frame-by-Frame playback | Press ❚❚ **(PAUSE/STEP)** repeatedly to play title Frame-by-Frame. (DVD, DivX only) |
| Skipping to the next/ previous chapter/ track/ file | During playback, press ⏮/⏭ **SKIP** to go to the next chapter/ track/ file or to return to the beginning of the current chapter/ track/ file. Press ⏮ **SKIP** twice briefly to step back to the previous chapter/ track/ file. |
| Locating a point quickly by playing a file in fast forward or fast reverse | During playback, press ◀◀/▶▶ **SCAN** repeatedly to select the required scan speed. To return to normal speed, press ▶ **(PLAY)**, **MONO/ STEREO**. |
| Playing repeatedly or randomly | Press ↻ **REPEAT** repeatedly, and the current title, chapter or track will be played back repeatedly or randomly. - DVD : Chapter/ Title/ Off - DivX : Title/ All/ Off - Audio CD/ MP3/ WMA : Track/ All/ Random/ Off |
| Slowing down the playing speed | In the pause mode, press SLOW (◀◀ or ▶▶) to select the required speed. (DVD, DivX only) The DivX file cannot be slow down reverse playback. |

# Other Operations

## Displaying Disc Information on-screen

You can display various information about the disc loaded on-screen.

1. Press **INFO/DISPLAY** to show various playback information.
   The displayed items differ depending on the disc type or playing status.
2. You can select an item by pressing ^ v and change or select the setting by pressing < >.

Title – Current title number/ total number of titles.

Chapter – Current chapter number/ total number of chapters.

Time – Elapsed playing time.

Audio – Selected audio language or channel.

Subtitle – Selected subtitle.

Angle – Selected angle/ total number of angles.

**NOTE**

If any button is not pressed for a few seconds, the on-screen display disappears.

## To display the DVD Menu DVD

When you play a DVD which contains several menu, you can select the menu you want using the Menu.

1. Press **DISC MENU**.
   The disc's menu appears.
2. Select the menu by using ∧ ∨ < >.
3. Press ▶ **(PLAY)**, **MONO/STEREO** to confirm.

## To display the DVD title DVD

When you play a DVD which contains several title, you can select the title you want using the Menu.

1. Press **TITLE**.
   The disc's title appears.
2. Select the menu by pressing ∧ ∨ < >.
3. Press ▶ **(PLAY)**, **MONO/STEREO** to confirm.

## 1.5 times speed playback DVD

The 1.5 speed allows you to watch the pictures and listen to the sound quicker than playing at a normal speed.

1. During playback, press ▶ **(PLAY)**, **MONO/STEREO** to play at 1.5 times speed. "▶X1.5" appears on the screen.
2. Press ▶ **(PLAY)**, **MONO/STEREO** again to exit.

## Screen Saver

The screen saver appears when you leave the unit in Stop mode for about five minutes.

## Starting play from selected time DVD DivX

To start playing at any chosen time on the file or title.

1. Press **INFO/DISPLAY** during playback.
2. Press ∧ ∨ to select the time clock icon and "--:--:--" appears.
3. Input the required start time in hours, minutes, and seconds from left to right. If you enter the wrong numbers, press **CLEAR** to remove the numbers you entered. Then input the correct numbers.
   For example, to find a scene at 1 hour, 10 minutes, and 20 seconds, enter "11020" by using numerical buttons.
4. Press ⊙ **ENTER** to confirm. Playback starts from the selected time.

## Resume playback

DVD DivX ACD MP3 WMA

The unit records the point where you pressed the ■ (STOP) depending on the disc.
If "▮▮■ (Resume Stop)" appears on the screen briefly, press ▶ **(PLAY)**, **MONO/STEREO** to resume playback (from the scene point).

If you press ■ (STOP) twice or unload the disc, "■"(Complete Stop) appears on the screen. The unit will clear the stopped point.

**NOTE**

The resume point may be cleared when a button is pressed (for example; ⏻ **(POWER)**, ⏏ **OPEN/CLOSE**, etc).

## Marked Playback ACD MP3 WMA

The mark function enables you to store your favourite files from any disc or USB device in the unit memory.

1. Select [Music] on the [Home] menu.

Music menu

Returning to the upper folder. (MP3/ WMA only)

File information will be displayed according to the ID3TAG information on the appropriate music file. (MP3 only)




Selecting all tracks/ files.
Deselecting all tracks/files.

Moving to the previous or next file list.

2. Select a desired music on the [List] by using the ∧ ∨ then press **MARKER** to appears the mark on the list.
3. Press ⊙ **ENTER** or ▶ **(PLAY)**, **MONO/ STEREO**.
   Displays the play mode.
4. Select the play mode by using the ∧ ∨ and press ⊙ **ENTER**.

**[Mark Play]**
Marked playback.

**[Current Play]**
Normal playback

**NOTE**

If you want to select all files on the list, select [Select All] and press ⊙ **ENTER**.

### To delete a Marker

1. Use ∧ ∨ to select the track that you wish to erase from the marked file.
2. Press **MARKER**.

### To delete all Markers

Use ∧ ∨ < > to select [Deselect All] then press ⊙ **ENTER** in program edit mode.

**NOTE**

The markers are also cleared when the disc or USB device is removed, the unit is switched to power off or the function is switched to others.

## Changing subtitle code page DivX

If the subtitle is not displayed properly, you can change the subtitle code page to view the subtitle file properly.

1. During playback, press **INFO/DISPLAY** to display the On-Screen display.
2. Use ∧ ∨ to select the [Code Page] option.
3. Use < > to select desired code option.
4. Press ↶ **RETURN** to exit the On-Screen display.

## Viewing a PHOTO file JPG

This unit can play discs with photo files.

1. Select [Photo] on the [Home] menu and press ⊙ **ENTER**.

**Photo menu**




2. Press ∧ ∨ to select a folder, and then press ⊙ **ENTER**.
3. If you want to view a slide show, press ∧ ∨ to highlight a file and press ▶ **(PLAY)**, **MONO/STEREO**.

**About help menu in the [Photo] menu.**

| Menu | Buttons | Operation |
|---|---|---|
| ▶Slide Show | ▶ (PLAY), MONO/ STEREO | Viewing a slide show. |
| ▲▼◀▶ Move | ∧ ∨ < > | Moving to another file or content. |
| ⊙ Select | ⊙ ENTER | Viewing a particular file. |
| ↩ Close | ↩ RETURN | Returning to the [Home] menu. |

**About help menu in the full screen.**

| Menu | Buttons | Operation |
|---|---|---|
| Menu | INFO/ DISPLAY | Displaying the Option menu. |
| ◀/▶ Prev./ Next | </> | Moving to another file |
| ↩ Close | ↩ RETURN | Returning to the [Photo] menu. |

## Options while viewing a photo

You can use various options during viewing a photo in full screen.

1. While viewing a photo in full screen, press **INFO/DISPLAY** to display the option menu.
2. Select an option using ∧ ∨ < >.




**1** **Current photo/ Total number of photos** – Use < > to view previous/next photo.

**2** **Slide Show ▶/ ❚❚** – Press ⊙ **ENTER** to start or pause slide show.

**3** **Speed x3/ x2/ x1** – Use ⊙ **ENTER** to select a delaying speed between photos in a slide show.

**4** **Rotate** – Press ⊙ **ENTER** to rotate the photo.

**5** **Go to list** – Press ⊙ **ENTER** to return [Photo] menu.

## Sleep Timer Setting

Press **SLEEP** one or more times to select delay time between 10 and 180 minutes, after the unit will turn off.

To check the remaining time, press **SLEEP**.

To cancel the sleep function, press **SLEEP** repeatedly until "SLEEP 10" appears, and then press **SLEEP** once again while "SLEEP 10" is displayed.

**NOTE**

You can check the remaining time before the Unit turns off.
Press **SLEEP** The remaining time appears in the display window.

## Dimmer

Press **SLEEP** once. The display window will be darken by half. To cancel it, press **SLEEP** repeatedly until dim off.

## Turn off the sound temporarily

Press **MUTE** to mute your unit.

You can mute your unit in order, for example, to answer the telephone, appears the MUTE in the display window.

## Last Scene Memory DVD

This unit memorizes last scene from the last disc that is viewed. The last scene remains in memory even if you remove the disc from the unit or switch off the unit. If you load a disc that has the scene memorized, the scene is automatically recalled.

## System Select - Optional

You must select the appropriate system mode for your TV system. Press and hold **II (PAUSE/ STEP)** for more than five seconds to be able to select a system in the [Home] menu. (PAL/ NTSC)

**NOTE**

If the USB device is connected or a disc is inserted, this function is not operated.

## Adjust the speaker level settings

You can adjust the sound level of each speaker.

1. Press **SPEAKER LEVEL** repeatedly to select a desired speaker to set.
2. Press **VOL -/+** to adjust the sound level of the selected speaker while the level setting memu is displayed on the display window.
3. Repeat and adjust the sound level of the other speakers.

# Radio Operations

Be sure that both FM aerials are connected. (Refer to the page 22)

## Listening to the radio

1. Press ⊜ **RADIO&INPUT** until FM appears in the display window.
   The last received station is tuned in.
2. Press and hold **TUNING** (-/+) for about two seconds until the frequency indication starts to change, then release. Scanning stops when the unit tunes in a station.

   or

   Press **TUNING** (-/+) repeatedly.
3. Adjust the volume by rotating **VOLUME** on the front panel or by pressing **VOL** (+/- )on the remote control repeatedly.

## Presetting the Radio Stations

You can preset 50 stations for FM.

Before tuning, make sure that you have turned down the volume.

1. Press ⊜ **RADIO&INPUT** until FM appears in the display window.
2. Select the desired frequency by using **TUNING** (-/+)
3. Press ⊙ **ENTER** a preset number will flash in the display window.
4. Press **PRESET** (-/+) to select the preset number you want.
5. Press ⊙ **ENTER**.
   The station is stored.
6. Repeat the steps 2 to 5 to store other stations.

## Deleting all the saved stations

1. Press and hold **CLEAR** for two seconds. "ERASE ALL" will flash up on the unit display.
2. Press **CLEAR** to erase all saved of the radio stations.

## Deleting a saved station

1. Press **PRESET - / +** to Select a preset number you want to delete.
2. Press **CLEAR**, the preset number will blink in the display window.
3. Press **CLEAR** again, to delete the selectd preset number.

## Improving poor FM reception

Press ▶ **(PLAY)**, **MONO/STEREO** on the remote control. This will change the tuner from stereo to mono and usually improve the reception.

## Seeing information about a radio station

The FM tuner is supplied with the RDS (Radio Data System) facility. This shows information about the radio station being listened to. Press **RDS** repeatedly to cycle through the various data types. :

**PS** (Programme Service Name)
The name of the channel will appear in the display

**PTY** (Programme Type Recognition)
The programme type (e.g. Jazz or News) will appear in the display.

**RT** (Radio Text)
A text message contains special information from the broadcast station. This text may scroll across the display.

**CT** (Time controlled by the channel)
This shows the time and date as broadcast by the station.

You can search the radio stations by programme type by pressing **RDS**. The display will show the last PTY in use. Press **PTY** one or more times to select your preferred programme type. Press **< >**. The tuner will search automatically, when a station is found the search will stop.

# Sound adjustment

## Setting the surround mode

This system has a number of pre-set surround sound fields. You can select a desired sound mode by using **SOUND EFFECT**.

You can change the **SOUND EFFECT** using < > arrow key while the sound effect information is displayed on.

The displayed items for the equalizer maybe different depending on sound sources and effects.

| On Display | Description |
|---|---|
| NAT PLUS | You can enjoy the natural sound effect same as a 5.1-channel. |
| NATURAL | You can enjoy comfortable and natural sound |
| Local specialization equalizer | Regionally optimized sound effect. (DANGDUT/ ARABIC/ PERSIAN/ INDIA/ REGUETON/ MERENGUE/ SAMBA/ SALSA/ CUMBIA/ AFRO) |
| AUTO EQ | Realizes the sound equalizer that is the most similar to the genre of which is included in the MP3 ID3 tag of song files. |
| POP<br>CLASSIC<br>JAZZ<br>ROCK | This program lends an enthusiastic atmosphere to the sound, giving you the feeling you are at an actual rock pop, jazz or classic concert. |
| MP3 OPT | This function is optimized for compressible MP3, WMA file. It improves the treble sound. |
| BASS | During playback, reinforce the treble, bass and surround sound effect. |
| LOUDNESS | Improves the bass and treble sound. |
| VIRTUAL | You can enjoy more virtual surround sound. |
| BYPASS | You can enjoy the sound without equalizer effect. |

**NOTE**

- In some of surround modes, some speakers, there's no sound or low sound. It depends on the mode of surround and the source of audio, it is not defective.
- You may need to reset the surround mode, after switching the input, sometimes even after the sound track changed.

# Advanced Operations

## Recording to USB

You can record music or sound souce to USB device by connecting in to the port on the unit.

1. Connect the USB device to the unit.
2. Select a mode in which you want to record. Play back a sound source first.
3. Start the recording by pressing ● **REC**.
4. To stop recording, press ■ **(STOP)**.

**[All tracks/ files recording]**
Record to USB in stop or play mode.

**[Program list recording]**
After marking desired file(s) and you can record it to USB (Refer to the page 31).

**It'll be stored as follows**

| | |
|---|---|
| **Audio CD** | CD_REC<br>TRK_001<br>TRK_002 |
| **MP3/ WMA** | FILE_REC<br>001_ABC(File name)<br>002_DEF(File name) |
| **The other sources (Tuner, AUX, Portable)** | EXT_REC<br>AUDIO_001<br>AUDIO_002 |

### NOTE

- You can check the recording percentage rate for the USB record on the screen during the recording. (Audio CD or MP3/ WMA CD only)
- During recording MP3/WMA, there is no sound.
- When you stop recording during playback, the file that has been recorded at that time will be stored. (Audio CD only)
- Do not remove the USB device or turn off the unit during USB recording. If not, an incomplete file may be made and not deleted on PC.
- If USB recording does not work, the message like "NO USB", "ERROR", "USB FULL" or "NO REC" is displayed on the display window.
- Multi card reader divice or external HDD can not be used for USB recording.
- A file is recorded by 128 Mbyte (about 2 hours) when you record for a long term. There are recorded less than 4 files.
- When you stop recording during playback, the file will not be stored.
- In the state CD-G, DTS disc USB record is not operated.
- The files in the sub-folders are not recorded during all track recording.
- You may not record more than 999 files.
- The nunbering of the recording file is entered from the lowest number. So if you delete some of the recording files, the next recording file could be the lowest number among them.

The making of unauthorized copies of copy-protected material, including computer programs, files, broadcasts and sound recordings, may be an infringement of copyrights and constitute a criminal offense. This equipment should not be used for such purposes.
**Be responsible**
**Respect copyrights.**

# 5 Maintenance

## Notes on Discs

### Handling Discs



Never stick paper or tape on the disc.

### Storing Discs

After playing, store the disc in its case. Do not expose the disc to direct sunlight or sources of heat and never leave it in a parked car exposed to direct sunlight.

### Cleaning Discs



Do not use strong solvents such as alcohol, benzine, thinner, commercially available cleaners, or anti-static spray intended for older vinyl records.

## Handling the Unit

### When shipping the unit

Please save the original shipping carton and packing materials. If you need to ship the unit, for maximum protection, re-pack the unit as it was originally packed at the factory.

Keeping the exterior surfaces clean

- Do not use volatile liquids such as insecticide spray near the unit.
- Wiping with strong pressure may damage the surface.
- Do not leave rubber or plastic products in contact with the unit for a long period of time.

### Cleaning the unit

To clean the player, use a soft, dry cloth. If the surfaces are extremely dirty, use a soft cloth lightly moistened with a mild detergent solution. Do not use strong solvents such as alcohol, benzine, or thinner, as these might damage the surface of the unit.

### Maintaining the Unit

The unit is a high-tech, precision device. If the optical pick-up lens and disc drive parts are dirty or worn, the picture quality could be diminished. For details, please contact your nearest authorized service center.

# 6 Troubleshooting

| PROBLEM | CAUSE | CORRECTION |
|---|---|---|
| No power | The power cord is disconnected. | Plug the power cord into the wall outlet securely. |
| No picture | The TV is not set to receive the DVD signal. | Select the appropriate video input mode on the TV so the picture from the unit appears on the TV screen. |
| | The video cables are not connected securely. | Connect the video cables securely to both the TV and unit. |
| There is little or no sound | Equipment connected via the audio cable is not set to receive DVD signal output. | Select the correct input mode of the unit so you can hear the sound from the unit. |
| | The audio cables are not connected to the speakers or unit securely. | Connect the audio cables into the connection terminals correctly. |
| | The audio cables are damaged. | Replace with a new audio cable. |
| The DVD picture quality is poor | The disc is dirty. | Clean the disc using a soft cloth with outward strokes. |
| A DVD/CD will not play | No disc is inserted. | Insert a disc. |
| | An unplayable disc is inserted. | Insert a playable disc (check the disc type, colour system and regional code). |
| | The disc is inserted upside down. | Place the disc with the label or printed side facing upwards. |
| | There is a parental lock which prevents the playback of DVDs with a certain rating. | Enter your password or change the rating level. |
| Humming noise heard while a DVD or CD is playing | The disc is dirty. | Clean the disc using a soft cloth with outward strokes. |
| | The unit is located too close to the TV, causing feedback. | Move unit and audio components further away from your TV. |
| Radio stations can't be tuned in properly | The antenna is positioned or connected poorly. | Check the antenna connection and adjust its position. |
| | | Attach an external aerial if necessary. |
| | The signal strength of the radio station is too weak. | Tune to the station manually. |
| | No stations have been preset or preset stations have been cleared (when tuning by scanning preset channels). | Preset some radio stations, see page 34 for details. |
| The remote control doesn't work well / at all | The remote is not pointed directly at the unit. | Point the remote directly at the unit. |
| | The remote is too far from the unit. | Use the remote within 23 feet (7m) of the unit. |
| | There is an obstacle in the path between the remote control and the unit. | Remove the obstacle. |
| | The battery in the remote control are flat. | Replace the batteries with new ones. |

# 7 Appendix

## Language Codes

Use this list to input your desired language for the following initial settings: Disc Audio, Disc Subtitle, Disc Menu.

| Language | Code | Language | Code | Language | Code | Language | Code |
|---|---|---|---|---|---|---|---|
| Afar | 6565 | French | 7082 | Lithuanian | 7684 | Singhalese | 8373 |
| Afrikaans | 6570 | Frisian | 7089 | Macedonian | 7775 | Slovak | 8375 |
| Albanian | 8381 | Galician | 7176 | Malagasy | 7771 | Slovenian | 8376 |
| Ameharic | 6577 | Georgian | 7565 | Malay | 7783 | Spanish | 6983 |
| Arabic | 6582 | German | 6869 | Malayalam | 7776 | Sudanese | 8385 |
| Armenian | 7289 | Greek | 6976 | Maori | 7773 | Swahili | 8387 |
| Assamese | 6583 | Greenlandic | 7576 | Marathi | 7782 | Swedish | 8386 |
| Aymara | 6588 | Guarani | 7178 | Moldavian | 7779 | Tagalog | 8476 |
| Azerbaijani | 6590 | Gujarati | 7185 | Mongolian | 7778 | Tajik | 8471 |
| Bashkir | 6665 | Hausa | 7265 | Nauru | 7865 | Tamil | 8465 |
| Basque | 6985 | Hebrew | 7387 | Nepali | 7869 | Telugu | 8469 |
| Bengali; Bangla | 6678 | Hindi | 7273 | Norwegian | 7879 | Thai | 8472 |
| Bhutani | 6890 | Hungarian | 7285 | Oriya | 7982 | Tonga | 8479 |
| Bihari | 6672 | Icelandic | 7383 | Panjabi | 8065 | Turkish | 8482 |
| Breton | 6682 | Indonesian | 7378 | Pashto, Pushto | 8083 | Turkmen | 8475 |
| Bulgarian | 6671 | Interlingua | 7365 | Persian | 7065 | Twi | 8487 |
| Burmese | 7789 | Irish | 7165 | Polish | 8076 | Ukrainian | 8575 |
| Byelorussian | 6669 | Italian | 7384 | Portuguese | 8084 | Urdu | 8582 |
| Chinese | 9072 | Javanese | 7487 | Quechua | 8185 | Uzbek | 8590 |
| Croatian | 7282 | Kannada | 7578 | Rhaeto-Romance | 8277 | Vietnamese | 8673 |
| Czech | 6783 | Kashmiri | 7583 | Rumanian | 8279 | Volapük | 8679 |
| Danish | 6865 | Kazakh | 7575 | Russian | 8285 | Welsh | 6789 |
| Dutch | 7876 | Kirghiz | 7589 | Samoan | 8377 | Wolof | 8779 |
| English | 6978 | Korean | 7579 | Sanskrit | 8365 | Xhosa | 8872 |
| Esperanto | 6979 | Kurdish | 7585 | Scots Gaelic | 7168 | Yiddish | 7473 |
| Estonian | 6984 | Laothian | 7679 | Serbian | 8382 | Yoruba | 8979 |
| Faroese | 7079 | Latin | 7665 | Serbo-Croatian | 8372 | Zulu | 9085 |
| Fiji | 7074 | Latvian, Lettish | 7686 | Shona | 8378 | | |
| Finnish | 7073 | Lingala | 7678 | Sindhi | 8368 | | |

# Area Codes

Choose a area code from this list.

| Area | Code | Area | Code | Area | Code |
|---|---|---|---|---|---|
| Afghanistan | AF | Greenland | GL | Paraguay | PY |
| Argentina | AR | Hong Kong | HK | Philippines | PH |
| Australia | AU | Hungary | HU | Poland | PL |
| Austria | AT | India | IN | Portugal | PT |
| Belgium | BE | Indonesia | ID | Romania | RO |
| Bhutan | BT | Israel | IL | Russian Federation | RU |
| Bolivia | BO | Italy | IT | Saudi Arabia | SA |
| Brazil | BR | Jamaica | JM | Senegal | SN |
| Cambodia | KH | Japan | JP | Singapore | SG |
| Canada | CA | Kenya | KE | Slovak Republic | SK |
| Chile | CL | Kuwait | KW | Slovenia | SI |
| China | CN | Libya | LY | South Africa | ZA |
| Colombia | CO | Luxembourg | LU | South Korea | KR |
| Congo | CG | Malaysia | MY | Spain | ES |
| Costa Rica | CR | Maldives | MV | Sri Lanka | LK |
| Croatia | HR | Mexico | MX | Sweden | SE |
| Czech Republic | CZ | Monaco | MC | Switzerland | CH |
| Denmark | DK | Mongolia | MN | Taiwan | TW |
| Ecuador | EC | Morocco | MA | Thailand | TH |
| Egypt | EG | Nepal | NP | Turkey | TR |
| El Salvador | SV | Netherlands | NL | Uganda | UG |
| Ethiopia | ET | Netherlands Antilles | AN | Ukraine | UA |
| Fiji | FJ | New Zealand | NZ | United States | US |
| Finland | FI | Nigeria | NG | Uruguay | UY |
| France | FR | Norway | NO | Uzbekistan | UZ |
| Germany | DE | Oman | OM | Vietnam | VN |
| Great Britain | GB | Pakistan | PK | Zimbabwe | ZW |
| Greece | GR | Panama | PA | | |

# Trademarks and Licenses

Manufactured under license from Dolby Laboratories. Dolby and the double-D symbol are trademarks of Dolby Laboratories.

HDMI, the HDMI logo and High-Definition Multimedia Interface are trademarks or registered trademarks of HDMI licensing LLC.

"DVD Logo" is a trademark of DVD Format/Logo Licensing Corporation.

DivX is a registered trademark of DivX, Inc., and is used under license.

SIMPLINK
Easy LG TV Control

**What is SIMPLINK?**

Some functions of this unit are controlled by TV's remote control when this unit and LG TV with SIMPLINK are connected through HDMI connection. Controllable functions by LG TV's remote control; Play, Pause, Scan, Skip, Stop, Power Off, etc.

- Refer to the TV owner's manual for the details of SIMPLINK function.
- LG TV with SIMPLINK function has the logo as shown above.
- Use a higher version cable than 1.2 A HDMI cable.

# Specifications

## General

- Power requirements:
  200 - 240 V, 50/60 Hz
- Power consumption:
  55 W
- Dimensions (W x H x D):
  360 x 62.5 x 312.3 mm without foot
- Net Weight (Approx.):
  2.8 kg
- Operating temperature:
  41 °F to 95 °F (5 °C to 35 °C)
- Operating humidity:
  5 % to 90 %
- Bus Power supply (USB):
  DC 5 V ⎓ 500 mA

## Inputs/ Outputs

- VIDEO OUT:
  1.0 V (p-p), 75 Ω, sync negative, RCA jack x 1
- COMPONENT VIDEO OUT:
  (Y) 1.0 V (p-p), 75 Ω, sync negative, RCA jack x 1,
  (Pb)/(Pr) 0.7 V (p-p), 75 Ω, RCA jack x 2
- HDMI OUT (video/audio):
  19 pin (HDMI standard, Type A)
  HDMI version : 1.2A
- ANALOG AUDIO IN:
  2.0 Vrms (1 kHz, 0 dB), 600 Ω, RCA jack (L, R) x 1
- DIGITAL IN (OPTICAL 1):
  3 V (p-p), Optical jack x 1
- PORT. IN:
  0.5 Vrms (3.5 mm stereo jack)

## Tuner

FM Tuning Range:
87.5 to 108.0 MHz or 87.50 to 108.00 MHz

## Amplifier

- Stereo mode: 135 W + 135 W (4 Ω at 1 KHz)
- Subwoofer 170 W (3 Ω at 60 Hz)

## Speakers

- Front speaker

| | |
|---|---|
| Type: | 2 Way 2 speaker |
| Impedance : | 4 Ω |
| Rated Input Power: | 135 W |
| Max. Input power: | 270 W |
| Net Dimensions (W x H x D): | 125 x 245 x 125 mm |
| Net Weight: | 0.7 kg |

- Passive Subwoofer

| | |
|---|---|
| Type: | 1 Way 1 speaker |
| Impedance: | 3 Ω |
| Rated Input Power: | 170 W |
| Max. Input power: | 340 W |
| Net Dimensions (W x H x D): | 190 x 385 x 278 mm |
| Net Weight: | 4.7 kg |

Designs and specifications are subject to change without prior notice.




**Technology with the human touch**

## GUARANTEE

- LG Electronics U.K. Ltd. will provide the following services in order toexpedite this Guarantee.

1. All faulty components which fail due to defective manufacture will be replaced free of charge for a period of 12 months from the original date of purchase.
2. The dealer (or his service agent) who sold the product will be reimbursed for any labour provided in the repair of this LG equipment, for a period of 12 months from the original date of purchase. These claims must be made in accordance with the published scale of service charges and relevant claims procedure.

**PLEASE NOTE:**

A. The dealer may restrict the guarantee to the original purchaser.

B. The dealer is not obliged to carry out service under guarantee if unauthorized modifications are made to the apparatus, or if non standard components are used or if the serial number of the apparatus is removed, defaced, misused, or altered.

C. Any claims made under guarantee must be directed to the dealer from whom the equipment was originally purchased. The dealer may, before carrying out service under guarantee, require a receipted account as evidence of the date of purchase.

D. We respectfully point out that your dealer is not obligated to replace batteries if they become exhausted or worn in use.

E. Aerial alignment and consumer control adjustments are not covered by this guarantee.

This guarantee does not affect your statutory rights.

- REQUIREMENTS TO MAINTAIN WARRANTY COVERAGE:
  RETAIN YOUR RECEIPT TO PROVE DATE OF PURCHASE. A COPY OF YOUR RECEIPT MUST BE SURRENDERED AT THE TIME GUARANTEE SERVICE IS PROVED.
- Product Registration Card :
  It is helpful to complete at least your name, address, phone, model & serial numbers and return it. This will enable LG to assist you in the future should you lose your receipt, your units be stolen, or should modifications be necessary.
- To obtain information or assistance: Call 0870 873 5454 Monday-Friday 9.00am-4.30pm

| MODEL NO.* | SERIAL NO.* | DATE OF PURCHASE.* |
|---|---|---|
| | | |

**In all cases of difficulty - consult your LG dealer from whom the product was purchased**

LGEUK Website : www.lge.co.uk
( service website : www.lgelectronics.co.uk )



HT805S-D0_BGBRLL_ENG_4290.indd 44 2010-03-02 ¿ÀÈÄ 3:41:03


LG
Life's Good