LG
Life's Good

User Guide

FB44DAB



FULL HD UP-SCALING

HDMI HIGH DEFINITION MULTIMEDIA INTERFACE

DOLBY DIGITAL

FOR THE GUARANTEE TERMS & CONDITIONS,
PLEASE REFER TO BACK COVER OF THIS MANUAL.

DIVX

R·D·S

DAB
Digital Audio Broadcasting

P/NO: MFL41698473

Safety Precaution



CAUTION : TO REDUCE THE RISK OF ELECTRIC SHOCK DO NOT REMOVE COVER (OR BACK) NO USER-SERVICEABLE PARTS INSIDE REFER SERVICING TO QUALIFIED SERVICE PERSONNEL.



This lightning flash with arrowhead symbol within an equilateral triangle is intended to alert the user to the presence of uninsulated dangerous voltage within the product's enclosure that may be of sufficient magnitude to constitute a risk of electric shock to persons.




The exclamation point within an equilateral triangle is intended to alert the user to the presence of important operating and maintenance (servicing) instructions in the literature accompanying the product.

WARNING : TO PREVENT FIRE OR ELECTRIC SHOCK HAZARD, DO NOT EXPOSE THIS PRODUCT TO RAIN OR MOISTURE.

WARNING : Do not install this equipment in a confined space such as a book case or similar unit.

CAUTION : This product employs a Laser System.
To ensure proper use of this product, please read this owner's manual carefully and retain it for future reference. Should the unit require maintenance, contact an authorized service center.
Use of controls, adjustments or the performance of procedures other than those specified herein may result in hazardous radiation exposure.
To prevent direct exposure to laser beam, do not try to open the enclosure. Visible laser radiation when open. DO NOT STARE INTO BEAM.



CAUTION : The apparatus should not be exposed to water (dripping or splashing) and no objects filled with liquids, such as vases, should be placed on the apparatus.

CAUTION concerning the Power Cord

Most appliances recommend they be placed upon a dedicated circuit ;

That is, a single outlet circuit which powers only that appliance and has no additional outlets or branch circuits. Check the specification page of this owner's manual to be certain.

Do not overload wall outlets. Overloaded wall outlets, loose or damaged wall outlets, extension cords, frayed power cords, or damaged or cracked wire insulation are dangerous. Any of these conditions could result in electric shock or fire. Periodically examine the cord of your appliance, and if its appearance indicates damage or deterioration, unplug it, discontinue use of the appliance, and have the cord replaced with an exact replacement part by an authorized serv ice center.

Protect the power cord from physical or mechanical abuse, such as being twisted, kinked, pinched, closed in a door, or walked upon. Pay particular attention to plugs, wall outlets, and the point where the cord exits the appliance.

To disconnect power from the mains, pull out the mains cord plug. When installing the product, ensure that the plug is easily accessible.

Disposal of your old appliance



1. When this crossed-out wheeled bin symbol is attached to a product it means the product is covered by the European Directive 2002/96/EC.
2. All electrical and electronic products should be disposed of separately from the municipal waste stream via designated collection facilities appointed by the government or the local authorities.
3. The correct disposal of your old appliance will help prevent potential negative consequences for the environment and human health.
4. For more detailed information about disposal of your old appliance, please contact your city office, waste disposal service or the shop where you purchased the product.



This Product is manufactured to comply with EMC Directive 2004/108/EC and Low Voltage Directive 2006/95/EC.


European representative:
LG Electronics Service Europe B.V. Veluwezoom 15, 1327 AE Almere, The Netherlands
(Tel : +31-036-547-8940)

FB44-M0F_ENG.indd 2 2010-06-04 3:08:31

Welcome to your New DVD MICRO Hi-Fi SYSTEM

Contents


Setting up	4
Player	5
Remote control	6
OSD initial language settings -optional	7
Initial settings the Area Code	7
Adjusting the general settings	8-9
Setting the Clock	9
Displaying disc information	10
Playing a Disc	10-12
TV sound EZ setup	12
Listening to the radio	13
Listening to music from your portable player	14
Using an USB device	14
Recording to USB	15
Playing the iPod	16
Listening to the DAB (For England only)	17
Language Codes	18
Area Codes	18
Troubleshooting	19
Types of Playable Discs	20
Specifications	21



FB44-M0F_ENG.indd 3 2010-06-04 3:08:32

Setting up

Connecting your unit to your TV and aerials.



Plug the TV into the unit.
(For the model name FB44-??F only)

You can connect using a video cable.
If you are using a High Definition TV you can connect using the HDMI cable. Set the TV source to HDMI. Press **RESOLUTION** on the remote to select the correct resolution for you HDMI connection. The LG screen will appear when the correct resolution is selected.

1 **Connect the FM aerial.**

The reception will be at its best when the two loose ends of the aerial are in a straight and horizontal line.

2 **Connect the AM loop aerial to the unit.**
(Optional)

4 **Video Out connection**

Connect the VIDEO OUTPUT(MONITOR) jack on the unit to the corresponding input jack on your TV using a Video cable.

Componenet Video connection

Connect the COMPONENT VIDEO (PROGRESSIVE SCAN) OUTPUT jacks on the unit to the corresponding input jacks on your TV using a Y PB PR cable.

3 **Connect the DAB aerial**
(For England only)

Place it to the place where strong signals are received.

5 **Plug the unit plug into a wall socket.**

FB44-M0F_ENG.indd 4 2010-06-04 3:08:32

Player


USB Port
You can play video, image and sound files by connecting the USB device.


iPod Dock

PORT IN.
For connecting a portable device and listening to sound of it through this system's speakers.

PHONES
Headphone jack

⏏ OPEN / CLOSE
Open/ Close the disc door.
The disc door is opened or closed automatically.
Don't touch the disc door while opening or closing.





FUNC
(Function) Selects the function.
LG EQ
You can choose fixed sound impression.
CLOCK
(See "Setting the Clock")
TIMER
(See the "Using your player as an alarm clock")
SET
Confirms the settings.
RDS
Radio Data System
VOL -/+
Volume control

Power
Turn the unit on and off. Only the red light in the middle of the **POWER** button will show when it is in standby. The system uses less power if it is switched into the standby mode.

Disc Door

▶/❚❚
Play / Pause
⏮/⏭
Scanning/ Tuning/ Searching
■/DEMO
Stop
USB Rec.
Recording to USB.

FB44-M0F_ENG.indd 5 2010-06-04 3:08:33

Remote control

RETURN (↶) : moving backwards in the menu.or exited the setup menu.
REC (●) : USB Direct Recording
STOP (■) : Stops playback or recording.
PLAY (▶), MO./ST. : Starts playback. Selects Mono/ Stereo.
PAUSE/STEP (❚❚) : Pause playback
SKIP (⏮ / ⏭) : Go to next or previous chapter/ track/ file.
SCAN (◀◀/▶▶) : Search backward or forward.

TV Control buttons : Controls the TV. (LG TV only)

Controlling the TV.
You can control the sound level, input source, and power switching of LG TVs as well. Hold POWER (TV) and press **PR/CH** (+/–) button repeatedly until the TV turns on or off.

PROG./MEMO. : Accesses or removes Program menu.
CLEAR : Removes a track number on the Program List.
RESOLUTION : Sets the output resolution for HDMI and COMPONENT VIDEO OUT jacks.
RDS : Radio Data System.
PTY : Views the various displays of the RDS.

Screen Saver
The screen saver appears when you leave the unit in Stop mode for about five minutes.

System Select - Optional
You must select the appropriate system mode for your TV system. If "NO DISC" appears in the display window, press and hold **PAUSE/STEP** (❚❚) for more than five seconds to be able to select a system. (PAL/ NTSC)



FUNCTION : Selects the function and input source.
SLEEP : You can select delay time between 10 and 180 minutes, after the player will turn off. To check the remaining time, press **SLEEP**. (Dimmer : Dims the LED (Light-emitting diode) of front panel by half in power-on status.)
⏻ **POWER** : Switches the unit ON or OFF.
⏏ **OPEN/CLOSE** : Opens and closes the disc Drawer.
TITLE : If the current DVD title has a menu, the title menu appears on the screen. Otherwise, the disc menu may not appear.
DISPLAY : Accesses On-Screen Display.
MENU : Accesses the menu on a DVD disc.
SETUP : Accesses or removes setup menu
PRESET (∧ ∨) : Selects programme of Radio.
CH./ TUN. (-/+) : Tunes in the desired radio station.
∧ ∨ < > (left/ right/ up/ down): Used to navigate onscreen displays.
ENTER : Acknowledges menu selection.

TV→HT SPK : To select the AUX OPT directly.
REPEAT/RANDOM : To select a play mode. (random/ repeat)
MUTE : To mute the sound.
VOL (Volume) (+/-) : Adjusts speaker volume.
EQ/ LG EQ (Equalizer effect) : You can choose sound impressions.
SUBTITLE : During playback, you can select a desired subtitle language .
0-9 numerical buttons : Selects numbered options in a menu.

Put the battery into the remote control.
Make sure that the + (plus) and - (minus) on the battery match those on the remote control.

FB44-M0F_ENG.indd 6 2010-06-04 3:08:33

OSD initial language settings - Optional

During the first use of this unit, the initial language setup menu appears on your TV screen. You must complete initial language selection before using the unit.

	ON REMOTE
1 Turn the power on The language list appears.	**POWER**
2 Select the language	<>∧∨
3 Press	**ENTER**
4 To confirm press	**ENTER**

Initial settings the Area Code

When you use this unit for the first time, you have to set the Area Code as shown below.

	ON REMOTE
1 Display setup menu	**SETUP**
2 Select LOCK menu on the first level	∧ ∨
3 Move to second level The activated Area Code appears on the second level.	>
4 Move to the third level	>
5 Enter a new password	Numeric (0-9) and **ENTER**
6 Recheck the entered new password	Numeric (0-9) and **ENTER**
7 Select a code for a geographic area After select, Rating and Password will be activated.	∧ ∨ < > and **ENTER**
8 To confirm what you press Make sure to finish setting the Area Code.	**ENTER**

FB44-M0F_ENG.indd 7 2010-06-04 3:08:34

Adjusting the general settings

	ON REMOTE
1 Display setup menu	SETUP
2 Select a desired option on the first level	∧∨
3 Move to the second level	>
4 Select a desired option on the second level	∧∨
5 Move to the third level	>
6 Change the setting	∧∨, ENTER

Adjusting the general settings - more you can do

Adjusting the language settings

OSD (Menu Language) – Select a language for the Setup menu and on-screen display.

Disc Audio/ Disc Subtitle/ Disc Menu – Select a language for the Disc Audio/ Disc Subtitle/ Disc Menu.

[Original] Refers to the original language in which the disc was recorded.

[Other] To select another language, press number buttons then **ENTER** to enter the corresponding 4-digit number according to the language code list in the reference chapter **(Page 18)**. If you make a mistake before pressing **ENTER**, press **CLEAR**.

[Off] (for Disc Subtitle) Turn off Subtitle.

Adjusting the display settings

TV Aspect – Select which screen aspect to use based on the shape of your TV screen.

[4:3] Select when a standard 4:3 TV is connected.

[16:9] Select when a 16:9 wide TV is connected.

Display Mode – If you selected 4:3, you'll need to define how you would like wide screen programs and films to be displayed on your TV screen.

[Letterbox] This displays a wide screen picture with black bands at the top and bottom of the screen.

[Panscan] This fills the entire 4:3 screen, cropping the picture as necessary.

Adjusting the audio settings

DRC (Dynamic Range Control) – Make the sound clear when the volume is turned down (Dolby Digital only). Set to [On] for this effect.

Vocal – Select [On] to mix karaoke channels into normal stereo. This function is effective for multi-channel karaoke DVDs only.

HD AV Sync - Sometimes Digital TV encounters a delay between picture and sound. If this happens you can compensate by setting a delay on the sound so that it effectively 'waits' for the picture to arrive: this is called HD AV Sync. Use ∧ ∨ (on the remote control) to scroll up and down through the delay amount, which you can set at anything between 0 and 300m sec.

Adjusting the lock settings

To access the lock options, you must enter the 4-digit password. If you have not yet entered a password you are prompted to do so.

1 Enter a 4-digit password then press **ENTER**.

2 Enter it again then press ENTER to verify. If you make a mistake while entering number, press **CLEAR** then correct it.

Area Code – Select a code for a geographic area as the playback rating level. This determines which area's standards are used to rate DVDs controlled by the parental lock. See the Area Codes on **page 18**.

Rating – Select a rating level. The lower the level, the stricter the rating. Select [Unlock] to deactivate the rating.

Password – Sets or changes the password for lock settings.

[New] Enter a new 4-digit password using the numerical buttons then press **ENTER**. Enter the password again to confirm.

[Change] Enter the new password twice after entering the current password.

If you forget your password you can reset it.

1 Remove the disc in the unit.

2 Press **SETUP** to display the Setup menu. Input '210499' and press **ENTER**. The password has now been cleared.

FB44-M0F_ENG.indd 8 2010-06-04 3:08:34

Adjusting the others settings

DivX(R) Registration – We provide you with the DivX® VOD (Video On Demand) registration code that allows you to rent and purchase videos using the DivX® VOD service.
For more information, visit www.divx.com/vod.
Press **ENTER** and you can view the registration code of the unit.

Enjoying a pre-programmed sound field

The system has a number of pre-set surround sound fields. You can select a desired sound mode by using **EQ/ LG EQ**. The displayed items for the Equalizer may be different depending on sound sources and effects.

NATURAL	You can enjoy comfortable and natural sound.
Local specialization equalizer	Regionally optimized sound effect. (DANGDUT/ ARABIC/ PERSIAN/ INDIA/ REGUETON/ MERENGUE/ SALSA/ SAMBA)
AUTO EQ	Realizes the sound equalizer that is the most similar to the genre of which is included in the MP3 ID3 tag of song files.
POP **CLASSIC** **JAZZ** **ROCK**	This program lends an enthusiastic atmosphere to the sound, giving you the feeling you are at an actual rock pop, jazz or classic concert.
MP3 OPT	This function is optimized for compressible MP3/WMA file. It improves the bass sound.
XDSS ON	Reinforce the treble, bass and surround sound effect.
VIRTUAL	You can enjoy more virtual surround sound.
NORMAL	You can enjoy the sound without equalizer effect.

Setting the Clock

	ON UNIT
1 Turn the power on	⏻
2 Press for at least 2 seconds	**CLOCK**
3 Choose from either AM 12:00 (for an AM and PM display) or 0:00 (for a 24 hour display)	**I◀◀ / ▶▶I**
4 Confirm your selection	**SET**
5 Select the hours	**I◀◀ / ▶▶I**
6 Press	**SET**
7 Select the minutes	**I◀◀ / ▶▶I**
8 Press	**SET**

Using your player as an alarm clock

1 Press **TIMER**. Each functions flashes.
2 Press **SET** when the function you want to be woken by is showing.
3 "ON TIME" will be displayed. This is where you set the time you want the alarm to start. Use **I◀◀ / ▶▶I** to change the hours and minutes and SET to save.
4 The "OFF TIME" will be displayed. This is where you set the time you want the function to stop.
5 Use **I◀◀ / ▶▶I** to change the hours and minutes and press **SET** to save.
6 You will be shown the volume (VOL) you want to be woken by. Use **I◀◀ / ▶▶I** to change the volume and **SET** to save. Switch the system off. The clock icon "🕘" shows that the alarm is set.
7 When the system is turned off you can check the time the alarm and turn the alarm on and off by pressing **TIMER**.

FB44-M0F_ENG.indd 9 2010-06-04 3:08:34

Displaying Disc information

	ON REMOTE
1 Press	DISPLAY
2 Select an item	∧∨
3 Adjust the display menu settings	∧∨
4 To return the exit	↶ RETURN

Displaying Disc Information - more you can do

You can select an item by pressing ∧ ∨ and change or select the setting by pressing < >.



Current title (or track/ file) number/ total number of titles (or tracks/ files)



Current chapter number/ total number of chapters



Elapsed playing time



Selected audio language or channel



Selected subtitle



Selected angle/ total number of angles



Selected sound/EQ mode

Symbol Used in this Manual

All discs and file listed below	ALL	MP3 files	MP3
DVD and finalized DVD±R/RW	DVD	WMA files	WMA
DivX files	DivX	Audio CDs	ACD
JPEG files	JPG		

Playing a Disc

	ON REMOTE
1 Insert a disc on unit	⏏ OPEN/CLOSE
2 Select DVD/CD	FUNCTION
3 Adjust the menu settings / Select a file from the menu	<>∧∨
4 Start the disc playing	► PLAY/ENTER
5 To stop the disc playing	■ STOP

Playing a Disc or file - more you can do

Playing a DVD that has a menu DVD

Most DVDs now have menus which load first before the film begins to play.
1 You can navigate these menus using ∧ ∨ < > to highlight an option.
2 Press **ENTER** to select.

Skipping to the next/ previous chapter/ track/ file

MP3 WMA DVD DivX ACD

Press **SKIP** (►►I) to move to the next chapter/ track/ file.
Press **SKIP** (I◄◄) to return to the beginning of the current chapter/ track/ file.
Press **SKIP** (I◄◄) twice briefly to step back to the previous chapter/ track/ file.

Pausing playback ALL

1 Press **PAUSE/STEP** (❚❚) to pause playback.
2 Press **PLAY** (►) to continue playback.

Frame-by-Frame playback DVD DivX

Press **PAUSE/STEP** (❚❚) repeatedly to play title Frame-by-Frame.

Playing repeatedly or randomly MP3 WMA DVD DivX ACD

Press **REPEAT/RANDOM** repeatedly, and the current title, chapter or track will be played back repeatedly or randomly.
To return to normal playback, press **REPEAT/RANDOM** repeatedly.
- Random play mode : only music files.

FB44-M0F_ENG.indd 10 2010-06-04 3:08:34

Fast forward or fast reverse MP3 WMA DVD DivX ACD

Press **SCAN** (◀◀ or ▶▶) to play fast forward or fast reverse during playback.
You can change the playback speed by pressing **SCAN** (◀◀ or ▶▶) repeatedly. Press **PLAY** (▶) to continue play at normal speed.

Slow down the playing speed DVD

While playback is paused, press **SCAN** (◀◀ or ▶▶) to slow down forward or reverse playback. You can change the various playback speed by pressing **SCAN** (◀◀ or ▶▶) repeatedly. Press **PLAY** (▶) to continue play at normal speed.

1.5 times faster playback DVD

Press **PLAY** when a DVD is already playing to watch and listen to a DVD 1.5 times faster than normal playback speed. "▶ x1.5" will appear in the screen. Press **PLAY** again to return to normal playback speed.

Selecting a subtitle language DVD DivX

During playback, press **SUBTITLE** repeatedly to select a desired subtitle language.

Changing the character set to display DivX® subtitle correctly DivX

1 If the subtitle does not display properly during playback, press and hold **SUBTITLE** for about 3 seconds to display the language code menu.
2 Press **SUBTITLE** repeatedly to change the language code until the subtitle is displayed properly.

Viewing the Title menu DVD

Press **TITLE** to display the disc's title menu, if available.

Starting play from selected time DVD DivX

Searches for the starting point of entered time code.
1 Press **DISPLAY** then select clock icon.
2 Enter a time then press **ENTER**.
For example, to find a scene at 1 hour, 10 minutes, and 20 seconds, enter "11020" by using numerical buttons and press **ENTER**. if you enter the wrong number, press **CLEAR** to enter again.

Last Scene Memory DVD

This unit memorizes the last scene from the last disc that is viewed. The last scene remains in memory even if you remove the disc from the player or switch off (Stand-by mode) the unit. If you load a disc that has the scene memorized, the scene is automatically recalled.

Creating your own program MP3 WMA ACD

You can play the contents of a disc in the order you want by arranging the order of the musics on the disc. The program is cleared when the disc is removed.
1 Select a desired music then press **PROG./MEMO.** or select " ♫→ " and then press **ENTER** to add the music to the program list.
2 To add all music in the disc, select " ♫♫→ " and then press **ENTER**.
3 Select a music from the program list then press **ENTER** to start programmed playback.
4 To clear a music from the program list, select the music you want to clear then press **CLEAR** or select " ♫🗑 " icon and then press **ENTER**.
To clear all music from the program list, select " ♫♫🗑 " then press **ENTER**.

Displaying file information (ID3 TAG) MP3

While playing an MP3 file containing file information, you can display the information or time by pressing **DISPLAY** repeatedly.

Viewing photo files as a slide show JPG

1 Use ∧ ∨ < > to highlight (▶) icon then press **ENTER** to start slide Show.
2 You can change slide show speed using < > when (▶⏱) icon is highlighted.

Skipping to the next/ previous photo JPG

Press **SKIP** (I◀◀ or ▶▶I) or < > to view the previous/ next photo.

Rotating a photo JPG

Use ∧ ∨ to rotate the photo in full screen counterclockwise or clockwise while viewing a photo in full screen.

Mixed disc or USB Flash Drive – DivX, MP3/ WMA and JPEG

When playing a disc or USB Flash Drive containing with DivX, MP3/ WMA and JPEG files together, you can select menu of files which you would like to play by pressing **MENU**.

FB44-M0F_ENG.indd 11 2010-06-04 3:08:34

Playable file requirement

DivX

- Available resolution: within 800x600 (W x H) pixels
- The file name of the DivX subtitle should be entered within 45 characters.
- If there is impossible code to express in the DivX file, it may be displayed as " _ " mark on the display.
- If the video and audio structure of recorded files is not interleaved, either video or audio is outputted.
- Playable DivX file : ".avi", ".mpg", ".mpeg", ".divx"
- Playable Subtitle format : SubRip (*.srt/ *.txt), SAMI (*.smi), SubStation Alpha (*.ssa/ *.txt), MicroDVD (*.sub/ *.txt), SubViewer 2.0 (*.sub/ *.txt).
- Playable Codec format : "DIVX3.xx", "DIVX4.xx", "DIVX5.xx", "MP4V3", "3IVX".
- Playable Audio format : "AC3", "PCM", "MP3", "WMA".
- For Discs formatted in Live file system, you can not it on this player.
- If the name of movie file is different from that of the subtitle file, during playback of a DivX file, subtitle may not be display.
- If you play a DivX file differ from DivX spec, it may not operate normally.

MP3/ WMA


- Sampling frequency : within 32 - 48 kHz (MP3/ WMA)
- Bit rate : within 32 - 320 kbps (MP3), 40 - 192 kbps (WMA)
- File extensions : ".mp3"/ ".wma"
- CD-ROM file format : ISO9660 LEVEL 1 / JOLIET
- We recommend that you use Easy-CD Creator, which creates an ISO 9660 file system.

JPG

- Normal: 5120 x 3840, Progressive jpeg: 2043 x 1536
- Recording condition: ISO9660 LEVEL 1/ JOLIET
- Maximum files : Under 999.
- Some discs may not operate due to a different recording format or the condition of disc.
- File extensions: ".jpg"

TV sound EZ setup

You can enjoy to sound from TV, DVD and Digital Device. Even in power off mode, if you press **TV→HT SPK**, then power is on and automatically changed to AUX OPT mode.



	ON REMOTE
1 Connect the unit's OPTICAL IN jack to jack on optical out of your TV (or Digital Device etc).	
2 Select the AUX OPT To select the AUX OPT directly.	**TV→HT SPK**
3 Enjoy sound	
4 To escape from AUX OPT	**TV→HT SPK**

FB44-M0F_ENG.indd 12 2010-06-04 3:08:35

Listening to the radio

Be sure that the aerials are connected.

	ON REMOTE
1 Select FM or AM(optional)	**FUNCTION**
2 Select a radio station	**TUN - / +**
3 To save a radio station A preset number will show in the display.	**PROG./MEMO.**
4 Select the preset number Up to 50 radio stations can be saved.	**PRESET ∧∨**
5 To confirm press	**PROG./MEMO.**

Listening to the radio - More you can do

Looking for radio stations automatically

Press and hold **TUN.-/ TUN.+** for more than a second. The tuner will scan automatically and stop when it finds a radio station.

Deleting all the saved stations

1 Press and hold **PROG./MEMO.** for two seconds.
- "ERASE ALL" will flash up on the display.

2 Press **PROG./MEMO.** to erase all saved radio stations.

Improving poor FM reception

Press **PLAY** (▶) (MONO/ST) on the remote control. This will change the tuner from stereo to mono and usually improve the reception.

See information about your radio stations - OPTIONAL

The FM tuner is supplied with the Radio Data System (RDS) facility. This shows the letters RDS on the display, plus information about the radio station being listened to. Press **RDS** on the remote control several times to view the information.


PTY	Programme Type, such as News, Sport, Jazz.
RT	Radio Text, the name of the radio station.
CT	Time Control, the time at the location of the radio station.
PS	Programme Service name, the name of channel.

- You can search the radio stations by programme type by pressing **RDS**. The display will show the last **PTY** in use. Press **PTY** one or more times to select your preferred programme type. Press and hold **</>**. The tuner will search automatically. When a station is found the search will stop.

FB44-M0F_ENG.indd 13 2010-06-04 3:08:35

Listening to music from your portable player

The unit can be used to play the music from many types of portable player.

	ON REMOTE
1 Connect the portable player to the PORT.IN (PORTABLE IN) connector of the unit. 	
2 Turn the power on	⏻ **POWER**
3 Select the function Turn on the portable player and start it playing.	**FUNCTION**

Using an USB device

You can enjoy media files saved on an USB device by connecting it to the USB port of the unit. If you want to operate other function, see the CD playback section.

	ON REMOTE
1 Connect the USB device to the USB port of the unit.	
2 Select the function	**FUNCTION**
3 Select a file you want to play	∧∨
4 Start your media playing	► **PLAY**
5 To stop, press	■ **STOP**
6 Before disconnecting, you have to change to any other function	**FUNCTION**

Compatible USB Devices

- MP3 Player : Flash type MP3 player.
- USB Flash Drive : Devices that supports USB 2.0 or USB 1.1.
- The USB function of this unit does not support all USB devices.

USB device requirement

- Devices which require additional program installation when you have connected it to a computer, are not supported.

Look out for the follows.

- Do not extract the USB device while in operation.
- For a large capacity USB, it may take longer than a few minute to be searched
- To prevent data loss, back up all data.
- If you use a USB extension cable or USB hub, the USB device is not recognized.
- Using NTFS file system is not supported. (Only FAT(16/32) file system is supported.
- This unit is not supported when the total number of files is 1000 or more.
- External HDD, Card readers, Locked devices, or hard type USB devices are not supported.
- USB port of the unit cannot be connected to PC.
- The unit can not be used as a storage device.

FB44-M0F_ENG.indd 14 2010-06-04 3:08:35

Recording to USB

	ON REMOTE
1 Connect the USB device to the USB port of the unit.	
2 Select a mode in which you want to record (ex. CD/ TUNER/ ...) Play a sound source first If you want to record desired music file in disc to USB, play a file before starting the recording**.**	**FUNCTION**
3 Start the recording	**● REC**
4 To stop, press	**■ STOP**

Recording to USB - more you can do

Recording Music file in disc source to USB

One track recording
If the USB recording is started during playback of the CD, the one track/ file would be recording into the USB.

All tracks recording
If the recording button is pressed at the CD stop, all tracks/ files would be recording. The files in the sub-folders are not recorded during all track recording.

Program list recording
USB records after creating your own program if you want to record the track you want (AUDIO CD Only).

When you are recording, look out for the following

- You can check the recording percentage rate for the USB record on the screen during the recording. (AUDIO, MP3/ WMA CD only)
- During recording MP3/ WMA, there is no sound.
- When you stop recording during playback, the file that has been recorded at that time will be stored. (AUDIO CD Only)
- Do not remove the USB device during USB recording. If not, an incomplete file may be made and not deleted on PC.
- If USB recording does not work, the message like "NO USB", "ERROR", "USB FULL" or "NO REC" is displayed on the display window.
- Multi card reader device or External HDD can not be used for USB recording.
- A file is recorded by 2 hours when you record for a long term.
- When you stop recording during playback, the file will not be stored.
- In the state CD-G disc, USB record is not operated.
- You may not record more than 999 files.
- The file number is saved automatically.
- **It'll be stored as follows.**


AUDIO CD	MP3/ WMA	The other sources.
🗀 CD_REC	🗀 FILE_REC	🗀 EXT_REC
├ TRK-001	├ 001_ABC(File name)	├ AUD-001
├ TRK-002	├ 002_DEF(File name)	├ AUD-002
├ -	├ -	├ -
├ -	├ -	├ -
├ -	├ -	├ -

The making of unauthorized copies of copy-protected material, including computer programs, files, broadcasts and sound recordings, may be an infringement of copyrights and constitute a criminal offense.
This equipment should not be used for such purposes.
Be responsible
Respect copyrights

FB44-M0F_ENG.indd 15 2010-06-04 3:08:35

Playing the iPod

For detial refer to iPod guide.
iPod mode: You can operate your iPod by using the supplied remote control and directly control on your iPod.
OSD iPod mode: You can operate your iPod by controlling OSD menu on the TV screen with supplied remote control. The controls on your iPod are not operational in the OSD iPod mode.



	ON REMOTE
1 Open the iPod dock	
2 Connect your iPod to the dock.	
3 Select the iPod or OSD iPod function	FUNCTION
4 Select the menu If you want to move backwards in the menu, press **MENU.**	∧∨ and ENTER
5 Select a file	∧∨
6 Start the file playing	► PLAY
7 To stop the file playing	■ STOP
8 Before disconnecting the iPod, change to any other function by pressing	FUNCTION
9 Remove the iPod	

Playing the iPod - more you can do

Pausing playback

Press **PAUSE/STEP** (❚❚) or **PLAY** (►) to pause playback. Press **PAUSE/STEP** (❚❚) or **PLAY** (►) to continue playback.

Skipping to the next/previous file

Press **SKIP** (►►I) to move to the next file.
Press **SKIP** (I◄◄) to return to the beginning of the current file.
Press **SKIP** (I◄◄) twice briefly to step back to the previous file.

Fast forward or fast reverse

Audio files: During playback, press and hold **SCAN** (◄◄ / ►►) and then release at a point you want.

Playing repeatedly

Press **REPEAT/RANDOM** repeatedly to select an item to be repeated. The current file will be played back repeatedly. To return to normal playback, press **REPEAT/RANDOM** repeatedly. (On video files, this function is not available.)

iPod message

"**Please, check your iPod**" - If the power of your iPod is insufficient or the iPod is misconnected or unknown device. Reset the iPod if the iPod is not operating normally (Refer to http://www.apple.com/support/)
"Connect Video Out(only composite) from the HTS to the TV and switch TV input accordingly.", "Please, Control through an iPod's display." - When you connect the unit and TV to COMPONENT VIDEO OUT or HDMI OUT, connect the unit and TV to VIDEO OUT.

Compatible iPod

- When the unit is connected with dock connector may result in malfunctions.
- Compatibility with your iPod may vary depending on the type of your iPod.
- Depending on your iPod's software version, it may not be possible to control your iPod from the unit. We recommend installing the latest software version.

When you use iPod, look out for the following

- Interference may happen depending on iPod devices.
- The video files are outputted only when you connect the unit to VIDEO OUT.

FB44-M0F_ENG.indd 16 2010-06-04 3:08:35

Listening to the DAB

DAB (Digital Audio Broadcasting) is a new form of radio broadcasting using digital signals rather than traditional analogue signals. DAB provides listeners CD-like quality radio programs. DAB can carry not only audio but also text.

	ON REMOTE
1 Select the DAB function The frequency received first after scanning DAB bands is broadcasted.	**FUNCTION**
2 Select the DAB radio station	**I◄◄ ►►I**
3 Play the selected channel	**► PLAY**

Listening to the DAB - more you can do

DAB mode

You can change the display information of the currently broadcasting DAB channel.
Press **DAB MODE** on the remote control repeatedly, the display changes in the following order, SERVICE ⟶ PTY NAME ⟶ FREQUENCY ⟶ DLS ⟶ QUALITY ⟶ ENSEMBLE.
Select a display mode and then press **I◄◄ / ►►I**, the initials of the service name are displayed.

SERVICE	Displays the Name of Component for the current broadcast.
PTY NAME	Displays the Type of Component for the current broadcast.
FREQUENCY	Displays the frequency of Component for the current broadcast.
DLS	It displays the current Scroll of Component which is selected.
QUALITY	It displays the current strength of electric field of broadcasting which it doing.
ENSEMBLE	Displays the Ensemble of Component for the current broadcast.

Aligning the service names

Press **SCAN/SORT** on the remote control to display the sorting mode of DAB broadcasting. Then, press the button once again to change the mode.

Default sort	The service names are aligned in a scanning order.
Name sort	The service names are aligned in an alphabetical order.

DAB scan

Press **SCAN** on the remote control for longer than 3 seconds, all of the DAB bands are scanned. Then press it again, scanning will be canceled.

Selecting among Primary and Secondary broadcasting.

For the frequency on which secondary broadcasting channels exist, ► blinks after selection. Then, press **►/II** to select the secondary broadcasting.

NOTES:
- Broadcasting may be interrupted or stopped while using it in a forest, some places enclosed by buildings, or the places where reception sensitivity is weak.
- When you use the DAB function for the first time, the broadcasting channels are scanned automatically.

Researching the channel

The previously saved channels are deleted, and then channels are searched again.
1 Press and hold **CLEAR** for 3 seconds.
- "DAB INITIAL" is displayed.

2 Press **CLEAR** once more.
- The previously saved channels are deleted, and then channels are searched again.

3 Enjoy the broadcasting.

NOTES:
- "!!": It is displayed when signal reception gets weak. When the unit receives no broadcasting signals for the searched channel, then it searches available broadcasting channels.
- "2nd": It is displayed when secondary broadcasting is selected.

FB44-M0F_ENG.indd 17 2010-06-04 3:08:35

Language Codes

Use this list to input your desired language for the following initial settings: Disc Audio, Disc Subtitle, Disc menu.

Language	Code	Language	Code	Language	Code	Language	Code	Language	Code	Language	Code
Afar	6565	Croatian	7282	Hausa	7265	Lingala	7678	Quechua	8185	Tajik	8471
Afrikaans	6570	Czech	6783	Hebrew	7387	Lithuanian	7684	Rhaeto-Romance	8277	Tamil	8465
Albanian	8381	Danish	6865	Hindi	7273	Macedonian	7775	Rumanian	8279	Telugu	8469
Ameharic	6577	Dutch	7876	Hungarian	7285	Malagasy	7771	Russian	8285	Thai	8472
Arabic	6582	English	6978	Icelandic	7383	Malay	7783	Samoan	8377	Tonga	8479
Armenian	7289	Esperanto	6979	Indonesian	7378	Malayalam	7776	Sanskrit	8365	Turkish	8482
Assamese	6583	Estonian	6984	Interlingua	7365	Maori	7773	Scots Gaelic	7168	Turkmen	8475
Aymara	6588	Faroese	7079	Irish	7165	Marathi	7782	Serbian	8382	Twi	8487
Azerbaijani	6590	Fiji	7074	Italian	7384	Moldavian	7779	Serbo-Croatian	8372	Ukrainian	8575
Bashkir	6665	Finnish	7073	Javanese	7487	Mongolian	7778	Shona	8378	Urdu	8582
Basque	6985	French	7082	Kannada	7578	Nauru	7865	Sindhi	8368	Uzbek	8590
Bengali; Bangla	6678	Frisian	7089	Kashmiri	7583	Nepali	7869	Singhalese	8373	Vietnamese	8673
Bhutani	6890	Galician	7176	Kazakh	7575	Norwegian	7879	Slovak	8375	Volapük	8679
Bihari	6672	Georgian	7565	Kirghiz	7589	Oriya	7982	Slovenian	8376	Welsh	6789
Breton	6682	German	6869	Korean	7579	Panjabi	8065	Spanish	6983	Wolof	8779
Bulgarian	6671	Greek	6976	Kurdish	7585	Pashto, Pushto	8083	Sudanese	8385	Xhosa	8872
Burmese	7789	Greenlandic	7576	Laothian	7679	Persian	7065	Swahili	8387	Yiddish	7473
Byelorussian	6669	Guarani	7178	Latin	7665	Polish	8076	Swedish	8386	Yoruba	8979
Chinese	9072	Gujarati	7185	Latvian, Lettish	7686	Portuguese	8084	Tagalog	8476	Zulu	9085

Area Codes

Choose a area code from this list.

Area	Code	Area	Code	Area	Code	Area	Code	Area	Code	Area	Code
Afghanistan	AF	Costa Rica	CR	Greenland	GL	Maldives	MV	Paraguay	PY	Sri Lanka	LK
Argentina	AR	Croatia	HR	Hong Kong	HK	Mexico	MX	Philippines	PH	Sweden	SE
Australia	AU	Czech Republic	CZ	Hungary	HU	Monaco	MC	Poland	PL	Switzerland	CH
Austria	AT	Denmark	DK	India	IN	Mongolia	MN	Portugal	PT	Taiwan	TW
Belgium	BE	Ecuador	EC	Indonesia	ID	Morocco	MA	Romania	RO	Thailand	TH
Bhutan	BT	Egypt	EG	Israel	IL	Nepal	NP	Russian Federation	RU	Turkey	TR
Bolivia	BO	El Salvador	SV	Italy	IT	Netherlands	NL	Saudi Arabia	SA	Uganda	UG
Brazil	BR	Ethiopia	ET	Jamaica	JM	Netherlands Antilles	AN	Senegal	SN	Ukraine	uaw
Cambodia	KH	Fiji	FJ	Japan	JP	New Zealand	NZ	Singapore	SG	United States	US
Canada	CA	Finland	FI	Kenya	KE	Nigeria	NG	Slovak Republic	SK	Uruguay	UY
Chile	CL	France	FR	Kuwait	KW	Norway	NO	Slovenia	SI	Uzbekistan	UZ
China	CN	Germany	DE	Libya	LY	Oman	OM	South Africa	ZA	Vietnam	VN
Colombia	CO	Great Britain	GB	Luxembourg	LU	Pakistan	PK	South Korea	KR	Zimbabwe	ZW
Congo	CG	Greece	GR	Malaysia	MY	Panama	PA	Spain	ES		

FB44-M0F_ENG.indd 18 2010-06-04 3:08:35

Troubleshooting

PROBLEM	CAUSE	CORRECTION
No Power	The power cord is disconnected.	Plug the power cord into the wall outlet securely.
No Picture	The TV is not set to receive the DVD signal.	Select the appropriate video input mode on the TV so the picture from the unit appears on the TV screen.
	The video cables are not connected securely.	Connect the video cables securely to both the TV and unit.
The DVD picture quality is poor.	The disc is dirty.	Clean the disc using a soft cloth with outward strokes.
A DVD/CD will not play.	No disc is inserted.	Insert a disc.
	An unplayable disc is inserted.	Insert a playable disc (check the disc type, colour system and regional code).
	The disc is inserted upside down.	Place the disc the side you can see the printed side.
	The menu is open on screen.	Press **SETUP** to close the menu screen.
	There is a parental lock which prevents the playback of DVDs with a certain rating.	Enter your password or change the rating level.
Humming noise heard while a DVD or CD is playing.	The disc is dirty.	Clean the disc using a soft cloth with outward strokes.
	The unit is located too close to the TV, causing feedback.	Move the unit and audio components further away from your TV.
Radio stations can't be tuned in properly.	The antenna is positioned or connected poorly.	Check the antenna connection and adjust its position.
		Attach an external aerial if necessary.
	The signal strength of the radio station is too weak.	Tune to the station manually.
	No stations have been preset or preset stations have been cleared (when tuning by scanning preset channels).	Preset some radio stations.
The remote control doesn't work well / at all	The remote is not pointed directly at the unit.	Point the remote directly at the unit.
	The remote is too far from the unit.	Use the remote within 23 feet (7m) of the unit.
	There is an obstacle in the path between the remote control and the unit.	Remove the obstacle.
	The battery in the remote control is flat.	Replace the battery with new one.

FB44-M0F_ENG.indd 19 2010-06-04 3:08:36

Types of Playable Discs

Type	LOGO
DVD-VIDEO : Discs such as movies that canbe purchased or rented.	
DVD-R : Video mode and finalized only	
DVD-RW : Video mode and finalized only DVD VR format that have been finalized can not be played in this unit	
DVD+R : Video mode only Supports the double layer disc also	
DVD+RW : Video mode only	
Audio CD : Music CDs or CD-R/ CD-RW in music CD format that can be purchased**.**	
This unit plays DVD±R/ RW and CD-R/ RW that contains audio titles, DivX, MP3,WMA and/ or JPEG files. Some DVD±RW/ DVD±R or CDRW/ CD-R cannot be played on this unit due to the recording quality or physical condition of the disc, or the characteristics of the recording device and authoring software.	

"Dolby", "Pro Logic", and the double-D symbol are trademarks of Dolby Laboratories. Manufactured under license from Dolby Laboratories.

About the ⃠ Symbol Display

" ⃠ " may appear on your TV display during operation and indicates that the function explained in this owner's manual is not available on that specific DVD video disc.

Regional Codes

This unit has a regional code printed on the rear of the unit. This unit can play only DVD discs labeled same as the rear of the unit or "ALL".

- Most DVD discs have a globe with one or more numbers in it clearly visible on the cover. This number must match your unit's regional code or the disc cannot play.
- If you try to play a DVD with a different regional code from your player, the message "Check Regional Code" appears on the TV screen.

Copyrights

It is forbidden by law to copy, broadcast, show, broadcast via cable, play in public, or rent copyrighted material without permission. This product features the copy protection function developed by Macrovision. Copy protection signals are recorded on some discs. When recording and playing the pictures of these discs picture noise will appear. This product incorporates copyright protection technology that is protected by U.S. patents and other intellectual property rights. Use of this copyright protection technology must be authorized by Macrovision, and is intended for home and other limited viewing uses only unless otherwise authorized by Macrovision. Reverse engineering or disassembly is prohibited.

CONSUMERS SHOULD NOTE THAT NOT ALL HIGH DEFINITION TELEVISION SETS ARE FULLY COMPATIBLE WITH THIS PRODUCT AND MAY CAUSE ARTIFACTS TO BE DISPLAYED IN THE PICTURE. IN CASE OF 525 OR 625 PROGRESSIVE SCAN PICTURE PROBLEMS, IT IS RECOMMENDED THAT THE USER SWITCH THE CONNECTION TO THE 'STANDARD DEFINITION' OUTPUT. IF THERE ARE QUESTIONS REGARDING OUR TV SET COMPATIBILITY WITH THIS MODEL 525p AND 625p UNIT, PLEASE CONTACT OUR CUSTOMER SERVICE CENTER.

You have to set the disc format option to [Mastered] in order to make the discs compatible with the LG players when formatting rewritable discs. When setting the option to Live File System, you cannot use it on LG players.
(Mastered/ Live File System : Disc format system for Windows Vista)

FB44-M0F_ENG.indd 20 2010-06-04 3:08:36

Specifications

General	
Power supply	Refer to the label attached on the unit.
Power consumption	Refer to the label attached on the unit.
Net Weight	4.9 kg
External dimensions (WxHxD)	694 x 180 x 185 mm
Operating temperature	5 ℃ - 35 ℃
Operating humity	5 % - 85 %
Output power	20 W + 20 W
T.H.D	10 %
Tuner	
FM Tuning Range	87.5 - 108.0 MHz or 87.50 - 108.00 MHz
AM Tuning Range	522 - 1,620 kHz or 522 - 1,710 kHz or 520 - 1,710 kHz
DAB Tuning Range	174 - 239 MHz
DAB Bitrate Range	8 - 256 kbps
DVD/CD	
Frequency response	40 - 20000 Hz
Signal-to-noise ratio	70 dB
Dynamic range	50 dB
Available resolution according to connection	
[HDMI OUT]	1080p, 1080i, 720p and 480p (or 576p) and 480i (or 576i)
[COMPONENT VIDEO OUT]	480p (or 576p) and 480i (or 576i)
[VIDEO OUT]	480i (or 576i)

Designs and specifications are subject to change without prior notice.

Notes on HDMI Out connection

- If your TV does not accept your resolution setting, abnormal picture appears on the screen.("TV does not support" will appears in screen)

Please read owner's manual for TV, and then set the resolution that your TV can accept.

- Changing the resolution when the unit is connected with HDMI connector may result in malfunctions. To solve the problem, turn off the unit and then turn it on again.
- When you connect a HDMI or DVI compatible device make sure of the following :
  - Try switching off the HDMI/ DVI device and this unit. Next, switch on the HDMI/ DVI device and leave it for around 30 seconds, then switch on this unit.
  - The connected device's video input is set correctly for this unit.
  - The connected device is compatible with 720X576p(480p), 1280X720p, 1920X1080i or 1920X1080p video input.
  - The 1080p, 720p and 576p(480p) resolutions are the progressive scan applied resolution.
- Not all HDCP-compatible DVI devices will work with this unit.
  - The picture will not be displayed properly with non-HDCP device.

HDMI, the HDMI logo and High-Definition Multimedia Interface are trademarks or registered trademarks of HDMI licensing LLC.

FB44-M0F_ENG.indd 21 2010-06-04 3:08:36

POWER: This unit operates on a mains supply of 200-240V~, 50/60Hz.
WIRING: This unit is supplied with a BSI 1363 approved 13 amp mains plug, fused at 5 amp. When replacing the fuse always use a 5 amp BS 1362, BSI or ASTA approved type. Never use this plug with the fuse cover omitted. To obtain a replacement fuse cover contact your dealer. If the type of plug supplied is not suitable for the mains sockets in your home, then the plug should be removed and a suitable type fitted. Please refer to the wiring instructions below:
WARNING: A mains plug removed from the mains lead of this unit must be destroyed. A mains plug with bared wires is hazardous if inserted in a mains socket. Do not connect either wire to the earth pin, marked with the letter E or with the earth symbol ⏚ or coloured green or green and yellow. If any other plug is fitted, use a 5 amp fuse, either in the plug, or at the distribution board.
IMPORTANT: The wires in this mains lead are coloured in accordance with the following codes:
- BLUE: NEUTRAL, BROWN: LIVE - As the colours of the wires in the mains lead of this unit may not correspond with the coloured marking identifying the terminals in your plug, proceed as follows: The wire which is coloured blue must be connected to the terminal which is marked with the letter N or coloured black. The wire which is coloured brown must be connected to the terminal which is marked with the letter L or coloured red.

Made for iPod

iPod is a trademark of Apple Inc., registered in the U.S. and other countries.

ENERGY STAR

As an ENERGY STAR® Partner, LG has determined that this product or product models meet the ENERGY STAR® guidelines for energy efficiency.

ENERGY STAR® is a U.S. registered mark.

FB44-M0F_ENG.indd 22 2010-06-04 3:08:36

FB44-M0F_ENG.indd 23 2010-06-04 3:08:36

Technology with the human touch

GUARANTEE

- LG Electronics U.K. Ltd. will provide the following services in order to expedite this Guarantee.

1. All faulty components which fail due to defective manufacture will be replaced free of charge for a period of 12 months from the original date of purchase.
2. The dealer (or his service agent) who sold the product will be reimbursed for any labour provided in the repair of this LG equipment, for a period of 12 months from the original date of purchase. These claims must be made in accordance with the published scale of service charges and relevant claims procedure.

PLEASE NOTE:

A. The dealer may restrict the guarantee to the original purchaser.

B. The dealer is not obliged to carry out service under guarantee if unauthorized modifications are made to the apparatus, or if non standard components are used or if the serial number of the apparatus is removed, defaced, misused, or altered.

C. Any claims made under guarantee must be directed to the dealer from whom the equipment was originally purchased. The dealer may, before carrying out service under guarantee, require a receipted account as evidence of the date of purchase.

D. We respectfully point out that your dealer is not obligated to replace batteries if they become exhausted or worn in use.

E. Aerial alignment and consumer control adjustments are not covered by this guarantee.

This guarantee does not affect your statutory rights.

- REQUIREMENTS TO MAINTAIN WARRANTY COVERAGE:

  RETAIN YOUR RECEIPT TO PROVE DATE OF PURCHASE. A COPY OF YOUR RECEIPT MUST BE SURRENDERED AT THE TIME GUARANTEE SERVICE IS PROVED.

- Product Registration Card : It is helpful to complete at least your name, address, phone, model & serial numbers and return it. This will enable LG to assist you in the future should you lose your receipt, your units be stolen, or should modifications be necessary.

- To obtain information or assistance: Call 0870 873 5454 Monday-Friday 9.00am-4.30pm

MODEL NO.*	SERIAL NO.*	DATE OF PURCHASE.*

* Please complete for your own record

In all cases of difficulty - consult your LG dealer from whom the product was purchased

LGEUK Website : www.lge.co.uk
(service website : www.lgelectronics.co.uk)