LG
Life's Good

OWNER'S MANUAL

ROOM AIR CONDITIONER

Please read this manual carefully before operating your set and retain it for future reference.

TYPE : WINDOW

P/NO.:MFL70206101

www.lg.com

TABLE OF CONTENTS

1. Safety Precautions.....3

2. Operating Instructions.....8

3. Care and Maintenance...10

4. Hardware Installation.....12

5. Common Issues.....18

FOR YOUR RECORDS

Write the model and serial numbers here:

Model #

Serial #

You can find them on a label on the side of each unit.

Dealer's Name

Date Purchased

■ Staple your receipt to this page in the event you need it to prove date of purchase or for warranty issues.

READ THIS MANUAL

Inside you will find many helpful hints on how to use and maintain your air conditioner properly. Just a little preventive care on your part can save you a great deal of time and money over the life of your air conditioner.

You'll find many answers to common problems in the chart of troubleshooting tips. If you review our chart of

Troubleshooting Tips first, you may not need to call for service at all.

PRECAUTION

- **Contact the authorized service technician for repair or maintenance of this unit.**
- **Contact the installer for installation of this unit.**
- **The air conditioner is not intended for use by young children or invalids without supervision.**
- **Young children should be supervised to ensure that they do not play with the air conditioner.**
- **When the power cord is to be replaced, replacement work shall be performed by authorized personnel only using only genuine replacement parts.**
- **Installation work must be performed in accordance with the National Electric Code by qualified and authorized personnel only.**



Precautions

To prevent injury to the user or other people and property damage, the following instructions must be followed.

■ Incorrect operation due to ignoring instruction will cause harm or damage. The seriousness is classified by the following indications.

⚠**WARNING**	This symbol indicates the possibility of death or serious injury.
⚠**CAUTION**	This symbol indicates the possibility of injury or damage to properties only.

■ Meanings of symbols used in this manual are as shown below.

⊗	**Be sure not to do.**
❗	**Be sure to follow the instruction.**

⚠WARNING

■ Installation

Always install the expansion panel(s).

• No installation may cause fire and electric shock accident.



Do not place the power cord near a heater.

• It may cause fire and electric shock.



Do not use the power cord near flammable gas or combustibles such as gasoline, benzene, thinner, etc.

• It may cause explosion or fire.



Do not disassemble or modify products.

• It may cause failure and electric shock.



■ Operation

Plug in the power plug properly.

- Otherwise, it will cause electric shock or fire due to heat generation.



Do not operate or stop the unit by inserting or pulling out the power plug.

- It will cause electric shock or fire due to heat generation.



Do not damage or use an unspecified power cord.

- It will cause electric shock or fire.



Do not modify power cord length.

- It will cause electric shock or fire due to heat generation.



Do not share the outlet with other appliances.

- Otherwise, it will cause electric shock or fire due to heat generation.



Always plug into a grounded outlet.

- No grounding may cause electric shock (See Installation Manual).



Unplug the unit if strange sounds, odors, or smoke come from it.

- Otherwise it may cause fire and electric shock accident.



Do not use the socket and power cord if it is loose or damaged.

- It may cause fire and electric shock.



Do not operate with wet hands or in damp environment.

- It will cause electric shock.



Do not allow water to run into electric parts.

- It will cause failure of machine or electric shock.



Leave the door closed while the air conditioner is running.

- It is not designed to cool the entire house.



Do not operate the air conditioner if you smell gas.

- It may cause explosion, fire, and burn.



⚠CAUTION

■ Installation

Never touch the metal parts of the unit when removing the filter.

- They are sharp and may cause injury.



Do not block the inlet or outlet.

- It may cause failure of appliance or accident.



Ensure that the Cabinet is not damaged by age or wear.

- If leaving appliance damaged, there is concern of damage due to the falling of product.



■ Operation

Be cautious not to touch the sharp edges when installing.

- It may cause injury.



Hold the plug by the hand (not the cable) when taking it out.

- It may cause electric shock and damage.



Turn off the main power switch when not using it for a long time.

- Prevent accidental startup and the possibility of injury.



Do not place heavy object on the power cord and take care so that the cord should not be pressed.

• There is danger of fire or electric shock.



If water enters the product, turn off the the power switch of the main body of appliance. Contact service center after taking the power-plug out from the socket.



Do not clean the air conditioner with water.

• Water may enter the unit and degrade the insulation. It may cause an electric shock.



Turn off the power and breaker firstly when cleansing the unit.

• Since the fan rotates at high speed during operation, it may cause injury.



Do not put a pet or house plant where it will be exposed to direct air flow.

• This could injure the pet or plant.



Do not use this appliance for special purposes such as cooling pets, foods, precision machinery, or objects of art.

• It is an air conditioner, not a precision refrigeration system.



Always insert the filter securely.
Clean it every two weeks.

• Operation without filters will cause failure.



Use a soft cloth to clean. Do not use wax, thinner, or a strong detergent.

• The appearance of the air conditioner may deteriorate, change color, or develop surface flaws.



Do not drink water drained from air conditioner. / Do not direct airflow at room occupants only.

• It contains containments and will make you sick. / This could damage your health.



Prior to Operation

Preparing for operation

1. Contact an installation specialist for installation.
2. Plug in the power plug properly.
3. Do not use a damaged or non-standard power cord.
4. Do not share the same outlet with other appliances.
5. Do not use an extension cord.
6. Do not start/stop operation by plugging/unplugging the power cord.

Usage

1. Being exposed to direct airflow for an extended period of time could be hazardous to your health. Do not expose occupants, pets, or plants to direct airflow for extended periods of time.
2. Due to the possibility of oxygen deficiency, ventilate the room when used together with stoves or other heating devices.
3. Do not use this air conditioner for non-specified special purposes (e.g. preserving precision devices, food, pets, plants, and art objects). Usage in such a manner could harm such property.

Cleaning and maintenance

1. Do not touch the metal parts of the unit when removing the filter. Injuries can occur when handling sharp metal edges.
2. Do not use water to clean inside the air conditioner. Exposure to water can destroy the insulation, leading to possible electric shock.
3. When cleaning the unit, first make sure that the power and breaker are turned off. The fan rotates at a very high speed during operation. There is a possibility of injury if the unit's power is accidentally triggered on while cleaning inner parts of the unit.

Service

For repair and maintenance, contact your authorized service dealer.

Operating Temperature

COOLING MODE			
INDOOR		OUTDOOR	
MAX.	MIN.	MAX.	MIN.
32 °C	21 °C	48 °C	21 °C

Remote Control Operations

The remote control and control panel will look like one of the following pictures.





1 POWER

Operation starts when this button is pressed and stops when you press the button again.

2 OPERATION MODE SELECTOR

Select cooling mode to cool the room.

Select fan mode for basic ventilating fan operation.

Dry mode is used to remove humidity from the room without additional cooling .Once the set temperatureies reached , the compressor and circulation fan turns off , Fan speed is pre-set and cannot be adjusted.

3 ON/OFF TIMER

The timer can be set to start and stop the unit in hourly increments (up to 12 hours).

4 FAN SPEED SELECTOR

Press this button repeatedly to adjust the fan speed: High[F3]→Low[F1]→Med[F2]

For increased power while cooling select a higher fan speed.

5 TEMPERATURE CONTROL

The thermostat monitors room temperature to maintain the desired temperature.

The thermostat can be set between 16 °C~30 °C (61 °F~86 °F).

The unit takes an average of 30 minutes to adjust the room temperature by 1 °C (1.8 °F).

6 AUTO SWING BUTTON (available in some models)

Allows the unit to automatically swing its louvers left and right during operation. If the option is de-selected, the louvers will stop in their last position and orient the airflow in the corresponding direction.

7 REMOTE SENSOR

When using the remote control, hold its transmitter facing the sensor.

8 ENERGY SAVER

The fan stops when the compressor stops cooling.

Approximately every 3 munutes the fan will turn on and check the room air to determine if cooling is needed.

Auto Restart

In case the power comes on again after a power failure, Auto Restarting Operation is the function to operate procedures automatically to the previous operating conditions.

Inserting the Remote Control Batteries (AAA size)

1. Push out the cover on the back of the remote control with your thumb.
2. Pay attention to polarity and insert two new AAA 1.5 V batteries.
3. Reattach the cover.



NOTICE Do not use rechargeable batteries. Make sure that both batteries are new.

- In order to prevent discharge, remove the batteries from the remote control if the air conditioner is not going to be used for an extended period of time
  Keep the remote control away from extremely hot or humid places.
  To maintain optimal operation of the remote control, the remote sensor should not be exposed to direct sunlight.
- The remote control can be mounted on a wall using the mountable holder.



Adjusting the Air Flow Direction

Vent Control

The vent control is located above the control knobs.

For maximum cooling efficiency, CLOSE the vent. This will allow internal air circulation.

OPEN the vent to discharge stale air.



CLOSE VENT OPEN

To open the vent, pull the lever toward you. To close it, push it in.

Adjusting the air flow Direction

Airflow can be adjusted by changing the direction of the air conditioner's louvers. This can also increase the cooling efficiency of the air conditioner.



Adjusting Horizontal Air Flow Direction

Adjusting the vertical louvers left and right will change horizontal airflow.

Adjusting Vertical Air flow Direction

Adjusting the horizontal louvers up and down will change vertical airflow. The louvers can be adjusted by nudging the back or up and down of the vertical louvers.

Recommended Orientation of louvers

Adjust louvers to face upwards when cooling to maximize cooling efficiency.



Care and Maintenance

Turn the power off and unplug the power plug before cleaning the air conditioner.

Grille and Cabinet

Use water and mild detergent when cleaning. Do not use bleach or harsh abrasives.

Rear Coils

Check the rear coils on a regular basis. It should be professionally steam- cleaned if it is clogged with dirt or soot. Professional cleaning service is available at your local dealer or service center.



Air Filter

The air filter behind the inlet grille should be checked and cleaned at least once every 2 weeks (or as necessary) to maintain optimal performance of the air conditioner.



How to remove the air filter

1. The grille may be opened from the bottom for easy maintenance after installation.
2. Open the inlet grille by pulling off the exposed door on the bottom of the unit (based on installation).
3. Pull the tab slightly to release the filter. Pull the filter in the same direction as the opening.
4. Clean the filter with warm, soapy water. The water should be below 40 °C (104 °F).
5. Rinse it off and gently shake off excess water from the filter. Let it dry before replacing it.



NOTICE Mark ∆ of inlet grille means opening direction.

Drainage (Optional)

The base pan may overflow due to high humidity. To drain the excess water, remove the drain cap from the back of the unit and secure the drainpipe.



1. Take the drain pan which is shipped in the air discharge or on the Cabinet.
2. Remove the rubber plug from the bottom of the base pan.
3. Install the drain pan over the corner of the cabinet where you removed the plug with 4 (or 2) screws.
4. Connect the drain hose to the outlet located at the bottom of the drain pan. You can purchase the drain hose or tubing locally to satisfy your particular needs. (Drain hose is not supplied).
5. Select the most appropriate connection from among the following figures (by considering the hole of the unit) to fit drain pan to your own unit.



Fig. 1



Fig. 2



Fig. 3



Fig. 4

Hardware Installation

Product Features

CAUTION : This appliance should be installed in accordance with national wiring regulations. This guide acts as a guide to help to explain product features.



1. CABINET
2. FRONT GRILLE
3. AIR FILTER
4. AIR INTAKE (INLET GRILLE)
5. AIR DISCHARGE
6. VERTICAL AIR DEFLECTOR (HORIZONTAL LOUVER)
7. HORIZONTAL AIR DEFLECTOR (VERTICAL LOUVER)
8. EVAPORATOR
9. CONTROL PANEL
10. POWER CORD
11. COMPRESSOR
12. BASE PAN
13. BRACE
14. CONDENSER
15. REMOTE CONTROLLER

Circuit Breaker Installation and Parts for Installation

Read thoroughly and follow all directions provided.

A circuit breaker must be installed between the power source and the unit if the plug is not used (see illustration below).



NOTICE

Use 15A circuit breaker.



Installation Steps

Select the Best Location

1. Measure the space for installation to assure a good fit. The air conditioner must be installed firmly into place to prevent vibration and noise.
2. Avoid exposure to direct sunlight.
3. Remove all obstacles from the rear of the unit. There must be at least 50 cm (20in.) of cleared space around the rear of the unit. Obstacles restricting the airflow may reduce the cooling efficiency of the unit.
4. The unit should be installed with a slight tilt towards the outside (approx. 3°) to allow condensed water to drain. (About 10~15mm or 1/4 bubble with level)





NOTICE The external grille must be exposed outside for air discharge.

Remove the Air Conditioner From the Cabinet

1. Remove 2 shipping screws from the back of the cabinet.
2. Remove the 2 screws on each side of the cabinet. Keep these for later use.
3. Slide out the air conditioner from the cabinet by pulling the base-pan handle while bracing the cabinet.
4. Remove the white Styrofoam shipping block from the compressor. (Applicable for some models)



Attaching the Drain Pan (Optional)

The drain pan is used to collect condensed water.

The base-pan may overflow due to high humidity. The base-pan may also collect excess water when in reverse mode (in Reverse Cycle models only). To drain the excess water, remove the drain cap from the back of the unit and secure the drainpipe as follows:

1. Remove the drain pan located in the air discharge or on the cabinet.
2. Remove the rubber cap from the hole on the base-pan. (Not applicable to all models)
3. Install the drain pan to the left corner of the cabinet with 2-4 screws.
4. Connect the drain hose to the hole located on the bottom of the drain pan.

You can purchase the drain hose or tubing locally to satisfy your particular needs. (Drain hose not included)

Installation of the Cabinet

Step 1

Remove the air conditioner from it's packaging and slide the air conditioner out of it's housing.

Step 2

Prepare the hole in the wall so that the bottom of the housing is well supported, the top has minimum clearance and the air inlet louveres have clearance as shown. Holes from the outside through to the cavity should be sealed. The housing should slope down towards the rear by about 5mm to allow water formed during operation to drain.

Step 3

Install the housing into the wall and secure. Ensure the foam seals are not damaged. Flash, seal or fill gaps around the inside and outside to provide satisfactory appearance and protection against the weather, insects and rodents.

NOTICE UNIT MAY BE SUPPORTED BY A SOLID FRAME FROM BELOW OR BY A HANGER FROM A SOLID OVERHEAD SUPPORT.



Preferred method of installation into a timber framed wall, partition or window.

Installations of the unit into the Cabinet

1. Slide the unit into the cabinet until it is firmly against the rear of the cabinet. Care is required to ensure the foam sealing strips on the cabinet remain in position.
2. Connect the air conditioner to the power and coil excess cord length beneath the air conditioner base or control box.
3. Engage the Chassis Lock into the bottom cabinet rail and secure to the base with the screw provided.
4. Remove the front panel from it's carton and plastic bag and fit as per the Operating Instruction.
5. Switch unit on. Check for operation of the unit and check for vibration in the installation.
6. Fit the drain pan to the cabinet and run a drain line to a suitable location if required.



Alternative method of installation if external support cannot be provided.

Installations of the unit into the wall



OPTION A



OPTION B

Install the Air Conditioner in the Cabinet

1. Slide the air conditioner into the cabinet. Reinstall the 2 screws removed earlier on each side of the cabinet.



CAUTION: The power cord must be connected to an independent circuit. The green wire must be grounded.

2. Stuff the foam between the top of the unit and the wall to prevent air and insects from getting into the room.



3. Before installing the front grille, pull out the vent control lever located above the unit control knobs, as shown. (for some models)



4. Attach the front grille to the cabinet by inserting the tabs on the grille into the slots on the front of the cabinet. Push the grille in until it snaps into place. When you detach the front grille from the cabinet, push the grille to your right side and pull it toward you.





5. Lift the inlet grill and secure the front grille with a screw(L:10mm). Lower the inlet grille into place. (for some models)



Install the Frame Accessory (Optional)

If you want to decorate the gap between unit and wall,you can use the **FRAME ACCESSORY.**

1 Assembly 8 frames using screws as shown below.



2 Slide frame over the front of the air conditioner until frame is flush with the wall.



Common Problems and Solutions

Before calling for service, please review the following list of common problems and solutions.

The air conditioner is operating normally when:

- You hear a pinging noise. This is caused by water being picked up by the condenser on rainy days or in highly humid conditions. This feature is designed to help remove moisture in the air and improve cooling efficiency.
- You hear the thermostat click. This is caused by the compressor cycle starting and stopping.
- You see water dripping from the rear of the unit. Water may be collected in the base pan in highly humid conditions or on rainy days. This water overflows and drips from the rear of the unit.
- You hear the fan running while the compressor is silent. This is a normal operational feature.

The air conditioner may be operating abnormally when:

Problem	Possible Causes	What To Do
The air conditioner does not operate at all.	■The air conditioner is unplugged or not plugged in completely.	•Make sure the plug is completely plugged into the outlet.
	■The fuse is blown/circuit breaker is triggered.	•Check the fuse/circuit breaker box and replace the fuse or reset the breaker.
	■Power failure.	• In the event of a power failure, set the power control to OFF. When the power is restored, wait 3 minutes to restart the air conditioner to prevent the compressor from overloading.
Air conditioner does not cool.	■Air flow is restricted.	•Make sure there are no curtains, blinds, furniture or other obstacles in front of the air conditioner.
	■ The THERMOSTAT may not be set cool enough.	• Turn the knob to a higher setting. The highest setting provides maximum cooling.
	■The air filter is dirty.	• Clean the filter at least every 2 weeks. Refer to the **Care and Maintenance** section of the manual.
	■The air conditioner was just turned on.	•After the air conditioner is turned on, you need to give the air conditioner some time to cool the room.
	■Cold air is escaping.	•Check for open furnace floor resisters and cold air returns. • CLOSE the air conditioner vent.
	■Cooling coils are iced up.	•See “Ice appears on the air conditioner” below.
Ice appears on the air conditioner.	■The cooling coils are iced over.	•Ice may block the air flow and obstruct the air conditioner from properly cooling the room. Set the fan at MED or HIGH while setting the thermostat at 1 or 2 until the ice melts.


LG
Life's Good