LG
Life's Good

ENGLISH

OWNER'S MANUAL

# WASHING MACHINE

Please read this manual carefully before operating your washing machine and retain it for future reference.

FHT1409SNW/L/S
FHT1485SNW/L/S
FHT1285SNW/L/S
FHT1408SNW/L/S
FHT1208SNW/L/S
FHT1275SNW/L/S
FHT1075SNW/L/S
FHT1207SNW/L/S
FHT1007SNW/L/S
FHT1007HNW/L/S

MFL67584578

www.lg.com

P/NO : MFL67584578
Rev. No.: 00_22/06/2018

Copyright © 2018 LG Electronics Inc. All rights reserved.

# Product Features



- **Protection against creases**
  With the alternate rotation of the drum, creasing in the laundry is minimized.



- **Built-in heater**
  Internal heater automatically heats the water to the best temperature on selected cycles.



- **More economical by Intelligent Wash System**
  Intelligent Wash System detects the amount of load and water temperature, and then determines the optimum water level and washing time to minimize energy and water consumption.



- **Child Lock**
  The Child lock prevents children from changing the settings, if they press any button during operation.



- **Low noise speed control system**
  By sensing the amount of load and balance, it evenly distributes load to minimize the spinning noise level.



- **Auto Restart**
  Auto Restart allows the program to restart all by itself in case of power failure. It does from the stage where it stopped.




- **6 Motion**
  Washer is able to perform various drum actions or a combination of different actions depending on the wash program selected.
  Combined with a controlled spin speed and the ability of the drum to rotate both left and right, the wash performance of the machine is greatly improved, giving you perfect results every time.



- **Direct Drive System**
  The advanced Brushless DC motor directly drives the drum without belt and pulley.

* This Manual may contain images or content different from the model you purchased.
* This Manual is subject to revision by the manufacturer.

# Contents


Safety Information ..... 3
Specifications ..... 4
Installation ..... 5
Care before washing ..... 11
Adding detergent ..... 12
Function ..... 14
How to use washer ..... 15
Smart Functions ..... 22
Maintenance ..... 23
Troubleshooting guide ..... 27
Terms of Warranty ..... 31

# Safety Information

READ ALL INSTRUCTIONS AND EXPLANATION OF THE INSTALLATION BEFORE USE

**⚠ WARNING** For your safety, the information in this manual must be followed to minimize the risk of fire or explosion, electric shock, or to prevent property damage, personal injury, or loss of life.

## IMPORTANT SAFETY INSTRUCTIONS

**⚠ WARNING**

To reduce the risk of fire, electric shock, or injury to persons when using the washer, follow basic precautions, including the following:

- **Before installation, check exterior damages. If it has, do not install.**
- **Do not install or store the washer where it will be exposed to the weather (Rain / Water Splash).**
  If the product is exposed to such conditions, electric shock, fire, break down or deformation may occur.
- **Do not tamper with controls.**
  It may lead to electric shock, fire, break down or deformation.
- **Do not repair or replace any part of the washer or attempt any servicing unless specifically recommended in the user-maintenance instructions or published user-repair instructions that you understand and have the skills to carry out.**
  Operating the machine with improperly replaced parts may be a cause for fire or electric shock.
- **Keep the area underneath and around your appliances free of combustible materials such as lint, paper, rags, chemicals, etc.**
  Operating with such materials around the machine may trigger explosion or fire.
- **Close supervision is necessary if this appliance is used by or near children. Do not allow children to play on, with, or inside this or any other appliance.**
  There is a potential danger that children might drown in the tub.
- **Keep small animals away from the appliance.**
- **Do not leave the washer door open. An open door could entice children to hang on the door or crawl inside the washer.**
- **Never reach into washer while it is moving. Wait until the drum has completely stopped.**
  Even slow rotation can cause injury.
- **The laundry process can reduce the flame retardant of fabrics.To avoid such a result, carefully follow the garment manufacturer's wash and care instructions.**
- **Do not wash or dry articles that have been cleaned in, washed in, soaked in, or spotted with combustible or explosive substances (such as wax, oil, paint, gasoline, degreasers, dry-cleaning solvents, kerosene, etc.).**
  It may ignite or explode. Oil may remain in the tub after a whole cycle resulting in fire during drying.
  So, do not load oiled clothes.
- **Do not slam the washer door closed or try to force the door open when locked.**
  This could result in damage to the washer.
- **When the machine runs high temperature, the front door may be very hot. Don't touch it.**
- **To minimize the possibility of electric shock, unplug this appliance from the power supply or disconnect the washer from the household distribution panel by removing the fuse or switching off the circuit breaker before attempting any maintenance or cleaning.**
- **When unplugging power cord, do not pull out by grasping the cord.**
  Otherwise, the power cord may be damaged.
- **Never attempt to operate this appliance if it is damaged, malfunctioning, partially disassembled, or has missing or broken parts, including a damaged cord or plug.**
  Operating with a damaged plug may cause electric shock.
- **Before discarding an old machine unplug it. Render the plug useless. Cut off the cable directly behind the appliance to prevent misuse.**
- **When a product was under water, Please call service center. The risk of electric shock and fire.**
- **When washer door is opened, do not push down the door excessively.**
  This could topple over the washer.

SAVE THESE INSTRUCTIONS

## GROUNDING INSTRUCTIONS

This appliance must be grounded. In the event of malfunction or breakdown, grounding will reduce the risk of electric shock by providing a path of least resistance for electric current. This appliance is equipped with cord having an equipment-grounding conductor and grounding plug. The plug must be plugged into an appropriate outlet that is properly installed and grounded in accordance with all local codes & ordinance.

- Do not use an adapter or otherwise defect the grounding plug.
- If you don't have the proper outlet, consult an electrician.

**⚠ WARNING** Improper connection of the equipment-grounding conductor can result in risk of electric shock. Check with a qualified electrician or serviceman if you are indoubt the plug provided with the appliance-if it does not fit the outlet, have a proper outlet installed by a qualified electrician as to whether the appliance is properly grounded. Do not modify the plug provided with the appliance-if it does not fit the outlet, have a proper outlet installed by a qualified electrician.

# Specifications




1 Transit bolts
2 Power plug
3 Drawer*
4 Control panel*
5 Drum
6 Door*
7 Drain hose
8 Drain plug
9 Drain pump filter
10 Cap Cover
11 Adjustable Leg

■ Name : Front loading washing machine

■ Power supply : 220V~,50Hz

■ Size : 600mm(W) x 560mm(D) x 850mm(H)

■ Weight/Max.Watt : 62kg / 2100W

■ Wash capacity : 9.0kg : [FHT1409SNW/L/S]
8.5kg : [FHT1485SNW/L/S, FHT1285SNW/L/S]
8.0kg : [FHT1408SNW/L/S, FHT1208SNW/L/S]
7.5kg : [FHT1275SNW/L/S, FHT1075SNW/L/S]
7.0kg : [FHT1207SNW/L/S, FHT1007SNW/L/S, FHT1007HNW/L/S]

■ Spin speed : No/400/800/1000/1200/1400: [FHT1409SNW/L/S, FHT1485SNW/L/S, FHT1408SNW/L/S]
No/400/800/1000/1100/1200: [FHT1285SNW/L/S, FHT1208SNW/L/S, FHT1275SNW/L/S, FHT1207SNW/L/S]
No/400/600/800/900/1000: [FHT1075SNW/L/S, FHT1007SNW/L/S, FHT1007HNW/L/S]

■ Permissible water pressure :100-1000kPa (1.0-10kgf/cm$^2$)

- The appearance and specifications may be varied without notice to raise the **product** quality.

## ■ Accessories



Inlet hose*(1EA)



Spanner(1EA)

* Part can be different according to different models.

# Installation

**Install or store where it will not be exposed to temperatures below freezing or exposed to the weather.**
**Properly ground washer to conform with all governing codes and ordinances.**
**The base opening must not be obstructed by carpeting when the washing machine is installed on a carpeted floor.**
**In countries where there are areas which may be subjected to infestation by cockroaches or other vermin, pay particular attention in keeping the appliance and its surroundings in clean condition at all times. Any damage which may be caused by cockroaches or other vermin will not be covered by the appliance guarantee.**

## ■ Transit bolts

The appliance is fitted with transit bolts to prevent internal damage during transport.

• Packing and all transit bolts must be removed before using the Machine.

## ■ Removing transit bolts





1. To prevent internal damage during transport, the special 4 bolts are locked. Before operating the washer, remove the bolts along with the rubber bungs.
• If they are not removed, it may cause heavy vibration, noise and malfunction.
2. Unscrew the 4 bolts with the spanner supplied.
3. Take out the 4 bolts along with the rubber bungs by slightly twisting the bung. Keep the 4 bolts and the spanner for future use.
• Whenever the appliance is transported, the transit bolts must be refitted.
4. Close the holes with the caps supplied.

# Installation

## ■ Installation place requirement




**Level floor :**
Allowable slope under entire washer is 1˚
**Power outlet :**
Must be within 1.5 meters of either side of location of washer. Do not overload the outlet with more than one appliance.
**Additional Clearance :**
For wall, door and floor modeling is required.
(10cm : rear /2cm:right & left side)
Do not place or store laundry products on top of washer at any times.
They can damage the finish or controls.

## ■ Positioning

Install the washer on a flat hard floor.
Make sure that air circulation around the washer is not impeded by carpets,rug etc.

- Never try to correct any unevenness in the floor with pieces of wood, cardboard or similar materials under the washer.
- If it is impossible to avoid positioning the washer next to a gas cooker or coal burning stove,an insulation(85x60cm) covered with aluminum foil on the side facing the cooker or stove,must be inserted between the two appliances.
- The washer must not be installed in rooms where the temperature can drop below 0°C.
- Please ensure that when the washer is installed, it is easily accessible for the engineer in the event of a breakdown.
- With the washer installed adjust all four adjustable legs using the transit bolt spanner provided ensuring the appliance is stable, and a clearance of approximately 20mm is left between the top of the washer and the underside of the work-top.

**⚠WARNING**

It is advisable to avoid, the usage of trolley & the movement of Washing Machine after installation, As it may disturb the levelling of washer, which can create excessive noise & vibration.

# Installation

## ■ Electrical connection

1. Do not use an extension cord or double adapter.
2. If the supply cord is damaged, it must be replaced by the manufacturer or its service agents or equally qualified person in order to avoid a hazard.
3. Always unplug the machine and turn off the water supply after use.
4. Connect the machine to an earthed socket in accordance with current wiring regulations.
5. The appliance must be positioned so that the plug is easily accessible.

- Repairs to the washing machine must only be carried out by qualified personnel. Repairs carried out by inexperienced persons may cause injury or serious malfunctioning. Contact your local service center.
- Do not install your washing machine in rooms where temperature below freezing may occur. Frozen hoses may burst under pressure. The reliability of the electronic control unit may be impaired at temperatures below freezing point.
- If the appliance is delivered in the winter months and temperatures are below freezing : Place the washing machine at room temperature for a few hours before putting it into operation.

### ⚠CAUTION

The appliance is not intended for use by young children or infirm persons without supervision.
Young children should be supervised to ensure that they do not play with appliance.

### ⚠CAUTION

CAUTION concerning the Power Cord

Most appliances recommend they be placed upon a dedicated circuit; that is, a single outlet circuit which powers only that appliance and has no additional outlets or branch circuits. Check the specification page of this owner's manual to be certain.
Do not overload wall outlets. Overloaded wall outlets, loose or damaged wall outlets, extension cords, frayed power cords, or damaged or cracked wire insulation are dangerous. Any of these conditions could result in electric shock or fire. Periodically examine the cord of your appliance, and if its appearance indicates damage or deterioration, unplug it, discontinue use of the appliance, and have the cord replaced with an exact replacement part by an authorized service Centre.
Protect the power cord from physical or mechanical abuse, such as being twisted, kinked, pinched, closed in a door, or walked upon. Pay particular attention to plugs, wall outlets, and the point where the cord exits the appliance.

## ■ Washing Machine is to be connected to the water mains using new hose-sets and old hose-sets should not be used.

## ■ Connecting water supply hose*




- *Water supply pressure must be between 100kPa and 1000kPa (1.0~10kgf/cm²)*
- *Don't strip or crossthread when connecting Inlet hose to the valve.*
- *If the water supply pressure is more than 1000kPa, a decompression device should be installed.*
- Two rubber seals are supplied with the water inlet hoses. They are used for preventing water leaks.
- Make sure the connection to taps is tight enough.
- Periodically check the condition of the hose and replace the hose if necessary.
- Make sure that there is no kink on the hose and that it is not crushed.

**NOTE** After completing connection, if water leaks from the hose, repeat the same steps. Use the most conventional type of faucet for water supply. In case the faucet is square or too big, remove the spacing ring before inserting the faucet into the adaptor.

* Part can be different according to different models.

# Installation

## ■ Normal Tap without thread & screw type inlet hose

**1.** Unscrew the fixing screw to attach the tap.




**2.** Push the connector up till the rubber packing is in tight contact with the tap. Then tighten the 4 screws.




**3.** Push the water supply hose vertically upwards so that the rubber packing within the hose can adhere completely to the tap and then tighten it by screwing it to the right.




## ■ Normal Tap without thread & one touch type inlet hose (Single inlet models)

**1.** Untighten the upper connector screw.




- In case the diameter of the tap is large remove the guide plate.




| Use the horizontal tap | |
|---|---|
| Horizontal tap |  |
| Extension tap |  |
| Square tap |  |

**2.** Push the upper connector up till the rubber packing is in tight contact with the tap. Then tighten the 4 screws.




- Turn the middle connector not to have water leaked.
- Make sure that the rubber seal is inside the hose connector.




**3.** Connect the water supply hose to the middle connector, pushing the plate down.




- To separate the water supply hose from the middle connector shut off the tap. Then pull the inlet hose down, pushing the plate down.



- Your machine comes with only cold water connection.
- Make sure that there are no kinks in the hose and that it is not crushed.

## ■ Tap with thread & screw type inlet hose

**1.**
- Two rubber seals are provided with inlet hose connectors.
- These are used to prevent water leakage.
- Make sure the connection to tap is sufficiently tight.

**2.** Check rubber seals in inlet hose connectors.




**3.** Screw the hose connector onto water supply tap.



# Installation

This equipment is not designed for maritime use or for use mobile installations such as caravans, aircraft etc.
Turn off the stopcock if the machine is to be left for any length of time (e.g. holiday), especially if there is no floor drain(gully) in the immediate vicinity.
When disposing of the appliance, cut off the mains cable and destroy the plug. Break the door lock to prevent young children being trapped inside.
Packaging material (e.g. Films, Styrofoam,PE Bags)can be dangerous for children. There is a risk of suffocation !
Keep all packaging well away from children.

## ■ Installation of drain hose




- The drain hose should not be placed higher than 100 cm above the floor.
- Proper securing of the drain hose will protect the floor from getting wet due to water leakage.
- When the drain hose is too long, do not force back into the washer. This will cause abnormal noise/leakage.

# Installation

## ■ Level adjustment



1. Adjusting the washing machine level properly prevents excessive noise and vibration.
   Install the appliance on a solid and level floor surface, preferably in a corner of the room.

   NOTE Timber or suspended type flooring may contribute to excessive vibration and unbalance errors.




2. If the floor is uneven, adjust the adjustable leg as required. (do not insert pieces of wood etc. under the legs)
   Make sure that all four legs are stable and resting on the floor and then check that the appliance is perfectly level. (use a spirit level)

※ *After the washer is levelled, tighten all lock nuts up towards the base of the washer.*

NOTE In the case the washing machine is installed on a raised platform, it must be securely fastened in order to eliminate the risk that it might fall off.



※ *Diagonal Check*

*When pushing down the edges of the washing machine top plate diagonally, the machine should not move up and down at all. (Please, check both of two directions)*
*If machine rocks when pushing the machine top plate diagonally, adjust the legs again.*

### ■ Concrete floors

- The installation surface must be clean, dry and level.
- Install washer on a flat hard floor.

### ■ Tile floors (Slippery floors)

- Position each leg on the Tread Mate and level the machine to suit. (Cut Tread Mate into 70x70 mm sections and stick the pieces on to the dry tile where machine is to be placed.)

※ *Tread Mate is a self adhesive material used on ladders & steps that prevents slipping.*

### ■ Wooden floors (Suspended floors)




- Wooden floors are particularly susceptible to vibration.
- To prevent vibration we recommend you place rubber cups under each leg, at least 15mm thick under the washer, secured to at least 2 floor beams with screws.
- If possible, install the washer in one of the corners of the room, where the floor is more stable.

※ *Insert the rubber cups to reduce vibration.*
※ *You can obtain the rubber cups (p/no.4620ER4002B) from the LG spares dept.*

**Important!**

- Proper placement and levelling of the washer ensure long,regular and reliable operation.
- The washer must be absolutely horizontal and stand firmly in position.
- It must not “Seesaw” across corners under load.
- The installation surface must be clean, free from floor wax and other lubricant coatings.
- Do not let the legs of the washer get wet. If legs of the washer get wet, slipping may occur.

# Care before washing

## ■ Before the first washing

Select a cycle (Cotton 60°C, add a half load of detergent) allow the unit to wash without clothing. This will remove residues and water from the drum that may have been left during manufacturing.

## ■ Caring before washing

### 1. Care Labels

Look for a care label on your clothes. This will tell you about the fabric content of your garment and how it should be washed.

### 2. Sorting

To get the best results, Sort clothes into loads that can be washed with the same wash cycle. Water temperature and spin speed and different fabrics need to be washed in different ways. Always sort dark colors from pale colors and whites. Wash separately as dye and lint transfer can occur causing discoloration of white etc. If possible, do not wash heavily soiled items with lightly soiled one.

| | |
|---|---|
| Soil (Heavy, Normal, Light) ..... | Separate clothes according to amount of soil. |
| Color (White, Lights, Darks) ..... | Separate white fabrics from colored fabrics. |
| Lint (Lint producers, Collectors) ..... | Wash lint producers and lint collectors separately. |

### 3. Caring before loading

■ **Combine large and small items in a load. Load large items first. Large items should not be more than half the total wash load.**
**Do not wash single items. This may cause an out-of-balance load. Add one or two similar items.**



• Check all pockets to make sure that they are empty. Items such as nails, hair clip, matches, pens, coins and keys can damage both your washer and your clothes.



• Pre treat dirt and stains by brushing a little detergent dissolved in water onto stains like collars and cuffs to help shift dirt.



• Close zippers, hooks and strings to make sure that these items don't snag on other clothes.



• Check the folds of the flexible gasket (gray) and remove any small articles,if any.

• Check inside of the drum and remove any left items in it for next wash cycle.



• Remove any clothing or items on the flexible gasket to prevent clothing and the gasket damages.

# Adding detergent

## ■ Adding detergent and fabric softener

### 1. The Dispenser Drawer




- Main wash only ➔
- Pre Wash + Main Wash ➔ •

**⚠WARNING**

Keep all washing detergents away from children as there is danger of poisioning.
Too much detergent, bleach or softener may cause an overflow.
Be sure to use the appropriate amount of detergent.

### 2. Adding Fabric Softener




- Do not exceed the maximum fill line. Close the dispenser drawer slowly. Overfilling can cause early dispensing of the fabric softener which could stain clothes.
- Do not leave the fabric softener in the detergent drawer for more than 2 days. (Fabric softener could harden)
- Softener will be automatically added during the last rinse cycle.
- Do not open the drawer when water is supplied.
- Solvents(benzene etc) are not allowable.

NOTE Do not pour fabric softener directly on the cloths

# Adding detergent

## 3. Detergent dosage

- The detergent should be used according to the instruction of the detergent manufacturer.
- If too much detergent is used, too many suds can occur and this will decrease the washing result or cause heavy load to the motor.
- It is recommended that you use powdered detergent for best results.
- If you wish to use liquid detergent follow guidelines provided by the detergent manufacturer.
- You can pour liquid detergent directly in to the main detergent drawer if you are starting the cycle immediately.
- Please do not use liquid detergent if you are using ' Delay end' as the liquid may harden, or if you have selected 'Pre-Wash'.

※ If suds occur too much, please reduce the detergent amount.

- Detergent usage may need to be adjusted for water temperature, water hardness, size and soil level of the load. For best results, avoid oversudsing.

**⚠WARNING**

Do not let the detergent harden.
Doing so may lead to blockages,poor rinse performance or bad odor.

NOTE
- Full load : according to manufacturer's recommendation.
- Part load : 3/4 of the normal amount.
- Minimum load : 1/2 of full load.

- Detergent is flushed from the dispenser at the begining of the cycle.

## 4. Adding water softener



- A water softener, such as Anti limescale (e.g. Calgon) can be used to cut down on the use of detergent in extremely hard water areas. Dispense according to the amount specified on the packaging.
  First add detergent and then the water softener.
- Use the quantity of detergent as for soft water.

## 5. Using the Tablets



1) Open the door and put tablets into the drum.



2) Load the laundry into the drum and close the door.

# Function

## ■ Recommended courses according to the laundry type

| Program | Description | Fabric Type | Proper Temp. | Maximum Load |
|---|---|---|---|---|
| Cotton | Provides better performance by combining various drum motions. | Coloured fast garments (shirts, night-dresses, pajamas, etc.) and normally soiled cotton load (underwear). | 40 °C (Cold to 95 °C) | Rating |
| Cotton+ | Provides optimised washing performance for large amount of laundry with less energy consumption. | | 60 °C (Cold to 60 °C) | |
| Easy Care | Suitable for casual shirts that do not need ironing after washing. | Polyamide, acrylic, polyester. | 40 °C (Cold to 60 °C) | 3 kg |
| Mix | Enables various fabrics to be washed simultaneously. | Various kind of fabrics except special garments (silk/delicate, sports wear, dark clothes, wool, duvet/curtains). | 40 °C (Cold to 40 °C) | |
| Allergy Care | Helps to remove allergens such as house mites, pollen and cat fur. | Cotton, underwear, pillow covers, bed sheets, baby wear. | 60 °C | |
| Duvet | For large items such as bed covers, pillows, sofa covers, etc. | Cotton bedding except special garments (delicates, wool, silk, etc.) with filling: duvets, pillows, blankets, sofa covers with light filling. | 40°C (Cold to 40°C) | 1 single size |
| Sports Wear | Suitable for sports wear such as jogging clothes and running wear. | Coolmax, gore-tax, fleece and sympatex | 40°C (Cold to 40°C) | 2 kg |
| Baby Steam Care | Removes solid and protein stains, provides better rinse performance. | Lightly soiled baby wear. | 60 °C | 4 kg |
| Silent Wash | Provides less noise and vibration and saves money by using overnight electricity. | Coloured fast garments (shirts, night-dresses, pajamas, etc.) and lightly soiled white cotton (underwear). | 40 °C (Cold to 60 °C) | 4.5 kg |
| Dark Wash | Helps to prevent decolorization (Use detergent for colored fabrics). | Dark garments made from cotton or mixed fabrics. | 20 °C (Cold to 40 °C) | 2 kg |
| Quick 30 | Provides fast washing time for small loads and lightly soiled clothes. | Lightly soiled colour laundry. | 20 °C (Cold to 40 °C) | |
| Gentle Care | For hand and machine washable delicate clothes such as washable wool, lingerie, dresses etc. (Use detergent for machine washable woolens). | Wool, hand washable clothes, delicate, easily damaged laundry. | 20 °C (Cold to 30 °C) | 1.5 kg |
| Stain Care | Wash off several kinds of stain such as wine, juice, dirt, etc. (Water temperature is increased step by step for washing various stains). | Cotton blended fabrics, no delicate clothes. | 40 °C (30°C to 60°C) | 3 kg |
| Download Cycle | For downloadable programs. If you did not download any program, the default is Rinse+Spin. | | | |

* Water Temperature: Select the water temperature to the wash cycles.
Always follow garment manufacturer's care label or instructions when laundering.
* Notes: Neutral detergent is recommended.

## **Extra Options

| Program | Time Save | Intensive | Rinse+ | Delay End | Crease Care | Pre Wash |
|---|---|---|---|---|---|---|
| Cotton | • | • | • | • | • | • |
| Cotton+ | • | | • | • | • | • |
| Easy Care | • | • | • | • | • | • |
| Mix | • | • | • | • | • | • |
| Allergy Care | | • | • | • | • | |
| Baby Steam Care | | • | • | • | • | |
| Silent Wash | | • | • | • | • | |
| Duvet | | • | • | • | • | |
| Sports Wear | | • | • | • | • | |
| Dark Wash | | • | • | • | • | |
| Quick 30 | | • | • | • | • | • |
| Gentle Care | | | • | • | • | |
| Stain Care | | | • | • | • | • |

** Extra Options selection can vary depending on different models.

# How to use washer

*Part can be different according to different models.

## Control Panel




### 1 Power Button

- Press the **Power** button to turn the washing machine on.

### 2 Start/Pause Button

- This **Start/Pause** button is used to start the wash cycle or pause the wash cycle.
- If a temporary stop of the wash cycle is needed, press the **Start/Pause** button.

### 3 Display

- The display shows the settings, estimated time remaining, options, and status messages. When the product is turned on, the default settings in the display will illuminate.
- The display shows estimate time remaining. While the size of the load is being calculated automatically, blinking or 'Detecting' appears.
- The RPM may differ depending on the models.

### 4 Program Knob

- Programs are available according to the laundry type.
- The lamp will light up to indicate the selected program.

### 5 Options

- This allows you to select an additional program and will light when selected.
- Use these buttons to select the desired program options for the selected cycle.

## Beep On / Off

1. Press the **Power** button.
2. Press the **Start/Pause** button.
3. Press and hold the **Temp.** and **Delay End** button simultaneously for 3 seconds to set the Beep on/off function.

### NOTE

- Once the Beep on/off function is set, the setting is memorized even after the power is turned off.
- If you want to turn the Beeper off, simply repeat this process.

# How to use washer

*Part can be different according to different models.




(1) Button : Power
(2) Button : Start / Pause
(3) Display
(4) Dial : Program
(5) Options

## Power



### 1. Power

- Press the Power button to turn the washing machine ON/OFF.
- To cancel the Time Delay function, the power button should be pressed.

### 2. Initial Program

- When the Power button is pressed, the washer is ready for Cotton program and the other initial conditions as follows.
- So, if you want to advance into the washing cycle without changing the program, just press the **Start/Pause** button and then the washer will proceed.

■ *Initial program*

**[FHT1409SNW/L/S, FHT1485SNW/L/S, FHT1408SNW/L/S]**
Cotton Program/Main Wash/
Normal Rinse/1400rpm/40°C
**[FHT1285SNW/L/S, FHT1208SNW/L/S, FHT1275SNW/L/S, FHT1207SNW/L/S]**
Cotton Program/Main Wash/
Normal Rinse/1200rpm/40°C
**[FHT1075SNW/L/S, FHT1007SNW/L/S, FHT1007HNW/L/S]**
Cotton Program/Main Wash/
Normal Rinse/1000rpm/40°C

## Program




- 14 programs are available according to the laundry type.
- Lamp will light up to indicate selected program.

- When **Start/Pause** button is pressed, the Cotton program is automatically selected.
- By turning the Program dial, the program is selected in order of

**"Cotton - Cotton+ ▢ - Mix - Easy Care - Duvet-Allergy Care - Baby Steam Care - Download Cycle - Quick 30 - Silent Wash - Stain Care - Dark Wash - Gentle Care - Sports Wear"**

***Regarding to the laundry type for each program Please refer to the page 14.***

# How to use washer

## Start/Pause



### 1. Start

- This **Start/Pause** button is used to start wash cycle or pause the wash cycle.

### 2. Pause

- If temporary stop of wash cycle is needed, press the **Start/Pause** button.
- When in Pause, the power is turned off automatically after 4 minutes approx.

## Door Lock



- Lights whenever the door of the washer is locked.
- The door can be unlocked by pressing the Start/Pause button to stop the washer.
- The door can be opened after a short delay.

## Detecting



- While the " " is shown in the display the machine rotates slowly and detects how much laundry is loaded in the drum. It will take a few seconds.

## Option




- By Pressing the Option Button, all Option functions may be selected.

### 1. Intensive

- If the laundry is heavily soiled "Intensive" option is effective.
- By selecting the intensive option, the wash time may be extended, depending on the program selected.

### 2. Time Save

- This option can be used to reduce the time of a wash program. It is best used on lightly soiled loads.

### 3. Rinse+

- Additional Rinse for better washing quality.

### 4. Delay End

- You can set a time delay so that the washing machine will start automatically and finish after a specified time interval.

### 5. Add Item

Laundry can be added or removed after the washing program is started.

1. Press the **Add Item** button when the LED is turned on. 2. Add or remove laundry.
3. Close the door and Press the **Start/Pause** button.

**NOTE**

- For safety reasons, the door remains locked when the water level or temperature is high. It is not possible to add laundry during this time.
- If the water temperature in the drum is high, wait until it cools down.

**⚠ CAUTION**

- When adding laundry, make sure to completely push it into the drum. If laundry gets stuck in the door latch hole, the rubber packing may be damaged, causing water leakage and malfunction.
- Forcing the door open may cause part damage, destruction, or safety problems.
- If you open the door while there are a lot of suds and water in the drum, the suds or water may flow, causing burn injury or wet floor.

***The required lamp will light up for identification.***

## Pre Wash

- If the laundry is heavily soiled, the Pre Wash program is recommended (Press for about three seconds).

# How to use washer

## Tub Clean ( )




Tub Clean course can be set by pressing ***Tub Clean** (About three seconds)

When Tub Clean course is set, display " tcL " .




**TUB CLEAN** is special cycle to clean inside of the washer.This cycle uses higher water level with higher spin speed.Perform this cycle regularly.

**How to use the Tub Clean cycle:**

1. Remove any clothing or items from the washer and close the door.
2. Open the dispenser drawer and add Anti limescale (Calgon) to the main wash compartment.

**NOTE :** Do not add any detergent to the detergent compartments.Excessive suds may generate & leak from the washer.

3. Close the dispenser drawer slowly.
4. Power On and then press and hold ***Tub Clean** for 3 seconds. then " tcL " is displayed in LED.
5. Press the Start/Pause button to start.
6. After the cycle is complete, leave the door open so that moisture present inside the washer can dry.

**⚠CAUTION**

If there is a small child, be careful not to leave the door open for too long.

## Crease Care ( )

- If you want to prevent creasing, the Crease Care program is recommended (Press for about three seconds).

## Child Lock ( )




If you choose to lock the buttons on the control assembly to prevent tampering this function may be selected.

- Child Lock can be set by pressing the ***Child Lock** (About three seconds)




- To deactivate Child Lock system, press ***Child Lock** again. (About three seconds)




- To change to the desired program, whilst in child lock mode.

1. Press ***Child Lock** once again. (About three seconds)
2. Press the **Start/Pause** button.
3. Select the desired program and press the **Start/Pause** button again.




The child lock can be set at any time and it can be deactivated only by using child lock cancel process. Turning the power off and operational errors will not affect child lock.

# How to use washer

## Spin

| | | |
|---|---|---|
| No 400 800<br>1000 1200 1400 | Spin | FHT1409SNW/L/S<br>FHT1485SNW/L/S<br>FHT1408SNW/L/S |
| No 400 800<br>1000 1100 1200 | Spin | FHT1285SNW/L/S<br>FHT1208SNW/L/S<br>FHT1275SNW/L/S<br>FHT1207SNW/L/S |
| No 400 600<br>800 900 1000 | Spin | FHT1075SNW/L/S<br>FHT1007SNW/L/S<br>FHT1007HNW/L/S |

- After selecting the spin course,the spin speed can be chosen by pressing the spin button.

### 1. Spin selection

- Spin Speed is available according to the program as follows

**[FHT1409SNW/L/S, FHT1485SNW/L/S, FHT1408SNW/L/S]**

**-Cotton, Cotton+ ◯, Download Cycle, Mix, Allergy Care, Stain Care, Dark Wash, Quick 30**
No-400-800-1000-1200-1400
**-Silent Wash, Easy Care, Duvet, Baby Steam Care**
No-400-800-1000
**-Sports Wear, Gentle Care**
No-400-800

**[FHT1285SNW/L/S, FHT1208SNW/L/S, FHT1275SNW/L/S, FHT1207SNW/L/S]**

**-Cotton, Cotton+ ◯, Download Cycle, Mix, Allergy Care, Stain Care, Dark Wash, Quick 30**
No-400-800-1000-1100-1200
**-Silent Wash, Easy Care, Duvet, Baby Steam Care**
No-400-800-1000
**-Sports Wear, Gentle Care**
No-400-800

**[FHT1075SNW/L/S, FHT1007SNW/L/S, FHT1007HNW/L/S]**

**-Cotton, Cotton+ ◯, Download Cycle, Mix, Allergy Care, Stain Care, Dark Wash, Quick 30**
No-400-600-800-900-1000
**-Silent Wash, Easy Care, Duvet, Baby Steam Care**
No-400-600-800
**-Sports Wear, Gentle Care**
No-400-600

### 2. No spin

- If No spin is selected, the washer stops after draining water.

***The required lamp will light up for identification.***

# How to use washer

## Water Temp.




- By pressing the Temp. button, the water temperature can be selected.
- ***Cold***
- ***20˚C / 30˚C / 40˚C / 60˚C / 95˚C***

- Water temperature can be selected according to the program.

***The required temperature lamp will light up for identification.***

***For the more detailed information, please refer to the page14.***

## Delay End




***Preparing washing before starting "Delay End"***

- Turn on the water tap.
- Load laundry and close the door.
- Place the detergent and fabric softener in the drawer.

- How to set " **Delay End** "
  - Press **Power** button.
  - Turn the **Program** dial to select the program you require.
  - Press **Delay End** button and set the desired time.
  - Press the **Start/Pause** button. (":" blinks.)
- If **Delay End** button is pressed, "3:00" is displayed. The maximum delayed time is 19 hours and the minimum time is 3 hours.
- Each pressing of the button advances on time delay by one hour.
- To cancel the **Delay End**, press the **Power** button.
- **Delay End** is 'expected time' from the present to the completion of washing cycle or selected process (Wash, Rinse, Spin).
- ***According to the condition of water supply and temperature, the delayed time and the actual washing time may vary.***

# How to use washer

## Display




### 1. Special function display

- When child lock is selected, the "CL" is displayed.
- When time delay is selected, it shows the remaining time to finish the selected program.

### 2. Self diagnosis display

- If the machine encounters a fault during operation, the associated fault will be displayed.

"PE" : Water pressure sensing error
"FE" : Problem of overfilling water
"dE" : Door is not closed
"LE" : Over load in motor
"IE" : Water inlet trouble
"OE" : Drainage trouble
"UE" : Unbalanced load
"tE" : Water temperature trouble
"FF" : Supply/Drain hose or drain pump frozen
"AE" : Water Leaks
"dHE" : Does not dry

***If these error letters are displayed, please refer to the troubleshooting page and follow the guide.***

### 3. Completion of washing

- When washing cycle is completed, "End" is displayed on the "***Multi display***".

### 4. Time left

- During washing cycle, the remaining washing time is displayed.
- The washing time may vary by the amount of laundry, water pressure, water temperature and other washing conditions.
- If an unbalanced load is detected or if the suds removing program operates, the wash time may be extended.

## Using the Tag On Function

Conveniently use the Smart Diagnosis™ to communicate with the appliance directly from a smart phone.

- The Tag On function can only be used with most smart phones equipped with the NFC (Near Field Communication) function and based on the Android OS (operating system).

### Installation of the Application

- Search LG SmartThinQ application on the Google Play Store or Apple App Store from your smart phone.




## Using the Application

LG SmartThinQ application allows you to use various features for your convenience.

- Cycle Download
- Smart Diagnosis™
- Tag On Cycle Set
- Laundry Stats

**NOTE**

- Press ? in the LG SmartThinQ application for a more detailed guide on how to use the Tag On function.
- Depending on the smart phone manufacturer and Android OS version, the NFC activation process may differ. Refer to the manual of your smart phone for details.
- Because of the characteristics of NFC, if the transmission distance is too far, or if there is a metal sticker or a protective case on the phone, transmission will not be good. In some cases, NFC-equipped phones may be unable to transmit successfully.
- The content found in this manual may differ depending on the version of LG SmartThinQ application, and it may be modified without notice to users.

### Download Cycle

Download new and special cycles that are not included in the basic cycles on the appliance.

Appliances that have been successfully registered can download a variety of specialty cycles specific to the appliance.

Only one cycle can be stored on the appliance at a time.

Once cycle download is completed in the appliance, the product keeps the downloaded cycle until a new cycle is downloaded.

# Maintenance

* **Before cleaning the washer interior, unplug the electrical power cord to avoid electrical shock to avoid electrical shock hazards.**
* **When disposing of the appliance, cut off the mains cable, and destroy the plug. Disable the door lock to prevent young children being trapped inside.**

## ■ The water inlet filter

- " IE " error message will blink on the control panel when water does not enter the detergent drawer.

- If water is very hard or contains traces of lime deposit, the water inlet filter may become clogged.
It is therefore a good idea to clean it from time to time.



1. Turn off the water tap.



2. Unscrew the water inlet hose.



3. Clean the filter using a hard bristle brush.



4. Tighten up the inlet hose.

# Maintenance

## ■ The drain pump filter

✻ The drain filter collects threads and small objects left in the laundry.
Check regularly that the filter is clean to ensure smooth running of your machine.

⚠CAUTION First drain using the drain hose and then open the pump filter to remove whatever any threads or objects.
Be careful when draining if the water is hot.

✻ Allow the water to cool down before cleaning the drain pump, carrying out emergency emptying or opening the door in an emergency.




**1.** Open the lower cover cap (①) by using a coin.
Drain plug (②) to pull out the hose.




**2.** Unplug the drain plug (②), allowing the water to flow out. At this time use a vessel to prevent water flowing on to the floor. When water does not flow any more, turn the pump filter (③) open to the left.



**3.** Remove out any foreign material from the pump filter (③).




**4.** After cleaning, turn the pump filter (③) clockwise and insert the drain plug (②)to the original place. Close the lower cover cap.



# Maintenance

## ■ Dispenser drawer

❋ After a while detergents and fabric softeners leave a deposit in the drawer.

- It should be cleaned from time to time with a jet of running water.
- If necessary it can be removed completely from the machine by pressing the latch downwards and by pulling it out.
- To facilitate cleaning, the upper part of the fabric softener compartment can be removed.



## ■ The drawer recess

❋ Detergent can also accumulate inside the recess which should be cleaned occasionally with an old toothbrush.

- Once you have finished cleaning, replace the drawer and run a rinse cycle without laundry.



## ■ The washing drum

- If you live in a hard water area, limescale may continuously build up in places where it cannot be seen and thus not easily removed.
  Over time the build up of scale clogs appliances, and if it is not kept in check these may have to be replaced.
- Although the washing drum is made of Stainless steel, specks of rust can be caused by small metal articles (paper clips, safety pins) which have been left in the drum.
- The washing drum should be cleaned from time to time.
- If you use descaling agents, dyes or bleaches, make sure they are suitable for washing machine use.

❋ Descaler may contain chemicals that may damage part of your washing machine.

❋ Remove any spots with a stainless steel cleaning agent.

❋ Never use steel wool.

# Maintenance

## ■ Cleaning your washer

### 1. Exterior

Proper care of your washer can extend its life.

The outside of the machine can be cleaned with warm water and a neutral non abrasive household detergent.

Immediately wipe off any spills. Wipe with damp cloth.

Try not to hit surface with sharp objects.

✻ IMPORTANT: Do not use methylated spirits, diluents or similar products.

### 2. Interior

Dry around the washer door opening, flexible gasket and door glass.

Run washer through a complete cycle using hot water.
Repeat process if necessary.

NOTE Remove hard water deposits using only cleaners labeled as washer safe.

## ■ Cold condition

If the washer is stored in an area where freezing may occur or moved in freezing temperatures, follow these instructions to prevent damage to the washer:

1. Turn off water supply tap.
2. Disconnect hoses from water supply and drain water from hoses.
3. Plug electrical cord into a properly grounded electrical outlet.
4. Add 1gallon(3.8L) of nontoxic recreational vehicle(RV) antifreeze into an empty wash drum. Close the door.
5. Set spin cycle and let washer spin for 1minute to drain out all water.
   Not all of the RV antifreeze will be expelled.
6. Unplug electrical power cord, dry the drum interior, and close the door.
7. Remove dispenser drawer drain and dry excessive water from the compartments.
8. Store washer in an upright position.
9. To remove antifreeze from washer after storage, run empty washer through a complete cycle using detergent. Do not add wash load.

# Troubleshooting guide

✳ **This washing machine is equipped with automatic safety functions which detect and diagnose faults at an early stage and react appropriately**
**When the machine does not function properly or does not function at all, check the following points before you contact your service provider.**

| Symptom | Possible Cause | Solution |
|---|---|---|
| Rattling and clanking noise | • Foreign objects such as coins or safety pins maybe in drum or pump. | Stop washer and check drum and drain filter. If noise continues after washer is restarted, call your authorised service centre. |
| Thumping sound | • Heavy wash loads may produce a thumping sound. This is usually normal. | If sound continues, washer is probably out of balance. Stop and redistribute wash load. |
| Vibrating noise | • Have all the transit bolts and packing been removed?<br>• Are all the feet resting firmly on the ground? | If not removed during installation. Refer to Installation guide for removing transit bolts.<br>Wash load may be unevenly distributed in drum. Stop washer and rearrange wash load. |
| Water leaks | • Fill hoses or drain hose are loose at tap or washer. | Check and tighten hose connections. |
| | • House drain pipes are clogged. | Unclog drain pipe. Contact plumber if necessary. |
| Oversudsing | | Too much detergent or unsuitable detergent may cause excessive foaming which may result in water leaks. |
| Water does not enter washer or it enters slowly | • Water supply is not adequate in area. | Check another tap in the house. |
| | • Water supply tap is not completely open. | Fully open tap. |
| | • Water inlet hose(s) are kinked. | Straighten hose. |
| | • The filter of the inlet hose(s) clogged. | Check the filter of the inlet hose. |
| Water in the washer does not drain or drains slowly | • Drain hose is kinked or clogged. | Clean and straighten the drain hose. |
| | • The drain filter is clogged. | Clean the drain filter |

# Troubleshooting guide

| Symptom | Possible Cause | Solution |
|---|---|---|
| Washer does not start | • Electrical power cord may not be plugged in or connection may be loose. | Make sure plug fits tightly in wall outlet. |
| | • House fuse blown, circuit breaker tripped,or a power outage has occurred. | Reset circuit breaker or replace fuse. Do not increase fuse capacity. If problem is a circuit overload, have it corrected by a qualified electrician. |
| | • Water supply tap is not turned on. | Turn on water supply tap. |
| Washer will not spin | • Check that the door is firmly shut. | Close the door and press the Start/Pause button. After pressing the Start/Pause button, it may take a few moments before the clothes washer begins to spin. The door must lock before spin can be achieved. |
| | | Add 1 or 2 similar items to help balance the load. Rearrange load to allow proper spinning |
| Door does not open | | Once machine has started, the door can not be opened for safety reasons. Check if the "Door Lock" icon is illuminated. You can safely open the door after the "Door Lock" icon turns off. |
| Wash cycle time delayed | | The washing time may vary by the amount of laundry, water pressure, water temperature and other usage conditions. If the imbalance is detected or if the suds removing program works, the wash time shall be increased. |
| Fabric softner overflow | • Too much softener may cause an overflow. | Follow softener guidelines to ensure appropriate amount is used. Do not exceed the maximum fill line. |
| Softeners dispensed too early | | Close the dispenser drawer slowly. Do not open the drawer during the wash cycle. |
| Dry problem | Check water supply tap. | • Do not overload. Check that the washing machine is draining properly to extract adequate water from the load. Clothes load is too small to tumble properly. Add a few towels.<br>• Turn off water supply tap. |

# Troubleshooting guide

| Symptoms | Reason | Solution |
|---|---|---|
|  | **Water supply is not adequate in area.** | • Check another tap in the house. |
| | **Water supply taps are not completely open.** | • Fully open tap. |
| | **Water supply hose(s) are kinked.** | • Straighten hose(s). |
| | **The filter of the supply hose(s) are clogged.** | • Check the filter of the supply hose. |
| | | |
|  | **Load is too small.** | • Add 1 or 2 similar items to help balance the load. |
| | **Load is out of balance.** | • Add 1 or 2 similar items to help balance the load. |
| | **The appliance has an imbalance detection and correction system. If individual heavy articles are loaded (e.g. bath mat, bath robe, etc.) this system may stop spinning or even interrupt the spin cycle altogether.** | • Rearrange load to allow proper spinning. |
| | **If the laundry is still too wet at the end of the cycle, add smaller articles of laundry to balance the load and repeat the spin cycle.** | • Rearrange load to allow proper spinning. |
|  | **Drain hose is kinked or clogged.** | • Clean and straighten the drain hose. |
| | **The drain filter is clogged.** | • Clean the drain filter. |
|  | **Ensure door is not open.** | • Close the door completely. If dE, dE 1, dE2 is not released, call for service. |
|  | **Control error.** | • Unplug the power plug and call for service. |
|  | **Water overfills due to the faulty water valve.** | • Close the water tap.<br>• Unplug the power plug.<br>• Call for service. |
|  | **Malfunction of water level sensor.** | • Close the water tap.<br>• Unplug the power plug.<br>• Call for service. |
|  | **Over load in motor.** | • Allow the washing machine to stand for 30 minutes to allow the motor to cool, then restart the cycle. |
|  | **Is supply/drain hose or drain pump frozen?** | • Supply warm water into the drum and unfreeze drain hose and drain pump. Wet a towel in warm water and apply to supply hose. |
|  | **Water leaks.** | • Call for service. |
|  | **Does not dry** | • Call for service. |

# Troubleshooting guide

NOTE

• SMARTDIAGNOSIS™ function is available only for the products with a SMARTDIAGNOSIS™ mark. In case of a mobile phone with static option, the SMARTDIAGNOSIS™ function might not operate.

## ■ Using SMARTDIAGNOSIS™

•Only use this feature when instructed to do so by the call center.
The transmission sounds similar to a fax machine, and so has no meaning except to the call center.

•SMARTDIAGNOSIS™ cannot be activated if the washer does not power up.
If this happens, then troubleshooting must be done without SMARTDIAGNOSIS™.

If you experience problems with your washer, call to Customer Information Center.
Follow the call center agent's instructions, and do the following steps when requested:




1. Press the Power button to turn on the washer. Do not press any other buttons or turn the cycle selector knob.




2. When instructed to do so by the call center, place the mouthpiece of your phone very close to the Power button.



3. Press and hold the “Temp.” button for six seconds, while holding the phone mouthpiece to the icon or Power button.
4. Keep the phone in place until the tone transmission has finished.
This takes about 6 seconds, and the display will count down the time.
   - For best results, do not move the phone while the tones are being transmitted.
   - If the call center agent is not able to get an accurate recording of the data, you may be asked to try again.
   - Pressing the Power button during the transmission will shut off the SMARTDIAGNOSIS™.
5. Once the countdown is over and the tones have stopped, resume your conversation with the call center agent, who will then be able to assist you using the information transmitted for analysis at the call to Customer Information Center.

# Terms of Warranty

**What Is Not Covered:**

- Service trips to your home to teach you how to use the product.
- If the product is connected to any voltage other than that shown on the rating plate.
- If the fault is caused by accident, neglect, misuse or Act of God.
- If the fault is caused by factors other than normal domestic use or use in accordance with the owner's manual.
- Provide instruction on use of product or change the set-up of the product.
- If the fault is caused by pests for example, rats or cockroaches etc..
- Noise or vibration that is considered normal for example water drain sound, spin sound, or warming beeps.
- Correcting the installation for example, levelling the product, adjustment of drain.
- Normal maintenance which recommended by the owner's manual.
- Removal of foreign objects / substances from the machine, including the pump and inlet hose filter for example, grit, nails, bra wires, buttons etc.
- Replace fuses in or correct house wiring or correct house plumbing.
- Correction of unauthorized repairs.
- Incidental or consequential damage to personal property caused by possible defects with this appliance.
- If this product is used for commercial purpose, it is not warranted.

(Example : Public places such as public bathroom, lodging house, training center, dormitory)

If the product is installed outside the normal service area, any cost of transportation involved in the repair of the product, or the replacement of a defective part, shall be borne by the owner.

## Disposal of your old appliance (as per e-waste Rules)



1. When this crossed out wheeled bin symbol is depicted on the product and its operator's manual, it means the product is covered by the e-waste Management and Handling Rules , 2011 and are meant to be recycled, dismantled, refurbished or disposed off.
2. **Dos**
   a. The product is required to be handed over only to the authorized recycler for disposal.
   b. Keep the product in isolated area, after it becomes non-functional/un-repairable so as to prevent its accidental breakage.

**Don't**

a. The product should not be opened by the user himself/herself, but only by authorized service personnel.

b. The product is not meant for re-sale to any unauthorized agencies/scrap dealer/ kabariwalah.

c. The product is not meant for mixing into household waste stream.

d. Do not keep any replaced spare part(s) from the product in exposed area.

3. Any disposal through unauthorized agencies/person will attract action under Environment (Protection) Act 1986 .
4. This product does not contain any of the hazardous substances as specified in rule 13(1) and (2) of the e-waste ( Management and Handling ) Rules, 2011.
5. To locate a nearest collection centre or call for pick-up (limited area only) for disposal of this appliance, please contact Toll Free No. **1800-315-9999 / 1800-180-9999** for details. All collection centre and pick up facilities are done by third parties with **LG Electronics India Pvt. Ltd.** merely as a facilitator.

For more detailed information , please visit : **http://www.lg.com/in**

## अपने पुराने उपकरण का निपटान (ई–अपशिष्ट नियम के अनुसार)



१. जब इस काटे गये पहिये वाले बिन का चिह्न किसी उपकरण और इसके ओपेरटर की पुस्तिका के साथ संलग्न होता हैं तो इसका मतलब है कि इसे "ई–अपशिष्ट" (प्रबंधन और हथालन) नियम २०११ के अन्तर्गत सम्मिलित किया गया है। और इसे नवीनीकरण, विघटन और निपटाना के लिए बनाया गया है।

२. **करें**–

क– उपकरण को सिर्फ अधिकृत पुनः नवीनीकरणकर्ता को ही निपटारण करने हेतु हस्तांतरित करें।

ख– जब उपकरण कार्यारत न हो इसे अलग क्षेत्र में रखे ताकि उपकरण से होने वाली दुर्घटनाओ से बचा जा सके।

**ना करें**–

क– इस उपकरण को स्वयं/खुद नही खोलना चाहिए, उपकरण को केवल अधिकृत अधिकारी के द्वारा ही खोला जाना चाहिए।

ख–इस उपकरण को पुनः बिक्री के लिए किसी भी कबाड़ीवाला / भंगार वाला / अनाधिकृत संस्था को न दें।

ग– इस उपकरण को किसी घरेलू अपशिष्ट सामान के साथ मिलाकर न रखें।

घ– उपकरण के बदले हुए या आतरिक पूर्जो को खुले क्षेत्र में न रखें।

३. यदि किसी अनाधिकृत विभाग या व्यक्ति के द्वारा निपटारण किया जाता है तो यह पर्यावरण (सुरक्षा) धारा १९८६ के अन्तर्गत आता है।

४. यह उत्पाद ई-अपशिष्ट (प्रबंधन और हथालन) नियम 2011 के अन्तर्गत 13(1) एवं (2) के तहत निर्दिष्ट खतरनाक पदार्थो की आवश्यकता का पालन करता है

५. उपरोक्त पदार्थो के निपटारन के लिए नजदीकी निपटारन संस्थान (संकीर्ण क्षेत्र) में कॉल करें। अधिक जानकारी के लिए हमारे टोल फ्री नम्बर १८००.३१५.९९९९ / १८००.१८०.९९९९ पर कॉल करें। सभी संग्रहण केन्द्र व पिक–अप की सुविधाएं किसी थर्ड–पार्टी जो **"LG Electronics India Pvt Ltd"** को अपनी सेवाएं प्रदान कर रही हों, से करवाएं।

अधिक जानकारी के लिए देखें वेबसाइट : http://www.lg.com/in

# Memo

# Memo

# Memo

# Memo




MFL67584578

LG 24 x 7 CUSTOMER CARE

1800-315-9999
1800-180-9999
(Toll Free)
CALL

5757554
(Send SMS)
SMS

www.lg.com/in/support
CLICK

www.facebook.com/lghomeappliances
www.twitter.com/LGIndiaTweets

To know more about LG, visit www.lg.com/in
For Corporate/Institutional enquiries,
please write to corp.enquiries@lge.com

**Regd. Office: LG Electronics India Pvt. Ltd.,** A Wing (3rd Floor), D-3, District Center, Saket, New Delhi-110017 CIN No. U32107DL1997PTC220109