




## www.lg.com

LK51\*

LK52\* LK53\*

## **Quick Start Guide**




: Depending on model

**Unpacking**Check your product box for the following items. If there are any missing accessories, contact the local dealer where you purchased your product. The illustrations in this manual may differ from the actual product and item. \*Image may vary depending on models



English

- Read Safety and Reference.
- For the power supply and power consumption, refer to the label attached to the product.



: Depending on model

∠
⚠ CAUTION -


Image shown may differ from your TV.


When attaching the stand to the TV set, place the screen facing down on a cushioned table or flat surface to protect the screen from scratches.


NOTE -


Image shown may vary depending on model.














	A	B	C	D	•	•	<b>G</b> -G
	(mm)					(kg)	
32LK558BPTF	739	472	168	461	92.6	5.90	5.85
Power requirement				AC 100-240 V ~ 50 / 60 Hz			

CAUTION Image shown may vary depending on model.