

Firmware upgrade manual for **42PT81** / **50PT81** Plasma TV


- Firmware version: 3.32
- Improved: Some DivX movies were not played smoothly

Upgrade instructions:

❶ Extract and copy **mtk.bin** file to the USB pendrive

Note:

- NTFS file system is not supported. Drive should be formatted for FAT32
- Some high-capacity USB pendrives may not be supported



❷ Turn off the TV set, plug the USB pendrive and turn on the TV.

The following message will appear.



**DVR downloading is in progress.
Don't remove the power cable.**

Do not remove the pendrive until the process is finished!

❸ TV set will switch off when the upgrade is finished.

Remove the USB pendrive.