

1. SmartShare PC SW(DLNA)

To use DLNA, the PC needs to have Nero MediaHome 4 Essentials.

DLNA stands for Digital Living Network Alliance.

You can enjoy video/audio/photo contents in PC/server using Home Networking on big and high-resolution TV screen.

[Computer requirements for Nero MediaHome 4 Essentials]

- Windows XP (Service Pack 2 or higher),
Windows Vista (no Service Pack required),
Windows XP Media Center Edition 2005 (Service Pack 2 or higher),
Windows Server 2003 (Service Pack 1 or higher)
- Windows 7 Home Premium, Professional, Enterprise or Ultimate (32 and 64-bit)
- Windows Vista 64-bit edition (application runs in 32-bit mode)
- Windows 7 64-bit edition (application runs in 32-bit mode)
- Hard drive space: 200 MB hard drive space for a typical installation of Nero MediaHome stand-alone
- 1.2 GHz Intel Pentium III or AMD Sempron™ 2200+ processors
- Memory: 256 MB RAM
- Graphics card with at least 32 MB video memory, minimum resolution of 800 x 600 pixels, and 16-bit color settings
- Windows Internet Explorer 6.0 or higher
- DirectX 9.0c revision 30 (August 2006) or higher
- Network environment: 100 Mb Ethernet, WLAN (IEEE 802.11g), or faster