



Please read this manual carefully before operating your set and retain it for future reference.

CEILING CASSETTE - 4WAY

Original instruction

[Representative] LG Electronics Inc. EU Representative: LG Electronics European Shared Service Center B.V. Krijgsman 1, 1186 DM Amstelveen, The Netherlands [Manufacturer] LG Electronics Inc. Changwon 2nd factory 84, Wanam-ro, Seongsangu, Changwon-si, Gyeongsangnam-do, KOREA



TABLE OF CONTENTS

Safety Precautions3
Prior to Operation8
Operating Instructions9
Maintenance and Service10
Before you Call for Service12



FOR YOUR RECORDS

Write the model and serial numbers here:

Model

Serial

You can find them on a label on the side of each unit.

Dealer's Name

Date Purchased

Staple your receipt to this page in the event you need it to prove date of purchase or for warranty issues.



READ THIS MANUAL

Inside you will find many helpful hints on how to use and maintain your air conditioner properly. Just a little preventive care on your part can save you a great deal of time and money over the life of your air conditioner.

You'll find many answers to common problems in the chart of troubleshooting tips. If you review our chart of

Troubleshooting Tips first, you may not need to call for service at all.



PRECAUTION

- Contact the authorized service technician for repair or maintenance of this unit.
- · Contact the installer for installation of this unit.
- The air conditioner is not intended for use by young children or invalids without supervision.
- Young children should be supervised to ensure that they do not play with the air conditioner.
- When the power cord is to be replaced, replacement work shall be performed by authorized personnel only using only genuine replacement parts.
- Installation work must be performed in accordance with the National Electric Code by qualified and authorized personnel only.



Safety Precautions

To prevent injury to the user or other people and property damage, the following instructions must be followed.

■ Incorrect operation due to ignoring instruction will cause harm or damage. The seriousness is classified by the following indications.

AWARNING This symbol indicates the possibility of death or serious injury.

A CAUTION

This symbol indicates the possibility of injury or damage to properties only.

■ Meanings of symbols used in this manual are as shown below.

	Be sure not to do.
0	Be sure to follow the instruction.

AWARNING

Installation

Do not use a defective or underrated circuit breaker. Use this appliance on a dedicated circuit.

 There is risk of fire or electric shock.

For electrical work. contact the dealer. seller, a qualified electrician, or an **Authorized Service** Center.

 Do not disassemble or repair the product. There is risk of fire or electric shock.

 There is risk of fire or electric shock.

Install the panel and the cover of control box securely.

 There is risk of fire or electric shock.

Always install a dedicated circuit and breaker.

 Improper wiring or installation may cause fire or electric shock

Use the correctly rated breaker or fuse.

Always ground the

product.

 There is risk of fire or electric shock.

Do not modify or extend the power cable.

 There is risk of fire or electric shock.

Do not install, remove, or re-install the unit by yourself (customer).

 There is risk of fire, electric shock, explosion, or injury.

Be cautious when unpacking and installing the product.

 Sharp edges could cause injury. Be especially careful of the case edges and the fins on the condenser and evaporator.

For installation, always contact the dealer or an Authorized Service Center. Do not install the product on a defective installation stand.

Do not turn on the breaker or power under condition that front panel, cabinet, top cover, control box cover are removed or opened.

 There is risk of fire, electric shock, explosion, or injury. It may cause injury, accident, or damage to the product. Otherwise, it may cause fire, electric shock, explosion or death.

Be sure the installation area does not deteriorate with age.

 If the base collapses, the air conditioner could fall with it, causing property damage, product failure, and personal injury. Use a vacuum pump or Inert (nitrogen) gas when doing leakage test or air purge. Do not compress air or Oxygen and Do not use Flammable gases. Otherwise, it may cause fire or explosion.

 There is the risk of death, injury, fire or explosion.

Operation

Take care to ensure that power cable could not be pulled out or damaged during operation.

· There is risk of fire or electric shock

Do not place a heater or other appliances

near the power cable.

 There is risk of fire and electric shock.

Do not use the product in a tightly closed space for a long time.

 Oxygen deficiency could occur.

Stop operation and close the window in storm or hurricane. If possible, remove the product from the window before the hurricane arrives.

 There is risk of property damage, failure of product, or electric shock.

Do not place anything on the power cable.

 There is risk of fire or electric shock

Do not allow water to run into electric parts.

• It may cause There is risk of fire, failure of the product, or electric shock.

When flammable gas leaks, turn off the gas and open a window for ventilation before turn the product on.

 Do not use the telephone or turn switches on or off. There is risk of explosion or fire

Do not open the inlet grill of the product during operation. (Do not touch the electrostatic filter, if the unit is so equipped.)

 There is risk of physical injury, electric shock, or product failure.

Do not touch(operate) the product with wet hands.

 There is risk of fire or electrical shock

Do not store or use flammable gas or combustibles near the product.

 There is risk of fire or failure of product.

If strange sounds, or small or smoke comes from product. Turn the breaker off or disconnect the power supply cable.

 There is risk of electric shock or fire.

When the product is soaked (flooded or submerged), contact an Authorized Service Center.

· There is risk of fire or electric shock.

Be cautious that water could not enter the product.

Ventilate the product from time to time when operating it together with a stove, etc. Turn the main power off when cleaning or maintaining the product.

 There is risk of fire, electric shock, or product damage. There is risk of fire or electric shock. There is risk of electric shock.

Take care to ensure that nobody could step on or fall onto the outdoor unit. Do not let the air conditioner run for a long time when the humidity is very high and a door or a window is left open.

Do not turn on the breaker or power under condition that front panel, cabinet, top cover, control box cover are removed or opened.

 This could result in personal injury and product damage. Moisture may condense and wet or damage furniture.

 Otherwise, it may cause fire, electric shock, explosion or death.

ACAUTION

■ Installation

Always check for gas (refrigerant) leakage after installation or repair of product.

 Low refrigerant levels may cause failure of product. Install the drain hose to ensure that water is drained away properly.

 A bad connection may cause water leakage. Keep level even when installing the product.

 To avoid vibration or water leakage.

Use two or more people to lift and transport the product.

· Avoid personal injury.

Operation

Do not expose the skin directly to cool air for long periods of time. (Don't sit in the draft.)

Do not use the product for special purposes, such as preserving foods, works of art, etc. It is a consumer air conditioner, not a precision refrigeration system.

Do not block the inlet or outlet of air flow.

- This could harm to your health.
- There is risk of damage or loss of property.
- It may cause product failure.

Use a soft cloth to clean. Do not use harsh detergents. solvents, etc.

Do not touch the metal parts of the product when removing the air filter. They are very sharp!

Do not step on or put anyting on the product. (outdoor units)

- There is risk of fire. electric shock, or damage to the plastic parts of the product.
- There is risk of personal injury.
- There is risk of personal injury and failure of product.

Do not drink the water

drained from the

product.

Always insert the filter securely. Clean the filter every two weeks or more often if necessarv.

· A dirty filter reduces the efficiency of the air conditioner and could cause product malfunction or damage.

Do not insert hands or other objects through the air inlet or outlet while the product is operated.

- There are sharp and moving parts that could cause personal injury.
- It is not sanitary and

could cause serious

health issues.

Use a firm stool or ladder when cleaning or maintaining the product.

Be careful and avoid personal injury.

Prior to Operation

Preparing for operation

- 1. Contact an installation specialist for installation.
- Use a dedicated circuit.

Usage

- Being exposed to direct airflow for an extended period of time could be hazardous to your health.
 Do not expose occupants, pets, or plants to direct airflow for extended periods of time.
- Due to the possibility of oxygen deficiency, ventilate the room when used together with stoves or other heating devices.
- Do not use this air conditioner for non-specified special purposes (e.g. preserving precision devices, food, pets, plants, and art objects). Such usage could damage the items.

Cleaning and maintenance

- Do not touch the metal parts of the unit when removing the filter. Injuries can occur when handling sharp metal edges.
- 2. Do not use water to clean inside the air conditioner. Exposure to water can destroy the insulation, leading to possible electric shock.
- 3. When cleaning the unit, first make sure that the power and breaker are turned off. The fan rotates at a very high speed during operation. There is a possibility of injury if the unit's power is accidentally triggered on while cleaning inner parts of the unit.

Service

For repair and maintenance, contact your authorized service dealer.

Operating Instructions

Auto Restart Function

In case the power comes on again after a power failure, Auto Restarting Operation is the function to operate procedures automatically to the previous operating conditions.

Tips for Filter sign LED

- 1. Filter sign lamp (LED) is ON.
- 2. If LED indicating filter sign lamp is ON, clean the filter.
- 3. After cleaning the filter, press the Timer button and ◀ button of wired remote controller at the same time for 3 s Then filter sign LED is OFF.

Maintenance and Service



CAUTION: Before performing any maintenance, turn off the main power to the system.

Grille, Case, and Remote Control

☐ Turn the system off before cleaning. To clean, wipe with a soft, dry cloth. Do not use bleach or abrasives.

NOTICE

Supply power must be disconnected before cleaning the indoor unit.


Air Filters

The air filters behind the front grille should be checked and cleaned once every 2 weeks or more often if neccessary.



- Never use any of the followings:
 - Water hotter than 40°C.
 Could cause deformation and/or discoloration.
 - Volatile substances.
 Could damage the surfaces of the air conditioner.





1. Remove the Air filters.

■ Take hold of the tab and pull slightly forward to remove the filter.



CAUTION: When the air filter is to be removed, do not touch the metal parts of the indoor unit. It may cause an injury.

- 2. Clean dirt from the air filter using a vacuum cleaner or washing with water.
 - If dirt is conspicuous, wash with a neutral detergent in lukewarm water.
 - If hot water (50°C or more) is used, it may be deformed.
- 3. After washing with water, dry well in the shade.
 - Do not expose the air filter to direct sunlight or heat from a fire when drying it.
- 4. Install the air filter.

When the air conditioner is not going to be used for a long time.

When it is not going to be used for a long time.



Operate the air conditioner at the following settings for 2 to 3 hours.

- Type of operation: Fan operation mode.
- This will dry out the internal mechanisms.



Turn off the breaker.





Turn off the breaker when the air conditioner is not going to be used for a long time.

Dirt may collect and may cause a fire.

Helpful information

The air filters and your electiric bill. If the air filters become clogged with dust, the cooling capacity will drop, and 6 % of the electricity used to operate the air conditioner will be wasted.

When the air conditioner is to be used again.



Clean the air filter and install it in the indoor unit.

(Refer to page 10 for cleaning it.)



Check that the air inlet and outlet of the indoor/outdoor unit are not blocked.



Check that the ground wire is connected correctly. It may be connect to the indoor unit side.

Operation Tips

Do not overcool the room.

This is not good for the health and wastes electricity.

Make sure that the doors and windows are shut tight.

Avoid opening doors and windows as much as possible to keep the cool air in the room.

Keep blinds or curtains closed.

Do not let direct sunshine enter the room when the air conditioner is in operation.

Clean the air filter regularly.

Blockages in the air filter reduce the airflow and lower cooling and dehumidifying effects. Clean at least once every two weeks.

Keep the room temperature uniform.

Adjust the vertical and horizontal airflow direction to ensure a uniform temperature in the room.

> Ventilate the room occasionally.

Since windows are kept closed, it is a good idea to open them and ventilate the room now and then.

Before you call for service...



Troubleshooting Tips! Save time and money!

Check the following points before requesting repairs or service.... If the malfunction persist, please contact your dealer.

The room has a The air conditioner It seems that Air conditioner does not operate for about does not operate. peculiar odor. condensation is leaking from the air 3 minutes when conditioner. restart. Condensation occurs Have vou made a · Check that this is not This is the protector mistake in timer a damp smell exuded when the airflow from of the mechanism by the walls, carpet, the air conditioner · Wait about three operation? Has the fuse blown furniture or cloth cools the warm room minutes and or has the circuit items in the room. operation will begin. breaker been tripped? Does not cool or heat The air conditioner Crack sound is Remote control display is faint, or no effectively. operation is noisy. heard. display at all. · For a noise that Is the air filter dirty? · This sound is generated Are the batteries See air filter cleaning sounds like water by the expansion/ depleted? instructions. flowing. constriction of the front Are the batteries inserted in the · The room may have -This is the sound of panel, etc. due to been very hot when freon flowing inside changes of opposite (+) and (-) the air conditioner directions? the room air temperature. conditioner was first unit turned on. Allow time · For a noise that Filter sign lamp (LED) is ON. for it to cool down. sounds like the Has the temperature compressed air been set incorrectly? releasing into · Are the indoor unit's atmosphere. · Cleaning the filter. air inlet or outlet vents -This is the sound of

NOTICE

obstructed?

WATER RESISTANT: The outdoor side of this appliance is WATER RESISTANT.

The indoor side is not water resistant and should not be exposed to excess water.

the dehumidifying

processed inside the

air conditioning unit.

water being

press the Timer button

and **d** button of wired

remote controller at

the same time for 3 s.

