LG
Life's Good

ENGLISH

SIMPLE MANUAL

ART#51 ART#52 ART#53

Portable Bluetooth Speaker

To view the instructions of advanced features, visit http://www.lg.com and then download Owner's Manual. Some of the content in this manual may differ from your unit.

MODELS
ART#51(ART51) ART#52(ART52) ART#53(ART53)

MFL69523505

www.lg.com

Safety Information

CAUTION: TO REDUCE THE RISK OF ELECTRIC SHOCK DO NOT REMOVE COVER (OR BACK)
NO USER-SERVICEABLE PARTS INSIDE REFER SERVICING TO QUALIFIED SERVICE PERSONNEL.



This lightning flash with arrowhead symbol within an equilateral triangle is intended to alert the user to the presence of uninsulated dangerous voltage within the product's enclosure that may be of sufficient magnitude to constitute a risk of electric shock to persons.



The exclamation point within an equilateral triangle is intended to alert the user to the presence of important operating and maintenance (servicing) instructions in the literature accompanying the product.

WARNING:

- To prevent fire or electric shock hazard, do not expose this product to rain or moisture.
- Do not install this equipment in a confined space such as a book case or similar unit.
- This unit contains magnets which can be harmful to some kind of object (Ex : Magnetic card, Pacemaker etc..).

CAUTION:

- Do not block any ventilation openings. Install in accordance with the manufacturer's instructions. Slots and openings in the cabinet are provided for ventilation and to ensure reliable operation of the product and to protect it from over heating. The openings shall be never be blocked by placing the product on a bed, sofa, rug or other similar surface. This product shall not be placed in a built-in installation such as a bookcase or rack unless proper ventilation is provided or the manufacturer's instruction has been adhered to.
- The apparatus should not be exposed to water (dripping or splashing) and no objects filled with liquids, such as vases, should be placed on the apparatus.
- No naked flame sources, such as lighted candles, should be placed on the apparatus.
- It is recommended that you use the 5 V AC adapter (more than 1.8 A) with this device. If you do not use the recommended adapter, charging is unavailable or charging time may differ.
- To avoid fire or electric shock, do not open the unit. contact to qualified personnel only.
- Do not leave the unit in a place near the heating appliances or subject to direct sunlight, moisture, or mechanical shock.

- To clean the unit, use a soft, dry cloth. If the surfaces are extremely dirty, use a soft cloth lightly moistened with a mild detergent solution. Do not use strong solvents such as alcohol, benzine, or thinner, as these might damage the surface of the unit.
- Do not use volatile liquids such as insecticide spray near the unit.Wiping with strong pressure may damage the surface. Do not leave rubber or plastic products in contact with the unit for a long period of time.
- Do not place the unit over the vehicle's air bag. When the air bag deploys, it may result in injury. Before using in the car, fix the unit.
- Do not use the handsfree function during driving a car.
- Do not leave the unit on an unstable place such as high shelves. it may fall down because of the vibration of the sound.
- Do not use high voltage products around this product. (ex. Electrical swatter) This product may malfunction due to electrical shock.

CAUTION when using this product in environments of low humidity.

- It may cause static electricity in environments of low humidity.
- It is recommended to use this product after touching any metal object which conducts electricity.


CAUTION concerning the Power Cord

The Power Plug is the disconnecting device. In case of an emergency, the Power Plug must remain readily accessible.

NOTICE: For safety marking information including product identification and supply ratings, please refer to the main label on the bottom of the apparatus.


This device is equipped with a portable battery or accumulator.

Safety way to remove the battery or the battery from the equipment: Remove the old battery or battery pack, follow the steps in reverse order than the assembly. To prevent contamination of the environment and bring on possible threat to human and animal health, the old battery or the battery put it in the appropriate container at designated collection points. Do not dispose of batteries or battery together with other waste. It is recommended that you use local, free reimbursement systems batteries and accumulators. The battery shall not be exposed to excessive heat such as sunshine, fire or the like.
Do not remove battery incorporated with product for your safety. If you need to replace the battery, take it to the nearest authorized LG Electronics service point or dealer for assistance.




Power / Battery	Power On / Off	Hold ⏻/I
	Check Battery Status	Press ⏻/I
Bluetooth	To pair your mobile device, select ***LG Music Flow P5 (xx)*** from device list.	
	Ready to pair another device	Hold ✱
Playback Controls	Play / Pause	Press >II
	Forward Skip	Press >II x2
	Backward Skip	Press >II x3


Download the app "Music Flow Bluetooth"



TV Private Sound



Dual Play



For more information, download the online owner's manual. http://www.lg.com

Specification

Power Supply:
- 5 V ⎓ 1.8 A (AC Adapter)
- Built-in rechargeable battery

Power consumption:
- 9 W

Dimensions (W x H x D):
Approx. 153 mm x 58 mm x 59.5 mm

Net Weight: Approx. 0.47 kg

Operating Temperature:
5 ℃ to 35 ℃

Operating Humidity: 5 % to 60 %

External Connector:
- ø 3.5 mm mini jack
- Micro USB port for charging battery

Communication: Bluetooth

Battery :
- Battery capacity : 2100 mAh
- Operating time is approx. 15 hours. It may vary depending on the battery status and operational conditions.

• Design and specifications are subject to change without notice.

Important Notice


• Fully charge the device before using for the first time.

• It is recommended that you use the 5 V AC adapter (more than 1.8 A) with this unit.

• Press and hold the ⏻/I button for 2 seconds to turn on or off the unit.

• **Resetting**

- In case that the unit freezes due to malfunction, press the RESET hole using and object like a thin pin.




LG
Life's Good

العربية

دليل بسيط

ART#51 ART#52 ART#53

سماعة Bluetooth محمولة

لعرض تعليمات الخصائص المتقدمة، قم بزيارة http://www.lg.com ومن ثم حمل دليل المالك. قد تختلف بعض محتويات هذا الدليل عن وحدتك.

الطرازات

ART#51(ART51) ART#52(ART52) ART#53(ART53)

MFL69523505

www.lg.com

معلومات السلامة

تنبيه: للتقليل من مخاطر الصدمة الكهربائية، لا تقم بإزالة الغطاء (أو الغطاء الخلفي)، حيث لا توجد أية أجزاء قابلة للصيانة عن طريق المستخدم، وقم بإسناد مهمة الصيانة لفني خدمة مؤهل.



يهدف الرمز الذي يحتوي على صاعقة برأس سهم داخل مثلث متساوي الأضلاع إلى تحذير المستخدم إلى وجود جهد كهربي خطر غير معزول داخل هيكل المنتج والذي قد يكون كافٍ ليشكل خطر تعرض الأشخاص لصدمة كهربائية.



كما يشير الرمز الذي يحتوي على علامة تعجب داخل مثلث متساوي الأضلاع إلى تنبيه المستخدم إلى وجود تعليمات تشغيل وصيانة (خدمة) مهمة في الكتيب المرفق مع المنتج.

تحذير:

- للتقليل من خطر نشوب الحرائق أو حدوث الصدمات الكهربية، لا تعرض الجهاز للمطر أو الرطوبة.
- لا تثبت هذا الجهاز في مكان محكم مثل مكتبة أو وحدة مشابهة.
- تحتوي هذه الوحدة على مغانط يمكن أن تسبب الضرر لبعض أنواع الأجسام (مثل: بطاقة مغناطيسية، جهاز تنظيم ضربات القلب، إلخ...)

تنبيه:

- لا تسد أي من فتحات التهوية. ينبغي تركيب الجهاز وفقًا لتعليمات المصنّع.
ويرجى الانتباه إلى أن وظيفة الثقوب والفتحات الموجودة في الحجيرة تتمثل في توفير التهوية وضمان التشغيل الموثوق للمنتج وحمايته من السخونة الزائدة. ينبغي عدم سد الفتحات بوضع المنتج على سرير أو أريكة أو أي سطح آخر شبيه بذلك. ينبغي عدم وضع هذا المنتج في التجهيزات المدمجة مثل المكتبة أو الرف ما لم يتم توفير التهوية المناسبة أو يتم الالتزام بتعليمات الشركة المصنعة.
- لا يجب تعريض المنتج للماء (قطرات الماء أو الرذاذ) ولا يجب وضع أي أشياء مملوئة بالماء، مثل الزهرية، فوق الجهاز.
- ينبغي عدم وضع مصادر اللهب المكشوف، مثل الشموع المشتعلة، على الجهاز.
- ينصح بأن تستخدم محول تيار ٥ ف (أكثر من ١,٨ أ) مع هذا الجهاز. إذا لم تستخدم المحول الموصى به، يكون الشحن غير متوفر أو قد يكون مختلفاً.

- لتجنب نشوب حريق أو التعرض لصدمة كهربائية، لا تفتح الوحدة. اتصل بالفني المؤهل فقط.
- لا تترك الوحدة في مكان بالقرب من أجهزة التدفئة أو تتعرض لأشعة الشمس المباشرة أو الرطوبة أو الصدمة الميكانيكية.
- لتنظيف الوحدة، استخدم قطعة قماشية ناعمة وجافة. إن كانت الأسطح متسخة للغاية، استخدم قطعة قماشية ناعمة مبللة بمحلول منظف معتدل. لا تستخدم المذيبات القوية مثل الكحول أو البنزين أو التنر نظراً لأن هذه المذيبات قد تتسبب في تلف سطح الوحدة.
- لا تستخدم سوائل طيارة مثل رشاش المبيد الحشري بالقرب من الوحدة. قد يتسبب المسح مع شدة الضغط في تلف السطح. لا تترك منتجات مطاطية أوبلاستيكية تلاصق الوحدة لفترة طويلة من الزمن.
- لا تضع الوحدة على الوسادة الهوائية بالسيارة. عندما تعمل الوسادة الهوائية، يمكن أن يسبب ذلك إصابة. قم بتثبيت الوحدة قبل الاستخدام في السيارة.
- لا تستخدم وظيفة السماعة الخارجية أثناء قيادة السيارة.
- لا تترك الوحدة في مكان غير ثابت مثل الأرفف العالية. يمكن أن تسقط بسبب الاهتزاز الناتج عن الصوت.
- لا تستخدم منتجات ذات جهد عالي حول هذا المنتج. (مثلا، منشة كهربائية) قد يتعطل المنتج بسبب صدمة كهربائية.

يرجى الحذر عند استخدام هذا المنتج في بيئات منخفضة الرطوبة.

- حيث قد يتسبب في وجود كهرباء ساكنة في البيئات منخفضة الرطوبة.
- يوصى باستخدام هذا المنتج بعد لمس أي شيء معدني يقوم بتوصيل الكهرباء.


التحذيرات المتعلقة بكابل الطاقة

لفصل مصدر التيار من مقبس، اسحب مقبس كابل الطاقة من منفذ التيار الموجود بالحائط. عند تثبيت المنتج، تأكد من سهولة الوصول للمقبس.

ملحوظة: لمعلومات الأمان شاملة التعريف بالمنتج ومعدل توافره، يرجى الرجوع للملصق الرئيسي أسفل الجهاز


يتم تزويد هذا الجهاز ببطارية قابلة للحمل أو ببطارية مختزنة.

الطريقة الآمنة لإزالة البطارية أو مجموعة البطارية من الأجهزة: أزل البطارية القديمة أو مجموعة البطارية، واتبع خطوات تجميعها بترتيب عكسي. لمنع تلوث البيئة والتسبب في جلب المخاطر لصحة البشر والحيوانات، يجب وضع البطارية أو مجموعة البطارية في حاوية مناسبة في نقاط التجميع المخصصة. تخلص من البطاريات أو البطارية مع النفايات الأخرى. يوصى باستخدام أنظمة البطاريات والمراكم المحلية. ينبغي عدم تعرض البطارية لدرجة حرارة زائدة عن الحد مثل أشعة الشمس أو الحريق أو ما شابه ذلك.
لا تنزع البطارية المزودة في المُنتج حرصًا على سلامتك.
إذا كنت تحتاج إلى استبدال البطارية، خذها إلى أقرب نقطة خدمة أو وكيل معتمد من إل جي إلكترونيكس للمساعدة.




الطاقة/ البطارية	تشغيل/إيقاف تشغيل الطاقة	استمر بالضغط ⏻/I
	تحقق من حالة البطارية	اضغط ⏻/I
Bluetooth	لوصل جهازك المحمول، اختر **LG Music Flow P5 (xx)** من قائمة الجهاز.	
	جاهز لوصل جهاز آخر.....	استمر بالضغط ᛒ
ضوابط إعادة التشغيل	تشغيل/إيقاف مؤقت.....	اضغط ⏯
	تخطي للأمام.....	اضغط ⏯ ٢x
	تخطي للخلف	اضغط ⏯ ٣x

التشغيل المزدوج




TV Private Sound



للمزيد من المعلومات، حمّل دليل المالك على الإنترنت.
http://www.lg.com

حمّل تطبيق
“Music Flow Bluetooth”



المواصفة

مصدر الطاقة:

- ٥ فولت ⎓ ١,٨أمبير (محول تيار متردد)
- بطارية مدمجة قابلة لإعادة الشحن

استهلاك الطاقة:

- ٩ واط

الأبعاد (عرض × ارتفاع × عمق):

١٥٣ ملم × ٥٨ ملم × ٥٩,٥ ملم تقريبًا

الوزن الصافي: ٠,٤٧ كجم تقريبًا

درجة حرارة التشغيل:

٥ مئوية إلى ٣٥ مئوية

درجة رطوبة التشغيل:

٥ % إلى ٦٠ %

موصل خارجي:

- مقبس صغير مقاس ٣,٥ ملم
- منفذ USB مصغر لشحن البطارية

الاتصال: Bluetooth

البطارية:

- سعة البطارية : ٢١٠٠ مللي أمبير ساعة
- وقت التشغيل ١٥ ساعات تقريبًا.


يمكن أن تختلف حسب حالة البطارية وظروف التشغيل.

- يخضع التصميم والمواصفات للتغيير دون إخطار مسبق.

ملاحظة مهمة

- اشحن الجهاز تمامًا قبل استخدامه للمرة الأولى.
- ينصح باستخدام محول تيار متردد بجهد 5 فولت (أكثر من ١,٨ أمبير) مع هذا الجهاز.
- اضغط مع الاستمرار على الزر ⏻/I لمدة ثانيتين لتشغيل الوحدة أو إيقافها.
- **إعادة التعيين**

- في حالة عدم استجابة الوحدة بسبب عطل، اضغط على فتحة RESET باستخدام شيء مثل الدبوس الرفيع.




LG
Life's Good