

## Unpacking

Check your product box for the following items. If there are any missing accessories, contact the local dealer where you purchased your product. The illustrations in this manual may differ from the actual product and item.

Image shown may vary depending on model.

 : Depending on model



[www.lg.com](http://www.lg.com)




English

- Read **Safety and Reference.**
- For the power supply and power consumption, refer to the label attached to the product.



## USING THE USER GUIDE



Press the (🏠) button  
To access home button.



Navigate & Select  
User Guide.




Refer User Guide for  
Detail information




43LJ55\*\*


1




2



3



4



**CAUTION**


Image shown may differ from your TV.

When attaching the stand to the TV set, place the screen facing down on a cushioned table or flat surface to protect the screen from scratches.




49/55LJ55\*\*



1




2




3



4




5




**NOTE**


Image shown may vary depending on model.  
All connection cables & devices shown in the picture are not  
included along with the TV set.




ANTENNA/  
CABLE IN




HDMI IN





HDMI IN/ARC



USB IN




LAN



**NOTE**

Image shown may vary depending on model.  
All connection cables & devices shown in the picture are not included along with the TV set.



H/P OUT




OPTICAL DIGITAL  
AUDIO OUT



**NOTE**





Image shown may vary depending on model.  
All connection cables & devices shown in the picture are not  
included along with the TV set.






**NOTE**






Image shown may vary depending on model.  
All connection cables & devices shown in the  
picture are not included along with the TV set.

## COMPONENT IN




## AV IN






**NOTE**

Image shown may vary depending on model.







	<b>A</b> (mm)	<b>B</b> (mm)	<b>C</b> (mm)	<b>D</b> (mm)	<b>E</b> (mm)	<b>F</b> (kg)	<b>F</b> - ( <b>G</b> <sub>1</sub> + <b>G</b> <sub>2</sub> ) (kg)
43LJ550V-TA 43LJ550T-TA 43LJ554T-TA 43LJ553T-TC 43LJ550Y-TA	977	615	187	575	80.8	8.1	8.0
49LJ550V-TA 49LJ550T-TA 49LJ554T-TA 49LJ553T-TC 49LJ550Y-TA	1110	705	235	650	81.1	11.4	11.3
Power requirement					AC 100-240 V ~ 50 / 60 Hz		

**NOTE**  
Image shown may vary depending on model.



	<b>A</b> (mm)	<b>B</b> (mm)	<b>C</b> (mm)	<b>D</b> (mm)	<b>E</b> (mm)	<b>F</b> (kg)	<b>F</b> - ( <b>G</b> <sub>1</sub> + <b>G</b> <sub>2</sub> ) (kg)
55LJ550V-TA 55LJ550T-TA 55LJ554T-TA 55LJ553T-TC 55LJ550Y-TA	1249	785	235	730	83.4	14.3	14.2
Power requirement					AC 100-240 V ~ 50 / 60 Hz		





ML69446181