

ENGLISH

Specification

Power requirements

- Refer to the main label.

Power consumption

- Refer to the main label.


Dimensions (W x H x D): Approx. 760.0 mm x 63.0 mm x 90.0 mm

Bus Power Supply (USB): 5 V  500 mA

Amplifier (Total RMS Output power): 100 W RMS

POWER: This unit operates on a mains supply of 100 - 240 V ~ 50 / 60 Hz.

Wiring: This unit is supplied with a BS 1363 approved main plug. When replacing the fuse, always use a fuse of the same rating and approved to BS 1362. Never use this plug with the fuse cover omitted. To obtain a replacement fuse cover contact your dealer. If the type of plug supplied is not suitable for the mains sockets in your home, then the plug should be removed and a suitable type fitted. Please refer to the wiring instructions below.

Warning: A mains plug removed from the mains lead of this unit must be destroyed. A mains plug with bared wires is hazardous if inserted in a mains socket. Do not connect either wire to the earth pin, marked with the letter E or with the earth symbol  or coloured green or green and yellow. If any other plug is fitted, use same rating of fuse in the plug.

Important: The wires in this mains lead are coloured in accordance with the following codes:

- **BLUE: NEUTRAL, BROWN: LIVE** - As the colours of the wires in the mains lead of this unit may not correspond with the coloured marking identifying the terminals in your plug, proceed as follows: The wire which is coloured blue must be connected to the terminal which is marked with the letter N or coloured black. The wire which is coloured brown must be connected to the terminal which is marked with the letter L or coloured red.



SIMPLE MANUAL

SOUND BAR


SP2



MFL71456235
2102_Rev01

www.lg.com

Copyright © 2021 LG Electronics Inc. All Rights Reserved.



ENGLISH Installing and Using the Product

Please read this manual carefully before operating your set and retain it for future reference.
To view the instructions of advanced features, visit <http://www.lg.com> or scan QR code and then download Owner's Manual. Some of the content in this manual may differ from your product.





- A** Sound bar
B Remote Control Receiver / Status LED (Refer to below table)
C External Device - (Blu-ray player, game console, etc.)

Power on	Standby	OPTICAL / HDMI ARC	Bluetooth ready	Bluetooth	LG TV	HDMI IN	USB
Red blinking	Red	White	Blue blinking	Blue	White	White	Green

- 1 Connect the sound bar to your TV via an optical cable or an HDMI cable.**
- 2 If you are using an external device (ex. Blu-ray player, game console, etc.), connect it to the sound bar via an HDMI cable.**
- 3 Using the product with your TV**
 - 1** Press the **Function** button repeatedly until the first from above LED lights up in white among the three LEDs.
 - 2** On your TV's settings, set the output speaker to [HDMI ARC], [Optical], or [External Speaker].
- 4 Connecting the product to your smartphone via Bluetooth**
 - 1** Tap the **Settings** button on your smartphone and select **Bluetooth**.
Turn on the **Bluetooth** function. (Off > On)
 - 2** Press the **Bluetooth pair** button. After a moment, the second LED lights up in blue and blinking among the three LEDs.
 - 3** Find and tap the product on your smartphone. The product appears as "LG SP2 (XX)".
- 5 Connecting to the LG Sound Bar app**
 - 1** Find and install the LG Sound Bar app on Google Play or App Store from your smartphone.
 - 2** You can get more information regarding its use by selecting [Help] in [Setting].

- Design and specifications are subject to change without notice.
- Google Play is a trademark of Google LLC.



Replacement of Battery

HDMI™
HIGH-DEFINITION MULTIMEDIA INTERFACE