



CE 0168

P/N: MFL67106433(1.0)

LG-A170GO User Guide - English

This guide will help you to understand your new mobile phone. It will provide you with useful explanations of the features on your phone.

Some of the contents of this manual may differ from your phone depending on the phone software or your service provider.

Disposal of your old appliance

- 1. When this crossed-out wheeled bin symbol is attached to a product it means the product is covered by the European Directive 2002/96/EC.
- 2. All electrical and electronic products should be disposed of separately from the municipal waste stream via designated collection facilities appointed by the government or the local authorities.
- 3. The correct disposal of your old appliance will help prevent potential negative consequences for the environment and human health.
- 4. For more detailed information about disposal of your old appliance, please contact your city office, waste disposal service or the shop where you purchased the product.

Disposal of waste batteries/accumulators

- 1. When this crossed-out wheeled bin symbol is attached to a product it means the product is covered by the European Directive 2006/66/EC.
- 2. This symbol may be combined with chemical symbols for mercury(Hg), cadmium(Cd) or lead(Pb) if the battery Contains more than 0.005% of mercury, 0.002% of cadmium or 0.004% of lead.
- 3. All batteries/accumulators should be disposed separately from the municipal waste stream via designated collection facilities appointed by the government or the local authorities.
- 4. The correct disposal of your old batteries/accumulators will help to prevent potential negative consequences for the environment, animal and human health.
- 5. For more detailed information about disposal of your old batteries/accumulators, please contact Your city office, waste disposal service or the shop where You purchased the product.



www.lg.com

Quick feature reference

Calendar

When you enter this menu, a calendar appears. A square cursor is placed on the current date. You can move the cursor to another date using the navigation keys.

Contacts

You can search for a contact in your Contacts.

1 Press Contacts and choose Search, select Contacts from the Menu screen or press ☎ (up) from the standby screen.

2 On the keypad enter the first letter of the contact you want to call.

3 To scroll through the contacts, use the up and down navigation keys. To scroll through their different numbers use the left and right navigation keys.

• **New contact:** You can add phonebook entries by using this menu.

• **Flight Mode:** Use this function to switch the Flight mode On or Off. You will not be able to make calls or send messages when Flight mode is switched On.

• **Headset:** When the headset is connected to the phone, the indicator ☎ will be displayed on the standby screen. You can personalise your call alert type, ring tones, ring volume, message alert type, message tones, message volume, keypad tones, keypad volume, flip tones, effect sound volume and power on/off volume.

Tools

• **Fake call:** You can set a fake incoming call which will come after a specific time with the name and number you set. To set Fake call, go to Fake call in Settings. Set Fake call to ON. Select the time after which you want the Fake call to be activated from the options. Give the Name and Number from whom the Fake call is to come, and finally press Save to save your settings. Now to invoke the fake call press ☎ from the standby screen.

• **Calculator:** This contains the standard functions such as Addition, Subtraction, Multiplication and Division.

• **Stopwatch:** This option allows you to use the function of a stopwatch.

• Do not disassemble this unit. Take it to a qualified service technician when repair work is required.

• Keep away from electrical appliances such as TVs, radios, and personal computers.

• The unit should be kept away from heat sources such as radiators or cookers.

• Do not drop.

• Do not subject this unit to mechanical vibration or shock.

• Switch off the phone in any area where you are required by special regulations. For example, do not use your phone in hospitals as it may affect sensitive medical equipment.

• Do not handle the phone with wet hands while it is being charged. It may cause an electric shock and can seriously damage your phone.

• Do not charge a handset near flammable material as the handset can become hot and create a fire hazard.

• Use a dry cloth to clean the exterior of the unit (do not use solvents such as benzene, thinner or alcohol).

• Do not charge the phone when it is on soft furnishings.

• The phone should be charged in a well-ventilated area.

• Do not subject this unit to excessive smoke or dust.

• Do not keep the phone next to credit cards or transport tickets; it can affect the information on the magnetic strips.

• Do not tap the screen with a sharp object as it may damage the phone.

Speed dials:

Assign contacts to any keys between 2 and 8.
• **SOS message:** (Speed dials-> Ok->Key 9) An emergency message can be sent to the predefined number's (3 maximum) by pressing and holding the 9 key. When the 9 key is pressed and held, a popup message appears: 'Set SOS message?'. Press 'Yes' then type the required message and enter 3 numbers to which you want the message to be sent in Emergency mode. Then press Save/Done.

• **Copy all:** You can copy all entries from the SIM card memory to the Phone memory or from the Phone memory to the SIM card memory.

• **Delete all:** You can delete all entries from the SIM card memory or Phone memory.

• **Memory status:** You can check the memory status for your SIM and phone.

• **Information**
• **Service dial number:** Access the list of service numbers assigned by your service provider securely.

• **Own number:** You can save and check your own numbers on the SIM card.

• **Business card:** You can save and check your business card containing information including your name, mobile phone, home office and email, and send it in a message.

• **Unit converter:** This converts any measurement into a unit you want.

• **World clock:** Allows you to determine the current time in another time zone or country.

Organiser

• **Alarm:** You can set up to 3 alarm clocks to go off at a specified time.

• **Memo:** You can register your own memos here.

Settings

• **Date & Time:** You can set functions relating to the date and time.

• **Languages:** You can change the language for the display texts in your phone. This change will also affect the Language Input mode.

• **Display:** You can adjust settings for the phone display.

• **LED Lighting:** When you select LED Lighting On, the LED display on the front cover works.

• **Power on/off, Folder open/close, Incoming SMS:** Flash 1 cycle.

• **Incoming call:** Keep flashing until ring tone ends.

• **Alarm:** Keep flashing until you turn it off or the end of the alarm duration.

• Do not expose the phone to liquid, moisture or humidity.

• Use accessories like earphones cautiously. Do not touch the antenna unnecessarily.

• Do not use the phone or accessories in places with high humidity such as pools, greenhouses, solariums or tropical environments, it may cause damage to the phone and invalidation of warranty.

Efficient phone operation

Electronic devices

• Do not use your mobile phone near medical equipment without requesting permission. Please consult your doctor and the device manufacturer to determine if operation of your phone may interfere with the operation of your medical device.

• Some hearing aids might be disturbed by mobile phones.

• Minor interference may affect TVs, radios, PCs, etc.

Pacemakers

Pacemaker manufacturers recommend that a minimum separation of 15 cm be maintained between a mobile phone and a pacemaker to avoid potential interference with the pacemaker. To achieve this use the phone on the opposite ear to your pacemaker and do not carry it in a breast pocket.

Hospitals

Switch off your wireless device when requested to do so in hospitals, clinics or health care facilities. These requests are

Getting to know your phone



Call history

You can check the record of all, missed, dialled, received calls and call durations. The number and name (if available) are displayed together with the date and time at which the call was made. You can also view the number of times you have called.

• **All calls:** Displays the lists of all three types (Received/ Dialled/Missed calls) by time.

• **Missed calls:** This option lets you view the last 20 unanswered calls.

• **Dialled calls:** This option lets you view the last 20 outgoing calls (called or attempted).

• **Received calls:** This option lets you view the last 20 incoming calls.

• **Call duration:** Allows you to view the duration of your incoming and outgoing calls.

Games

Your LG-A170GO comes with preloaded games to keep you amused when you have time to spare. Press Menu and select Games.

Messaging

Sending a message

1 Press Menu, select Messaging and choose New message.

2 A new message editor will open. The default setting of the message editor is SMS mode.

3 Enter your message using either the T9 predictive mode or ABC manual mode. You can switch text input modes by pressing #.

4 Press Options and choose Insert to add a Symbol, Template, Contact, Business card.

5 Press Send to.

6 Enter the phone number or press Options and select Contacts or Recent list to open your contacts list select the number and press Insert, then Option.

7 Press Send.

• **Inbox:** You will be alerted when you have received a message. It will also be saved here.

• **Drafts:** This menu shows the message you have saved.

• **Outbox:** This menu allows you to view the message which is about to be sent or could not be sent.

• **Sent:** This menu allows you to view the messages which have already been sent, including time and content.

• **Change codes** - To change your security code or PIN1 or PIN2 code, or ATMT code, enter the old code followed by the new one.

• **Call:** You can set the menu depending on the call.

• **Security:** This menu allows you to set the phone securely. > **PIN code request** - Choose a PIN code to be requested when you turn your phone on.

• **Phone lock** - Choose a security code to lock your phone. When power on, When SIM changed or Immediately.

• **Cash barring** - Choose a barring password for all outgoing calls, outgoing international, outgoing international when roaming, all incoming calls, or incoming when roaming.

• **Reset settings:** Use Reset to restore the factory settings. You need the security code to activate this function. The default number is "0000".

• **Memory status:** You can check the free space and memory usage of each repository.

Guidelines for safe and efficient use

Please read these simple guidelines. Not following these guidelines may be dangerous or illegal.

Exposure to radio frequency energy

THIS DEVICE MEETS INTERNATIONAL GUIDELINES FOR EXPOSURE TO RADIO WAVES

Your mobile device is a radio transmitter and receiver. It is designed and manufactured not to exceed the limits for exposure to radio frequency (RF) recommended by international guidelines (ICNIRP). These limits are part of comprehensive guidelines and establish

Installing the SIM Card and Charging the Battery

Installing the SIM Card

When you subscribe to a mobile phone network, you are provided with a plug-in SIM card which is loaded with your subscription details, such as your PIN, any optional services available and many others.

Important! The plug-in SIM card and its contacts can easily be damaged by scratches or bending, so be careful when handling, inserting or removing the card. Keep all SIM cards out of the reach of small children.
• only 2G/2.5G SIM supported

Illustrations



⚠ **WARNING:** Do not remove the battery while the phone is switched on, as this may damage the phone.

ABC manual mode

This mode allows you to enter letters by pressing the key labelled with the required letter once, twice, three or four times until the letter is displayed.

123 mode

Type numbers using one keystroke per number. You can also add numbers while remaining in letter modes by pressing and holding the desired key.

Profiles

You change your profile, then choose from General, Silent, Vibrator only, Outdoor, Flight mode and Headset.

• **General:** After setting up this profile, the indicator ☎ will be displayed on the standby screen.

• **Silent:** Ring tone and vibrator are both disabled. When you set up this profile, the indicator ☎ will be displayed on the standby screen.

• **Vibrate only:** The ring tone is disabled, only the vibrator is enabled. When you set up this profile, the indicator ☎ will be displayed on the standby screen.

• **Outdoor:** This is the default profile. Ring tone and key tone volume are set to maximum. When you set up this profile, the indicator ☎ will be displayed on the standby screen.

permitted levels of RF energy for the general population. The guidelines were developed by independent scientific organisations through periodic and thorough evaluation of scientific studies. The guidelines include a substantial safety margin designed to assure the safety of all persons, regardless of age and health.

The

highest SAR value for this device when tested for use at the body is 0.371 W/kg.

* The SAR limit for mobile devices used by the public is 2.0 watts/kilogram (W/kg) averaged over ten grams of body tissue. The guidelines incorporate a substantial margin of safety to give additional protection for the public and to account for any variations in measurements.

SAR values may vary depending on national reporting requirements and the network band.

Product care and maintenance

⚠ **WARNING:** Only use batteries, chargers and accessories approved for use with this particular phone model. The use of any other types may invalidate any approval or warranty applying to the phone, and may be dangerous.

is fully charged to save unnecessary power consumption of the charger.

• Actual battery life will depend on network configuration, product settings, usage patterns, battery and environmental conditions.

Technical data

General

Product name : LG-A170GO

System : GSM 900 /

DCS 1800 Dual band

Terminal Equipment

Ambient

Temperatures

Max : +55°C (discharging)

+45°C (charging)

Min : -10°C

