



Life's Good

**MODEL : LAC8900N / LAC7900N**

ENGLISH



## Table of Contents

2	Table of Contents	13	Connecting an Auxiliary Equipment
3	Safety Note		Changing settings
4	[LAC8900N] Front Panel / Remote Control	14-15	Connecting a Bluetooth wireless technology
5	[LAC7900N] Front Panel / Remote Control		Disconnecting a phone
6	[LAC8900N] About Detachable Control Panel		Answering and Ending a call
7	[LAC7900N] About Detachable Control Panel		Rejecting a call
8	Installation		Making a call saved preset number
	Basic installation		Missed call notification
	Removing the existing receiver unit		Audio transfer
	ISO-DIN installation		Making a call from the latest call
	Battery installation		Paring your unit and device with Bluetooth wireless technology
9	Connection		Playing MP3 files
10	Basic operation		Storing a call number in last answered
	Mute		Bluetooth wireless technology profiles information
	Using the EQ		The buttons with bluetooth wireless technology
	Adjusting the sound level	16	Adjusting the setting (Bluetooth wireless technology)
	XDSS+	17-18	Phone compatibility list (Bluetooth wireless technology)
	Checking the clock	19	Troubleshooting
	Setting the clock	20	Specifications
11	Listening to a CD		
	Pause or restart a CD		
	Search for a section within a track / file		
	Skip to another track / file		
	Intro scan		
	Repeat		
	Shuffle		
	MP3/WMA Track -10 / +10		
	MP3/WMA Folder UP/DOWN		
	Checking information about your music		
12	Listening to the radio		
	Auto search memory		
	Storing and recalling broadcast frequencies		
	To scan the preset stations		
	To tune in the preset stations		
	Connecting USB device		



This product is manufactured to comply with Directive 2006/28/EC (ANNEX I , 3.2.9), 72/245/EEC, 99/5/EC, and 2006/95/EC.

### European representative:

LG Electronics Service Europe B.V. Veluwezoom 15, 1327 AE Almere, The Netherlands (Tel: +31-036-547-8940)

## Safety Note



**CAUTION**  
RISK OF ELECTRIC SHOCK  
DO NOT OPEN



**CAUTION : TO REDUCE THE RISK OF ELECTRIC SHOCK DO NOT SPLIT COVER(OR BACK) NO USER SERVICEABLE PARTS INSIDE. REFER SERVICING TO QUALIFIED SERVICE PERSONNEL.**



This lightning flash with arrowhead symbol within an equilateral triangle is intended to alert the user to the presence of uninsulated dangerous voltage within the product's enclosure that may be of sufficient magnitude to constitute a risk of electric shock to persons.



The exclamation point within an equilateral triangle is intended to alert the user to the presence of important operating and maintenance (servicing) instructions in the literature accompanying the product.



Always operate the vehicle in a safe manner. Do not become distracted by the vehicle while driving, and always be fully aware of all driving condition. Do not change settings, or any functions. Pull over in a safe and legal manner before attempting such operations.



Do not use for many hours at extremely low or high temperature. (-10~60°C)



To reduce the risk of electric shock, do not remove the cover or back of this product. There are no user-serviceable parts inside. Refer servicing to qualified service personnel.



To reduce the risk of fire or electric shock, do not expose this product to dripping or splashing water, rain, or moisture.



The temperature of unit's outside can be extremely high, please use the unit after proper installation in your vehicle.




This unit cannot play 8cm disc (use 12cm disc only).

**CAUTION** : This product uses a Laser System.

To ensure proper use of this product, please read this owner's manual carefully and retain it for future reference.

Should the unit require maintenance, contact an authorized service center. Performing controls, adjustments, or carrying out procedures other than those specified herein may result in hazardous radiation exposure.

To prevent direct exposure to laser beam, do not try to open the enclosure. Visible laser radiation when open. **DO NOT STARE INTO BEAM.**



### **Caution**



When being connected in a wrong way, the unit displays as follows.

- **Antenna port short** : "ANTENNA ON PORT SHORT CIRCUIT CHECK"  
After connecting it again, restart the unit.

You have to set the disc format option to [Mastered] in order to make the discs compatible with the LG players when formatting rewritable discs.

When setting the option to Live File System, you cannot use it on LG players. (Mastered/Live File System : Disc format system for Windows Vista)

## [LAC8900N] Front Panel / Remote Control



- 1 • Auto Store [A/AS]
- Preset Scan [V/PS]
- MP3/WMA Track +10/-10 A/V
- Folder Up/Down A/V
- 2 Skip / Search / Seek / Tune ►I+
- 3 • ENTER
- Volume
- [MUTE]
- Power [PWR]
- 4 Equalizer [EQ]
- 5 Bluetooth wireless technology [B/T]
- 6 SOURCE [SRC]
- 7 Remote Sensor
- 8 Display window

- 9 Extreme Dynamic Sound System [XDSS+]
- 10 Display [DISP]
- 11 Release
- 12 USB slot
- 13 AUX in
- 14 Preset Station [1~6]
- 15 Shuffle [SHF]
- 16 Repeat [RPT]
- 17 Intro Scan [INT]
- 18 Play/Pause ►II
- 19 • [BAND]
- [DRIVE]
- 20 Select [SEL] / [MENU]
- 21 Skip / Search / Seek / Tune / Back -I◀

- 1 Power [POWER] / Mute
- 2 Select [MENU/SEL]
- 3 Source [SRC]
- 4 Play / Pause ►II
- 5 Intro Scan [INT]
- 6 Shuffle [SHF]
- 7 • MP3/WMA Track +10
- Folder Up ▲
- 8 • CD Skip / Search
- Seek / Tune I◀◀◀

- 9 • [BAND]
- DRIVE [DRV]
- 10 Volume Up ▲ / Down ▼
- 11 Number [#]
- 12 Repeat [RPT]
- 13 Number [0 -9]
- 14 • CD Skip / Search
- Seek / Tune ►►►I
- 15 Display [DISP.]
- 16 • MP3/WMA Track -10
- Folder Down ▼

### Note

There is the microphone in the left top position of the unit when you detach the control panel.



































