

LG Pocket Photo Update Tool

- [Install](#)
- [Uninstall](#)
- [Update](#)


< Installation Requirements >

- Microsoft Windows XP/Vista/7/8
- 100MB of available hard disk space
- 256MB of RAM
- Display resolution 1024x768 or higher
- Internet Explorer 6 or higher

1. Double-click the installation file




2. Preparing Setup




< Preparation >

- ① Download [LG Pocket Photo Update Tool](#).
- ② Connect to the internet.


3. Click **Next**.



4. Click **Next**.




5. Now Installing




6. Device driver installation (**Mandatory**)

- You may see the pop-up notification.




7. Click **Finish**, and then installation completed.



1. Run the uninstall program


Method 2:

- ① Click the **Start** button, and then click **Control Panel**.
- ② Click **Uninstall a program**.
- ③ Click **LG Pocket Photo Update Tool**.
- ④ Click **Uninstall**.




Method 2:


- ① Click the **Start** button, and then click **All Programs**.
- ② Click **LG Pocket Photo Update Tool**.
- ③ Click **Uninstall LG Pocket Photo Update Tool**.



2. Now uninstalling



3. Click **Finish**, and then uninstall completed.



< Preparation >

- ① Install [LG Pocket Photo Update Tool](#).
- ② Connect to the internet.
- ③ Connect the device and turn the device on.

1. Run [LG Pocket Photo Update Tool](#).



2. Click **Check Update** button.
 - USB connection and Power ON




3. Click **Update** button.
 - Compare current version and newest version.



4. Downloading firmware




5. Updating firmware



6. Click **OK**, and then update completed.

PD221, PD233, PD251 User



PD239, PD241, PD238 User

