



簡易手冊

全方位 便攜式揚聲器

Omnidirectional portable speaker

XO2TBK

XO2TBE



COV38135110

www.lg.com
版權所有 © 2024 LG Electronics Inc.
保留一切權利。
2407_Rev03




下載說明書
Download Manual

<Android>

<iOS>

下載應用程式
Download App





連接與使用揚聲器

- 1 在使用揚聲器之前，請開啟後蓋並使用隨附 USB 傳輸線（C 型轉 A 型）將揚聲器與交流電適配器（未提供）連接，為其充電。
- 2 使用此揚聲器之前，請按下電源  按鈕開啟揚聲器。頂部面板上的按鈕將亮起幾秒。
- 3 使用 Bluetooth 將揚聲器連接至智能手機
 - 1 請按下電源  按鈕開啟產品。Bluetooth LED 指示燈閃爍。
 - 2 輕觸智能手機上的設定  按鈕，然後選擇 **Bluetooth**。開啟 **Bluetooth** 功能。（ 關 >  開）
 - 3 從智能手機裝置清單中找到並輕觸「LG-X02T(XX)」。
 - 4 透過 **Bluetooth** 將智能手機連接後，**Bluetooth** LED 指示燈會亮起。使用智能手機的音樂應用程式，播放一首喜愛的歌曲。

4 連接到 LG XBOOM 應用程式

- 1 在 Google Play 或 App Store 中搜尋 **LG XBOOM 應用程式**，然後在智能手機上安裝。
- 2 運行 **LG XBOOM 應用程式** 並使用其功能。（EQ、Wireless Party Link、燈光、睡眠定時、設定等）

5 節能

如果 15 分鐘內沒有任何播放或按鈕操作，產品將自動關閉。您可以在 **LG XBOOM 應用程式** 上啟用或禁用 [自動關機]。

6 使用 One Touch 模式

- 1 在 **LG XBOOM 應用程式** 中設定您自己的 One Touch 模式。按照說明設定 One Touch 模式。
- 2 長按 **指示燈光**  按鈕約 2 秒即可啟動 One Touch 模式。

- 設計和規格若有變更，恕不另行通知。
- 如需更多資訊，請下載線上使用者手冊。

<http://www.lg.com>

Connecting and Using the Speaker

- ❶ Charge the speaker before using it by opening the rear cover and connecting the speaker to an AC adapter (not provided) by using the provided USB (Type C to A) cable.
- ❷ To use this speaker, turn it on by pressing the power  button. The buttons on the top panel will light up for a few seconds.
- ❸ Connect the speaker to a smartphone via Bluetooth
 - ❶ Press the **Power**  button to turn on the product. **Bluetooth LED blinks.**
 - ❷ Tap the **Settings**  button on your smartphone and select **Bluetooth**. Turn on the **Bluetooth** function.
( Off >  On)
 - ❸ From the list of smartphone devices, find and tap on "LG-XO2T(XX)."
 - ❹ Once the smartphone is connected via **Bluetooth**, the **Bluetooth LED** will

turn on. Play a desired track in the music app on your smartphone.

❹ Connecting the LG XBOOM App

- ❶ Find the **LG XBOOM app** on the Google Play or App Store and install it on your smartphone.
- ❷ Run the **LG XBOOM app** and use its functions. (EQ, Wireless Party Link, Lighting, Sleep Timer, Setting etc.)

❺ Power Saving

If there is no playback or button input for 15 minutes, the product turns off automatically. On the **LG XBOOM app**, you can enable or disable [Auto Power Off].

❻ Using the One Touch mode

- ❶ Set your own One Touch mode in the **LG XBOOM app**. Follow the instructions to set the One Touch mode.
 - ❷ Press the **Lighting**  button for about 2 seconds to start the One Touch mode.
- Design and specifications are subject to change without notice.
 - For more information, download the online owner's manual.
<http://www.lg.com>

中文

規格

電源供應：

- 5 V  2 A (AC 適配器)
- 內置式可充電電池

電源耗用

- 請參閱主標籤。

尺寸 (闊 x 高 x 深)：

大約 119.0 mm x 209.0 mm x 119.0 mm

工作溫度：攝氏5度至35度

工作濕度：5 % 至 80 %濕度範圍

入口保護：IP55 (根據在受控實驗室條件下進行的測試，本揚聲器的防水等級為 IP55。)

- 固體：防塵
- 液體：可抵禦來自各個方向的低壓水射流。在淡水中進行測試。請在使用前晾乾。在濕水時切勿充電。

電池壽命：長達 15 小時

- 電池使用時間基於 50 % 音量和無照明情況。實際電池使用時間可能有所不同。

安全資訊

小心：為減低觸電風險，切勿拆開本機前蓋（或後蓋）。播放器內並無使用者可自行修理的部份。如需維修，請聯絡合資格的技術人員。



等邊三角形內帶閃電箭頭的符號用以提醒使用者：產品內部含有未經絕緣的危險電壓，其強度可能會使人觸電。



等邊三角形內帶感嘆號的符號用以提醒使用者：產品隨附的資料中包含重要的操作及維修（服務）指引。

警告：

- 為免引起火警或觸電意外，切勿將本產品暴露於雨水或潮濕位置。
- 切勿把本設備安裝在狹窄的空間，如書櫃或類似的地方。
- 本機含有磁石，可能會損害其他物件（如磁卡，心臟起搏器等）。

注意：

- 切勿阻塞任何通風口。請依照生產商指示安裝。機殼上的插槽及通風開口特別為通風而設，可確保產品正常運作以及避免產品過熱。
- 切勿把產品置於睡床、沙發、地毯或其他類似的表面上，以免堵塞通風口。

除非已有正確通風或依照生產商指示, 否則本產品不應置於如書架或機架等內建裝置上。

- 切勿把本機暴露於有水(滴水或濺水)的地方,且不應將注滿液體的物體(如花瓶)於置在本機上。
- 切勿在本機上放置任何明火源,例如點燃的蠟燭。
- 建議對此設備使用 5 V AC 電源變壓器 (2 A 以上)。如果不使用建議電源變壓器,將無法充電,或者充電時間將有所不同。
- 為免引起火災或觸電意外,必須由合資格人士拆開本機。
- 切勿將本機置於供熱設備附近,或者直接曝露於陽光、潮濕或會受到機械性衝擊之處。
- 電源插頭為中斷電力連接的裝置。為緊急情況做好準備,確保電源插頭可隨時插上或拔掉。
- 如需清潔本機,請使用柔軟的乾布。
- 請勿在本機附近使用揮發性液體,例如殺蟲噴霧劑。強壓擦拭可能會損壞表面。請勿讓橡膠或塑膠產品長時間接觸本機。
- 切勿把本機置於汽車的安全氣囊之上。安全氣囊打開時,本機可能會導致受傷。在車內使用本機前,請先將其固定。

- 切勿在駕駛時使用免提功能。
- 請勿將本機放於不平穩的地方(如高櫃上)。本機可能因聲音振動而掉落。
- 切勿在這項產品附近使用高電壓產品(如電蚊拍)。這項產品可能會因電擊而發生故障。

注意 請小心謹慎地在低濕度環境中使用本機。

- 在低濕度的環境中使用可能會產生靜電。
- 為防止靜電,建議在使用本產品前先觸摸金屬物體。

說明:如欲了解安全標記信息包括產品標識和電源額定值,請參閱產品底部或其他表面上的主標籤。

符號

	指交流電 (AC)。
	指直流電 (DC)。
	指第二類設備。
	指待機狀態。
	指「開啟」(電源)。
	指危險電壓。

內置電池的型號

請勿在氣壓低於 11.6 kPa 和海拔高於 15000 m 處儲存或運輸。

- 更換錯誤型號的電池會破壞保護措施（例如，某些鋰電池類型）；
- 將電池丟入火中或熱烤箱中，或物理擠壓或切割電池，可能導致爆炸；
- 將電池放在極高溫的環境中，可能導致爆炸或易燃液體或氣體洩漏；
- 電池處於極低的氣壓下，可能導致爆炸或易燃液體或氣體洩漏。

適用於使用電池的型號

本機配有可攜式電池或蓄電池。

注意：如果電池更換為錯誤的類型，會有起火或爆炸的風險。

如何從設備上安全移除電池或電池組：

要移除舊的電池或電池組，按照與安裝步驟相反的順序操作。要防止環境污染和對人和/或動物健康的潛在威脅，舊電池或電池組必須放在適當的容器內，並置於專門的收集點。不要將電池或電池組與其他廢品一起處理。建議使用本地的免費報銷機制電池或電池組，（可能在您所處區域不適用）。電池或電池組不得暴露在過熱環境中，如陽光、火或類似環境。

ENGLISH

Specification

Power Supply:

- 5 V  2 A (AC Adapter)
- Built-in rechargeable battery

Power consumption

- Refer to the main label.

Dimensions (W x H x D):

Approx. 119.0 mm x 209.0 mm x 119.0 mm

Operating Temperature: 5 °C to 35 °C

Operating Humidity: 5 % to 80 % RH

Ingress Protection: IP55 (Speaker tested under controlled laboratory conditions with an IP55 rating.)

- Solid: Protected against dust
- Liquid: Protected against low pressure jets of water from all directions. Tested in fresh water. Dry before using. Do not charge while wet.

Battery life: Up to 15 hours

- Battery life based on 50 % volume and no lighting. Actual battery usage time may vary.

Safety Information

CAUTION: TO REDUCE THE RISK OF ELECTRIC SHOCK DO NOT REMOVE COVER (OR BACK). NO USER-SERVICEABLE PARTS INSIDE. REFER SERVICING TO QUALIFIED SERVICE PERSONNEL.



This lightning flash with arrowhead symbol within an equilateral triangle is intended to alert the user to the presence of uninsulated dangerous voltage within the product's enclosure that may be of sufficient magnitude to constitute a risk of electric shock to persons.



The exclamation point within an equilateral triangle is intended to alert the user to the presence of important operating and maintenance (servicing) instructions in the literature accompanying the product.

WARNING:

- TO PREVENT FIRE OR ELECTRIC SHOCK HAZARD, DO NOT EXPOSE THIS PRODUCT TO RAIN OR MOISTURE.
- Do not install this equipment in a confined space such as a book case or similar unit.
- This unit contains magnets which can be harmful to certain kinds of objects (Ex: Magnetic card, Pacemaker etc...).

CAUTION:

- Do not block any ventilation openings. Install in accordance with the manufacturer's instructions. Slots and openings in the cabinet are provided for ventilation and to ensure reliable operation of the product and to protect it from over heating. The openings should never be blocked by placing the product on a bed, sofa, rug or other similar surface. This product shall not be placed in a built-in installation such as a bookcase or rack unless proper ventilation is provided or the manufacturer's instruction has been adhered to.
- The apparatus should not be exposed to water (dripping or splashing) and no objects filled with liquids, such as vases, should be placed on the apparatus.

- No naked flame sources, such as lighted candles, should be placed on the apparatus.
- It is recommended that you use the 5 V AC adapter (more than 2 A) with this device. If you do not use the recommended adapter, charging is unavailable or charging time may differ.
- To avoid fire or electric shock, do not open the unit. contact a qualified personnel only.
- Do not leave the unit in a place near the heating appliances or subject to direct sunlight, moisture, or mechanical shock.
- The Power Plug is the disconnecting device. In case of an emergency, the Power Plug must remain readily accessible.
- To clean the unit, use a soft, dry cloth.
- Do not use volatile liquids such as insecticide spray near the unit. Wiping with strong pressure may damage the surface. Do not leave rubber or plastic products in contact with the unit for a long period of time.
- Do not place the unit over the vehicle's air bag. When the air bag deploys, it may result in injury. Before using in the car, fix the unit.

- Do not use the handsfree function during driving a car.
- Do not leave the unit on an unstable place such as high shelves. it may fall down because of the vibration of the sound.
- Do not use high voltage products around this product. (ex. Electrical swatter) This product may malfunction due to electrical shock.

CAUTION when using this product in environments of low humidity.

- It may cause static electricity in environments of low humidity.
- To prevent static electricity, it is recommended to touch metal objects before using this product.

NOTICE: For safety marking information including product identification and supply ratings, please refer to the main label on the bottom or the other surface of the product.

Symbols

	Refers to alternating current (AC).
	Refers to direct current (DC).
	Refers to class II equipment.
	Refers to stand-by.
	Refers to "ON" (power).
	Refers to dangerous voltage.

For models using a built-in battery

Do not store or transport at pressures lower than 11.6 kPa and at above 15,000 m altitude.

- replacement of a battery with an incorrect type that can defeat a safeguard (for example, in the case of some lithium battery types);
- disposal of a battery into fire or a hot oven, or mechanically crushing or cutting of a battery, that can result in an explosion;
- leaving a battery in an extremely high temperature surrounding environment that can result in an explosion or the leakage of flammable liquid or gas;

- a battery subjected to extremely low air pressure that may result in an explosion or the leakage of flammable liquid or gas.

For models using a battery

This device is equipped with a portable battery or accumulator.

CAUTION: Risk of fire or explosion if the battery is replaced by an incorrect type.

How to Safely remove the batteries or the battery pack from the equipment:

To Remove the old batteries or battery pack, follow the assembly steps in reverse order. To prevent contamination of the environment and bring on possible threat to human and/or animal health, the old batteries or the battery pack must be put in an appropriate container at designated collection points. Do not dispose of batteries or battery pack together with other waste. It is recommended that you use local, free reimbursement systems batteries or battery packs, (may not be available in your area). The batteries or the battery pack should not be exposed to excessive heat such as sunshine, fire or the like.



中文

符合標準聲明

在此，LG電子聲明 便攜式藍牙揚聲器類型的無線電設備符合 2014/53/EU指令。你可以從以下互聯網地址獲得歐盟符合性聲明的全文：

<http://www.lg.com/global/support/cedoc/cedoc#>

為使用者安全着想，安裝或使用裝置時，身體與裝置之間的距離不應少於20 厘米。



ENGLISH

Declaration of Conformity

Hereby, LG Electronics declares that the radio equipment type PORTABLE BLUETOOTH SPEAKER is in compliance with Directive 2014/53/EU. The full text of the EU declaration of conformity is available at the following internet address:

<http://www.lg.com/global/support/cedoc/cedoc#>

For consideration of the user, this device should be installed and operated with a minimum distance of 20 cm between the device and the body.





