



To view the instructions of advanced features, visit http://www.lg.com and then download Owner's Manual. Some of the content in this manual may differ from your unit.

MODEL LAS355B














Front Panel




ტ/I		 	 														F	c)\	٧	е	r		C)r	١.	/()	ff	:
F		 	 												·S	e	ŀ	e	C	t:	S	F	=	u	n	IC	ti	0	r	1
	(1)		 												. ,	Д	.(ij	u	S	t	S		V	'C	ılı	11	m	iE	,

1 Subwoofer Connection

Place the subwoofer near the sound bar and follow steps below.

- 1 Press each plastic finger pad to open subwoofer terminals on the unit.
- Connect the black wire to the terminals marked - (minus) and the other end to the terminals(red tube) marked + (plus).



Controller App



Download the **Music Flow Bluetooth** App to your device.


Rear Panel



$\mbox{SUB WOOFER(}4\Omega\mbox{)}\cdot\cdots\cdot\cdot\mbox{Connect to a subwoofer}$
OPT. IN · · · · · Connect to an Optical device
$\mbox{\sc PORT.IN} \cdots \cdots \cdots$ Connect to a Portable device
USB port ····· Connect to a USB device

2 TV Connection

- 1 Connect the the sound bar to the TV using Optical cable.
- 2 Set up [External Speaker (Optical)] on your TV setting menu.



LG Sound Sync (Wireless)



For more information, download the online owner's manual. http://www.lg.com


Additional Information

Specification

Power requirements	Refer to the main label.								
Danna	Refer to the main label.								
Power consumption	Networked standby : 0.5 W (If all network ports are activated.)								
Dimensions (W x H x D)	Approx. 880 mm x 59 mm x 90 mm								
Net Weight	Approx. 1.9 kg								
Bus Power Supply (USB)	5 V === 500 mA								
Amplifier (Total RMS Output power)	120 W								

Design and specifications are subject to change without notice.

Remote control




- □ : Makes comfortable sound at Dolby Digital.
- : Turns down the volume at night.
- Number : Synchronizes the audio and video.
- Sets the system to turn off automatically at a specified time.
- : Adjusts the volume level appropriately.
- POWER): Automatically turns on by an input source.

How to disconnect the wireless network connection or the wireless device

Set up the AUTO POWER ON/OFF function to off and turn off the unit.

Replacement of battery




Disposal of your old appliance



- All electrical and electronic products should be disposed of separately from the municipal waste stream via designated collection facilities appointed by the government or the local authorities.
- The correct disposal of your old appliance will help prevent potential negative consequences for the environment and human health.
- For more detailed information about disposal of your old appliance, please contact your city office, waste disposal service or the shop where you purchased the product.

Disposal of waste batteries/accumulators



- This symbol may be combined with chemical symbols for mercury(Hg), cadmium(Cd) or lead(Pb) if the battery Contains more that 0.0005% of mercury,0.002% of cadmium or 0.004% of lead.
- All batteries/accumulators should be disposed separately from the municipal waste stream via designated collection facilities appointed by the government or the local authorities.
- 3. The correct disposal of Your old batteries/ accumulators will help to prevent potential negative consequences for the environment, animal and human health.
- For more detailed information about disposal of Your old batteries/accumulators, please contact Your city office, waste disposal service or the shop where You purchased the product.

Contact office for compliance of this product:

LG Electronics (Levant) - Jordan Abdali Project, Rafik Al-Hariri Avenue, The Boulevard, Central Square, 5th Floor