

Specification

Power requirements

- Refer to the main label.
- Built-in rechargeable battery

Power consumption

- Refer to the main label.

Dimensions (W x H x D): Approx. 310 mm x 700 mm x 316 mm

Bus Power Supply (USB): 5 V  500 mA

Amplifier (Total RMS Output power): 250 W RMS

Operating Temperature: 5 °C - 35 °C

Operating Humidity: 5 % - 80 % RH

Ingress Protection: IPX4

- Liquid: Protected against splashing water.

Battery Life: Approx. 20 hours

- Operation time may vary depending on the battery or operation status.
- This unit contains magnets which can be harmful to some kind of object (Ex: Magnetic card, Pacemaker etc.).
- Internal lithium battery in the unit should not be replaced by user because of danger of explosion if battery is incorrectly replaced, and must be replaced with the same type battery by expert.
- Do not leave the unit on an unstable place such as high shelves. It may fall down because of the vibration of the sound.

CAUTION when using this product in environments of low humidity.

- It may cause static electricity in environments of low humidity.
- It is recommended to use this product after touching any metal object which conducts electricity.

For models using water-resistant products

When charged, the water-resistant function is limited, so use it in a place that is not exposed to water.



SIMPLE MANUAL


Portable Bluetooth Speaker

XL7S



MFL71944308

2211_Rev01




www.lg.com

Copyright © 2023 LG Electronics Inc. All Rights Reserved.



ENGLISH Installing and Using the Product

Please read this manual carefully before operating your set and retain it for future reference.
To view the instructions of advanced features, visit <http://www.lg.com> or scan QR code and then download Owner's Manual. Some of the content in this manual may differ from your product.



- (A) Handle
 - (B) Controls
 - (C) Flash Lighting
 - (D) Speaker (Tweeter)
 - (E) Dot Animation
 - (F) Speaker (Woofer) / Woofer Lighting
 - (G) Attaching the ferrite core (optional)
- Wind the power cord cable twice around the ferrite core.
- 1** Connect the power cord to the product by opening the rear cover and charge it before use
 - 2** Connecting the Speaker to a Smartphone via Bluetooth
 - ① Press the **Power** (⏻) button to turn on the product.
 - ② Press the **Function** (⏮) button on the product repeatedly to select the BT function. The BT LED blinks.
 - ③ Tap the **Settings** (⚙️) button on your smartphone and select **Bluetooth**. Turn on the **Bluetooth** function. (⏻ Off > ⏻ On)
 - ④ From the list of smartphone devices, find and tap on "LG-XL7S(XX)"
 - ⑤ Once the smartphone is connected to the product via **Bluetooth**, the BT LED will turn on. Play a desired track in the music app on your smartphone.

- 3** Playing Music from the USB
 - ① Open the back cover of the product and plug the USB storage device into the USB terminal.
 - ② Press the **Power** (⏻) button to turn on the product.
 - ③ Press the **Function** (⏮) button on the product repeatedly to select the USB function. The USB LED will turn on.
 - ④ Press the **Play/Pause** (⏮) button to enjoy the music.

- 4** Connecting to the LG XBOOM App
 - ① Find the **LG XBOOM app** on the Google Play or App Store and install it on your smartphone.
 - ② Run the **LG XBOOM app** and use its functions. (EQ, Wireless Party Link, Dot Animation, Lighting, Setting etc.)

- 5** Power Saving
If there is no playback or button input for 15 minutes, the product turns off automatically. On the **LG XBOOM app**, you can enable or disable [Auto Power Management].

⚠ This product has wheels and a handle so you can easily move the product.
Press the lock button on the handle and then pull the handle up. Release the lock button to lock the handle in place.

• Design and specifications are subject to change without notice.