







جميع الحقوق محفوظة. LG Electronics Inc., 2016 ملاحظة: يرجى قراءة كل المعلومات بعناية قبل استخدام LG 360 VR لتجنب الحاق ضرر بالمنتج وللاستمتاع بأفضل أداء.

All rights reserved, LG Electronics Inc., 2016 Note: Please read all information carefully prior to using the LG 360 VR in order to enjoy the best performance and prevent damage to the product.

نظرة عامة على المنتج

- إن LG 360 VR هو جهاز ذكي يستخدم تقنية الواقع الافتر اضى للاستمتاع بمحتوى الواقع الافتر اضي • عند تشغيل محتوى الواقع الافتراضي بواسطة LG 360 VR، يمكنك الاستمتاع بالصور ورؤيتها من كل الاتحاهات و كأنك كنت منو احدًا فيها أثناء التقاطها
- يمكنك استخدام LG 360 CAM (تُباع بشكل منفصل) اللتقاط صور ومقاطع فيديو لمحتوى VR وعرضها على LG 360 VR
 - هذا الجهاز غير متوافق مع LG G5^{SE}.

معلومات حول إشعار البرامج المفتوحة المصدر

 للحصول على التعليمات البرمجية المصدر بموجب GPL و LGPL و MPL وتراخيص مفتوحة المصدر أخرى يتضمنها هذا المنتج، يرجى زيارة الموقع http://opensource.lge.com. بالإضافة إلى التعليمات البرمجية المصدر، تتوفر كل أحكام الترخيص وإشعارات إخلاء المسؤولية وإشعارات حقوق النشر للتنزيل. ستوفر LG Electronics أيضًا التعليمات البرمجية المصدر على قرص مضغوط بتكلفة تغطى هذا التوزيع (مثل تكلفة الوسائط والشحن والاستخدام) عند طلبها بإرسال بريد الكتروني إلى opensource@lge.com. إن هذا العرض صالح لمدة ثلاث (3) سنوات اعتبارًا من تاريخ شراء المنتج.

يمكن العثور على نص ترخيص المصدر المفتوح في تطبيق المدير الذي يعمل مع هذا المنتج.


الاحتياطات

- صئم هذا المنتج لعرض محتوى الواقع الافتراضي. لتقادي التعرض الصابة، يستحسن أن تأخذ فترات استراحة متكررة ادى استخداء المنتج.
- · قبل توصيل المنتج بالهاتف، تأكد من أن الهاتف يتطابق مع جهاز LG 360 VR. قد لا يعمل LG 360 VR
 - بحسب توافقه مع الهاتف. • عند تشغيل محتوى غير مدعوم من المنتج، قد تومض الشاشة أو قد لا تظهر.
- لا يجدر بالأطفال الذين لم يبلغوا الـ 15 سنة استخدام هذا المنتج لمشاهدة مقاطع الفيديو أو تشغيل ألعاب الفيديو. قد بؤثر جهاز G 360 VR في تطور حاسة النظر لدى الأطفال.
 - إذا كنت تعلي أمراضًا مثل الخُول أو الغَمش، فلا تستخدم هذا المنتج. قد يؤدي استخدام المنتج إلى تفاقم هذه الأمراض.
- إذا كنّن تُعاني بشكل متكرر دوار الحركة؛ فقد تشعر بانزعاج أثناء استخدام هذا المنتج. وفي هذه الحالة، توقف عن استخدامه وخذ قسطًا من الواحة.
 - أما بالنسبة إلى النساء الحوامل أو الكبار في السن أو المرضى الذين يعانون أمراضًا نفسية وعقلية أو المرضى المصابين بأمراض القلب أو غيرها من الأمراض الخطيرة فيجدر بهم استثمارة طبيبهم قبل استخدام هذا المنتج.
 - ترقف عن استخدام المنتج إذا بات هو نفسه أو الهاتف ساخنًا. فقد يتسبب ذلك بحروق.
 استخدمه في وضعية مريحة مع وضع الجهاز بشكل أفقي. إذا كنت تضع المنتج على عينيك بشكل ماثل باتجاه
 - معيّن، فمن الممكن أن تشعر بالأنزعاج. أذا أنه حرار من الرائد أثال الرائب مل كرين إذا أركن أرازا كنت ترتيب الرائب أثال الآتال منه تتبث
 - لذا يُنصح باستخدام المنتج أثناء الجلوس على كرسي إذا أمكن. أما إذا كنت تستخدم الجهاز أثناء التنقل، فقد تتمثر
 أو تسقط وتصاب بإصابة خطيرة.
- قد تنسبب بحير أد الوقع الافتراضي في ظهور بعض العوارض مثل دوار الحركة. بالإضافة إلى دوار الحركة، من الممكن أن تنسبب إيضًا في دوار مغرط وتؤثر في قد رتك على أداء مهمات متحددة مغًا. كما من الممكن أن يشكّل استخدام المنتج خطرًا على صحتكا: لذا في حال استخدامه، احرص على أخذ قسط من الراحة قبل متابعة القيام بأي نشاطات جديدة أخرى.
 - إذا كنت تضع جهازًا طبيًا، استشر طبيبك قبل استخدام المنتج.
 - إذا استخدمت جهاز RG 360 VR لمدة طويلة؛ فمن الممكن أن تتهيّج بشرتك أو يمكن أن يترك علامة على وجهك.
- بعتبر هذا المنتج جهازًا انتكبير شاشة العرض من خلال عدسة بدرجة تكبير عالية. عند عرض المحتوى، قد تظهر
 جسيمات غريبة يكون حجمها أصغر من وحدات البكسل داخل شاشة العرض.

- قد تؤدي إز الة العدسة إلى تعريض الشاشة لمواد غريبة.
 على الأشخاص الذين يعانون اللابؤرية وضع عدسات لاصقة لتصحيح نظر هم.
- احرص على وضع الجهاز في الدقية الخاصة به عند حمله أو تخزينه. وحتى في هذه الحالة، قد يتعرض LG 360 VR


 ϵ

مكونات المنتج



- في حال فقدان أي مكونات؛ اتصل بالبائع بالتجزئة الذي المتريت منه المنتج.
 - تتَغَيِّر بعض العناصر من دون إشعار مسبق بحسب الظُّروف.
 يتغيِّر شكل المنتج ومواصفاته من دون إشعار مسبق لتحسين الأداء.
- · يتغيّر شكل المنتج ومواصفاته من دون إشعار مسبق لتحسين الأداء. ما يتعمد الألمان أنه الأمالية تتعميد المتعمل المتعملين الأداء.
- استخدم دائمًا المنتجات الأصلية. قد يؤدي استخدام المنتجات غير الأصلية أو توصيلها إلى الحاق ضرر بالمنتج وبالتالي إيطال ضمان الخدمة.

4



كيفية استخدام المفاتيح

 مفتاح التحديد الضغط: تحديد المحتوى أو القائمة المركزة في وسط الشاشة. الضغط باستمرار: دخول شاشة الإعدادات.

2. مفتاح الرجوع

الضغط: الانتقال إلى الشاشة السابقة او الإلغاء. الضغط باستمرار: الانتقال إلى الشاشة الرئيسية لتطبيق LG 360 VR.

5


ضبط وضعية العدسة

يمكنك تحريك العدسة إلى اليسار أو اليمين لضبطها.




ضبط تركيز العدسة

يمكنك تدوير العدسة لتركيزها لتناسب نظرك بشكل أفضل.



عند ضبط العدسة، انزع أداة حجب الضوء.



- قبر بترصيل كبيل USB الخاص بجهاز G 360 VR بمنذ USB على الهاتف. قد يستشرق الأمر بعض الوقت.
 سترقف أسائمة الهاتف عن التشغيل عندما يكرن جهاز LG 360 VR قيد التشغيل. يمكنك استخدام الهاتف كالرحة
 تعماء باللعام.
 - لن يعمل هذا المنتج بشكل عادي عند توصيله بجهاز GG لعلم LG G5 في حال كان LG CAM Plus أل LG G5.
 ل إليست من وحداث Plus with B&O PLAY أو أي أجهزة أخرى ليست من وحداث LG G5 موصولة بجهاز GG للمحادث
- عندما يكون جهاز LG 360 VR في وضع الخمول لـ 15 دقيقة على الأقل في الوقت الذي يكون فيه كبيل USB موصولاً، يتم تلقائياً قطع الاتصال بجهاز LG 360 VR لمنع استخدام طاقة البطارية.
- سيكرن هناك قبود على الاتصال بـ LG 360 VR في حال كان مستوى طاقة بطارية الهاتف منخفضًا أو إذا كانت درجة حرارة الهاتف مرتفعة.

7

تثبيت أداة حجب الضوء

1 تثبيت أداة حجب الضوء في جهاز LG 360 VR.



2 افتح هيكل الجهاز LG 360 VR، ضع أداة حجب الضوء مكاتها، ثم اضغط على الجائبين لتثبيت الخطافات الجائبية.



8 ثبّت الجهة السفلى من أداة حجب الضوء في جهاز RG 360 VR. امسك أداة حجب الضوء بإصبغي السيابة واضغط عليها بإيهامَيك لتثبيتها. اضغط عليها بإحكام مجددًا.



4 ثبّت الجهة العليا من أداة حجب الضوء في جهاز RG 360 VR. المسك أداة حجب الضوء بإصبعي السبابة واضغط عليها بإيهامَيك التبيئة. اضغط عليها بإيعامَيك



5 تم الأن تثبيت أداة حجب الضوء. إذا كانت الخطافات غير مشدودة بإحكام، اضغط عليها مجددًا.



الميزات والاستخدام

تحديد محتوى أو عنصر قائمة

ركز المحتوى أو عنصر القائمة لتحديده وسط الشاشة ثم اضغط على زر التحديد على جهاز LG 360 VR أو اضغط على شاشة الهاتف.

سحب الشاشة

إذا أردت تحديد محتويات كثيرة، يمكنك سحب شاشة الهاتف إلى الأعلى أو الأسفل أو اليمين أو اليسار لتحريكها. اعادة ته حمد الشاشة

يمكنك إعادة توجيه الشاشة بالضغط باستمرار عليها بإصبعيك. ينتقل وسط الشاشة إلى نطاق رؤيتك الحالي.

الانتقال الى الشاشة السابقة

اضغط على زر الرجوع على جهاز LG 360 VR أو اضغط باستمرار على شاشة الهاتف للانتقال إلى الشاشة السابقة.

الانتقال إلى الشاشة الرئيسية

اضغط باستمرار على زر الرجوع على جهاز LG 360 VR للانتقال إلى الشاشة الرئيسية.

إعدادات

اضغط باستمرار على زر التحديد على جهاز LG 360 VR للانتقال إلى الإعدادات. يمكنك ضبط إعدادات الإشعارات والسطوع واتجاه الشاشة على الشاشة ذات الصلة.

ميزات خاصة بالمكالمات

يمكنك الضغط على الزر للإجابة على الهاتف أو لإنهاء المكالمة. • عندما برن الهاتف

- اضغط على زر التحديد للرد على المكالمة.
- اضغط على زر الرجوع مرة واحدة لتعليق المكالمة الواردة. اضغط على الزر مرتين لرفض المكالمة.
 - أثناء التحدث على الهاتف
 - اضغط على زر التحديد أو زر الرجوع لإنهاء المكالمة.

معلومات هامة حول السلامة

الرعد والبرق

أثناء عواصف الرعد أو البرق القوية، توقف عن استخدام المنتج. فقد يتسبب البرق بإصابة خطيرة أو بنشوب
 حريق.

المياه

- لدى تعرّض المنتج للماء، لا تستخدم مجفّاً بنبعث منه هواء ساخنًا أو مجفف شعر أو تضعه في فرن المايكرويف
 أو في الغرن لتجفيفه. فقد يؤدي قيامك بذلك إلى انفجار المنتج أو إلى التسبب بتعطيله أو تشويهه.
- إذا كان المنتج مبلاً: فسيتغيّر لون الملصق الموجود داخله. وهي هذه الحالة؛ لا يمكنك تلقي خدمة مجانية لدى تعطل المنتج. لذا يرجى الحذر.
 - لا تستخدم المنتج وهو مبلل. فقد يؤدي القيام بذلك إلى نشوب حريق أو ارتفاع درجة حرارته بشكل مفرط أو
 حدوث انفجار أو تسرّب.

ببنات الاستخدام

- لا تستخدم المنتج في أماكن خطيرة، على المنحدرات أو التلال أو بجانب مجرى مياه مثلاً.
 - إذا علق الكيبل في أبواب مركبة، فهذا أمر خطير جداً. إذا يرجى الحذر.
- لدى استخدام المنتج في أماكن عامة، يرجى مراعاة الأشخاص الأخرين الموجودين حولك.

تفكيك المنتج

- لا تفكك المنتج واحمه من الصدمات المفاجئة. يوجد خطر حدوث صدمة كهربائية أو قصر في الدائرة أو نشوب
- حريق. - لا تستخدم المنتج إذا كان متضررًا! فقد يؤدي القيام بذلك إلى نشوب حريق أو التسبب بحروق أو إصابة أو بحدوث صنعة كهو بالنية.

الضوء والصوت

- لا تستخدم المنتج لفترة طويلة جدًا. فقد يؤدى ذلك إلى حدوث خلل في نظرك.
- لا تستخدمه لفترة طويلة مع مستوى صوت مرتفع جدًا. فقد يؤدي القيام بذلك إلى إلحاق ضرر بسمعك.

استخدم دائمًا المنتجات الأصلية

استخدم دائمًا المنتجات الأصلية. لا تستخدم هذا المنتج لأي غرض غير مخصص له.

استخدام المنتج أثناء التنقل

لا تستخدم المنتج أثناء التنقل فقد يكون ذلك خطيرًا جدًا. ومن شأنه أن يتسبب بحادث سير أو ضرر بالسلامة.

الحرارة والرطوبة المرتفعتان

 لا تترك المنتج معرضًا الأشعة الشمس العباشرة أو على بطانية أو بطانية كهربائية أو سجادة لفترة طويلة أو تتركه في مكان حار ورطب مثل غرفة الساونا. فقد يؤدي القيام بذلك إلى تشويه المنتج أو التسبب بتعطله أو بحدوث انفجار.

المواد الكيميانية

- لا تستخدم الكحول أو البنزين أو الثنر أو المنظفات لتنظيف المنتج. فقد يؤدى ذلك إلى نشوب حريق.
 - استخدم قطعة قماش ناعمة لمسح المنتج.

الأطفال والحيوانات الأليفة

 ابق المنتج بعيدًا عن متناول الأطفال والحيوانات الأليفة. لا تضع المنتج في فعك أو تعرّضه لصدمة قوية. يوجد أيضًا خطر حدوث صدمة كهربائية أو انفجار أو اختناق.

الحريق

- لا تقم بتوصيل مواد موصلة (قطع معدنية، رصاصات أقلام وغيرها) أو إدخالها في الموصلات الخارجية.
 - لا تغط المنتج أو تغلّفه ببطانية أثناء استخدامه.
 - لا تتخلص من المنتج كمهملات منزلية. فقد يؤدي ذلك إلى نشوب حريق أو إلحاق ضرر بالبيئة.

ضرر بالبشرة

إذا كنت تستخدم المنتج لفترة طويلة، فقد ترتفع درجة حرارة الهاتف عندما يكون موصولاً بالمنتج. تجنب لمس
 المنتج عندما يصبح ساخنا، فقد بودي ذلك إلى التعرض لحروق من الدرجة الخفيفة.

مغناطيس

 أبعد المنتج عن أي أجمام مخاطيسية كبطاقات الاتتمان وبطاقات الهواتف ودفاتر المصارف وبطاقات السفر. فقد تلحق هذه الأجمام المخاطيسية ضررًا به.

الطلاء

- إذا قمت بطلاء المنتج، فقد تلحق ضررًا بالجزء الخارجي منه أو تتسبب بعطل.
- في حال تَشر طلاء المنتج الخارجي أو ظهرت لديك حساسية بسبب إحدى المواد المستخدمة في المنتج؛ توقف عن استخدامه واستشر طبيبك.

التوصيل بأجهزة أخرى

- لا تقم بتوصيل المنتج بأي جهاز آخر بطريقة غير مُشار إليها في دليل المستخدم المفصل.
 - تأكد من عدم تشابك ذراعك أو أي أجسام غير ثابتة بالكيبل أو بالسلك.
- عليك التأكد من أن هاتفك مثبت بآمان أثناء أستخدام المنتج. وإلاه فقد يسقط الهاتف ولن تتمكن من استخدام جهاز
 LG 360 VR

ضرر المنتج

- بهدف منع إلحاق أي ضرر بالمنتج، إحرص على عدم إسقاطه على سطح قاس أو تعريضه لصدمة قوية.
- قد تتضرر بعض وظائف هذا المنتج أو قد يتغير شكله أو يتعطل في حال تم ثنيه أو سحقه ولم يتم تصليحه على

درجة الحرارة

 أستخدم الهاتف و خزّنه في مكان تتراوح درجة الحرارة بين 0 و 35 درجة منوية، إذا أمكن. قد يودي تعريض الهاتف إلى درجات حرارة مرتفعة أو متخفضة جدًا إلى إلحاق الضرر به أو تعطله أو حتى إلى حدوث انفجار.

معلومات اضافية

حصم \ التخلص من الأجهزة القديمة الخاصة بك



1 جميع الأجهزة الكهربائية والإلكترونية يجب التخلص منها بشكل منفصل عن النفايات المنزلية عبر منشأت التجميع المخصصة والمحددة من قبل الحكومة أو السلطات المحلية.

2 مساعد التخلص من جهازك القديم بشكل صحيح في الحد من التبعات السلبية المحتملة للبينة وصحة الإنسان.

3 لمزيد من المعلومات المفصلة حول التخلص من جهازك القديم، يرجى الاتصال بمكتب الشركة في مدينتك أو خدمة التخلص من النفايات أو بالمحل الذي اشتريت منه المنتج.

بيان التوافق

. و ل ك ك ل LG Electronics بموجبه أن المنتج LG-R100 يتوافق مع المتطلبات الأساسية و الأحكام الأخرى ذات الصلة الخاصة بالتوجيه 2014/30/EU. يمكن العثور على نسخة من إعلان التوافق على العنوان التالي http://www.lg.com/global/declaration

الضمان المحدود

تبعًا لشروط هذا الضمان المحدود، تضمن شركة LG ELECTRONICS أن يكون هذا المنتج خاليًّا من أي عوب غوب عليه من أي عوب المستهلك، ولمدة سنة (1) لاحقة. عوب في القصميع والمواد والتصنيع عند علية الشراء الأولى التي الجراها المستهلك، ولمدة سنة (1) لاحقة. إذا كان المنتج بحاجة إلى خدمة الضمان، يرجى إعادته إلى الباتع الذي الشتريقة منه أو الاتصال بمركز الاتصال المحلى الذيه بد من المعلومات.

ملاحظة: قد تختلف بعض المحتويات في الضمان المحدود حسب المنطقة أو منطقة الخدمة.

شركة إل جي للإلكترونيات – المشرق العربي منطقة مشروع العبدلي- جادة رفيق الحريري- الطابق الخامس

Product Overview

The LG 360 VR is a smart device that uses virtual reality technology for a unique immersive experience.

- When playing VR content with the LG 360 VR, you can enjoy the images as if you were in them by turning your head in any direction.
- You can use the LG 360 CAM (sold separately) to take photos and videos of VR content and view them on the LG 360 VR.
- This device is not compatible with the LG G5^{SE}.

Open Source Software Notice Information

- To obtain the source code under GPL, LGPL, MPL, and other open source licenses, that is
 contained in this product, please visit http://opensource.lge.com. In addition to the source
 code, all referred license terms, warranty disclaimers and copyright notices are available
 for download. LG Electronics will also provide open source code to you on CD-ROM for
 a charge covering the cost of performing such distribution (such as the cost of media,
 shipping, and handling) upon email request to opensource@lge.com. This offer is valid for
 three (3) years from the date on which you purchased the product.
- The open source license text can be found on the Manager app that works with the product.

ı


Precautions

- This product is for viewing VR content. To prevent injury, take frequent rests when using the product.
- Before connecting the product to your phone, make sure that you have checked if your phone is compatible with the LG 360 VR. The LG 360 VR may not operate if incompatible with the phone.
- When playing content not supported by the product, the screen may flicker or not be shown.
- Children under 15 years of age should not use this product to watch videos or play video games. The LG 360 VR may affect the vision development of children.
- If you have visual conditions such as strabismus or amblyopia, do not use this product. The
 use of this product may aggravate symptoms.
- If you often feel motion sickness, you may experience discomfort while using this product.
 If you feel any discomfort, immediately stop using it and take a rest.
- Pregnant women, senior citizens, mental health patients, patients with heart disease or any other serious conditions should consult their doctor before using this product.
- Stop using the product if it or the phone becomes hot. It may cause burns.
- Use it in a comfortable position while the device is horizontal. If you wear the product tilted to one side, you may become uncomfortable.
- It is recommended that you use the product while sitting in a chair, if possible. If you use it
 while moving around, you may trip over or fall and be seriously injured.
- The experience of virtual reality may cause certain symptoms, such as motion sickness.
 Besides motion sickness, it may cause excessive drowsiness and interfere with your ability to multitask. As it may pose a risk to your health, after using the product make sure that you take a rest before engaging in any other physical activities.
- · If you are using a medical device, consult your doctor before using the product.
- If you use the LG 360 VR for a long time, it may irritate your skin or leave an indentation on your face.

- This product is a device to magnify the display screen through a high-magnification lens.
 When viewing content, foreign particles smaller than pixels inside the display screen may be seen.
- · Removing the lens may cause the display to be contaminated by foreign substances.
- People with astigmatism should wear contact lenses to correct their vision.
- Whenever carrying or storing it, make sure that you keep it in the case. Even when in the case, the LG 360 VR may become worn or damaged by shock and vibration.




Product Components



- If there are any missing components, contact the retailer where you purchased the product.
- · Some items are subject to change without prior notice depending on the circumstances.
- The appearance and specifications of the product are subject to change without prior notice to improve performance.
- Always use genuine products. Using or connecting products that are not genuine may damage the product and thereby void the service warranty.

.

Product Description



How to Use the Keys

1. Select Key

Press: Select your content or a menu item focused in the centre of the screen. Press and hold: Enter the Settings screen.

2. Back Key


Press: Move to the previous screen or cancel operation.

Press and hold: Move to the home screen of the LG 360 VR app.

5

Adjusting the Position of the Lens

You can move the lens to the left or right to adjust it.




Adjusting the Focus of the Lens

You can turn the lens to focus it to better suit your vision.



When adjusting the lens, take the lens cap off.

Connections



- Connect the USB cable of the LG 360 VR to the USB port on your phone. It may take a
 while. With the LG 360 VR on, the screen of your phone will turns off. You can use your
 phone as a touch pad.
- This product will not operate normally when connected to an LG G5 if the LG CAM Plus, LG Hi-Fi Plus with B&O PLAY or any other devices that are not LG G5 modules are attached to the LG G5.
- When your LG 360 VR is idle for at least 15 minutes with its USB cable still connected, your LG 360 VR is automatically disconnected to prevent battery usage.
- There will be restrictions on connecting your LG 360 VR if your phone is low on battery or too hot.

7

Attaching the Light Blocker

1 Attaching the Light Blocker to the LG 360 VR.



2 Open the temples of the LG 360 VR, fit the Light Blocker in place, and then push on the sides to attach both of the side hooks.



3 Fit the bottom of the Light Blocker to the LG 360 VR. Hold the Light Blocker with your index fingers and then push on it with your thumbs to attach it. Press on it again firmly.



4 Fit the top of the Light Blocker to the LG 360 VR. Hold the Light Blocker with your index fingers and then push on it with your thumbs to attach it. Press on it again firmly.



5 The Light Blocker is now attached. If the hooks are not fastened completely, press on them again.



Features and Usage

Select Content or a Menu Item

To select content or a menu item, focus it in the centre of the screen, and then press the Select Key of the LG 360 VR or tap the screen of your phone.

Screen Drag

If you want to select a lot of content, you can drag the screen of your phone up, down, left, or right to move the screen.

Screen reorientation You can reorientate the screen

You can reorientate the screen by pressing and holding the screen with two fingers. The centre of the screen adjusts to your current perspective.

Move to the Previous Screen

Press the Back Key on the LG $360\,\mathrm{VR}$ or press and hold the screen of your phone to move to the previous screen.

Move to the Home Screen

Press and hold the Back Key on the LG 360 VR to move to the home screen.

Settings

Press and hold the Select Key on the LG 360 VR to go to Settings. You can adjust the screen orientation, brightness and notification settings via the relevant screen.

Call-related Features

You can press the button to answer the phone or end the call.

- · When the phone is ringing:
 - Press the Select Key to answer the call.
 - Press the Back button once to put the incoming call on hold. Press the button twice to reject the call.
- · When you are talking on the phone:
- Press the Select Key or the Back Key to end the call.

Important Safety Information

Thunder and Lightning

 During severe thunder or lightning storms, refrain from using the product. Lightning can cause serious injury or fire.

Water

- When the product is exposed to water, do not attempt to dry it out using a hot-air blower
 or hairdryer, or put it into a microwave or other oven. Doing so may cause the product to
 explode or cause it to deform or fail.
- If the product is wet, the colour of the label inside the product will change. In that case, you will not receive free service in the event the product fails. Please exercise care.
- Do not use the product when it's wet. Doing so may cause fire, excess heat, explosion or leakage.

Usage Environments

- Do not use it in dangerous places such as on a slope, cliff, or waterside.
- If the cable gets stuck in the doors of a vehicle, it can be very dangerous. Please exercise
 care.
- When you use the product in public places, be considerate of other people around you.

Disassembling the Product

- Do not disassemble the product and protect it from sudden impacts. There is a risk of electric shock, short circuit or fire.
- Do not use the product if it is damaged. Doing so may cause fire, burns, injury or electric shock.

Light and Sound

- Do not use the product for excessive periods of time. Doing so may cause visual impairment.
- Do not use it for a long time with the volume turned up high. Doing so may damage your hearing.

Only use Genuine Products

· Always use genuine products. Do not use this product for any unintended purposes.

Using the Product While Moving

 Do not use the product while you are moving around as it could be very dangerous. Doing so may also cause a traffic or other accident.

High Temperature and Humidity

Do not leave the product exposed to direct sunlight, on a blanket, an electric blanket or a
carpet for long periods of time, or in a hot and humid place, such as a sauna. Doing so may
cause the product to deform, fail or explode.

Chemicals

- Do not use alcohol, benzene, thinners or detergents to clean the product. Doing so may cause a fire.
- · Use a soft cloth to wipe the product.

Children and Pets

 Keep the product out of the reach of children and away from pets. Do not put the product in your mouth or subject it to a severe shock. There is also a risk of an electric shock, explosion, or suffication.

Fire

- Do not connect or insert conductive materials (metal pieces, pencil leads, etc.) into the
 external connectors.
- · Do not cover or wrap the product with a blanket while using it.
- Do not dispose of the product as household waste. Doing so may cause a fire or environmental damage.

Skin Damage

 If you use the product for a long time, the temperature of your phone may rise when it is connected to the product. Avoid touching the product when it becomes hot as it may cause a low-temperature burn.

Magnetism

 Place the product away from magnetic objects, such as credit cards, phone cards, bank books, and transit cards. Magnetism may damage the product.

Painting

- · If you paint the product, it may damage the exterior or cause a malfunction.
- If the exterior paint is peeling off, or you show an allergic reaction to a certain material in the product, stop using it and consult your doctor.

Connecting to Other Equipment

- Do not connect the product to any other equipment in a way that is not indicated in the detailed user quide.
- Make sure that your arm or any loose objects do not get entangled in the cable or cord.
- You must make sure that your phone is securely fastened while using the product.
 Otherwise, your phone may fall, and you will not be able to use the LG 360 VR.

Product Damage

- In order to prevent any damage, be careful not to drop the product on a hard surface or subject it to a severe shock.
- Some of the functions or the display may become damaged, or its appearance may be altered or impaired if it is bent or crushed and not repaired immediately.

Temperature

Use and store your phone in temperatures between 0°C and 35°C, if possible. Exposing
your phone to extremely low or high temperatures may result in damage, malfunction or
even explosion.

Additional Information



Disposal of your old appliance

- 1 All electrical and electronic products should be disposed of separately from the municipal waste stream via designated collection facilities appointed by the government or the local authorities.
- 2 The correct disposal of your old appliance will help prevent potential negative consequences for the environment and human health.
- 3 For more detailed information about disposal of your old appliance, please contact your city office, waste disposal service or the shop where you purchased the product.

DECLARATION OF CONFORMITY

Hereby, LG Electronics declares that this LG-R100 product is in compliance with the essential requirements and other relevant provisions of Directive 2014/30/EU. A copy of the Declaration of Conformity can be found at http://www.lg.com/global/declaration

Limited Warranty

SUBJECT TO THE CONDITIONS OF THIS LIMITED WARRANTY, LG ELECTRONICS WARRANTS THIS PRODUCT TO BE FREE FROM DEFECTS IN DESIGN, MATERIAL AND WORKMANSHIP AT THE TIME OF ITS ORIGINAL PURCHASE BY A CONSUMER, AND FOR A SUBSEQUENT PERIOD OF ONE (1) YEAR. SHOULD YOUR PRODUCT NEED WARRANTY SERVICE, PLEASE RETURN IT TO THE DEALER FROM WHOM IT WAS PURCHASED OR CONTACT YOUR LOCAL LG ELECTRONICS CONTACT CENTRE TO GET FURTHER INFORMATION.

Note: Some contents in Limited Warranty may differ depending on the region, or service area.

LG Electronics (Levant) - Jordan

Abdali Project, Rafik Al-Hariri Avenue, The Boulevard, Central Square, 5th Floor