



ENGLISH

SIMPLE MANUAL

LG Sound³⁶⁰ Portable *Bluetooth*[®] Speaker

To view the instructions of advanced features, visit <http://www.lg.com> and then download Owner's Manual. Some of the content in this manual may differ from your unit.

MODEL

NP7860W

NP7860P

NP7860U



* M F L 6 9 4 0 2 2 1 3 *

www.lg.com

Safety Information

CAUTION: TO REDUCE THE RISK OF ELECTRIC SHOCK DO NOT REMOVE COVER (OR BACK) NO USER-SERVICEABLE PARTS INSIDE REFER SERVICING TO QUALIFIED SERVICE PERSONNEL.

 This lightning flash with arrowhead symbol within an equilateral triangle is intended to alert the user to the presence of uninsulated dangerous voltage within the product's enclosure that may be of sufficient magnitude to constitute a risk of electric shock to persons.

 The exclamation point within an equilateral triangle is intended to alert the user to the presence of important operating and maintenance (servicing) instructions in the literature accompanying the product.

WARNING:

- To prevent fire or electric shock hazard, do not expose this product to rain or moisture.
- Do not install this equipment in a confined space such as a book case or similar unit.
- This unit contains magnets which can be harmful to some kind of object (Ex: Magnetic card, Pacemaker etc.).

CAUTION:

- Do not block any ventilation openings. Install in accordance with the manufacturer's instructions. Slots and openings in the cabinet are provided for ventilation and to ensure reliable operation of the product and to protect it from over heating. The openings shall be never be blocked by placing the product on a bed, sofa, rug or other similar surface. This product shall not be placed in a built-in installation such as a bookcase or rack unless proper ventilation is provided or the manufacturer's instruction has been adhered to.
- The apparatus should not be exposed to water (dripping or splashing) and no objects filled with liquids, such as vases, should be placed on the apparatus.
- No naked flame sources, such as lighted candles, should be placed on the apparatus.
- It is recommended that you use the 5 V AC adapter (more than 1.2 A) with this device. If you do not use the recommended adapter, charging is unavailable or charging time may differ.
- To avoid fire or electric shock, do not open the unit. Contact to qualified personnel only.
- Do not leave the unit in a place near the heating appliances or subject to direct sunlight, moisture, or mechanical shock.

- To clean the unit, use a soft, dry cloth. If the surfaces are extremely dirty, use a soft cloth lightly moistened with a mild detergent solution. Do not use strong solvents such as alcohol, benzine, or thinner, as these might damage the surface of the unit.
- Do not use volatile liquids such as insecticide spray near the unit. Wiping with strong pressure may damage the surface. Do not leave rubber or plastic products in contact with the unit for a long period of time.
- Do not place the unit over the vehicle's air bag. When the air bag deploys, it may result in injury. Before using in the car, fix the unit.
- Do not use the hands free function during driving a car.
- Do not leave the unit on an unstable place such as high shelves. It may fall down because of the vibration of the sound.
- Do not use high voltage products around this product. (Ex. Electrical swatter) This product may malfunction due to electrical shock.

CAUTION when using this product in environments of low humidity.

- It may cause static electricity in environments of low humidity.
- It is recommended to use this product after touching any metal object which conducts electricity.

CAUTION concerning the Power Cord

The Power Plug is the disconnecting device. In case of an emergency, the Power Plug must remain readily accessible.

NOTICE: For safety making information including product identification and supply ratings, please refer to the main label on the bottom of the apparatus.

This device is equipped with a portable battery or accumulator.

Safety way to remove the battery or the battery from the equipment:

Remove the old battery or battery pack, follow the steps in reverse order than the assembly. To prevent contamination of the environment and bring on possible threat to human and animal health, the old battery or the battery put it in the appropriate container at designated collection points. Do not dispose of batteries or battery together with other waste. It is recommended that you use local, free reimbursement systems batteries and accumulators. The battery shall not be exposed to excessive heat such as sunshine, fire or the like.

Disposal of your appliance




The symbol indicating separate collection for electrical and electronic equipment consists of the crossed-out wheeled bin.

Contact office for compliance of this product:

LG Electronics (Levant) - Jordan
Abdali Project, Rafik Al-Hariri Avenue, The Boulevard,
Central Square, 5th Floor

Operating



		Press the top of the speaker
Power	Power on / off  
BLUETOOTH	To pair your mobile device, select LG Sound 360 (xx) from device list.	
	Ready to pair another device Hold 
Playback Controls	Play / Pause Touch 
	Forward Skip Touch 
	Backward Skip Touch 
Equalizer Mode	Bass Boost / Treble Boost / Power Boost Touch 
LED light Control	Blinking / Always On / Off Touch 

LG Sound Sync



Dual Play



NFC Tag



For more information, download the online owner's manual. <http://www.lg.com>

Specification

Power Supply:

- 5 V \equiv 1.2 A (AC Adapter)
- Built-in rechargeable battery

Power consumption:

Dimensions: $\varnothing 67 \text{ mm} \times 204 \text{ mm}$

Net Weight: Approx. 0.6 kg

Operating Temperature:

5 °C to 35 °C

Operating Humidity: 5 % to 60 %

External Connector:

Micro USB port for charging battery

Communication: Bluetooth

Speaker:

- Type : Built-in
- Impedance Rate : Woofer 4 Ω , full range 8 Ω
- Rated Input Power : 12 W

Battery:

- Battery capacity : 5200 mAh
- Operating time is approx. 20 hours. It may vary depending on the battery status and operational conditions.

- Design and specifications are subject to change without notice.



دليل بسيط

LG Sound³⁶⁰ سماعة Bluetooth[®] محمولة

لعرض تعليمات الخصائص المتقدمة، قم بزيارة <http://www.lg.com> ومن ثم حمل دليل المالك.
قد تختلف بعض محتويات هذا الدليل عن وحدتك.

الطرزات

NP7860U

NP7860P

NP7860W



* M F L 6 9 4 0 2 2 1 3 *

www.lg.com

معلومات السلامة

تنبيه: للقليل من مخاطر الصدمة الكهربائية، لا تقم بازالة الغطاء (أو الغطاء الخالي)، حيث لا توجد أية أجزاء قابلة للصيانة عن طريق المستخدم، وقم بإياده مهمة الصيانة لفني خدمة أو هيل.

ينبه المرمز الذي يحتوي على صيغة برأس سهم داخل مثلث متساوي الأضلاع إلى تحذير المستخدم إلى وجود جهة كهربائية خطر غير معزول داخل هيكل المنتج والذي قد يكون كافٍ ليشكل خطراً يعرض الأشخاص لصدمة كهربائية.

كما يشير المرمز الذي يحتوي على علامة تعجب داخل مثلث متساوي الأضلاع إلى تنبيه المستخدم إلى وجود تعليمات تتغفل وصياغة (خدمة) مهمة في الكتيب المرافق مع المنتج.



تحذير:

• للقليل من خطير نشوب الحرائق أو حدوث الصدمات الكهربائية، لا تعرّض الجهاز للنّظر أو

• لا تثبت هذا الجهاز في مكان محمّل ممكّن أو وحدة مشابهة.

• تحذير هذه الوحدة على مغناطيسية يمكن أن تسبّب الضرر لبعض أنواع الأجسام

(مثلاً: بطاقة مغناطيسية، جهاز تنظيم ضربات القلب، الخ.).

تنبيه:

• لا تنسى من فتحات التهوية، ينبع تركيب الجهاز وفقاً لتعليمات المصانع.

ويزوي الآتيه إلى أن وظيفة التفريغ والفتحات الموجودة في الحجيرة تتطلّب في توفير التهوية وضمان التسخيل المزورق للمنتج وحمايةه من المخونة الزائنة. ينبع عدم سد الفتحات بوضع المنتج على سرير أو أريكة أو أي سطح آخر شبيه بذلك، ينبع عدم وضع هذا المنتج في التجهيزات المدحّمة مثل المكتبة أو الرف ما لم يتم توفير التهوية المناسبة أو يتم الالتزام بتعليمات الشركة المصنعة.

• لا يجب تعرّض المنتج للماء (قطرات الماء أو الرذاذ) ولا يجب وضع أي أشياء ملوثة بالماء، مثل الزهرة، فوق الجهاز.

• ينبع عدم وضع مصدر الالهيب المكسّف، مثل الشموع المشتعلة، على الجهاز.

• ينصح بإن تستخدم محول تيار 5 ف (أقل من 1.2 آ) مع هذا الجهاز. إذا لم تستخدم المحول الموصى به، يكون الشحن غير متوفّر أو قد يكون مختلفاً.

- لا تترك الوحدة في مكان بالقرب من أي ماء، لا تفتح الأجهزة، اتصل بالفني المؤهل فقط أو المساعدة الكهربائية.
 - لتنظيف الوحدة، استخدم قطعة قماشية ناعمة وجافة. إن كانت الأسطح متخصّصة للغایة، استخدم قطعة قماشية ناعمة مبللة بملوّن منظف معتمّل. لا تستخدم المباني الغوية مثل الكحول أو البنزين أو التتر نظراً لأن هذه المباني قد تسبّب في تلف سطح الوحدة.
 - لا تستخدم سوائل طهارة مثل رشاش المبيد الحشري بالقرب من الوحدة. قد يتسبّب السجع مع شدة الضغط في تلف السطح. لا تترك منتجات مطاطية أو إلاستيكية تلتصق الوحدة لفترة طويلة من الزمن.
 - لا تضع الوحدة على الوسادة الهوائية بالسيارة، عندما تعمل الوسادة الهوائية، يمكن أن يسبّب ذلك إصابة، قد تسبّب الحادث قبل الاستخدام في السيارة.
 - لا تستخدم وظيفة المساعدة الخارجية أثناءقيادة السيارة.
 - لا تترك الوحدة في مكان غير متّلّل الأرائك العالية. يمكن أن تسقط سبب الاهتزاز الناتج عن الماء.
 - لا تستخدم منتجات ذات جهد عالي حول هذا المنتج. (مثلاً، منشأة كهربائية) قد يتطلّب المنتج سبب صدمة كهربائية.
 - يرجي الحذر عند استخدام هذا المنتج في بيوت منخفضة الرطوبة.
 - حيث قد يتسبّب في وجود كهرباء ساقطة في البيوت منخفضة الرطوبة.
 - يوصى باستخدام هذا المنتج بعد امس أي شيء معدني يفوق توصيل الكهرباء.
- التحذيرات المتعلقة بقابلية الطاقة**
- لفصل مصدر التيار من مقبس، اسحب مقبس كابل الطاقة من منفذ التيار الموجود بالحانط. عند تثبيت المنتج، تأكّد من سهولة الوصول المقصى.
- ملحوظة: معلومات الأمان شاملة التعريف بالمنتج ومعدل توافره، يرجى الرجوع للملصق الرئيسي أسفل الجهاز.
- يتم تزويد هذا الجهاز ببطاريات قابلة للحمل أو بطارية مختبرة.
- الطريقة الآمنة لزالة البطاريات أو مجموعة البطاريات من الأجهزة: أزّل البطاريات القديمة أو مجموعة البطاريات، وابعد خطوات تجعيمها ترتيب عكسي، أمنّ تأوّل البتنة والتسبّب في جبل المخاطر لصحة البشر والحيوانات، يجب وضع البطاريات أو مجموعة البطاريات في حاوية مناسبة في نقاط التجميع المخصصة. تخلص من البطاريات أو البطاريات مع النفايات الأخرى، يوصى باستخدام أنظمة البطاريات والرمّاك المحلاة. ينبع عدم تعرّض البطاريات لدرجة حرارة زائدة عن الحد مثل أشعة الشمس أو الحرائق أو ما شابه ذلك.

اتخاذ من الجهاز الخاص بك

الرمز الذي يشير إلى مجموعة منفصلة من المعدات الإلكترونية والكهربائية هو عبارة عن صندوق قمامه بعجلات ومشطوب.



اتصل بـمكتب الامتثال الخاص بهذا المنتج:

شركة إل جي للإلكترونيات - المشرق العربي
منطقة مشروع العبدلي- جادة رفيق الحريري- الطابق الخامس

التشغيل



المواصفة

التيار الكهربائي:

- ٥ فـ --- ١.٢ آ (موجه تيار)
- بطارية مدمجة قابلة لإعادة الشحن

استهلاك الطاقة:

6 واط

الارتفاع:

٦٧ مم x ٢٠٤ مم

صافي الوزن:

حوالي 0.6 كغ

درجة حرارة التشغيل:

٥°C مئوية إلى ٣٥°C مئوية

درجة رطوبة التشغيل:

٥% إلى ٦٠%

الموصل الخارجي:

منفذ USB مصغّر لشحن البطارية

الاتصال: بلوتوث

السماعة:

- النوع: مدمجة
- نسبة المقاومة: مضخم ٤ أوم، نطاق كامل ٨ أوم
- قدرة الإدخال المصنفة: ١٢ واط

البطارية:

- سعة البطارية: 5200 مأ سن
- وقت التشغيل 20 ساعة تقريباً قد يختلف تبعاً لحالة البطارية والظروف التشغيلية.

- يخضع التصميم والمواصفات للتغيير دون إخطار مسبق.

اضغط على أعلى السماعة



تشغيل/إيقاف تشغيل الطاقة

الطاقة

لوصل جهازك المحمول اختر (xx) من قائمة الجهاز: LG Sound 360

جاهز لوصل جهاز آخر استمر بضغط

تشغيل/إيقاف مؤقت لمس

تحطيم للأمام لمس

خطوة للخلف لمس

تفعيل الجهير/تفعيل الثلاثي/تفعيل الطاقة لمس

يومض/مشغل دالما/إيقاف التشغيل لمس

البلوتوث

إعادة تشغيل

التحكمات

الوضع المساوي

حكم المؤشر الضوئي

NFC Tag



التشغيل المزدوج



مزاومة صوت LG



لزيادة المعلومات، حمل دليل المالك عبر الإنترنت . <http://www.lg.com>