


Quick Start Guide



*Image may vary depending on models.

⊕ : Depending on model

Unpacking

Check your product box for the following items. If there are any missing accessories, contact the local dealer where you purchased your product. The illustrations in this manual may differ from the actual product and item.



www.lg.com


P/No: MFL69446159 (1701-REV00)



English

- Read **Safety and Reference**.
- For the power supply and power consumption, refer to the label attached to the product.

USING THE USER GUIDE









Press the  button
to access home menu



Navigate & Select
User Guide



Refer User Guide for
detail information



CAUTION


Image shown may differ from your TV

When attaching the stand to the TV set, place the screen facing down on a cushioned table or flat surface to protect the screen from scratches.




6-A

55/60/65SJ85**




6-B


75/86SJ95**



7




8



CAUTION

Image shown may differ from your TV


When attaching the stand to the TV set, place the screen facing down on a cushioned table or flat surface to protect the screen from scratches.



CAUTION

Image shown may vary depending on model.
All connection cables & devices shown in the picture are not included along with the TV set.


ANTENNA /
CABLE IN




HDMI IN




HDMI IN/ARC




USB IN



LAN





AUDIO OUT/ H/P OUT



OPTICAL DIGITAL AUDIO OUT



! NOTE

Image shown may vary depending on model.
All connection cables & devices shown in the picture are not included along with the TV set.

! NOTE


- Some USB Hubs may not work. If a USB device connected using a USB Hub is not detected, connect it to the USB port on the TV directly.
- Connect the external power source if your USB is needed.

! NOTE

- Do not look into to the optical output port, Looking at the laser beam may damage your vision.
- Audio with ACP (Audio Copy Protection) function may block digital audio output.


ARC (Audio Return Channel)


- An external audio device that supports SIMPLINK and ARC must be connected using HDMI IN/ ARC port.
- When connected with a high-speed HDMI cable, the external audio device that supports ARC outputs SPDIF audio without additional audio cable and supports the SIMPLINK function.




NOTE

Image shown may vary depending on model.
All connection cables & devices shown in the picture are not included along with the TV set.











SJ85**




SJ95**




! NOTE


Image shown may vary depending on model.



! NOTE

Image shown may vary depending on model.





	A (mm)	B (mm)	C (mm)	D (mm)	E (mm)	F (kg)	F - G (kg)
55SJ850V-TA 55SJ850T-TA 55SJ850Y-TA	1229	763	245	708	58.2	19.6	18.1
60SJ850V-TA 60SJ850T-TA 60SJ850Y-TA	1338	827	285	769	58.7	23.7	22.1
Power requirement					AC 100-240 V ~ 50 / 60 Hz		

**NOTE**

Image shown may vary depending on model.



	A (mm)	B (mm)	C (mm)	D (mm)	E (mm)	F (kg)	F - G (kg)
65SJ850V-TA 65SJ850T-TA 65SJ850Y-TA	1452	891	285	833	58.7	28.6	27.0
75SJ955V-TA 75SJ955T-TA 75SJ955Y-TA	1680.6	1020.3	341.0	959.0	56.0	50.3	46.8
86SJ957V-TA 86SJ957T-TA 86SJ957Y-TA	1938	1176	366	1114	67.4	54.6	50.3
Power requirement					AC 100-240 V ~ 50 / 60 Hz		



MF_6946159

IN002043