




Diagram illustrating the power and remote control setup for the LG television.

Power Setup:

- Connect the power cord to the back of the TV and a power outlet.
- Press the power button on the TV or the remote control to turn the TV on.

Remote Control Setup:

- Insert the batteries into the back of the remote control.
- Press the power button on the remote control to test the batteries.

Dimensions and Weight:

Diagram showing the dimensions (A, B, C, D, E, F, G) and weight (kg) of the television models.

MODELS	A	B	C	D	E	F	F-G	Power consumption							
MODELOS	(mm)								(kg)				Consumo de potencia		
43UK6310PSE	977	977	629	629	216	216	575	575	80.8	80.8	8.4	8,4	8.3	8,3	95 W
43UK6300PSB															
43UK6300PDB															
49UK6300PSB	1110	1 110	709	709	231	231	650	650	81.1	81,1	11.3	11,3	11.1	11,1	120 W
49UK6310PSE															
49UK6300PDB															
50UK6300PSB	1133	1 133	723	723	231	231	663	663	87.9	87,9	10.8	10,8	10.6	10,6	130 W
50UK6300PDB															
55UK6300PSB	1247	1 247	785	785	231	231	729	729	88.6	88,6	13.9	13,9	13.7	13,7	135 W
65UK6300PDB	1468	1 468	917	917	269	269	854	854	89.9	89,9	21.4	21,4	21.0	21,0	190 W
43UK6200PSA	975	975	615	615	188	188	574	574	80.3	80,3	8.4	8,4	8.3	8,3	95 W
43UK6200PDA															
49UK6200PSA	1108	1 108	705	705	235	235	649	649	79.5	79,5	11.0	11,0	10.9	10,9	120 W
49UK6200PDA															
55UK6200PSA	1247	1 247	783	783	235	235	728	728	88.3	88,3	13.3	13,3	13.2	13,2	135 W
55UK6200PDA															
60UK6200PSA	1368	1 368	857	857	255	255	796	796	89.1	89,1	19.6	19,6	19.4	19,4	205 W
60UK6200PDA															

Power requirement / Alimentación requerida: AC 100-240 V ~ 50 / 60 Hz