




Quick Start Guide

LG Digital Signage (MONITOR SIGNAGE)

32SE3D	43SE3D	49SE3D	55SE3D	65SE3D
32SE3KD	43SE3KD	49SE3KD	55SE3KD	65SE3KD



+ Depending upon country

(Image may vary depending on models)


Unpacking

Check your product box for the following items. If there are any missing accessories, contact the local dealer where you purchased your product. The illustrations in this manual may differ from the actual product and item.



MFL69446187

P/No: MFL69446187 (1706-REV00)





English

You can download the web manuals for this product at the following websites. (Keyword : SE3D, SE3KD)



- World Wide : www.lg.com



SuperSign : <http://partner.lge.com>




32SE3D	43SE3D	49SE3D	55SE3D
32SE3KD	43SE3KD	49SE3KD	55SE3KD



CAUTION

Image shown may vary depending on model.
All connection cables & devices shown in the picture are not included along with the set.





+ 32/43/49/55SE3D





65SE3D


65SE3KD






CAUTION

Image shown may vary depending on model.
All connection cables & devices shown in the picture are not included along with the set.

 65SE3D





CAUTION
Image shown may vary depending on model.



IN002043