



簡易手冊

電競揚聲器

GAMING SPEAKER

GP9



MFL71805530

www.lg.com
版權所有 © 2023 LG Electronics Inc.
保留一切權利。
2203_Rev01



下載說明書
Download Manual


<Android>



<iOS>



下載應用程式
Download App



中文

連接及使用揚聲器

- 1 打開後蓋，並將揚聲器連接至電源適配器，以便在使用前充電。
- 2 使用 USB 傳輸線將揚聲器連接至桌上電腦

* 如果使用 USB 纜線連線揚聲器和裝置（PS4/PS5/PC 等）時沒有音訊輸出，請關閉 XBOOM 應用程式或電腦應用程式選單中的 UAC 2.0 選項。該設定在揚聲器關閉然後再開啟時應用。

- 1 使用 USB type-C 傳輸線將揚聲器連接至桌上電腦。
- 2 按下揚聲器上的電源  按鈕將其開啟。
- 3 重複按下揚聲器上的功能  按鈕，直至功能指示燈轉為白色。

❗ 如您是透過集成麥克風或頭戴式耳機進行語音聊天，請按下麥克風  按鈕。

❸ 使用光纖線將揚聲器連接至遊戲主機

- 1 使用光纖線將揚聲器連接至遊戲主機。
- 2 按下揚聲器上的電源  按鈕將其開啟。

❸ 重複按下揚聲器上的功能  按鈕，直至功能指示燈轉為紅色。

❹ 使用 Bluetooth 將揚聲器連接至智能手機

- 1 按下揚聲器上的電源  按鈕將其開啟。
- 2 重複按下揚聲器上的功能  按鈕，直至功能指示燈閃爍藍色。
- 3 按下智能手機上的設定  按鈕，選擇 Bluetooth 。開啟 Bluetooth 功能。
(關  > 開 )

- ④ 在智能手機的裝置清單中找到 "LG-GP9 (XX)", 並進行連接。智能手機透過 Bluetooth 成功連接後, 功能指示燈會轉為藍色。

- ⑤ 在智能手機上播放您選擇的音樂。

⑤ 連接 LG XBOOM 應用程式

- ① 在 Google Play 或 App Store 中搜尋 LG XBOOM 應用程式, 並安裝到您的智能手機上。

- ② 執行 LG XBOOM 應用程式 並使用其功能 (EQ、語音聊天、設定 等)。

- ❗ 對於耳機模式的 EQ, 產品頂部的音效按鈕可能會因產品 S/W 版本而異。

- 產品軟體更新後, 當 **耳機** 按鈕開啟時, 您可以使用 DTS Headphone: X 音效或使用 EQ 按鈕自定義 EQ。在耳機模式下無法選擇 FPS 或 RTS。

長按 **耳機** 按鈕 2 秒開關前置燈。

- ✦ 如需使用頭戴式耳機或耳機, 請將其連接至 **BT** 端子。

- 設計和規格若有變更, 恕不另行通知。
- 請於 <http://www.lg.com> 下載用戶說明書, 以了解更多資訊。

ENGLISH

Connecting and Using the Speaker

- 1 Charge the speaker before using it by opening the rear cover and connecting the speaker to the charging adapter.

- 2 Connect the speaker to the PC via a USB cable

* If there is no audio output when the speaker and device (PS4/PS5/PC, etc.) are connected with a USB cable, turn off the UAC 2.0 option in the XBOOM App or PC App menu. The setting is applied when the speaker is turned off and then on.

- 1 Connect the speaker to the PC via a USB C-type cable.
- 2 Press the **Power**  button on the speaker to turn it on.

- 3 Press the **Function**  button on the speaker repeatedly until the Function LED turns white.

- ! If you are using a voice chat through integrated microphone or headset, press the **Microphone**  button.

- 3 Connect the speaker to the Game Console via an optical cable

- 1 Connect the speaker to the Game Console via an optical cable.

- 2 Press the **Power**  button on the speaker to turn it on.

- 3 Press the **Function**  button on the speaker repeatedly until the Function LED turns red.

- 4 Connect the speaker to a smartphone via Bluetooth

- 1 Press the **Power**  button on the speaker to turn it on.

- 2 Press the **Function**  button on the speaker repeatedly until the Function LED flashes blue.

- ③ Press the **Settings**  button on the smartphone and select **Bluetooth** . Turn on the Bluetooth function.

(Off  > On )

- ④ Find "LG-GP9 (XX)" on the device list on the smartphone and connect to it. Once the smartphone is connected via Bluetooth, the Function LED turns blue.

- ⑤ On the smartphone, play a music of your choice.

⑤ Connecting the LG XBOOM App

- ① Find **LG XBOOM** app on the **Google Play** or **App Store** and install it on your smartphone.
- ② Run the **LG XBOOM** app and use more features (EQ, Voice Chat, Setting etc.)
- ❗ For EQ of Headset mode, the sound effects button on the top of the product may be different depending on the product S/W version.

-After product S/W update, you can use the DTS Headphone: X or Custom EQ with the EQ button while the **Headset**  button is On. FPS or RTS cannot be selected in Headset mode.

Press and hold the **Headset**  button for 2 seconds to turn the front lighting on or off.

- ✦ For using a headset or earphones connect it to the  terminal.

- Design and specifications are subject to change without notice.
- For more information, download the online owner's manual. <http://www.lg.com>

中文

規格

電源供應：

- 19 V  2.1 A (電源適配器)
- 內置式可充電電池

電源耗用

- 請參閱主標籤。

電源適配器

- 型號：ADS-45SN-19-2 19040G
- 製造商：SHENZHEN HONOR ELECTRONIC CO.,LTD
- 輸入：100 - 240 V ~ 50/60 Hz
- 輸出：19 V  2.1 A

尺寸 (闊 x 高 x 深)：

大約 376 mm x 86 mm x 108 mm

工作溫度：5 °C 至 35 °C

工作濕度：5 % 至 60 %

連接鐵芯 (可選)

把耳機線纏繞在鐵芯周圍。



安全資訊

小心：為減低觸電風險，切勿拆開本機前蓋 (或後蓋) 播放器內並無使用者可自行修理的部份如需維修，請聯絡合資格的技術人員。



等邊三角形內帶閃電箭頭的符號用以提醒使用者：產品內部含有未經絕緣的危險電壓，其強度可能會使人觸電。



等邊三角形內帶感嘆號的符號用以提醒使用者：產品隨附的資料中包含重要的操作及維修 (服務) 指引。

警告：

- 為免引起火警或觸電意外,切勿將本產品暴露於雨水或潮濕位置。
- 切勿把本設備安裝在狹窄的空間,如書櫃或類似的地方。
- 本機含有磁石,可能會損害其他物件(如磁卡,心臟起搏器等)。

注意：

- 切勿阻塞任何通風口。請依照生產商指示安裝。機殼上的插槽及通風開口特別為通風而設,可確保產品正常運作以及避免產品過熱。
切勿把產品置於睡床、沙發、地毯或其他類似的表面上,以免堵塞通風口。除非已有正確通風或依照生產商指示,否則本產品不應置於如書架或機架等內建裝置上。
- 切勿把本機暴露於有水(滴水或潑水)的地方,且不應將注滿液體的物體(如花瓶)於置在本機上。
- 切勿在本機上放置任何明火源,例如點燃的蠟燭。
- 為免引起火災或觸電意外,必須由合資格人士拆開本機。
- 切勿將本機置於供熱設備附近,或者直接曝露於陽光、潮濕或會受到機械性衝擊之處。

- 電源插頭為中斷電力連接的裝置。為緊急情況做好準備,確保電源插頭可隨時插上或拔掉。
- 如需清潔本機,請使用柔軟的乾布。如果表面非常髒,請用溫和的清潔劑溶液蘸濕的軟布輕輕擦拭。請勿使用酒精、汽油或稀釋劑等強溶劑,否則可能會損壞本機表面。
- 請勿在本機附近使用揮發性液體,例如殺蟲噴霧劑。強壓擦拭可能會損壞表面。請勿讓橡膠或塑膠產品長時間接觸本機。
- 切勿把本機置於汽車的安全氣囊之上。安全氣囊打開時,本機可能會導致受傷。在車內使用本機前,請先將其固定。
- 切勿在駕駛時使用免提功能。
- 請勿將本機放於不穩的地方(如高櫃上)。本機可能因聲音振動而掉落。
- 切勿在這項產品附近使用高電壓產品(如電蚊拍)。這項產品可能會因電擊而發生故障。

注意 請小心謹慎地在低濕度環境中使用本機。

- 在低濕度的環境中使用可能會產生靜電。
- 建議使用本產品前先觸摸任何導電的金屬物件。

說明：如欲了解安全標記信息包括產品標識和電源額定值，請參閱產品底部或其他表面上的主標籤。

注意：產品 只可使用本裝置提供的 AC 轉接器。請勿使用由其他裝置或其他製造商提供的電源供應。使用其他電線或電源供應可能導致裝置故障並使保養失效。

符號

	指交流電 (AC)。
	指直流電 (DC)。
	指第二類設備。
	指待機狀態。
	指「開」(電源)。
	指危險電壓。

內置電池的型號

請勿在氣壓低於 11.6 kPa 和海拔高於 15000 m 處儲存或運輸。

- 更換錯誤型號的電池會破壞保護措施 (例如，某些鋰電池類型)；
- 將電池丟入火中或熱烤箱中，或物理擠壓或切割電池，可能導致爆炸；
- 將電池放在極高溫的環境中，可能導致爆炸或易燃液體或氣體洩漏；
- 電池處於極低的氣壓下，可能導致爆炸或易燃液體或氣體洩漏。

適用於使用電池的型號

本機配有可攜式電池或蓄電池。

注意：如果電池更換為錯誤的類型，會引起火或爆炸的風險。

如何從設備上安全移除電池或電池組：

要移除舊的電池或電池組，按照與安裝步驟相反的順序操作。要防止環境污染和對人和/或動物健康的潛在威脅，舊電池或電池組必須放在適當的容器內，並置於專門的收集點。不要將電池或電池組與其他廢品一起處理。建議使用本地的免費報銷機制電池或電池組，（可能在你所處區域不適用）。電池或電池組不得暴露在過熱環境中，如陽光、火或類似環境。

安全注意事項

本機的插頭握柄是專為本產品所設計，且與附贈的電源線結合為一體，若您因為任何理由而需截短此電源線時

請勿再使用該插頭

應使用全新的插頭以確保連續使用之安全性。
請依據1994年之插頭及插座規範的規定，將插頭確實地與電源線結合。

ENGLISH

Specification

Power Supply:

- 19 V  2.1 A (AC Adapter)
- Built-in rechargeable battery

Power consumption

- Refer to the main label.

AC adapter

- Model : ADS-45SN-19-2 19040G
- Manufacturer : SHENZHEN HONOR ELECTRONIC CO.,LTD
- Input : 100 - 240 V ~ 50/60 Hz
- Output : 19 V  2.1 A

Dimensions (W x H x D):

Approx. 376 mm x 86 mm x 108 mm

Operating Temperature: 5 °C to 35 °C

Operating Humidity: 5 % to 60 %

Attaching the ferrite core (optional)

Wind the headset's wire once around the ferrite core.



Safety Information

CAUTION: TO REDUCE THE RISK OF ELECTRIC SHOCK DO NOT REMOVE COVER (OR BACK) NO USER-SERVICEABLE PARTS INSIDE. REFER SERVICING TO QUALIFIED SERVICE PERSONNEL.



This lightning flash with arrowhead symbol within an equilateral triangle is intended to alert the user to the presence of uninsulated dangerous voltage within the product's enclosure that may be of sufficient magnitude to constitute a risk of electric shock to persons.



The exclamation point within an equilateral triangle is intended to alert the user to the presence of important operating and maintenance (servicing) instructions in the literature accompanying the product.

WARNING:

- TO PREVENT FIRE OR ELECTRIC SHOCK HAZARD, DO NOT EXPOSE THIS PRODUCT TO RAIN OR MOISTURE.
- Do not install this equipment in a confined space such as a book case or similar unit.
- This unit contains magnets which can be harmful to some kind of object (Ex : Magnetic card, Pacemaker etc.).

CAUTION:

- Do not block any ventilation openings. Install in accordance with the manufacturer's instructions. Slots and openings in the cabinet are provided for ventilation and to ensure reliable operation of the product and to protect it from over heating. The openings should never be blocked by placing the product on a bed, sofa, rug or other similar surface. This product shall not be placed in a built-in installation such as a bookcase or rack unless proper ventilation is provided or the manufacturer's instruction has been adhered to.
- The apparatus should not be exposed to water (dripping or splashing) and no objects filled with liquids, such as vases, should be placed on the apparatus.
- No naked flame sources, such as lighted candles, should be placed on the apparatus.
- To avoid fire or electric shock, do not open the unit: contact a qualified personnel only.
- Do not leave the unit in a place near the heating appliances or subject to direct sunlight, moisture, or mechanical shock.
- The Power Plug is the disconnecting device. In case of an emergency, the Power Plug must remain readily accessible.
- To clean the unit, use a soft, dry cloth. If the surfaces are extremely dirty, use a soft cloth lightly moistened with a mild detergent solution. Do not use strong solvents such as alcohol, benzine, or thinner, as these might damage the surface of the unit.
- Do not use volatile liquids such as insecticide spray near the unit. Wiping with strong pressure may damage the surface. Do not leave rubber or plastic products in contact with the unit for a long period of time.
- Do not place the unit over the vehicle's air bag. When the air bag deploys, it may result in injury. Before using in the car, fix the unit.
- Do not use the handsfree function during driving a car.

- Do not leave the unit on an unstable place such as high shelves. it may fall down because of the vibration of the sound.
- Do not use high voltage products around this product. (ex. Electrical swatter) This product may malfunction due to electrical shock.

CAUTION when using this product in environments of low humidity.

- It may cause static electricity in environments of low humidity.
- It is recommended to use this product after touching any metal object which conducts electricity.

NOTICE: For safety marking information including product identification and supply ratings, please refer to the main label on the bottom or the other surface of the product.

CAUTION: Only use the AC adapter supplied with this device. Do not use a power supply from another device or another manufacturer. Using any other power cable or power supply may cause damage to the device and void your warranty.

Symbols

	Refers to alternating current (AC).
	Refers to direct current (DC).
	Refers to class II equipment.
	Refers to stand-by.
	Refers to "ON" (power).
	Refers to dangerous voltage.

For models using a built-in battery

Do not store or transport at pressures lower than 11.6 kPa and at above 15,000 m altitude.

- replacement of a battery with an incorrect type that can defeat a safeguard (for example, in the case of some lithium battery types);
- disposal of a battery into fire or a hot oven, or mechanically crushing or cutting of a battery, that can result in an explosion;
- leaving a battery in an extremely high temperature surrounding environment that can result in an explosion or the leakage of flammable liquid or gas; and
- a battery subjected to extremely low air pressure that may result in an explosion or the leakage of flammable liquid or gas.

For models using a battery

This device is equipped with a portable battery or accumulator.

CAUTION: Risk of fire or explosion if the battery is replaced by an incorrect type.

How to Safely remove the batteries or the battery pack from the equipment: To Remove the old batteries or battery pack, follow the assembly steps in reverse order. To prevent contamination of the environment and bring on possible threat to human and/or animal health, the old batteries or the battery pack must be put in an appropriate container at designated collection points. Do not dispose of batteries or battery pack together with other waste. It is recommended that you use local, free reimbursement systems batteries or battery packs, (may not be available in your area). The batteries or the battery pack should not be exposed to excessive heat such as sunshine, fire or the like.

IMPORTANT SAFETY NOTICE

The cord grip for the plug fitted to this product is built into the existing power cord as supplied. If, for any reason you need to shorten the cord,

DO NOT RE-USE THE PLUG

A new plug must be used to ensure your continued safety by securing the plug to the power cord in accordance with Plug & Socket Regulations 1994.

中文

符合標準聲明



LG Electronics 特此聲明，電競揚聲器類型的無線電設備符合 2014/53/EU 指令。你可以從以下互聯網地址獲得歐盟符合性聲明的全文：

<http://www.lg.com/global/support/cedoc/cedoc#>

為使用者安全着想，安裝或使用裝置時，身體與裝置之間的距離不應少於 20 厘米。

ENGLISH

Declaration of Conformity



Hereby, LG Electronics declares that the radio equipment type GAMING SPEAKER is in compliance with Directive 2014/53/EU. The full text of the EU declaration of conformity is available at the following internet address:

<http://www.lg.com/global/support/cedoc/cedoc#>

For consideration of the user, this device should be installed and operated with a minimum distance of 20 cm between the device and the body.







