



## OWNER'S MANUAL

# Stand

---

Please read this manual carefully before operating your set and retain it for future reference.

AM-ST19BA

AM-ST18CA

AM-ST18CB

AM-ST19CA

AM-ST19CC

AM-ST20BB



\* M F L 7 1 4 6 8 2 0 1 \*

(2111-REV05)

[www.lg.com](http://www.lg.com)

Copyright © 2019 LG Electronics Inc. All Rights Reserved.

\* Image shown may differ from your product.

## Safety instructions


 This symbol is intended to alert the user to the presence of important operating and maintenance (servicing) instructions in the literature accompanying the appliance.

Please read these safety precautions carefully before using the product.

-  • When lifting or moving the product, at least two people are required due to the heavy weight of the product.
  - The product may fall down, causing a malfunction or injury.
- Do not let children hang on or climb onto the product.
  - The product may fall down, causing an injury or even death.
- Do not install the product in an area which is unstable, vibrating or where the product is not completely supported (e.g. a shaky or tilted shelf).
  - The product may fall down or overturn, causing an injury or malfunction.
- Put the product on a flat and firm floor.
  - The product may fall and cause an injury.
- When moving or handling a product assembled with the Stand, be cautious about damaging the exterior of the product.
- When there is a stain or fingerprint left on the surface, wipe it off gently.
  - When removing a stain, do not use excessive force. Wiping with excessive force may cause scratches or discoloration on the product.

## Assembling and Preparing


### Accessories




## How to Assemble the Stand




1



2




3




4


► AM-ST19BA / AM-ST18CA / AM-ST18CB / AM-ST19CA / AM-ST19CC




► AM-ST20BB



5



6






- When assembling the stand, put the product on a table or a flat floor with its screen facing downwards. Before this place a soft, fluffy cloth on the surface then put the product on top to prevent the screen from being damaged.
- When assembling the stand, check if the screws are completely fastened. (If they are not completely fastened, the product may lean forward after being installed.) Avoid fastening the screws with excessive force because otherwise the joint part of the screws may be worn out, and the screws might come off.
- When assembling the product, do not use foreign substances (oil, lubricant, etc.) on the screws.
  - It may cause damage to the product.
- Before installing a wall mount support, disassemble the Stand by conducting the method to assemble the stand in a reverse order.

## Mounting on a Table

- 1 Lift and tilt the TV into its upright position on a table.
  - Leave a 10 cm (minimum) space from the wall for proper ventilation.



- 2 Connect the power cord to a wall outlet.




- Do not apply foreign substances (oils, lubricants, etc.) to the screw parts when assembling the product. (Doing so may damage the product.)
- If you install the TV on a stand, you need to take actions to prevent the product from overturning. Otherwise, the product may fall over, which may cause injury.
- Do not use any unapproved items to ensure the safety and product life span.
- Any damage or injuries caused by using unapproved items are not covered by the warranty.
- Make sure that the screws are inserted correctly and fastened securely. (If they are not fastened securely enough, the TV may tilt forward after being installed.) Do not use too much force and over tighten the screws; otherwise screw may be damaged and not tighten correctly.
- Only use the authorized stand and wall mounting bracket made specifically for LG products.
  - Pursuant to Consumer Protection Law, LG Electronics will not be held responsible for any product malfunction, material damage or injury caused by using products not authorized by LG Electronics.

## Attaching the TV to a Desk

(Depending on model)


**WARNING:** The TV should be attached to a desk so it cannot be pulled in a forward/backward direction, potentially causing injury or damaging the product.

### A type




- Screw : M5 x L (\*L: Table depth + 8~10 mm)  
ex) Table depth: 15 mm, Screw: M5 x L25


### B type



2-Screws for Stand Fixing,  
2-Washers for Stand Fixing,  
2-Nuts for Stand Fixing  
(Supplied with TV)




## Securing the TV to a Wall



- 1 Insert and tighten the eye-bolts, or TV brackets and bolts on the back of the TV.
  - If there are bolts inserted at the eye-bolts position, remove the bolts first.
- 2 Mount the wall brackets with the bolts to the wall. Match the location of the wall bracket and the eye-bolts on the rear of the TV.
- 3 Connect the eye-bolts and wall brackets tightly with a sturdy rope. Make sure to keep the rope horizontal with the flat surface.
  - Use a platform or cabinet that is strong and large enough to support the TV securely.
  - Brackets, bolts and ropes are not provided. You can obtain additional accessories from your local dealer.

## Adjusting the Angle of the TV to suit view

Swivel 20 degrees to the left or right and adjust the angle of the TV to suit your view.



- When adjusting the angle of the product, watch out for your fingers.
- Personal injury may occur if hands or fingers are pinched. If the product is tilted too much, it may fall, causing damage or injury.

## Specifications

AM-ST19BA	
<b>Model</b>	43UT782H0ZA
	43UT782H9ZA
	43UT782V0ZA
	43UT782V0ZC
	43UT782V9ZC
	43UT782H1ZA
	43UT782V2ZA
43UT782V9ZA	
<b>Width x Depth x Height (mm)</b>	570 x 303 x 235.1
<b>Weight (kg)</b>	3.2

AM-ST18CA	
<b>Model</b>	43/49UU662H-ZE
	49UT662H2ZB
	49UT662H0ZB
<b>Width x Depth x Height (mm)</b>	570 x 303 x 299.2
<b>Weight (kg)</b>	3.2

AM-ST18CB	
<b>Model</b>	55UU662H-ZE
<b>Width x Depth x Height (mm)</b>	570 x 303 x 227
<b>Weight (kg)</b>	3.2

AM-ST19CA	
<b>Model</b>	43UT662H0ZC
	43UT662H2ZC
	43US662H0ZC
	43US662H9ZC
	43US665H0ZC
	43US342H0ZC
	43US342H9ZC
<b>Width x Depth x Height (mm)</b>	570 x 303 x 228.7
<b>Weight (kg)</b>	3.2

<b>AM-ST19CC</b>	
<b>Model</b>	55UT662H0ZC 55UT662H2ZC 50/55US662H0ZC 50/55US662H9ZC 50/55US665H0ZC 50/55US342H0ZC 50/55US342H9ZC
<b>Width x Depth x Height (mm)</b>	570 x 303 x 226.0
<b>Weight (kg)</b>	3.2

<b>AM-ST20BB</b>	
<b>Model</b>	49US762H0ZC 55US762H0ZC
<b>Width x Depth x Height (mm)</b>	570 x 303 x 228
<b>Weight (kg)</b>	3.2



The model and serial number of the product are located on the back and on one side of the product. Record them below in case you ever need service.

Model

---

Serial No.

---