



SIMPLE MANUAL

# Wireless Sound Bar

ENGLISH

Please read this manual carefully before operating your set and retain it for future reference.

To view the instructions of advanced features, visit <http://www.lg.com> and then download Owner's Manual. Some of the content in this manual may differ from your unit.


MODEL  
SJ3



[www.lg.com](http://www.lg.com)  
Copyright © 2017-2021 LG Electronics Inc. All Rights Reserved.



## Front Panel




$\phi/I$  ..... Standby/ON

F ..... Selects Function

- / + ..... Adjusts Volume

## Rear Panel



PORT.IN ..... Connect to a Portable device

OPTICAL IN ..... Connect to an Optical device

USB ..... Connect to a USB device

## 1

## Subwoofer Connection

Place the wireless subwoofer near the speaker and follow steps below.

- 1 Connect the power cord of wireless subwoofer and sound bar to the outlet.
- 2 Turn on the main unit :


The sound bar and wireless subwoofer will be **automatically** connected. The subwoofer's green LED turns on.

## Subwoofer Connection Manually

- 1 Press **Pairing** button on the rear of the wireless subwoofer.
  - The green LED on the rear of wireless subwoofer blinks quickly.
- 2 Turn on the main unit.
- 3 Pairing is completed.
  - The green LED on the rear of wireless subwoofer turns on.




Keep the sound bar and the subwoofer away from the device (ex. wireless router, microwave oven, etc.) over 1m to prevent wireless interference.



## 2


## TV Connection

- 1 Connect the sound bar to the TV using Optical cable.
- 2 Set up [External Speaker (Optical)] on your TV setting menu.



### Additional Device Connection

- 1 Connect to the external device as follows.



- 2 Set the input source by pressing **F** on the remote control or unit repeatedly.

## Remote control




**ASC/STANDARD/CINEMA:** Selects the sound effect.

**NIGHT ON/OFF:** Turns down the volume at night.

**WOOFR LEVEL +/-:** Adjusts the volume level of subwoofer.

**AUTO POWER ON/OFF:** Automatically turns on by an input source.

### Replacement of battery



## Additional Information

### Specification

|                                    |                                                                                                |
|------------------------------------|------------------------------------------------------------------------------------------------|
| Power requirements                 | Refer to the main label.                                                                       |
| Power consumption                  | Refer to the main label.                                                                       |
| Dimensions (W x H x D)             | Approx.<br>950 mm x 71 mm x 47 mm                                                              |
| Bus Power Supply (USB)             | 5 V  500 mA |
| Amplifier (Total RMS Output power) | 300 W RMS                                                                                      |

Design and specifications are subject to change without notice.



### **Российская Федерация**

Импортер ООО "ЛГ Электроникс Рус"

Адрес импортера: 143160, Российская Федерация, Московская область, Рузский городской округ, территория Минское шоссе, километр 86-й, дом 9

Адрес производителя : ЛГ Электроникс (Хужоу) Инк., завод Хатаи  
516006, Китай, пров. ГуанДонг, г. Хужоу, Промышленная зона  
Жонгкай, Индустриальный парк Хутай, ХуФенг Донг Уи Роуд, 13.

**Сделано в Китае**

### **Україна**

Вироблено в : ЛГ Електронікс (Хужоу) Інк., завод Хатай  
516006, Китай, пров. ГуанДонг, м. Хужоу, Промислова зона Жонгкай,  
Індустріальний парк Хутай, ХуФенг Донг Уі Роуд, 13.

### **Қазақстан Республикасы**

Импорттаушы АҚ "ЭЛ Джи Электроникс Алматы Қазақстан", 050061, Алматы қ., Көкорай көшесі, 2А/9

Өндірушінің мекенжайы: LG Electronics(Huizhou) Inc. Huitai Factory  
516006, Қытай, ГуанДонг ауданы, Хужоу қаласы,  
Жонгкай өнеркәсіптік аймағы, Хутай Индустриялық саябағы,  
ХуФенг Донг Уи Роуд, 13.

Қазақстан Республикасы территориясында тұтынушылардан келіп түскен талаптар мен ұсыныстарды қарайтын және тауарды жөндеу мен техникалық қызмет көрсететін ұжым:

АҚ «Эл Джи Электроникс Алматы Қазақстан», 050061, Қазақстан Республикасы, Алматы қ., Көкорай көшесі, 2А/9. Басқа сервис орталықтары жайында мағлұматты "Тұтынушыға қызмет көрсету орталығына" телефон шалу арқылы білуге болады.

**Қытайда жасалған**

