



## Pagination & Folding

8 pages



4 pages



## Printing Specifications

|                       |       |                                    |      |  |               |             |             |
|-----------------------|-------|------------------------------------|------|--|---------------|-------------|-------------|
| Material              | Cover | Woodfree 80 g/m <sup>2</sup>       | Note |  | RYU HWA YEONG |             |             |
|                       | Inner | Woodfree 80 g/m <sup>2</sup>       |      |  |               |             |             |
| Coating               | Cover | Uncoated                           |      |  | Prepared      | Description | Manual      |
|                       | Inner | Uncoated                           |      |  |               |             |             |
| Color                 | Cover | 1 color (Black)                    |      |  | 2018-07-19    | P/No.       | MFL70460190 |
|                       | Inner | 1 color (Black)                    |      |  | Checked       |             |             |
| Size                  |       | 148 x 210 mm (A5 size_Folded size) |      |  | Approved      | Ver.        | 1.0         |
| Binding Method        |       | Only folding                       |      |  |               |             |             |
| Book Binding          |       | Folding 3 times                    |      |  |               |             |             |
| Completed total pages |       | 8                                  |      |  |               |             |             |

# SIMPLE MANUAL

## Sound Bar

Please read this manual carefully before operating your set and retain it for future reference.  
To view the instructions of advanced features, visit <http://www.lg.com> and then download  
Owner's Manual. Some of the content in this manual may differ from your unit.

MODEL  
SK1D




MFL70460190

[www.lg.com](http://www.lg.com)


Copyright © 2018 LG Electronics Inc. All Rights Reserved.

1806\_Rev01

ENGLISH



### Front Panel




o/I ..... Standby/ON

F ..... Selects Function.

- / + ..... Adjusts Volume.

### Rear Panel




PORT.IN ..... Connect to a Portable device

OPTICAL IN ..... Connect to an Optical device

USB ..... Connect to a USB device


### TV Connection

- 1 Connect the sound bar to the TV using Optical cable.
- 2 Set up [External Speaker (Optical)] on your TV setting menu.




### Additional Device Connection

- 1 Connect to the external device as follows.



- 2 Set the input source by pressing **F** on the remote control or unit repeatedly.

### Remote control




**ASC/STANDARD/CINEMA:** Selects the sound effect.

**NIGHT ON/OFF:** Turns down the volume at night.

**DRC ON/OFF:** Dynamic Range Control optimizes the volume level of compatible Dolby Digital content.

**AUTO POWER ON/OFF:** Automatically turns on by an input source.

### Replacement of battery



### Additional Information

#### Specification

|                                    |                                   |
|------------------------------------|-----------------------------------|
| Power requirements                 | Refer to the main label.          |
| Power consumption                  | Refer to the main label.          |
| Dimensions (W x H x D)             | Approx.<br>950 mm x 71 mm x 47 mm |
| Bus Power Supply (USB)             | 5 V  500 mA                       |
| Amplifier (Total RMS Output power) | 100 W RMS                         |

Design and specifications are subject to change without notice.

MANUAL DE USUARIO

Barra de sonido

Lea este manual detenidamente antes de utilizar el aparato y guárdelo como referencia para el futuro.  
Lea atentamente este manual antes de operar su producto. Para ver las instrucciones de las funciones avanzadas, visite <http://www.lg.com> y descargue el Manual del Propietario. Puede que algunos de los contenidos de este manual no se ajusten exactamente a su unidad.

MODELO  
SK1D




www.lg.com  
Copyright © 2018 LG Electronics Inc. Todos los derechos reservados.  
1806\_Rev01

ESPAÑOL




Panel frontal



⏻/I ..... Modo de espera/Encendido  
F ..... Selecciona la Función  
- / + ..... Ajusta el volumen


Panel trasero



PORT.IN ..... Conectar a un dispositivo Portátil  
OPTICAL IN ..... Conectar a un dispositivo Óptico  
USB ..... Conectar a un dispositivo USB


Conexión del TV

- 1 Conecte el dispositivo a la Barra de sonido y a la TV utilizando un cable Óptico.
- 2 Establezca [Altavoz Externo (Óptico)] en el menú de ajuste de su TV.




Conexión de un dispositivo externo

- 1 Conecte el dispositivo externo como sigue.



- 2 Seleccione la fuente de entrada pulsando F repetidamente en el mando a distancia o la unidad.

Mando a distancia




**ASC/STANDARD/CINEMA** : Seleccione el efecto de sonido.

**NIGHT ON/OFF**: Baja el volumen durante la noche.

**DRC ON/OFF**: Dynamic Range Control optimiza el nivel del volumen del contenido Dolby Digital compatible.

**AUTO POWER ON/OFF**: Esta unidad se enciende automáticamente con una fuente de entrada.

Reemplazo de batería



Información adicional

Especificación

|                                             |                                             |
|---------------------------------------------|---------------------------------------------|
| Requisitos de alimentación                  | Consulte la etiqueta principal del aparato. |
| Consumo de energía                          | Consulte la etiqueta principal del aparato. |
| Dimensiones (L x A x F)                     | Aprox. 950 mm x 71 mm x 47 mm               |
| Suministro de Alimentación de Bus (USB)     | 5 V  500 mA                                 |
| Amplificador (potencia de salida RMS total) | 100 W Eficaz                                |

El diseño y las especificaciones están sujetos a cambios sin previo aviso.