



## SIMPLE MANUAL

# Mini Hi-Fi Audio

ENGLISH

Please read this manual carefully before operating your set and retain it for future reference.

To view the instructions of advanced features, visit <http://www.lg.com> and then download Owner's Manual. Some of the content in this manual may differ from your unit.

MODEL

OL45



MFL71379829


1902\_Rev01

[www.lg.com](http://www.lg.com)

Copyright © 2021-2022 LG Electronics Inc. All Rights Reserved.



## Front Panel



### 1 (Standby)

Turns the power on or off.

#### F (Function)

- Selects the function and input source.
- Press and hold to adjust delay time when using PARTY LINK with AUX.

#### VOL (Volume) -/+

Adjusts speaker volume.

### 2 MIC (Microphone) ECHO / DEMO

- Selects ECHO mode.
- In power off status, if you press **MIC ECHO / DEMO**, show demo mode.

#### VOCAL EFFECTS

Selects various vocal effects mode.

#### LIGHTING

Selects the lighting mode.

### 3 USB Port

You can play sound files by connecting the USB device.

### 4 Display window

### 5 Disc tray

### 6 (Remote sensor)

### 7 (Play/Pause)

Starts or pauses playback.

#### (Skip/Search)

- Skips backward or forward.
- Searches for a section within a track/file.
- Selects the radio stations.

#### (Stop)

Stops playback or cancels DELETE function.

### 8 (Open/Close)

Opens and closes the disc tray.


#### MIC VOL (Microphone volume) -/+

Adjust microphone volume.

#### TWIN

Connects two speakers for TWIN mode in WIRELESS PARTY LINK.

## Rear panel



- 1** Power cord
- 2** MIC (Microphone) jack
- 3** ANTENNA (FM)
- 4** **AUX IN** (L/R): Connect an auxiliary device.  
**AUX OUT** (L/R): Connect to an input of external device.

### Controller App



Download the **LG XBOOM** App to your device.  
(Android only)

### LG Sound Sync (Wireless)



For more information, download the online owner's manual. <http://www.lg.com>

## Additional Information

### Specifications

|                                       |                                                                                              |
|---------------------------------------|----------------------------------------------------------------------------------------------|
| Power Requirements                    | Refer to the main label on the unit.                                                         |
| Power Consumption                     | Refer to the main label on the unit.                                                         |
|                                       | Networked standby : 0.5 W<br>(If all network ports are activated.)                           |
| Dimensions (W x H x D)                | Approx. 451.5 mm x 317.0 mm x 305.5 mm                                                       |
| Bus Power Supply (USB)                | 5 V  500 mA |
| Amplifier<br>(Total RMS output power) | 220 W RMS                                                                                    |

Design and specifications are subject to change without notice.


### Note

- Do not look directly at the light emitting part when the LIGHTING is turned on.
- If the illumination brightness is glaring, switch on the room lights or turn off the LIGHTING of the unit.

### How to disconnect the wireless network connection or the wireless device

Turn off the unit by pressing the power button for more than 5 seconds.

### Replacement of battery



### Declaration of Conformity



Hereby, LG Electronics declares that the radio equipment type MINI HI-FI AUDIO is in compliance with Directive 2014/53/EU. The full text of the EU declaration of conformity is available at the following internet address:

<http://www.lg.com/global/support/cedoc/cedoc#>

For consideration of the user, this device should be installed and operated with a minimum distance of 20 cm between the device and the body.



-----

-----

-----

-----

-----

-----

-----

-----

-----

-----



-----

-----

-----

-----

-----

-----

-----

-----

-----

-----



-----

-----

-----

-----

-----

-----

-----

-----

-----

-----



#### **Российская Федерация**

Импортер ООО "ЛГ Электроникс Рус"

Адрес импортера: 143160, Российская Федерация, Московская область, Рузский городской округ, территория Минское шоссе, километр 86-й, дом 9

Адрес производителя : ЛГ Электроникс (Хужоу) Инк., завод Хатаи  
516006, Китай, пров. ГуанДонг, г. Хужоу, Промышленная зона  
Жонгкай, Индустриальный парк Хутай, ХуФенг Донг Уи Роуд, 13.

**Сделано в Китае**

#### **Україна**

Вироблено в : ЛГ Електронікс (Хужоу) Інк., завод Хатай  
516006, Китай, пров. ГуанДонг, м. Хужоу, Промислова зона Жонгкай,  
Індустріальний парк Хутай, ХуФенг Донг Уі Роуд, 13.

#### **Қазақстан Республикасы**

Импорттаушы АҚ "ЭЛ Джи Электроникс Алматы Қазақстан", 050061, Алматы қ., Көкорай көшесі, 2А/9

Өндірушінің мекенжайы: LG Electronics(Huizhou) Inc. Huitai Factory  
516006, Қытай, ГуанДонг ауданы, Хужоу қаласы,  
Жонгкай өнеркәсіптік аймағы, Хутай Индустриялық саябағы,  
ХуФенг Донг Уи Роуд, 13.

Қазақстан Республикасы территориясында тұтынушылардан келіп түскен талаптар мен ұсыныстарды қарайтын және тауарды жөндеу мен техникалық қызмет көрсететін ұжым:

АҚ «Эл Джи Электроникс Алматы Қазақстан», 050061, Қазақстан Республикасы, Алматы қ., Көкорай көшесі, 2А/9. Басқа сервис орталықтары жайында мағлұматты "Тұтынушыға қызмет көрсету орталығына" телефон шалу арқылы білуге болады.

**Қытайда жасалған**