



Air Cleaner

OWNER'S MANUAL

- Please read this manual carefully and thoroughly before operating this unit.
- Contact the authorized SVC man for repair or maintenance of this unit.
- The appliance is not intended for use by young children or infirm persons without supervision.
- To ensure that young children do not play with the appliance, they should be supervised.

ITALIANO

20560FM

..... P.1 - P.8

..... P.9 - P.16

TABLE OF CONTENTS

SAFETY PRECAUTIONS.....	2
POSITIONING	4
FEATURES	5
HOW TO USE	6
HOW AND WHEN TO CHANGE FILTER	7
CLEANING/TROUBLESHOOTING	8

SAFETY PRECAUTIONS

To prevent injury to the user or other people and property damage, the following instructions must be followed.

■ Incorrect operation due to ignoring these instructions may cause harm or damage to the user. The seriousness of these hazards are classified by the following indications.

**Warning** : This indication shows the possibility of causing death or serious injury.

**Caution** : This indication shows the possibility of causing injury or damage to property only.



■ The items to be followed are classified by the following symbols.

	Symbol(with white background) denotes item that is PROHIBITED from doing.
	Symbol(with white background) denotes item that is COMPULSORY to be carried out.




⚠ WARNING

- Otherwise, it will cause an electrical shock or fire due to heat generation or electrical shock.
- It will cause electrical shock or fire due to heat generation.
- It will cause electrical shock or fire.
- If the supply cord is damaged, it must be replaced by the manufacturer or its service agent or a similarly qualified person in order to avoid a hazard.





- It will cause electrical shock or fire due to heat generation.
- It may cause electrical shock.
- If the unit continues to be operated in an abnormal condition, it may cause a fire, trouble, etc. In this case, consult your dealer.




⚠ CAUTION

- Since the fan rotates at high speed during operation, it may cause an injury.
- Water may enter the unit and degrade the insulation. It may cause an electric shock.
- An oxygen shortage may occur.



⚠ CAUTION


- It may cause a fire or deformation of the cabinet.



- It may cause an electric shock.



- Do not use attachments not recommended by L.G.






- It may cause some destructions of unit.




POSITIONING

- In general, it is advisable to place the Air Cleaner with its rear side against the wall and standing on the floor.
- Never obstruct the air inlet or outlet openings.
- Especially for allergic users it is advisable to use more Air Cleaners than one in both the bedroom and the living room and to let these run continuously.




FEATURES




■ Electrostatic & Deodorization Filter is in the filter case.

HOW TO USE


- Plug the power plug into a wall outlet.



- Push the  /  (On/Off & Fan Speed) button, then the unit will work. The indicator lamp will show the present fan speed at the same time.




- By continually pushing the button, the fan speed will change in the  (Low → Normal → High → Stop) working order. Set the  /  (On/Off & Fan Speed) button to the desired setting.
- Ionization works from start to finish working.
- A little displeasurable smell may occur, due to many negative ions.




HOW AND WHEN TO CHANGE FILTER


- Disconnect the power plug from a wall outlet, then push the "hand" mark of the filter case which is located in the right section of body.



- Open the filter case by pulling the upper part of the filter case. Then throw the dirty filter away.





- After removing the outer vinyl of a new filter, install the new filter in the filter case positioning the white side of the filter upside.
- Assemble each upper and lower filter case by hooking them up to the center part. Then insert the filter case into the body of the unit.




- Replace old filters periodically. If a dirty filter is not changed, purifying doesn't work well.

- The filter can be used for about three months, but the period of usage may be shorten depending on environmental conditions. (ex: smoking, pollution)



CLEANING

- Always disconnect the appliance from the wall outlet before removing parts and cleaning.
- The appliance can be cleaned with a damp cloth, if required, with some detergent.
- Use only the original LG filters.



TROUBLE SHOOTING

Problem	Possible Causes	What to do
The unit doesn't work at all.	• Check the power cord. • The fuse is blown or circuit breaker is tripped.	• Plug the power plug into a wall outlet. • Check the house fuse or circuit breaker box and replace the fuse or reset the breaker.
The unit doesn't work well.	• Check the used filters for the degree of dirtiness. • The air inlet may be blocked.	• If three months have passed, then change the old filter. (Refer to HOW AND WHEN TO CHANGE FILTER) • Remove any obstacles

