

繁體中文
簡體中文
ENGLISH

nexus 4

快速入門指南
快速入门指南
Quick Start Guide



CE 0168 !

MBM63862522 (1.0) G

繁體中文

nexus 4

快速入門指南


如需網上協助及支援，請前往
support.google.com/nexus

Google、Android、Gmail、Google 地圖、Nexus、Google Play、YouTube、Google+、及其他商標均屬於 Google Inc.。Google 的註冊商標已於 <http://www.google.com/permissions/guidelines.html> 列出。LG 及 LG 標誌乃 LG Electronics Inc. 的註冊商標。所有其他商標均屬於其擁有者。

本指南的內容可能與產品或其軟件的某些細節有所不同。此文件中所有資訊如有更改，恕不另行通知。

如需網上協助及支援，請前往 support.google.com/nexus


產品包裝內包含：



Nexus 4



Micro USB 線




旅行充電器




SIM 彈出工具

- 如任何部件損壞或缺失，請聯絡銷售商以尋求協助。
- 請只使用經認可配件。
- 配件可能因國家和地區而有所不同。

您的 Nexus 4





返回




底部

為電池充電

當首次開啓您的 Nexus 4 包裝時電池可能未完成充電。您可於盡早於可能的情況下為電池完成充電。

如您使用的為手機隨附的旅行充電器，將數據線的一端連接至手機的充電接口並將另一端連接至旅行充電器。然後將旅行充電器連接到電源插座。




- 旅行充電器會因國家和地區而有所不同。
- 請只使用 Nexus 4 隨附的旅行充電器及 Micro USB 線。使用不同的旅行充電器或連接線有可能對手機造成損壞。
- 機身電源插座與此旅行充電器的輸入電壓範圍為 AC 100V-240V，並此旅行充電器而定輸出電壓為 DC 5V、1.2A。
- 通過以 USB 線接駁到其他如手提電腦的其他裝置進行充電，可能比以旅行充電器需更長時間完成充電。
- Nexus 4 的電池並不能被移除。切勿嘗試將手機打開。

如您使用的為無線充電器，請閱覽充電器隨附的指引說明。

注意：如您使用無線充電器，請務必使用經認可的型號及於使用時必須根據指引。Nexus 4 或不能產生足夠電流以啟動無線充電器。

插入 Micro SIM 卡，開啓手機電源

於開始使用手機前，您可能需插入 Micro SIM 卡。如並無插入 Micro SIM 卡，手機鎖定畫面將顯示「沒有 SIM 卡」訊息。




SIM 卡槽位於手機左側的音量鍵下方。彈出按鍵為位於卡槽上方的細小圓孔。要安裝新的 SIM 卡：

1. 要安裝新的將與手機隨附的 SIM 卡彈出工具（或幼針）插入彈出按鍵孔並用力按壓直至卡槽彈出。
2. 拉出卡槽並將 micro SIM 卡以接觸點向外及帶角的一端指向右方的方式放置到卡槽中。除此方式外並無可能將 SIM 卡緊貼置於卡槽上。

3. 小心重新調整卡槽以將其滑進並推回到手機中。

提示：您的手機的識別碼位於 SIM 卡槽上。您可能於稍後需以此編碼因服務提供用途對您的手機進行識別。於 QSG 中記下您的 IMEI 號拍下產品包裝上的標籤相片。

要開啓 Nexus 4 的電源，按壓手機右側近頂部位置的電源鍵數秒。



當 Nexus 4 處於開啓時，重複按電源鍵以進入或取消睡眠模式。

要關閉 Nexus 4，按壓電源鍵直至確認對話框出現。然後點按確認以完成電源關閉程序。

如要於您的 Nexus 4 在沒有回應的情況下重啓，按壓電源/鎖定鍵最少 10 秒。

提示：要快速將手機切換到靜音或飛行模式，按壓電源鍵一到兩秒以顯示快速話框，從快速話框進行變更，於鎖定屏幕亦一樣。

設定您的 Nexus 4



於首次開啓您的手機時，您將會看到歡迎畫面。要選擇不同語言，點按功能表。然後點按開始並根據屏幕說明進行操作。

一系列屏幕指引將引領您完成設定程序。如您已有 Gmail 帳戶，請於要求時使用您的 Gmail 電郵地址及密碼。如您並無 Gmail 或任何其他 Google 帳戶，您可建立一個。

Google 帳戶允許您從任何電腦或流動裝置存取您的個人資料：

- **於任何地方存取帳戶。** 不論於任何地方使用任何電腦或流動裝置檢視您的電郵、文字或社交訊息 - 您只需連接到無線或流動數據網絡。於 Google Play 程式庫中播放音樂、電影、或電子書時亦使用同樣方式。
- **永不再遺失聯絡人。** 當您以 Google 帳戶登入手機，聯絡人應用程式將自動備份所有於您帳戶中的聯絡人。您可隨時於任何電腦或流動裝置通過 Google 帳戶存取。
- **使用您的所屬物件及保障其安全。** Google 全天候運作以防止您的私人數據於未授權情況下被存取並確保隨時隨地於您需要時向你提供。
- **同步及備份所有數據。** 不論起草電郵、新增聯絡人、日程到您的行事曆、或拍攝相片，您所執行的正不斷被備份及同步到任何您使用同一 Google 帳戶的電腦上。

- **使用其他 Google 服務。** 您的 Google 帳戶亦允許您使用其他如 Gmail、Google 地圖導航、Google Play、YouTube、Google+ 及更多您想使用的 Google 應用程式及服務。

如您錯過某些於設定精靈中的步驟，可設定新帳戶（包括 Gmail）並隨時調整更多其他設定。從任何桌面點按  所有應用程式，然後點按  設定。

如需額外協助及支援，請瀏覽 support.google.com/nexus。

飛行時注意事項

如您想於航班上使用 Nexus 4 請與航空公司職員查詢。大部份航空公司禁止使用電子裝置。大部份航空公司於起飛及著陸期間禁止使用電子裝置。

三種主要使用於機場保安的裝置類型為：X-光機（用於放置於輸送帶上的物件）；磁力探測器（用於通過安全檢查點範圍的人士）及；手持磁力探測器（用於個別人士或物件的手持裝置）。您的 Nexus 4 可通過 X-光機輸送檢驗。但切勿讓您的 Nexus 4 通過機場磁力探測器或暴露於手持磁力探測器。

安全及有效使用準則

請讀取以下簡易的使用規則。違反這些準則可能會發生危險或觸犯法律。

無線電波暴露準則

無線電波暴露及特定吸收比率 (SAR) 資訊。

本型號手機 LG-E960 之設計符合適用的無線電波暴露安全要求。這些要求乃基於可確保所有使用者安全的科學指引，範圍涵蓋任何年齡與任何健康狀況的人士。

- 無線電波暴露指引的量度單位叫作特定吸收比率或 SAR。SAR 測試使用標準方法進行，用手機以在所有使用的頻帶最高的合格電源水平傳輸。
- 雖然不同型號 LG 手機的 SAR 水平有所差異，但所有這些手機的設計均符合無線電波暴露的相關指引。
- 國際非離子化輻射保護委員會 (ICNIRP) 建議的 SAR 限制，即平均 10 克組織 2 W/kg。
- 經 DASY4 測試，此型號手機在耳邊使用時的最高 SAR 值為 0.407 W/kg (10 克)，在身上佩戴時為 0.479 W/kg (10 克)。

- 在將手機置於耳邊正常使用或使其距身體至少 1.5 厘米遠的情況下，此流動電話符合關於 RF 暴露的指引。如果隨身攜帶手機，所用的手機套或其他裝置中不可包含金屬物品，並應使手機與身體至少保持 1.5 厘米的距離。要傳輸數據檔案或訊息時，該裝置與網絡進行有效的連接。在某些情況下，數據檔案或訊息的傳送可能會延遲，直至這類連接可用為止。請確保遵守以上的特別距離指示，知道傳輸完成為止。

產品保護及維護

警告：

請僅使用經認可適用於此特定型號手機的電池、充電器及配件。使用其他種類的配件可能會導致手機的認可或保養失效，並可能引致危險。

- 請勿拆開此裝置。如手機需要維修，請由合資格的維修技師進行維修。
- 根據 LG 的政策，保養期內的維修可能會包括更換部件或主板，這些用於更換的部件或主板可能全新的或是經過翻新的，但其功能與被更換的部件相同。
- 請遠離如電視、收音機或個人電腦等電器產品而使用手機。
- 裝置需遠離發熱來源，如散熱器或烹調器具。
- 請勿摔落手機。
- 請勿讓此裝置遭機械震動或衝擊。

- 請於任何有特殊限制的地方關閉手機。例如，請勿在醫院內使用手機，否則它可能會對敏感的醫療設備造成影響。
- 請勿以潮濕的雙手對充電中的手機進行操作。這可能會引致觸電和造成手機嚴重損壞。
- 請不要在易燃材料附近為手機充電，因為充電期間手機會發熱並導致火災。
- 使用乾布清潔裝置表面（請勿使用苯、稀釋劑或酒精等溶劑）。
- 切勿在布質家具上為手機充電。
- 手機應在通風良好的環境中充電。
- 請勿讓此裝置接觸過多煙霧或塵埃。
- 請勿將手機置於信用卡或車票附近，這可能會影響磁帶上的資料。
- 請勿以尖銳物件敲打屏幕，否則可能會對手機造成損毀。
- 請勿將手機暴露於液體或濕氣中。
- 請小心使用配件，例如耳機。如非必要，請勿觸及天線。
- 如果玻璃屏幕碎裂，請勿使用、接觸或嘗試移除或修補玻璃。因妄用或不正確使用而導致玻璃屏幕受損並不在保養範圍內。
- 您的手機是一部電子裝置，在正常操作期間，會產生熱力。在沒有足夠通風的環境下，長時間與皮膚直接接觸可能導致不適或輕度灼傷。因此，操作期間或操作之後處理手機時，請謹慎使用。

有效地操作手機

電子裝置

所有手機均可能受訊號干擾，這可能會影響手機效能。

- 請勿在未得到批准下在醫療儀器附近使用您的手機。避免將手機放置在心臟起搏器附近，例如您胸口上的口袋。
- 一些助聽器可能會受手機干擾。
- 手機可能會輕微干擾電視、收音機、個人電腦等。

道路安全

檢查您駕駛時所在地區使用手機的法例及規則。

- 駕駛時切勿使用手持手機。
- 請專心一致駕駛。
- 請視乎駕駛情況，駛離馬路並停泊好汽車後才撥打或接聽電話。
- RF 能量可能會影響車內某些電子系統，例如車載立體聲音響及安全設備等。
- 如果您的汽車配有氣囊，切勿讓已安裝的無線設備或手提無線設備阻擋氣囊。這可能會導致氣袋無法正常彈出，使其失去保護作用或造成嚴重人身傷害。
- 如果在外出時聆聽音樂，請確保將音量設定至合適水平，以便可以對周圍環境產生警覺。這在路邊時特別重要。

避免損害您的聽覺



避免聽力受損，請不要長時間在高音量下聆聽。

如果長時間以較大音量收聽，可能會對聽覺造成損害。所以我們建議開啓或關閉手機時，不要將它放於太近耳朵。我們亦建議將音樂及通話音量設定至合適水平。

- 使用耳機時，如果您未能聽見附近的人說話，或者坐在您身邊的人能聽見您正在聆聽的聲音，就應將聆聽音量調低。

注意：耳筒和耳機的聲壓過大可能會導致聽力受損。

玻璃部件

您的手機的部分部件以玻璃製造。如您的手機摔在堅硬的表面上或受猛烈撞擊，玻璃部件可能會破裂。如玻璃破裂，請勿接觸或嘗試移除碎片。請停止使用您的手機，直至授權的服務供應商為您更換玻璃部件。

爆破地區

請勿在進行爆破時使用手機。請嚴格遵守相關限制、規定或條例。

潛在爆炸氣壓

- 請勿在加油站使用手機。
- 請勿在燃料或化學物質附近使用手機。
- 請勿在放置了手機及配件的汽車車廂運送或擺放易燃氣體、液體或爆炸物。

在飛機上

無線裝置可引致飛機干擾。

- 登機前，請先關掉手機。
- 未經地勤人員批准，請勿在陸上使用手機。

兒童

請將手機放在兒童接觸不到的安全地方。手機包含微細零件，如果拆開，可能造成哽咽危險。

緊急通話

某些流動網絡可能無法使用緊急通話。因此，您不應僅倚賴手機作為緊急通話的方式。請向您本地的服務供應商查詢。

電池資料及保護

- 充電前，您無須完全放電。跟其他電池系統不同，沒有記憶影響可降低電池的效能。
- 只使用 LG 電池及充電器。LG 充電器是為將電池壽命擴至最大而設。
- 請勿拆解電池或造成電池短路。
- 如果電池很久沒有使用，重新充電以擴展其用量。
- 請勿直接將充電器暴露於日光下或高濕度環境（如浴室）中。
- 請勿將電池置於過熱或過冷的地方，此類場合可能會損害電池效能。
- 若使用類型不當的電池，則有發生爆炸的危險。
- 請根據製造商的指示來處理廢棄電池。盡量回收利用。請勿作為家庭廢棄物處理。
- 如果需要更換電池，請帶同手機前往最近的授權 LG 電子產品服務點或經銷商以尋求協助。
- 請謹記在手機完全充電後從牆壁插座拔出充電器，避免充電器造成不必要的電力損耗。
- 電池的實際壽命將取決於網絡設定、產品設定、使用模式、電池及環境條件。
- 請勿讓如動物牙齒、指甲等尖銳物與電池發生接觸。這可能會引起火災。

確認聲明

LG Electronics 在此聲明 **LG-E960** 產品符合對 **1999/5/EC** 指示的基本要求和相關規定。確認聲明副本請見：<http://www.lg.com/global/support/cedoc/RetrieveProductCeDOC.jsp>

環境溫度

最高：+45°C（放電），+45°C（充電）

最低：-10°C

法規資訊

前往「**系統設定 > 關於手機 > 法規資訊**」以獲取法規資訊。



简体中文

nexus 4

快速入门指南


如需联机帮助和支持, 请访问
support.google.com/nexus

Google、Android、Gmail、Google Maps、Nexus、Google Play、YouTube、Google+ 和其他商标是 Google Inc 的财产。访问 <http://www.google.com/permissions/guidelines.html>, 可以查看 Google 商标列表。LG 和 LG 徽标是 LG Electronics Inc 的商标。所有其他商标是其各自所有者的财产。


本指南内容的某些细节可能因产品或其软件而异。本指南的所有信息如有更改，恕不另行通知。

如需联机帮助和支持，请访问 support.google.com/nexus


包装盒内物品



Nexus 4



Micro USB 数据线




旅行适配器




SIM 弹出工具


- 如果任何物品损坏或缺失，请与购机处联系寻求帮助。
- 仅使用经核准的配件。
- 配件可能因国家或地区而异。

您的 Nexus 4





后退




底部

充电

首次打开 Nexus 4 包装时, 电池未完全充电。请尽快为电池完全充电。

如果使用手机的原装旅行适配器, 请将数据线的一端连接至手机底部的充电器端口, 另一端连接至旅行适配器。然后, 将旅行适配器连接至电源插座。




- 旅行适配器因国家或地区而异。
- 仅使用 Nexus 4 原装的旅行适配器和 Micro USB 数据线。使用其他旅行适配器或数据线可能损坏您的手机。
- 墙上插座与该旅行适配器之间的输入电压范围是 AC 100V-240V, 旅行适配器的输出电压是 DC 5V, 1.2A。
- 通过 USB 数据线连接其他设备(如笔记本电脑)为手机充电比使用旅行适配器充电所耗的时间长。
- Nexus 4 的电池不能拆卸。不要拆开手机。

如果使用无线充电器, 请参阅充电器随附的说明。

重要说明: 如果使用无线充电器, 只能按照说明使用经核准的型号。Nexus 4 旅行适配器可能无法产生足够的电流向无线充电器送电。

插入 Micro SIM 卡和开机

开始使用手机前，可能需要插入 Micro SIM 卡。如果未安装 SIM 卡，手机锁定屏幕上会出现“无 SIM 卡”的消息。




SIM 卡文件盘位于手机左侧音量键下方。弹出按钮是文件盘门上方的小圆孔。安装新 Micro SIM 卡：

1. 将手机随附的 SIM 弹出工具（或细针）插入弹出按钮孔，捏紧并轻轻用力推进，直至文件盘弹出。
2. 取下文件盘，放入 Micro SIM 卡，触点朝外，圆角朝右。只有采用这种方式才能完全吻合地把 SIM 卡放入文件盘。

3. 小心地将文件盘重新放入插槽，轻轻推入手机。

提示：手机的 IMEI 识别码位于 SIM 卡文件盘上。以后，可能需要此识别码识别您的手机以接受服务。在您的 QSG 中写下 IMEI 识别码或者拍下产品包装盒上的标签。

要开启 Nexus 4，请按住手机顶部右侧的电源按钮几秒钟。



Nexus 4 处于开机状态时，再按电源按钮可进入睡眠模式或唤醒手机。

要关闭 Nexus 4，请按住电源按钮，直至出现确认对话框。然后点触**确定**完成关机。

要在 Nexus 4 没有响应时重新启动，请按住电源/锁定键至少 10 秒。

提示：要快速静音或切换飞行模式，请按住电源按钮一两秒钟，快速话框，从快速话框进行变更，于锁定屏幕亦一样。

设置 Nexus 4



首次开机时，您会看到欢迎屏幕。要选择其他语言，请点触菜单。然后，点触**开始**并按照屏幕上的说明操作。

经过一系列屏幕即可完成设置流程。如果您已经有 Gmail，需要时，请使用您的 Gmail 地址和密码。如果您没有 Gmail 或任何其他 Google 帐户，请继续操作并创建一个。

使用 Google 帐户可以从任何计算机或移动设备访问您的个人信息：

- **从任何地点访问。** 不论您身在何处，也不论您使用哪里的电脑或移动设备，只要有 Wi-Fi 或移动数据连接，就可以查看您的电子邮件、文本信息或社交流。同样，您可以随意播放您 Google Play 库里的音乐、电影或书籍。
- **绝不会再次丢失联系人。** 当您使用手机登录 Google 帐户时，系统会自动在 People 应用程序中备份与该帐户关联的所有联系人。从任何电脑或移动设备，都可以通过您的 Google 帐户访问这些联系人。
- **保持您的文档安全和可用性。** Google 全天候保护您的个人数据免遭未经授权访问，并确保不论您何时何地需要，都能获取个人数据。

- **同步和备份所有数据。** 不论您是草拟电子邮件，添加联系人，向日历中添加事件，还是拍照，Google 都会不间断地对您的工作进行备份，并与您使用相同 Google 帐户的任何计算机同步。
- **使用其他 Google 服务。** 您的 Google 帐户还可以让您充分利用您准备使用的任何其他 Google 应用程序和服务，如 Gmail、Google Maps Navigation、Google Play、YouTube、Google+ 等。

如果跳过了设置向导的某些步骤，您可以随时配置新帐户（包括 Gmail）并调整许多其他设置。从任何主屏点触  所有应用程序图标，然后点触  设置。

如需其他帮助和支持，请访问 support.google.com/nexus。

飞机上的注意事项

登机后, 如果想使用 Nexus 4, 请咨询飞机乘务员。多数航空公司对使用电子设备有限制。多数航空公司仅允许在飞行过程中使用电子设备, 在起飞和降落时则禁止使用。

机场安检设备主要有三种: X 光机 (用于检测放在传送带上的物品)、磁力探测仪 (用于检测步行通过安检的人员) 和磁棒 (用于检测人员或个人物品的手持设备)。Nexus 4 可以经机场 X 光机通过安检。但是, 不要将 Nexus 4 经机场磁力探测仪过安检或接触磁棒。

关于安全有效使用手机的准则

请阅读以下简单的准则。违反这些准则可能造成危险或者触犯法律。

暴露在射频能量之下

无线电波暴露和“特定吸收率”（SAR）信息。

此款 LG-E960 型手机已设计为遵守有关适用的无线电波暴露安全要求。此要求基于相关的科学准则，其中包括为确保所有人员（无论年龄和健康状况）安全而设计的安全裕量。

- 无线电波暴露准则采用一种称为“特定吸收率”或 SAR 的测量单位。SAR 测试是在所有用到的频带中以手机的最高认可功率电平进行发射时使用标准化方法执行的。
- 不同的 LG 手机型号可能有不同的 SAR 能级，但它们均符合相关的无线电波暴露准则。
- 国际非游离辐射防护委员会（ICNIRP）建议的 SAR 上限值为：每 10g 重的人体组织吸收的能量平均值不超过 2 W/kg。
- 经过 DASY4 对该型号手机进行的测试，人耳能够承受的 SAR 最大值为 0.407 W/kg（10 克），戴在身体上时，其值为 0.479 W/Kg（10 克）。

- 本设备在靠近耳朵的正常使用位置使用或放置在距人体至少 1.5 厘米的位置时符合 RF 暴露标准。当使用便携盒、皮带夹或皮套进行身体佩戴操作时，不得包含金属并且产品应至少距身体 1.5 厘米。为了发送数据文件或信息，此设备需要高质量的网络连接。在某些情况下，数据文件或信息的发送可能被延迟，直到有这样的连接可用。确保遵照以上间隔距离说明直到完成发送。

产品保养和维护

警告

仅使用经核准为用于此特定手机型号的电池、充电器和配件。使用任何其它类型可能导致适用于此手机的许可或保修失效，并可能造成危险。

- 不要拆解本机。当需要维修时，请将手机送往合格的服务技术人员处。
- 保修（由 LG 决定）可能包括使用新的或返修的更换部件或板，只要其功能与更换的部件等效。
- 远离诸如电视、收音机或个人计算机之类的电器。
- 远离诸如暖气片或厨灶之类的热源。
- 小心不要让手机摔落。
- 不要让手机受到机械振动或撞击。
- 在任何有特殊条例要求的区域关闭手机。例如，请勿在医院使用手机，因为它可能影响敏感的医疗装置。
- 手机充电时，请勿用湿手操作手机。这可能会导致电击或手机严重受损。

- 请勿在靠近易燃物体的位置充电，因为手机可能因加热而引发火灾。
- 使用干布清洁手机外壳（不要使用如苯、稀释剂或酒精之类的溶剂）。
- 如果手机置于柔软物体之上，请不要充电。
- 应将手机放在完全通风的位置充电。
- 不要在烟雾或灰尘过多的环境中使用或存放手机。
- 不要将手机放在信用卡或卡式车票旁边，它可能会影响磁条上的信息。
- 不要用尖锐物体敲击屏幕，这可能会损坏手机。
- 不要将手机暴露在液体或潮气中。
- 谨慎使用诸如耳机之类的配件。在不必要的情况下，不要触摸天线。
- 请勿使用、触摸或试图取下或修复破碎或破裂的玻璃。由于滥用或误用造成的玻璃显示屏损坏不在保修范围内。
- 本手机为正常使用过程中会发热的电子设备。在缺乏足够通风的条件下过长时间直接接触皮肤时，可能导致不舒服或轻微灼伤。因此，在操作的过程中或之后立即处理您的手机时，应特别小心。

有效的手机操作

电子设备

所有手机都可能受到干扰，这种干扰会对性能造成影响。

- 在未经允许的情况下，不得在医疗装置附近使用手机。不要将手机放在心脏起搏点上，即胸前的口袋内。
- 手机可能会对某些助听器造成干扰。

- 微弱的干扰可能会影响电视、收音机、个人计算机等。

行车安全

查阅有关在驾驶时使用手机的本地法律法规。

- 不要在驾驶时使用手持式手机。
- 将注意力完全集中在驾驶上。
- 如果行驶条件需要，请在拨打或接听电话之前将车辆驶离道路并停车。
- 射频能量可能影响车辆内的电子系统，例如立体声音响、安全设备等。
- 当车辆配备气囊时，不要让安装的便携式的无线设备阻挡气囊。这样做可能因性能不当而导致气囊无法释放或导致严重受伤。
- 如果您在外出时使用耳机收听音乐，请确保将音量设置为合理的音量级别，以便注意周围的情况。在靠近马路时，尤其要注意这一点。

防止损伤您的听力



为防止听力可能受损，请勿长时间高音量倾听。

如果您长时间置于高音环境中，那么您的听力可能会遭到伤害。因此，我们建议您在开机或关机时不要将手机置于耳边。同时，我们还建议您将音乐和通话音量设置为合理的音量级别。

- 使用耳机时，如果您不能听到附近的人说话，或者坐在您旁边的人能听到您在听的内容，则将音量调低。

备注：耳机声音压力过大可能导致听力受损。

玻璃部分

手机部分为玻璃制。如果手机摔落到坚硬表面或受到强烈撞击，玻璃会破碎。如果玻璃破碎，请勿触摸或尝试取出玻璃碎片。停止使用手机，在授权的服务提供商处更换玻璃。

爆破区域

不要在正进行爆破的地区使用手机。请依照有关限制，并遵守任何规章或规定。

易爆环境

- 不要在加油站内使用手机。
- 不要在靠近燃料或化学制品处使用手机。
- 不要在放有手机和配件的车厢内运输或存放可燃气体、液体或爆炸品。

在飞机上

无线设备可能对飞机造成干扰。

- 登机前，请关机。
- 未经机务人员允许，不得在地面上使用手机。

儿童

将手机放在儿童接触不到的安全地方。手机中包含细小零件，如果脱落可能导致窒息危险。

紧急电话

并非在所有手机网络中均可使用紧急电话。因此，您不应仅依赖于手机的紧急呼叫功能。请向本地的服务提供商核准。

电池信息及保养

- 您无需在再次充电前对电池进行完全放电。与其它电池系统不同，本机电池不具有可能影响电池性能的记忆效应。
- 只能使用 LG 电池和充电器。LG 充电器设计为最大程度地延长电池使用寿命。
- 不要拆解电池或将其短路。
- 如果很长一段时间都没用过电池，请将电池再次进行充电以保持最佳使用状态。
- 不要将电池充电器暴露在直射阳光下，也不要在于诸如浴室之类的高湿环境中使用。
- 不要将电池存放在过热或过冷的地方，这可能损害电池的性能。
- 如果用不适当的电池进行替换，可能会有爆炸危险。
- 请按制造商的说明处置用过的电池。如果可能，请循环使用电池。不要象处理家用废物一样处理电池。
- 如果要更换电池，请将其携带至 LG Electronics 授权服务点或经销商处以寻求帮助。

- 手机充好电后，请务必将充电器从墙上插座拔下，以避免不必要的耗电。
- 实际的电池寿命将取决于网络配置、产品设置、使用方式、电池和环境条件。
- 确保没有细尖的物体，如动物牙齿、指甲等进入手机内触碰电池。这可能引发火灾。

确认声明

LG Electronics 特此宣布此 **LG-E960** 产品符合指令 **1999/5/EC** 的核心要求和其它相关规定。有关《确认声明》的副本，请访问 <http://www.lg.com/global/support/cedoc/RetrieveProductCeDOC.jsp>

外部环境

最高温度: +45° C (放电), +45° C (充电)

最低温度: -10° C

监管信息

转到“**系统设置 > 关于手机 > 监管信息**”，可以查看监管信息。

ENGLISH

nexus 4

Quick Start Guide


For online help and support, visit
support.google.com/nexus

Google, Android, Gmail, Google Maps, Nexus, Google Play, YouTube, Google+, and other trademarks are property of Google Inc. A list of Google trademarks is available at <http://www.google.com/permissions/guidelines.html>. LG and the LG logo are trademarks of LG Electronics Inc. All other trademarks are properties of their respective owners.


The content of this guide may differ in some details from the product or its software. All information in this document is subject to change without notice.

For online help and support, visit support.google.com/nexus


What's in the box



Nexus 4



Micro USB cable




Travel adapter




SIM ejection tool


- If any item is damaged or missing, contact your point of purchase for assistance.
- Use only approved accessories.
- Accessories may vary by country or region.

Your Nexus 4





BACK




BOTTOM

Charge the battery

Your battery will not be fully charged when you first unpack your Nexus 4. It's a good idea to fully charge the battery as soon as you get a chance.

If you're using the travel adapter that comes with the phone, connect one end of the data cable to the charger port at the bottom of the phone, and the other end to the travel adapter. Then connect the travel adapter to a power outlet.




- The travel adapter varies by country or region.
- Use only the travel adapter and Micro USB cable that come with your Nexus 4. Using a different travel adapter or cable may damage your phone.
- The input voltage range between the wall outlet and this travel adapter is AC 100V–240V, and the travel adapter's output voltage is DC 5V, 1.2A.
- Charging your phone through a USB cable attached to another device, such as a laptop computer, takes longer than charging with a travel adapter.
- Nexus 4's battery can't be removed. Don't attempt to open the phone.

If you're using a wireless charger, see the instructions that come with the charger.

IMPORTANT: If you use a wireless charger, you must use an approved model and only as directed. The Nexus 4 travel adapter may not generate enough current to power a wireless charger.

Insert Micro SIM card & turn on phone

Before you start using your phone, you may need to insert your Micro SIM card. If no card is installed, the message “No SIM card” appears on the phone’s lock screen.




The SIM card tray is located on the left side of the phone below the volume button. The eject button is a small round aperture just above the tray door. To install a new Micro SIM card:

1. Insert the SIM ejection tool that comes with the phone (or a thin pin) into the eject button aperture, and push firmly but gently until the tray pops out.

2. Remove the tray and place the micro SIM card inside it, with the contacts out and the angled corner to the right. There is only one possible way to fit the card snugly into the tray.
3. Carefully reposition the tray in the slot and push it gently back into the phone.

TIP: Your phone's IMEI identification number is on the SIM card tray. You may need this number later to identify your phone for service purposes. Write the IMEI number down in your QSG or take a photo of the label on the product box.

To turn on your Nexus 4, press and hold the Power button on the right edge near the top for a few seconds.



When Nexus 4 is on, press the Power button again to put it into sleep mode or wake it up.

To turn off your Nexus 4, press and hold the Power button until a confirmation dialog appears. Then touch **OK** to complete the shut down.

To restart your Nexus 4 if it becomes unresponsive, press and hold the Power/Lock key for at least 10 seconds.

TIP: To quickly silence your phone or toggle airplane mode, press and hold the power button for one or two seconds to see a quick confirmation dialog – even from the lock screen.

Set up your Nexus 4

The first time you turn on your phone, you'll see a Welcome screen. To choose a different language, touch the menu. Then touch **Start** and follow the on-screen instructions.



A series of screens takes you through the setup process. If you already have Gmail, use your Gmail address and password when asked. If you don't have Gmail or any other Google Account, go ahead and create one.

A Google Account lets you access your personal information from any computer or mobile device:

- **Access from anywhere.** View your email messages, text messages, or social stream no matter where you are or what computer or mobile device you're using – as long as you have a Wi-Fi or mobile data connection. The same goes for Play music, movies, or books in your Google Play libraries.
- **Never lose your contacts again.** When you sign into your phone with a Google Account, all the contacts you associate with that account in the People

app are automatically backed up. They're always accessible through your Google Account from any computer or mobile device.

- **Keep your stuff secure and available.** Google works around the clock to protect your personal data from unauthorized access and to ensure that you get it when you need it, wherever you need it.
- **Synchronize and back up all your data.** Whether you draft an email, add a contact, add an event to your calendar, or take a photo, your work gets backed up continuously by Google and synchronized with any computer where you use the same Google Account.
- **Use other Google services.** Your Google Account also lets you take full advantage of any other Google apps and services that you may want to use, such as Gmail, Google Maps Navigation, Google Play, YouTube, Google+, and many more.

If you skipped some of the steps in the Setup Wizard, you can configure new accounts (including Gmail) and adjust many other settings at any time. Touch the  All Apps icon from any Home screen, then  Settings.

For additional help and support, visit support.google.com/nexus.

Airplane precautions

Check with airline personnel if you want to use your Nexus 4 on board an aircraft. Most airlines have restrictions for using electronic devices. Most airlines allow electronic use only between and not during takeoffs and landings.

There are three main types of airport security devices: X-ray machines (used on items placed on conveyor belts), magnetic detectors (used on people walking through security checks), and magnetic wands (hand-held devices used on people or individual items). You can send your Nexus 4 through airport X-ray machines. But do not send your Nexus 4 through airport magnetic detectors or expose it to magnetic wands.

Guidelines for safe and efficient use

Please read these simple guidelines. Not following these guidelines may be dangerous or illegal.

Exposure to radio frequency energy

Radio wave exposure and Specific Absorption Rate (SAR) information.

This mobile phone model LG-E960 has been designed to comply with applicable safety requirements for exposure to radio waves. These requirements are based on scientific guidelines that include safety margins designed to assure the safety of all persons, regardless of age and health.

- The radio wave exposure guidelines employ a unit of measurement known as the Specific Absorption Rate, or SAR. Tests for SAR are conducted using standardised methods with the phone transmitting at its highest certified power level in all used frequency bands.
- While there may be differences between the SAR levels of

various LG phone models, they are all designed to meet the relevant guidelines for exposure to radio waves.

- The SAR limit recommended by the International Commission on Non-Ionizing Radiation Protection (ICNIRP) is 2 W/kg averaged over 10g of tissue.
- The highest SAR value for this model phone tested by DASY4 for use at the ear is 0.407 W/kg (10g) and when worn on the body is 0.479 W/Kg (10g).
- This device meets RF exposure guidelines when used either in the normal use position against the ear or when positioned at least 1.5 cm away from the body. When a carry case, belt clip or holder is used for body-worn operation, it should not contain metal and should position the product at least 1.5 cm away from your body. In order to transmit data files or messages, this device requires a quality connection to the network. In some cases, transmission of data files or messages may be delayed until such a connection is available. Ensure the above separation distance instructions are followed until the transmission is completed.

Product care and maintenance

WARNING: Only use batteries, chargers and accessories approved for use with this particular phone model. The use of any other types may invalidate any approval or warranty applying to the phone and may be dangerous.

- Do not disassemble this unit. Take it to a qualified service technician when repair work is required.
- Repairs under warranty, at LG's discretion, may include replacement parts or boards that are either new or reconditioned, provided that they have functionality equal to that of the parts being replaced.
- Keep away from electrical appliances such as TVs, radios and personal computers.
- The unit should be kept away from heat sources such as radiators or cookers.
- Do not drop.
- Do not subject this unit to mechanical vibration or shock.
- Switch off the phone in any area where you are required to by special regulations. For example, do not use your phone in hospitals as it may affect sensitive medical equipment.
- Do not handle the phone with wet hands while it is being charged. It may cause an electric shock and can seriously damage your phone.
- Do not charge a handset near flammable material as the handset can become hot and create a fire hazard.
- Use a dry cloth to clean the exterior of the unit (do not use solvents such as benzene, thinner or alcohol).
- Do not charge the phone when it is on soft furnishings.
- The phone should be charged in a well ventilated area.
- Do not subject this unit to excessive smoke or dust.
- Do not keep the phone next to credit cards or transport tickets; it can affect the information on the magnetic strips.
- Do not tap the screen with a sharp object as it may damage

the phone.

- Do not expose the phone to liquid or moisture.
- Use accessories like earphones cautiously. Do not touch the antenna unnecessarily.
- Do not use, touch or attempt to remove or fix broken, chipped or cracked glass. Damage to the glass display due to abuse or misuse is not covered under the warranty.
- Your phone is an electronic device that generates heat during normal operation. Extremely prolonged, direct skin contact in the absence of adequate ventilation may result in discomfort or minor burns. Therefore, use care when handling your phone during or immediately after operation.

Efficient phone operation

Electronics devices

All mobile phones may receive interference, which could affect performance.

- Do not use your mobile phone near medical equipment without requesting permission. Avoid placing the phone over pacemakers, for example, in your breast pocket.
- Some hearing aids might be disturbed by mobile phones.
- Minor interference may affect TVs, radios, PCs etc.

Road safety

Check the laws and regulations on the use of mobile phones in the area when you drive.

- Do not use a hand-held phone while driving.
- Give full attention to driving.
- Pull off the road and park before making or answering a call if driving conditions so require.
- RF energy may affect some electronic systems in your vehicle such as car stereos and safety equipment.
- When your vehicle is equipped with an air bag, do not obstruct with installed or portable wireless equipment. It can cause the air bag to fail or cause serious injury due to improper performance.
- If you are listening to music whilst out and about, please ensure that the volume is at a reasonable level so that you are aware of your surroundings. This is of particular importance when near roads.

Avoid damage to your hearing



To prevent possible hearing damage, do not listen at high volume levels for long periods.

Damage to your hearing can occur if you are exposed to loud sound for long periods of time. We therefore recommend that you do not turn on or off the handset close to your ear. We also recommend that music and call volumes are set to a reasonable level.

- When using headphones, turn the volume down if you cannot hear the people speaking near you, or if the person sitting next to you can hear what you are listening to.

NOTE: Excessive sound pressure from earphones and headphones can cause hearing loss.

Glass Parts

Some parts of your mobile device are made of glass. This glass could break if your mobile device is dropped on a hard surface or receives a substantial impact. If the glass breaks, do not touch or attempt to remove it. Stop using your mobile device until the glass is replaced by an authorised service provider.

Blasting area

Do not use the phone where blasting is in progress. Observe restrictions and follow any regulations or rules.

Potentially explosive atmospheres

- Do not use your phone at a refueling point.
- Do not use near fuel or chemicals.
- Do not transport or store flammable gas, liquid or explosives in the same compartment of your vehicle as your mobile phone or accessories.

In aircraft

Wireless devices can cause interference in aircraft.

- Turn your mobile phone off before boarding any aircraft.
- Do not use it on the ground without permission from the crew.

Children

Keep the phone in a safe place out of the reach of small children. It includes small parts which may cause a choking hazard if detached.

Emergency calls

Emergency calls may not be available on all mobile networks. Therefore you should never depend solely on your phone for emergency calls. Check with your local service provider.

Battery information and care

- You do not need to completely discharge the battery before recharging. Unlike other battery systems, there is no memory effect that could compromise the battery's performance.
- Use only LG batteries and chargers. LG chargers are designed to maximise the battery life.
- Do not disassemble or short-circuit the battery.
- Recharge the battery if it has not been used for a long time to maximise usability.

- Do not expose the battery charger to direct sunlight or use it in high humidity, such as in the bathroom.
- Do not leave the handset in hot or cold places, as this may deteriorate the internal battery performance.
- There is risk of explosion if the battery is replaced with an incorrect type.
- If you need to replace the battery, take it to the nearest authorised LG Electronics service point or dealer for assistance.
- Always unplug the charger from the wall socket after the phone is fully charged to save unnecessary power consumption of the charger.
- Actual battery life will depend on network configuration, product settings, usage patterns, battery and environmental conditions.
- Make sure that no sharp-edged items such as animal's teeth or nails, come into contact with the handset. This could cause damage to the internal battery and potentially cause a fire.

DECLARATION OF CONFORMITY

Hereby, LG Electronics declares that this **LG-E960** product is in compliance with the essential requirements and other relevant provisions of Directive **1999/5/EC**. A copy of the Declaration of Conformity can be found at **<http://www.lg.com/global/support/cedoc/RetrieveProductCeDOC.jsp>**

Ambient temperatures

Max: +45°C (discharging), +45°C (charging)

Min: -10°C

Regulatory information

Go to “**System setting > About Phone > Regulatory information**” to get the regulatory information.