

繁體中文
ENGLISH



MBM65221101 (1.0)

LG Watch Urbane

LG-W150

QUICK START GUIDE

www.lg.com





CE0168

如需查閱使用手冊及詳情，請瀏覽 www.lg.com。

- 視乎地區、服務供應商、軟件版本或操作系統版本而定，部份內容及圖片可能與您的裝置不同，並可隨時更改而不作事先通知。
- 只可使用原裝 LG 配件。提供的配件只適用於此裝置，與其他裝置可能不兼容。
- 可用的配件視乎您的地區、國家或服務供應商可能有所不同。


手錶版面



！警告 不要以尖銳物件關閉或插入裝置底部的洞裡。這樣可能會令您的裝置無法正常操作。

為手錶充電

首次使用手錶前，您應先充電。



- 使用提供的充電座為手錶充電。
- 將充電座連接電源插座，並將手錶放於充電座上。手錶會自動開啟。
- 為了將電池壽命擴至最大，首次使用前，確保電池已完全充電。

為手錶充電

⚠ 請留意充電終端被侵蝕

使用產品期間，接觸到汗水或其他外來物料，可能導致充電時終端被侵蝕。


為防止被侵蝕，充電前請以乾布抹一抹產品。

⚠ 配戴皮帶前應注意


- LG Watch Urbane 的縫制皮帶十分厚，符合高品質標準。配戴皮帶前，請先將其彎曲數次。這樣可令您配戴時感到更舒適。
- 按使用者的皮膚狀況而定，手錶可能對接觸的皮膚造成預期外的敏感反應。

開啟手錶

如要開啟手錶，點按**電源鍵**（手錶右方）數秒。



關閉手錶




- 1 按住**電源鍵**直至顯示應用程式清單。
- 2 點按 **Settings > Power off**。
- 3 當看到提示 **Power off: Are you sure?** 點按 。

配對前

配對前，請於手機或平板電腦上進行下列步驟。

- 1 確保手機或平板電腦的 Android 版本是 Android 4.3 或以上，並支援藍牙®。
 - 如要了解您的手機或平板電腦是否支援 Android Wear，請使用您的手機或平板電腦瀏覽 <http://g.co/WearCheck>。
 - 若您的手機或平板電腦並非 Android 4.3 或以上，請詢問製造商可否作軟件更新。
- 2 確保手機或平板電腦放在手錶旁邊。

配對前

- 3 在手機或平板電腦上，前往 **Play Store**  下載 **Android Wear**  應用程式，並安裝。檢查您的手機或平板電腦的 **Android Wear**  應用程式是否已安裝並更新至最新版本。
- 4 確保您的手機或平板電腦已連接至流動數據或 Wi-Fi。您需要有數據連接才可首次設定手錶。
- 5 保持手錶於設定期間連接至電源。

備註：

- 取決於您的手錶安裝的軟件而定，您的手錶可能會自動下載並安裝更新。
- 取決於網絡狀況而定，設定過程可能需時超過 20 分鐘。

如何配對手錶

- 1 開啟手錶，向左滑動歡迎畫面以開始。
- 2 點按語言。
- 3 連接手錶至電源，並向左滑動以繼續。

提示：若電量低於 20%，您的手錶可能未能移至下一步。


- 4 按照屏幕指示向左滑動，直至顯示手錶配對碼。
- 5 於手機或平板電腦開啟 **Android Wear**  應用程式。若尚未開啟，於設定期間開啟藍牙。

如何配對手錶

- 6 於手機或平板電腦上，您可看到附近裝置的列表。點按手錶的配對碼。
- 7 您將於手機或平板電腦及手錶看到配對碼。檢查配對碼是否一致。
- 8 於手機或平板電腦點按**配對**，以開始配對。
- 9 手錶配對後您將看到確認訊息。這需時數分鐘，請耐心等待。
- 10 按照屏幕上的指示，完成初始設定。

心率感應器

正確地配戴手錶於手腕上才能量度心跳率。



備註：


- 太鬆或太多動作可能造成量度不準確。
- 不要直接看著心率感應燈，因為可能會有損視力。
- 當心率不正確時，把手錶移至其中一隻手腕的內方，重新量度心率。

連接至另一個流動裝置

如要連接手錶至另一個裝置，您必須重新設定手錶。

重新設定手錶

此設定會重新設定手錶的設定至原廠預設值，並清除全部數據。

- 1 按住**電源鍵**直至顯示應用程式清單。
 - 2 點按 **Settings > Factory reset**。將有提示確認。
 - 3 點按 。
- 手錶每次只可連接一個流動裝置。
 - 重設將清除手錶記憶的全部數據。完成後，才可連接至另一個流動裝置。

安全資訊

開啟產品前，請檢視這裡的基本安全資訊。

一般安全及處理

當使用產品時，請注意下列一般指引。

您的環境

- **安全操作溫度。** 於 0°C/32°F 至 40°C/104°F 的溫度之間使用及儲存產品。將產品曝露在極低或極高的溫度下可能會導致產品損壞、故障或甚至爆炸。
- **駕駛期間。** 開車時，駕駛是您的首要責任。駕駛時，使用流動裝置或配件作通話或使用其他應用程式，可能會導致分心。請留意路面狀況。
- **爆炸品環境。** 請勿在存放有火花產品的地方使用，這樣可能會引起火災或爆炸。

- **乘坐飛機。** 遵守使用電子裝置的所有規例及指示。大部份航空公司於起飛及著陸期間禁止使用電子裝置。三種主要使用於機場保安的裝置類型為：X-光機（用於放置於輸送帶上的物件）；磁力探測器（用於通過安全檢查點範圍的人士）及；手持磁力探測器（用於個別人士或物件的手持裝置）。您可攜帶產品通過機場的X光機。但切勿讓裝置通過機場磁力探測器或暴露於手持磁力探測器。
- 必須要遵守指定地區的任何特別規定。於禁止使用或可能導致干擾或危險的地區關閉裝置。
- 將腕帶更換成金屬腕帶可能導致藍牙/Wi-Fi 連線問題。

安全提示

警告：充電座含有強力磁石，可干擾心律調校器、信用卡、手錶及其他對磁石敏感的物件。

為避免損壞產品及減少火災或觸電、爆炸或其他危險的風險，請遵守這些一般預防措施：

- 只使用經 LG 認可的電線、充電器及其他配件。
- 切勿跌下、猛烈撞擊或搖晃您的產品。
- 切勿彎曲、扭曲、拉扯、加熱電線或放置重物於電線上。
- 此產品配備 USB 線，以連接至桌面電腦、手提電腦或充電器。請確保您的電腦已適當地連接地線，才把產品連接至電腦。桌面電腦或手提電腦的電源線擁有設備接地線及接地插頭。插頭必須插入適當並已妥善安裝的插座，並根據所有本地規例及條例連接地線。
- 切勿嘗試維修、改裝或再製造產品。產品已裝有內部充電電池，只可由 LG 或獲授權的 LG 維修中心更換。
- 切勿開啟、拆卸、擠壓、使其彎曲或變形、刺穿或搗碎產品。
- 切勿將異物插入產品。
- 切勿將產品置於微波爐中
- 切勿將產品放置於火災、爆炸或其他危險的環境中。

- 使用柔軟的濕布清潔。切勿使用刺激性化學品（例如酒精、稀釋劑或天拿水）或清潔劑清潔產品。
 - 把產品及電池與家庭廢物分開處置，並根據本地規例棄置。
 - 與多款電子裝置一樣，您的產品於正常操作時會發熱。在沒有足夠通風的環境下，長時間與皮膚直接接觸可能導致不適或輕度灼傷。因此，操作期間或操作之後處理產品時，請謹慎使用。
 - 若您於使用產品有問題，請停止使用並諮詢授權的 LG Electronics 客戶服務中心。
 - 請勿將產品浸於水或其他液體中。
- 計步器、睡眠、運動及心率是不適用於治療或診斷任何疾病，只應用作休閒、健康及健身用途。
 - 心率數據可被量度狀況及您的環境所影響。確保讀取心率前，您已坐下，並放鬆身體。

- 此產品已根據 IP67 評級防水和防塵，此標準測試在浸入最深一米的水中多達 30 分鐘。不防震。外盒必須完全關閉。
- 心率數據可能因應皮膚狀況、量度狀況及您的環境所影響。
- 切勿直接看著心率感應器的燈光，因為可能會有損視力。
- 若裝置發熱，不要配戴，直至冷卻為止。皮膚長期接觸熱表面可能會導致皮膚燒傷。
- 心率功能只用作量度心跳，不得用作任何其他用途。

電池警告

- 切勿開啟、拆卸、擠壓、使其彎曲或變形、刺穿或搗碎產品。
- 切勿改裝或再製造、嘗試將異物插入電池、浸入水中、置於水或其他液體、火災、爆炸或其他危險中。
- 請勿讓如動物牙齒、指甲等尖銳物與電池發生接觸。這可能會引起火災。

- 僅使用系統指定的電池。
- 只可使用根據 CTIA 電池系統符合 IEEE1725 規定的認證要求的合資格充電系統電池。使用不符合的電池或充電器，可能會導致火災危險、爆炸、漏電或其他危險。
- 切勿讓電池短路或允許金屬導電物件接觸電池終端。
- 只能使用符合 IEEE-Std-1725 標準的電池來更換電池。使用不符合的電池，可能會導致火災危險、爆炸、漏電或其他危險。只可由授權服務供應商更換電池（若電池不能由用戶更換）。
- 應監督兒童使用電池。
- 避免掉落產品或電池。如果掉落產品或電池，尤其是掉落在硬表面，以及用戶懷疑的任何損壞，應將產品帶到服務中心進行詳細檢測。
- 電池使用不當可能會導致火災、爆炸或其他危險。
- 請緊記在產品完全充電後從牆壁插座拔出充電器，避免充電器造成不必要的電力損耗。

- 若使用類型不當的電池，則有發生爆炸的危險。

警告：電池更換須知

- 為確保安全，請勿移除併入產品內的電池。如果需要更換電池，請帶同手機前往最近的授權 LG 電子產品服務點或經銷商以尋求協助。
- 鋰電池是一種可能會造成人身傷害的危險元件。
- 將電池更換為不合格的產品可能會導致您的裝置受損。

防水性質備註

此產品已根據防水防護等級 IP67* 評級防水和防塵。

* IP67 評級表示產品即使溫和地浸入一缸最深一米的室溫開水約 30 分鐘，產品仍可正常運作。

避免使本產品處於在灰塵和潮濕的環境中。切勿在下列環境中使用產品。



切勿把產品浸入水以外的任何化學液體（例如肥皂等）。



切勿把產品浸入鹽水中，例如海水。



切勿把產品浸入溫泉。



切勿於游泳時配戴本產品。



切勿於水底使用本產品。



切勿把產品直接放於沙（例如在海灘）或泥中。

- 產品沾濕後，水份可能會流入主機的罅隙中。搖動產品以把水份流走。
- 即使水份流走後，內部可能仍有水份。雖然可使用產品，但不要放於一定不能沾濕的物品旁。小心不要把衣服、手袋或手袋內的物品弄濕。

- 若由於咪高風內有水份，導致語音啟動未能正常運作，請先把水份風乾。
- 切勿於可能被噴上高壓水柱的地方（例如水龍頭或花灑頭）使用產品，或長時間浸入水中，因為產品並非設計為可承受高壓水力。
- 本產品不防震。切勿掉落產品或令其受到衝擊。這樣可能會損或令主體變形，導致防水功能受損。

心律調校器及其他醫療儀器

使用心律調校器的人員：

- 當產品處於開機狀態時，應始終保持產品與他們的心律調節器的距離超過六吋。
- 不可將產品置於胸部口袋中。
- 應使用與心律調節器相反一邊的手腕，以盡量減少潛在的 RF 干擾。
- 如果有顯示出現干擾，請立即關閉產品。

如果您使用任何其他個人醫療儀器，可以向醫生或該裝置製造商諮詢以確定其是否能夠充分阻擋外部 RF 能量。

於手錶使用藍牙及 Wi-Fi 的提示

- 當連接產品到其他流動裝置時，兩個裝置必須放於十分接近的位置。如果不能的話，按照使用環境而定，可能會造成不當操作或嘈音。
- 於空曠地方，藍牙通訊範圍通常跨越約 10 米。這範圍可能按照使用環境而有所不同。
- 不要於產品與已連接裝置之間放置障礙物。發出/收到訊號可能因使用者的身體、牆壁、角落或障礙物而有所減弱。請於沒有障礙物時使用。
- 當使用 Wi-Fi 連接時，即使藍牙不可用，您的手錶都可由您的手機或平板電腦獲得通知。
- 您的手錶將按照您的手機登記的 Wi-Fi 清單，搜尋及連接至最近的 Wi-Fi 網絡。

屏幕提示

- 不要長期顯示靜止的影像。可能會構成影像固定或對螢幕造成色斑。
- 不建議使用顯示相同畫面超過 10 分鐘的應用程式，因為保養不包括可能造成的螢幕損害。

無線電波暴露準則

無線電波暴露及特定吸收比率 (SAR) 資訊。

本產品之設計符合適用的無線電波暴露安全要求。這些要求乃基於可確保所有使用者安全的科學指引，範圍涵蓋任何年齡與任何健康狀況的人士。

- 無線電波暴露指引的量度單位叫作特定吸收比率或 SAR。SAR 測試使用標準方法進行，用產品在所有使用的頻帶最高的合格電源水平傳輸。
- 雖然不同型號 LG 產品的 SAR 水平有所差異，但所有這些產品的設計均符合無線電波暴露的相關指引。
- 國際非離子化輻射保護委員會 (ICNIRP) 建議的 SAR 限制，口部 SAR 為平均 10 克組織 2W/kg，肢體配戴 SAR 為平均 10 克組織 4.0W/kg。
- 經測試，該型號產品在口部附近（臉部）使用的最高 SAR 值為 0.016 W/kg (10g)，肢體（手腕）配戴為 0.385 W/kg (10g)。

- 經測試，此裝置在一般肢體（手腕）配戴操作時，使用者身體（手腕）與裝置背面之間的距離為 0 厘米。此外，經測試，此裝置於口部附近（臉部）操作時，使用者的口部與裝置正面之間的距離為 1 厘米。為確保符合 R&TTE SAR 要求，請確保於口部附近（臉部）操作時，維持最少相隔 1 厘米的距離。

歐盟確認聲明

LG Electronics 在此聲明 **LG-W150** 產品符合對 **1999/5/EC** 指示的基本要求和相關規定。確認聲明副本請見：

<http://www.lg.com/global/declaration>。

注意：開放來源程式碼軟件

若要獲取此產品所包含的 GPL、LGPL、MPL 來源程式碼和其他開放來源程式碼認證，請瀏覽 <http://opensource.lge.com>。

除了來源程式碼，所有涉及到的授權條款、免責聲明和版權聲明可供下載。

LG Electronics 亦可以透過收費 CD-ROM 提供開放來源程式碼，費用包括 CD-ROM 成本（例如媒體成本、運費以及處理費），您可透過 opensource@lge.com 索取。此服務由購買產品日期起計算三年內有效。

監管資訊

1. 按住**電源鍵**直至顯示應用程式清單。
2. 前往 **Settings > About > Regulatory information** 以獲得監管資訊。

如何更新您的裝置

存取最新韌體更新、新增軟件功能以及改善地方。

1. 按住**電源鍵**直至顯示應用程式清單。
2. 前往 **Settings > About > System updates**。

.....

.....

.....



.....

.....

Visit ***www.lg.com*** to view the user guide and more information.

- Some contents and illustrations may differ from your device depending on the region, service provider, software version, or OS version, and are subject to change without prior notice.
- Always use genuine LG accessories. The supplied items are designed only for this device and may not be compatible with other devices.
- Available accessories may vary depending on your region, country or service provider.


Watch layout



! Warning Do not close or push the hole located at the bottom of the device with a sharp object. Doing so may cause your device to work improperly.

Charging the watch

Before using your watch for the first time, you should charge the battery.



- Use the charging cradle provided with the your watch to charge its battery.
- Connect the charging cradle to a power outlet and place the watch on it. The watch will turn on automatically.
- To maximize battery life, make sure that the battery is fully charged before you use it for the first time.

Charging the watch

Cautions to be taken regarding the corrosion of charging terminals

Exposing to sweat or other foreign material during the use of the product may cause corrosion at the terminals while charging it.


To prevent this, wipe the product with a cloth before charging.

Cautions before wearing the leather strap


- The LG Watch Urbane's stitched leather strap is thick enough to meet high quality standard. Before wearing the leather strap, please bend it back and forth a few times. This will help you feel more comfortable when wearing it.
- Depending on the user's skin condition, the watch may cause unintended allergic reactions on the skin it's in contact with.

Turning on the watch

To turn on the watch, press and hold the **Power Key** (on the right hand side of the watch) for a few seconds.



Turning off the watch

- 1 Press and hold the **Power Key** until the apps list appears.
- 2 Tap **Settings** > **Power off**.
- 3 When prompted with the message **Power off: Are you sure?**, tap .

Before Pairing

Before pairing, please do the following on the phone or tablet.

- 1 Make sure that the Android version on your phone or tablet is Android 4.3 or higher and supports Bluetooth®.
 - To find out whether your phone or tablet supports Android Wear, visit <http://g.co/WearCheck> from your phone or tablet.
 - If your phone or tablet is not Android 4.3, or later, please check with your manufacturer for a possible software update.
- 2 Make sure your phone or tablet is next to your watch.
- 3 On your phone or tablet, download the **Android Wear**  app from the **Play Store**  app and install it. Check that the **Android Wear**  app is installed and updated to the latest version on your phone or tablet.

Before Pairing

- 4 Make sure your phone or tablet is connected to mobile data or Wi-Fi. You need a data connection to set up your watch for the first time.
- 5 Keep the watch connected to power during setup.

NOTES:

- Depending on the software installed on your watch, your watch may automatically download and install an update.
- Depending on the network condition, the setup process might take over 20 minutes.


How to pair your watch

- 1 Turn on the watch and swipe the welcome screen left to begin.
- 2 Tap a language.
- 3 Connect your watch to a power source and swipe left to continue.

Tip: If the battery is less than 20%, your watch may not move to the next step.


- 4 Swipe left following the onscreen instruction until the watch code is displayed.

How to pair your watch

- 5 Open the **Android Wear**  app on your phone or tablet. Turn Bluetooth on during setup, if it isn't already on.
- 6 On your phone or tablet, you'll see a list of nearby devices. Tap your watch's code.
- 7 You'll see a pairing code on your phone or tablet and watch. Check that the codes match.
- 8 Tap **Pair** on your phone or tablet to start pairing.
- 9 You'll see a confirmation message on your watch once it is paired. This can take a few minutes, so please wait a while.
- 10 Follow the onscreen instructions to complete the initial setup.

Heart Rate Sensor

Wear your watch on your wrist correctly before measuring the heart rate.



Heart Rate Sensor

NOTES:


- Loose fitting or too much movement may cause inaccurate measurements.
- Never look directly at the heart rate sensor light as this may damage your eyesight.
- When heart rate readings are inaccurate, retake your heart rate measurements by putting your watch on the inside of one of your wrists.

Connecting to another mobile device

If you want to connect your watch to another device, you must reset your watch.

Reset your watch

This setting resets your watch's settings to their factory default values and deletes all of your data.

- 1 Press and hold the **Power Key** until the apps list appears.
 - 2 Tap **Settings** > **Factory reset**. You are prompted to confirm.
 - 3 Tap .
- Your watch connects to one mobile device at a time.
 - Factory reset erases all data from your watch's memory. After completion, it is ready to connect to another mobile device.

Safety information

Before turning on your product, review the basic safety information provided here.

General safety & handling

While using your product, be aware of the following common-sense guidelines.

Your environment

- **Safe operating temperatures.** Use and store your product in temperatures between 0°C/32°F and 40°C/104°F. Exposing your product to extremely low or high temperatures may result in damage, malfunction, or even explosion.
- **While driving.** When driving a car, driving is your first responsibility. Using a mobile device or accessory for a call or other application while driving may cause distraction. Keep your eyes on the road.

- **Around explosives.** Do not use in areas where sparks from the product might cause a fire or explosion.
- **On airplanes.** Observe all rules and instructions for use of electronic devices. Most airlines allow electronic use only between and not during takeoffs and landings. There are three main types of airport security devices: X-ray machines (used on items placed on conveyor belts), magnetic detectors (used on people walking through security checks), and magnetic wands (hand-held devices used on people or individual items). You can pass your product through airport X-ray machines. But do not send it through airport magnetic detectors or expose it to magnetic wands.
- Always follow any special regulations in a given area. Turn your device off in areas where use is forbidden or when it may cause interference or danger.
- Changing the wrist straps to metal straps might cause Bluetooth/Wi-Fi connectivity problem.

Safety tips

WARNING: The charging cradle contains strong magnets that may interfere with pacemakers, credit cards, watches, and other magnet-sensitive objects. To avoid damaging your product and reduce the risk of fire or electric shock, explosion, or other hazards, observe these common-sense precautions:

- Use only with cables, chargers, and other accessories approved by LG.
- Do not drop, strike, or shake your product.
- Do not damage the power cord by bending, twisting, pulling, heating, or placing heavy items on it.
- This product is equipped with a USB cable for connecting to a desktop or notebook computer or to the charger. Be sure your computer is properly grounded before connecting your product to the computer. The power supply cord of a desktop or notebook computer has an equipment-grounding conductor and a grounding plug. The plug must be plugged into an appropriate outlet that is properly installed and grounded in

accordance with all local codes and ordinances.

- Do not attempt to repair or modify or remanufacture the product. It is equipped with an internal rechargeable battery, which should be replaced only by LG or an authorized LG repair center.
- Do not open, disassemble, crush, bend or deform, puncture, or shred the product.
- Do not insert foreign objects into the product.
- Do not place the product in a microwave oven.
- Do not expose the product to fire, explosion, or other hazards.
- Clean with a soft, damp cloth. Don't use harsh chemicals (such as alcohol, benzene, or thinners) or detergents to clean your product.
- Dispose of your product and battery separately from household waste and in accordance with local regulations.
- Like many electronic devices, your product generates heat during normal operation. Extremely prolonged, direct skin contact in the absence of

adequate ventilation may result in discomfort or minor burns. Therefore, use care when handling your product during or immediately after operation.

- If you have a problem with using the product, please stop using it and consult with the authorised LG Electronics customer service center.
 - Do not immerse or expose the product to water or other liquids.
- Pedometer, Sleep, Exercise, and Heart rate are not intended to treat or diagnose any medical condition, and should be used for leisure, well-being and fitness purposes only.
 - Heart rate readings can be affected by measurement conditions and your surroundings. Make sure you are seated and relaxed before reading your heart rate.

- This product is water and dust-resistant according to the IP67 Rating, which tests submersion in water at up to one metre for up to 30 minutes. Not shockproof. The case must be completely closed.
- Heart rate readings may be affected by skin condition, measurement conditions and your surroundings.
- Never look directly at the light of the heart rate sensor as this may damage your eyesight.
- If your device becomes hot, remove it until it cools down. Exposing skin to the hot surface for a long period of time may cause skin burn.
- The Heart rate feature is only intended for measuring your heart rate and must not be used for any other purposes.

Battery warnings

- Do not disassemble or open crush, bend or deform, puncture or shred.

- Do not modify or remanufacture, attempt to insert foreign objects into the battery, immerse or expose to water or other liquids, expose to fire, explosion or other hazard.
- Make sure that no sharp-edged items, such as animal's teeth or nails, come into contact with the battery. This could cause a fire.
- Only use the battery for the system for which it is specified
- Only use the battery with a charging system that has been qualified with the system per CTIA Certification Requirements for Battery System Compliance to IEEE1725. Use of an unqualified battery or charger may present a risk of fire, explosion, leakage, or other hazard.
- Do not short circuit a battery or allow metallic conductive objects to contact battery terminals.
- Replace the battery only with another battery that has been qualified with the system per this standard, IEEE-Std-1725. Use of an unqualified battery may present a risk of fire, explosion, leakage or other hazard.

Only authorized service providers shall replace battery (If the battery is non-user replaceable)

- Battery usage by children should be supervised.
- Avoid dropping the product or battery. If the product or battery is dropped, especially on a hard surface, and the user suspects damage, take it to a service center for inspection.
- Improper battery use may result in a fire, explosion or other hazard.
- Always unplug the charger from the wall socket after the product is fully charged to save unnecessary power consumption of the charger.
- There is risk of explosion if the battery is replaced with an incorrect type.

WARNING Notice for Battery replacement

- For your safety, do not remove the battery incorporated in the product. If you need to replace the battery, take it to the nearest authorized LG Electronics service point or dealer for assistance.
- Li-Ion Battery is a hazardous component which can cause injury.
- Battery replacement by non-qualified professional can cause damage to your device.

Notes on water resistant properties

This product is water and dust resistant in compliance with the Ingress Protection rating IP67*.

* The IP67 rating means that the product will maintain its operability even if it is gently submerged in a tank of still tap water at room temperature for about 30minutes, up to a depth of 1 meter.

Avoid exposing the product to environments with excessive dusts or

moisture. Do not use the product in the following environments.



Do not immerse the product in any liquid chemicals (soap, etc.) other than water.



Do not immerse the product in salt water, such as sea water.



Do not immerse the product in hot spring.



Do not swim wearing this product.



Do not use the product underwater.



Do not place the product directly on sand (such as at a beach) or mud.

- Once the product gets wet, water may remain in gaps of the main unit. Shake the product well to drain water.
- Even after water is drained, the inner parts might be still wet. Although

you can use the product, do not place it near things that must not get wet. Take care not to wet your clothes, bag or contents of the bag.

- Drain water if the voice activation does not work properly due to water remaining in the microphone.
- Do not use the product in places where it may be sprayed with high-pressure water (e.g. near a faucet or shower head) or submerge it in water for extended periods of time, as the product is not designed to withstand high water pressure.
- This product is not resistant to shock. Do not drop the product or subject it to shock. Doing so might damage or deform the main unit causing water leak.

Pacemakers and other medical devices

Persons with pacemakers should:

- ALWAYS keep the product more than six (6) inches from their pacemaker when the product is turned ON.

- Not carry the product in a breast pocket.
- Use the wrist opposite the pacemaker to minimize the potential for RF interference.
- Turn the product OFF immediately if there is any indication that interference is taking place.

If you use any other personal medical device, consult your physician or the manufacturer of your device to determine if it is adequately shielded from external RF energy.

Tips for using Bluetooth and Wi-Fi on your watch

- When connecting your product to other mobile devices, the devices must be positioned close to each other. If not, it may cause abnormal operation or noise, depending on the use environment.
- In an open space, the Bluetooth communication range usually spans approximately 10m. This range may vary depending on the use environment.
- Do not place obstacles between your product and connected devices. Outgoing/incoming signal can weaken due to user's body, walls, corners or obstacles. Use where there is no obstacle.
- When using a Wi-Fi connection, your watch can get notifications from your phone or tablet even if Bluetooth is unavailable.
- Your watch will search and connect to the nearest Wi-Fi network based on the Wi-Fi list registered on your phone.

Tips for the display screen

- Do not display non-moving images for an extended period. This may cause image burn-in or stains on the screen.
- Applications that display the same screen for more than 10 minutes are not recommended because the potential screen damage is not covered by the warranty.

Exposure to radio frequency energy

Radio wave exposure and Specific Absorption Rate (SAR) information. This product has been designed to comply with applicable safety requirements for exposure to radio waves. These requirements are based on scientific guidelines that include safety margins designed to assure the safety of all persons, regardless of age and health.

- The radio wave exposure guidelines employ a unit of measurement known as the Specific Absorption Rate, or SAR. Tests for SAR are conducted using standardised methods with the product transmitting at its highest certified power level in all used frequency bands.
- While there may be differences between the SAR levels of various LG product models, they are all designed to meet the relevant guidelines for exposure to radio waves.
- The SAR limit recommended by the International Commission on Non-ionizing Radiation Protection (ICNIRP) is 2 W/kg averaged over 10g of tissue for the Mouth SAR or 4.0 W/kg averaged over 10g of tissue for the Limb-worn SAR.
- The highest SAR value for this model product when tested for use at Next-to-Mouth(Face) is 0.016 W/kg (10g) and for Limb-worn(Wrist) is 0.385 W/kg (10g).

- This device was tested for typical Limb-worn(Wrist) operations kept 0 cm between the user's body(Wrist) and the back of the device. Additionally this device was tested for typical Next-to-Mouth(Face) operations with the front of the device kept 1 cm between the user's mouth(Face) and the front of the device. To ensure compliance with R&TTE SAR requirements, please ensure a minimum separation distance of 1 cm is maintained for next-to-mouth (face) operations.

EU DECLARATION OF CONFORMITY

Hereby, **LG Electronics** declares that this **LG-W150** product is in compliance with the essential requirements and other relevant provisions of Directive **1999/5/EC**. A copy of the Declaration of Conformity can be found at **<http://www.lg.com/global/declaration>**.

Open Source Software Notice Information

To obtain the source code under GPL, LGPL, MPL, and other open source licenses, that is contained in this product, please visit <http://opensource.lge.com>.

In addition to the source code, all referred license terms, warranty disclaimers and copyright notices are available for download.

LG Electronics will also provide open source code to you on CD-ROM for a charge covering the cost of performing such distribution (such as the cost of media, shipping, and handling) upon email request to opensource@lge.com. This offer is valid for three (3) years from the date on which you purchased the product.

Regulatory information

1. Press and hold the **Power Key** until the apps list appears.
2. Tap **Settings** > **About** > **Regulatory information** to get regulatory information.

HOW TO UPDATE YOUR DEVICE

Access to latest firmware releases, new software functions and improvements.

1. Press and hold the **Power Key** until the apps list appears.
2. Tap **Settings** > **About** > **System updates** on your device.



Warranty Card
產品保用證

Service Commitment

服務承諾

LG's mission is to create value for customers. We are committed to improve the life of our customers by putting the customers first, and delivering the best possible pre and after sales services in the way they want.

為顧客創造價值乃LG一貫宗旨。我們致力提供最貼心的售前及售後服務，一切以顧客為先，希望為客戶帶來最優質的生活。

Warranty Card

產品保用證

LG Customer Care Centre

客戶維修服務中心

Welcome to contact for detailed information

歡迎致電查詢詳細資料

Customer Service Hotline 客戶服務熱線

: (852) 3543 7777

E-mail Us 客戶查詢電郵

: cshelpdesk@lge.com

LG Website 瀏覽網站

: www.lg.com

Privacy Statement

You are aware that any information supplied by you after purchase of our product will be retained by LG Electronics HK Ltd. and will not be released to third parties. You also authorize LG Electronics HK Ltd. to send you direct promotion materials. Please contact our Customer Service Hotline at (852) 3543 7777 if you wish to modify or erase your provided personal information.

私隱聲明

閣下在購買本公司產品後所提供的任何資料，將會由LG Electronics HK Ltd.保有，不會透露給予第三方，並授權本公司對閣下發出直接推廣通訊。如希望修改或刪除所提供的個人資料，可聯絡本公司客戶服務熱線(852) 3543 7777作出相關安排。

Thank you for your purchase of LG Electronics product under the terms and conditions listed on this warranty card.

多謝閣下購買及使用本公司之產品，請參閱保用證所列之產品保用條款。

IMPORTANT : Please keep and present this warranty card and purchase invoice when services are rendered. Otherwise, this warranty will be voided.

重要事項 : 顧客請保留此保用證及購貨發票，並需在檢查/維修時出示，否則保用無效。

Warranty Policy of the Product 產品保用條款

- (1) LG Electronics Hong Kong Limited (hereafter LGEHK) provides warranty period from the date of purchase are as follows and only valid for product purchase in Hong Kong / Macau only (any promotion gift item is not included):

(i) Device	: 12 months	(ii) Charger	: 6months
(iii) Battery	: 6months	(iv) Hand free earphone	: 3months
(v) Data cable	: 3months		
- (2) Warranty is valid only for authorized product; parallel import and counterfeit product are invalid.
- (3) Product is under warranty against manufacturing defects by reason of faulty workmanship or internal electronic parts materials. This warranty does not cover defects arising from natural wear of the product (Including casing, key pad, display, antenna, and accessories, etc.)

- (4) If check-up or repairing are required, customer must present the original invoice and warranty card on which the relevant SN/CSN number was printed. Upon any failure to present the above documentation, customer must pay for the costs of the services provided.
- (5) All parts replaced within the warranty period are the property of LGEHK. We have rights to handle those parts as necessary.
- (6) Data stored in devices may be lost after the repair and thus should be properly stored by customer beforehand.
- (7) Warranty will be voided under the following conditions, and LGEHK reserves the right to refuse providing service and/or shall demand charges for any costs of servicing from customer:
 - (i) Product has been tampered with or undergone unauthorized repair by third parties, improper installation, alternation or modification to this product, or damage, tearing, removal of the warranty sticker that is affixed to this product.
 - (ii) Defects arising from misuse, mishandling, abuse, accident, negligence and damage caused directly or indirectly by fire, flood, liquid water, corrosion, convulsion of nature, war, riot or civil commotion.
 - (iii) The SN/CSN number sticker on this product has been erased or modified.
 - (iv) The content of warranty policy has been modified without authorization.
- (8) LGEHK is not responsible for any loss of data or system corruption during the process of transportation or repair to and from the Service Centre and due to the forces of nature.

- (9) LGEHK reserves the right to terminate or modify the terms of this warranty card. For exceptional cases, subject to report of our investigation, we reserve the right to terminate this warranty card or modify terms of warranty policy.
- (10) Our company will not be liable for any loss directly or indirectly caused by the breakdown of the product.
- (11) This warranty card is restricted within Hong Kong SAR / Macau SAR only.
- (12) LG and its Authorized Service Centers reserve the right to use refurbished or reconditioned parts or whole products for the same or functionally equivalent model when conducting product repairs and replacement.

(1) 本公司為客戶提供保修期如下，只適用於香港/澳門購買之產品，並不包括各促銷活動之贈品(由購買日起計)

- | | | | |
|----------|--------|-----------|-------|
| (i) 裝置機身 | : 12個月 | (ii) 充電器 | : 6個月 |
| (iii) 電池 | : 6個月 | (iv) 免提耳機 | : 3個月 |
| (v) 數據線 | : 3個月 | | |

- (2) 保修服務只適用於原裝行貨；水貨及冒牌貨均屬無效。
- (3) 此保修只適用於生產上的瑕疵，如電子零件偶然出現毛病，並不包括產品的自然磨損包括外殼、鍵盤、顯示屏、天線、附件等。
- (4) 用戶要求維修服務時，須同時攜同產品裝置、保用證及印有SN / CSN 號碼之有效發票正本到本公司指定之維修中心進行維修，否則保修服務無效，客戶須繳付維修費用。

- (5) 在保修期內維修更換後的所有零件、配置及附件，均屬本公司所有，本公司有權作出任何處理。
- (6) 裝置內存資料有可能因維修後遺失，請顧客要自行保存。
- (7) 在下列情況下本保用證將自動失效，本公司有權拒絕維修該產品或向客人徵收所有的維修費用。
 - (i) 產品曾作未許可之維修、不適當的安裝、更改，或貼於其上的維修貼紙遭受損毀、撕破、除去，保修服務即無效。
 - (ii) 產品曾被錯誤使用，錯誤處理，疏忽使用，直接或間接意外由火、液體、火災、腐蝕、地震、戰爭、暴亂或天災所造成的損壞。
 - (iii) 產品上的SN / CSN 號碼貼紙(如適用)一經修改或除去，保修服務即無效。
 - (iv) 擅自修改本保用證的內容。
- (8) 本公司將對任何於使用、維修或運送時引致之系統錯誤及資料流失，或因天然災害，意外事件造成之損失概不負責。
- (9) 本保用證的發出及終止權均屬本公司所有。就不明的情況或個案，經審查後，本公司有權發出或終止本保用證。
- (10) 本公司將不負責由於產品損壞而直接或間接引致之任何損失。
- (11) 此保用證只適用於香港/澳門特別行政區範圍內。
- (12) 本公司及其授權之維修中心在維修或更換產品時，保留使用與產品或功能相同的部分或全部再生零件之權利。

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....