


Quick Start Guide

19M38A	20M38A	22M38A	24M38A	27MP38VQ
19M38D	20M38D	22M38D	24M38D	27MP38HQ
19M38H	20M38H	22M38H	24M38H	
19M38AB	19M38HB			



www.lg.com

+ Depending on country

Unpacking

Check your product box for the following items. If there are any missing accessories, contact the local dealer where you purchased your product. The illustrations in this manual may differ from the actual product and item.

*Image may vary depending on models.




MBM64536741

P/No: MBM64536741 (1608-REV00)




English


It is recommend that use the supplied components.




2



19M38A	20M38A	22M38A	24M38A
19M38D	20M38D	22M38D	24M38D
19M38H	20M38H	22M38H	24M38H
19M38AB	19M38HB		




3




27MP38VQ
27MP38HQ

2





4




CAUTION

Image shown may differ from your Monitor
When attaching the stand to the Monitor,
place the screen facing down on a cushioned
table or flat surface to protect the screen
from scratches.









Note : All connection cables shown in the picture are not included along with the monitor set.





English

- Using a DVI to HDMI / DP (Display Port) to HDMI cable may cause compatibility issues.
- Make sure to use the supplied cable. Otherwise, this may cause the device to malfunction.



or



*Image may vary depending on models.

