



SIMPLE MANUAL

# Mini Hi-Fi System

ENGLISH

Please read this manual carefully before operating your set and retain it for future reference.  
To view the instructions of advanced features, visit <http://www.lg.com> and then download  
Owner's Manual. Some of the content in this manual may differ from your unit.


MODEL  
CK43




MFL71987901

[www.lg.com](http://www.lg.com)

Copyright © 2018-2022 LG Electronics Inc. All Rights Reserved.



## Front Panel



**1** USB 1 Port  
You can play sound files by connecting the USB device.

**3** Display window

**3** (Remote sensor)

**4** USB 2 Port  
You can play sound files by connecting the USB device.

**5** **MASTER VOL.** (Volume)  
Adjust speaker volume.

**6** **BASS BLAST** (or **BASS BLAST+**)  
Press to select BASS (or BASS+) effect directly.

### DEMO

In power off status, if you press **DEMO**, show DEMO mode.

### **WIRELESS LINK**

- Selects MAIN or OTHER on WIRELESS PARTY LINK mode.
- Enable or disable WIRELESS PARTY LINK mode.

**7** **F** (Function)  
Selects the function and input source.

### (Skip/Search)

- Skips forward.
- Searches for a section within a track/file.
- Selects the radio stations.

### (Open/Close)

Opens and closes the disc tray.

**8** **AUTO DJ**  
Selects the AUTO DJ mode.

### (Play/Pause)

- Starts or pauses playback.
- Selects stereo/mono.

**9** (Standby)  
Turns the power on or off.

### (Skip/Search)

- Skips backward.
- Searches for a section within a track/file.
- Selects the radio stations.

### (Stop)

Stops playback or cancels DELETE function.

**10** Disc tray

**11** **SPECIAL EQ**  
Chooses special equalizer.

### **SEARCH**


Moves to folder or file in selection mode.

### **OK**

Selects a folder when searching a file.


**12** **EQUALIZER / SEARCH**  
- Chooses sound impressions.  
- Searches a folder or a file.

## Rear Panel



- 1** Power cord
- 2** **SPEAKERS** terminals
- 3** **AUX IN (L/R)**  
Connect an auxiliary device.
- 4** **ANTENNA (FM)**

## Speaker Connection



### Controller App



Download the **Music Flow Bluetooth** App to your device. (Android only)

### LG Sound Sync (Wireless)



For more information, download the online owner's manual. <http://www.lg.com>

## Additional Information

### Specifications


|                                       |                                                                                                            |
|---------------------------------------|------------------------------------------------------------------------------------------------------------|
| Power Requirements                    | Refer to the main label on the unit.                                                                       |
| Power Consumption                     | Refer to the main label on the unit.<br>Networked standby : 0.5 W<br>(If all network ports are activated.) |
| Dimensions (W x H x D)                | Approx. 300 mm x 163 mm x 241 mm                                                                           |
| Bus Power Supply (USB)                | 5 V  500 mA               |
| Amplifier<br>(Total RMS output power) | 300 W RMS                                                                                                  |

Design and specifications are subject to change without notice.

### How to disconnect the wireless network connection or the wireless device

Turn off the unit by pressing the power button for more than 5 seconds.

### Replacement of battery



### Declaration of Conformity



Hereby, LG Electronics declares that the radio equipment type Mini Hi-Fi System is in compliance with Directive 2014/53/EU. The full text of the EU declaration of conformity is available at the following internet address:

<http://www.lg.com/global/support/cedoc/cedoc#>

For consideration of the user, this device should be installed and operated with a minimum distance of 20 cm between the device and the body.



-----

-----

-----

-----

-----

-----

-----

-----

-----

-----



-----

-----

-----

-----

-----

-----

-----

-----

-----

-----



-----

-----

-----

-----

-----

-----

-----

-----

-----

-----



### **Российская Федерация**

Импортер ООО "ЛГ Электроникс Рус"

Адрес импортера: 143160, Российская Федерация, Московская область, Рузский городской округ, территория Минское шоссе, километр 86-й, дом 9

Адрес производителя : ЛГ Электроникс (Хужоу) Инк., завод Хатаи  
516006, Китай, пров. ГуанДонг, г. Хужоу, Промышленная зона  
Жонгкай, Индустриальный парк Хутай, ХуФенг Донг Уи Роуд, 13.

**Сделано в Китае**

### **Україна**

Вироблено в: ЛГ Електронікс (Хужоу) Інк., завод Хатай  
516006, Китай, пров. ГуанДонг, м. Хужоу, Промислова зона Жонгкай,  
Індустріальний парк Хутай, ХуФенг Донг Уі Роуд, 13.

### **Қазақстан Республикасы**

Импорттаушы АҚ "ЭЛ Джи Электроникс Алматы Қазақстан", 050061, Алматы қ., Көкорай көшесі, 2А/9

Өндірушінің мекенжайы: LG Electronics(Huizhou) Inc. Huitai Factory  
516006, Қытай, ГуанДонг ауданы, Хужоу қаласы, Жонгкай өнеркәсіптік аймағы,  
Хутай Индустриялық саябағы, ХуФенг Донг Уи Роуд, 13.

Қазақстан Республикасы территориясында тұтынушылардан келіп түскен талаптар мен ұсыныстарды қарайтын және тауарды жөндеу мен техникалық қызмет көрсететін ұжым:

АҚ «Эл Джи Электроникс Алматы Қазақстан», 050061, Қазақстан Республикасы, Алматы қ., Көкорай көшесі, 2А/9. Басқа сервис орталықтары жайында мағлұматты "Тұтынушыға қызмет көрсету орталығына" телефон шалу арқылы білуге болады.

**Қытайда жасалған**