

Specification

Power requirements

- Refer to the main label.
- Built-in rechargeable battery

Power consumption

- Refer to the main label.
- Networked standby: 1.0 W

Dimensions (W x H x D): Approx. 310 mm x 700 mm x 316 mm

Bus Power Supply (USB): 5 V  500 mA

Amplifier (Total RMS Output power): 250 W RMS

Operating Temperature: 5 °C - 35 °C

Operating Humidity: 5 % - 80 % RH

Ingress Protection: IPX4

- Liquid: Protected against splashing water.

How to deactivate the wireless network connection(s).

Set up the [Auto power-on.] to off on **LG XBOOM app** and turn off the product by pressing the **Power**  button.

Battery Life: Approx. 20 hours

- Operation time may vary depending on the battery or operation status.
- This unit contains magnets which can be harmful to some kind of object (Ex: Magnetic card, Pacemaker etc.).
- Internal lithium battery in the unit should not be replaced by user because of danger of explosion if battery is incorrectly replaced, and must be replaced with the same type battery by expert.
- Do not leave the unit on an unstable place such as high shelves. It may fall down because of the vibration of the sound.

CAUTION when using this product in environments of low humidity.

- It may cause static electricity in environments of low humidity.
- It is recommended to use this product after touching any metal object which conducts electricity.

For models using water-resistant products

When charged, the water-resistant function is limited, so use it in a place that is not exposed to water.

מפרט

דרישות חשמל

- עיין בתווית הראשית.
- סוללה נטענת מובנית

צריכת חשמל

- עיין בתווית הראשית.
- חיבור לרשת במצב המתנה: 1.0 וואט

מידות (רוחב x גובה x עומק): 310 מ"מ x 700 מ"מ x 316 מ"מ (בקירוב)

אפיק אספקת חשמל (USB): 5 V  500 mA

מגבר (סה"כ עוצמת הספק (RMS): 250 W RMS

טמפרטורת עבודה: 5 °C - 35 °C

לחות עבודה: 5 % - 80 % RH

הגנה מפני כניסה: IPX4

- נוזל: מוגן מפני התזת מים

ניתוק חיבור הרשת הרשת האלחוטית

הגדר את [הפעלה אוטומטית]. לכיבוי באפליקציית **LG XBOOM** וכבה את המוצר על ידי לחיצה על לחצן **ההפעלה** .

חיי סוללה: כ. 20 שעות

- זמן הפעולה עשוי להשתנות בהתאם לסוללה או למצב הפעולה.
- יחידה זו מכילה מגנטים שעלולים להזיק לסוג כלשהו של חפץ (למשל: כרטיס מגנטי, קוצב לב וכו').
- אין להחליף את סוללת הליתיום הפנימית ביחידה על ידי המשתמש בגלל סכנת פיצוץ אם הסוללה תוחלף בצורה שגויה, ויש להחליפה בסוללה מאותו סוג על ידי מומחה.
- אל תשאיר את היחידה במקום לא יציב כגון מדפים גבוהים. זה עלול ליפול בגלל הרטט של הצליל.

זהירות בעת שימוש במוצר זה בסביבות של לחות נמוכה.

- זה עלול לגרום לחשמל סטטי בסביבות של לחות נמוכה.
- מומלץ להשתמש במוצר זה לאחר נגיעה בכל חפץ מתכת שמוליך חשמל.

לדגמים המשתמשים במוצרים עמידים במים

בעת טעינה, הפונקציה עמידה במים מוגבלת, לכן השתמשו בו במקום שאינו חשוף למים.



מדריך מהיר רמקול בלוטות' נייד

Portable Bluetooth Speaker

XL7S



www.lg.com
זכויות יוצרים © כל ה זכויות שמורות לחברת
LG ELECTRONICS INC 2024



MFL71944345
2211_Rev01

ENGLISH Installing and Using the Product

Please read this manual carefully before operating your set and retain it for future reference.
To view the instructions of advanced features, visit <http://www.lg.com> or scan QR code and then download Owner's Manual. Some of the content in this manual may differ from your product.



- A** Handle

B Controls

C Flash Lighting

D Speaker (Tweeter)
- E** Dot Animation

F Speaker (Woofers) / Woofer Lighting

G Attaching the ferrite core (optional)
- Wind the power cord cable twice around the ferrite core.

- 1** Connect the power cord to the product by opening the rear cover and charge it before use
- 2** Connecting the Speaker to a Smartphone via Bluetooth
- 1** Press the **Power** button to turn on the product.

2 Press the **Function** button on the product repeatedly to select the BT function. The BT LED blinks.

3 Tap the **Settings** button on your smartphone and select **Bluetooth**. Turn on the **Bluetooth** function. (Off > On)

4 From the list of smartphone devices, find and tap on "LG-XL7S(XX)"

5 Once the smartphone is connected to the product via **Bluetooth**, the BT LED will turn on. Play a desired track in the music app on your smartphone.
- 3** Playing Music from the USB
- 1** Open the back cover of the product and plug the USB storage device into the USB terminal.

2 Press the **Power** button to turn on the product.

3 Press the **Function** button on the product repeatedly to select the USB function. The USB LED will turn on.

4 Press the **Play/Pause** button to enjoy the music.
- 4** Connecting to the LG XBOOM App
- 1** Find the **LG XBOOM app** on the Google Play or App Store and install it on your smartphone.

2 Run the **LG XBOOM app** and use its functions. (EQ, Wireless Party Link, Dot Animation, Lighting, Setting etc.)
- 5** Power Saving
- If there is no playback or button input for 15 minutes, the product turns off automatically. On the **LG XBOOM app**, you can enable or disable [Auto Power Management].

! This product has wheels and a handle so you can easily move the product.
Press the lock button on the handle and then pull the handle up. Release the lock button to lock the handle in place.

• Design and specifications are subject to change without notice.

עברית התקנה ושימוש במוצר

אנא קרא מדריך זה בעיון לפני הפעלת המכשיר ושומר אותו לשימוש עתידי.
לצפייה בהוראות עבור תכונות מתקדמות, בקר בכתובת <http://www.lg.com> או סרוק את קוד ה-QR והורד את המדריך למשתמש. חלק מתוכן מדריך זה עשוי להיות שונה מהמוצר שלך.



- A** ידית

B בקורות

C תאורת פלאש (רמקול (טוויטר)

D רמקול (וופר) / תאורת וופר

E אנימצית נקודות

F רמקול (וופר) / תאורת וופר

G חיבור ליבת הפריט (אופציונלי)
- סובב את כבל כבל החשמל פעמיים סביב ליבת הפריט.
- E** אנימצית נקודות

F רמקול (וופר) / תאורת וופר

G חיבור ליבת הפריט (אופציונלי)
- סובב את כבל כבל החשמל פעמיים סביב ליבת הפריט.

- 1** חבר את כבל החשמל למוצר על ידי פתיחת המכסה האחורי וטען אותו לפני השימוש
- 2** חיבור הרמקול לסמארטפון באמצעות בלוטות'
- 1** הקש על הפעלה/כיבוי לחצן להפעלת המוצר.

2 הקש על לחצן פונקציה במוצר שוב ושוב כדי לבחור בפונקציית בלוטות'. נורית בלוטות' מהבהבת.

3 הקש על הגדרות לחצן בטלפון החכם ובחר **Bluetooth**. הפעל את פונקציית **Bluetooth**. (כבוי > על)

4 מרשימת מכשירי הסמארטפון, מצא והקש על "LG-XL7S(XX)".

5 ברגע שהסמארטפון מחובר למוצר באמצעות **Bluetooth**, נורית ה-בלוטות' תידלק. הפעל רצועה רצויה באפליקציית המוזיקה בסמארטפון שלך.
- 3** השמעת מוזיקה מה-USB
- 1** פתח את המכסה האחורי של המוצר וחבר את התקן אחסון ה-USB למסוף ה-USB.

2 הקש על הפעלה/כיבוי לחצן להפעלת המוצר.

3 הקש על לחצן פונקציה במוצר שוב ושוב כדי לבחור את פונקציית ה-USB. נורית ה-USB תידלק.

4 הקש על הפעלה/השהה לחצן כדי ליהנות מהמוזיקה.
- 4** מתחבר לאפליקציית LG XBOOM
- 1** למצוא את האפליקציית **LG XBOOM** ב-Google Play או ב-App Store והתקן אותו בסמארטפון שלך.

2 הפעל את אפליקציית **LG XBOOM** והשתמש בפונקציות שלו. (אקולייזר, קישור מסיבה אלחוטי, אנימצית נקודות, תאורה, הגדרה וכו')
- 5** חסכון באנרגיה
- אם אין השמעה או כניסת לחצן במשך 15 דקות, המוצר נכבה אוטומטית. באפליקציית **LG XBOOM**, אתה יכול להפעיל או להשבית את [ניהול צריכת חשמל אוטומטי].

! למוצר זה יש גלגלים וידית כך שתוכל להזיז את המוצר בקלות.
לחץ על לחצן הנעילה על הידית ולאחר מכן משוך את הידית כלפי מעלה. שחרר את לחצן הנעילה כדי לנעול את הידית במקומה.

• העיצוב והמפרט עשויים להשתנות ללא הודעה מוקדמת.

