


Pagination & Folding



Printing Specifications

Material	Cover	Woodfree 80 g/m²	Note	· FSC logo size:	No FSC		Description	Sheet
	Inner	Woodfree 80 g/m²		· Purpose:				
Coating	Cover	Uncoated		· Country:	Global			
	Inner	Uncoated		· Application type:	For Product	Prepared		
Color	Cover	1 color (Black)		· Especially, Don't use or contain lead (Pb) and cadmium (Cd) in ink. · It should be printed with inks whose the total Mineral Oil(MOSH and MOAH) content is below 1% applied to the ink weight.		2025-08-14	P/No.	MFL72019438
	Inner	1 color (Black)				Checked		
Size		80 mm x 80 mm (Folded size)					Ver.	1.0
Binding Method		In order				Approved		
Book Binding		Saddle stitching						
Completed total pages		16						



SIMPLE MANUAL

Portable Bluetooth Speaker

XG8T



MFL72019438

www.lg.com
Copyright © 2024-2025 LG Electronics Inc.
All Rights Reserved.
2505_Rev02




Download Manual

<Android>

<iOS>

Download App







ENGLISH





Connecting and Using the Speaker

1 Charge the speaker before using it by opening the rear cover and connecting the speaker to the charging adapter.

2 Charging a smartphone

- 1** Connect the speaker to the charging adapter. Or if the adapter is not connected, press the **Power**  button on the speaker to turn it on.
- 2** Connect the smartphone to the **DC OUT (5 V  2 A)** terminal via the USB cable. The smartphone starts to be charged.

3 Connect the speaker to a smartphone via Bluetooth

- 1** Press the **Power**  button on the speaker to turn it on. **Bluetooth** LED blinks.
- 2** Press the **Settings**  button on the smartphone and select **Bluetooth**. Turn on the **Bluetooth** function. (Off  > On )
- 3** Find "LG-XG8T (XX)" on the device list on the smartphone and connect to it. Once the smartphone is connected via **Bluetooth**, the **Bluetooth** LED will turn on.
- 4** On the smartphone, play a music of your choice.


4 Connecting the LG XBOOM App

- ① Find **LG XBOOM app** on the Google Play or App Store and install it on your smartphone.
 - ② Run the **LG XBOOM app** and use more features. (EQ, Wireless Party Link, Lighting, Sleep Timer, Setting etc.)
- Design and specifications are subject to change without notice.
 - For more information, download the online owner's manual.
<http://www.lg.com>

ENGLISH

Specification


Power Supply:

- 19 V  3.42 A (AC Adapter)
- Built-in rechargeable battery

Power consumption

- Refer to the main label.

AC adapter

- Model : ADS-65AI-19-3 19065E
- Manufacturer : Shenzhen Honor Electronic Co.,Ltd
- Input : 100-240 V ~ 50-60 Hz
- Output : 19 V  3.42 A

BUS Power Supply (USB): 5 V 2 A

- Charging of devices other than smartphones cannot be guaranteed.
- Charging the smartphone via USB port is available when the speaker is turned on or connected to the charging adapter.

Dimensions (W x H x D):

Approx. 370 mm x 150.5 mm x 147 mm

Operating Temperature: 5 °C to 35 °C

Operating Humidity: 5 % to 60 %

Ingress Protection: IP67

- Solid: The unit is dust-tight.
- Liquid: Protection against being immersed in 1 meter of water.

Battery life: Approx. 15 hours

- Based on 50% volume, no lighting and Standard EQ. (Internal test result.)
- Actual usage time may vary.

Safety Information

CAUTION: TO REDUCE THE RISK OF ELECTRIC SHOCK DO NOT REMOVE COVER (OR BACK). NO USER-SERVICEABLE PARTS INSIDE. REFER SERVICING TO QUALIFIED SERVICE PERSONNEL.



This lightning flash with arrowhead symbol within an equilateral triangle is intended to alert the user to the presence of

uninsulated dangerous voltage within the product's enclosure that may be of sufficient magnitude to constitute a risk of electric shock to persons.



The exclamation point within an equilateral triangle is intended to alert the user to the presence of important operating and

maintenance (servicing) instructions in the literature accompanying the product.

WARNING:

- TO PREVENT FIRE OR ELECTRIC SHOCK HAZARD, DO NOT EXPOSE THIS PRODUCT TO RAIN OR MOISTURE.
- Do not install this equipment in a confined space such as a book case or similar unit.
- This unit contains magnets which can be harmful to certain kinds of objects (Ex: Magnetic card, Pacemaker etc..).

CAUTION:

- Do not block any ventilation openings. Install in accordance with the manufacturer's instructions. Slots and openings in the cabinet are provided for ventilation and to ensure reliable operation of the product and to protect it from over heating. The openings should never be blocked by placing the product on a bed, sofa, rug or other similar surface. This product shall not be placed in a built-in installation such as a bookcase or rack unless proper ventilation is provided or the manufacturer's instruction has been adhered to.
- The apparatus should not be exposed to water (dripping or splashing) and no objects filled with liquids, such as vases, should be placed on the apparatus.
- No naked flame sources, such as lighted candles, should be placed on the apparatus.
- To avoid fire or electric shock, do not open the unit. contact a qualified personnel only.

- Do not leave the unit in a place near the heating appliances or subject to direct sunlight, moisture, or mechanical shock.
- The Power Plug is the disconnecting device. In case of an emergency, the Power Plug must remain readily accessible.
- To clean the unit, use a soft, dry cloth. If the surfaces are extremely dirty, use a soft cloth lightly moistened with a mild detergent solution. Do not use strong solvents such as alcohol, benzene, or thinner, as these might damage the surface of the unit.
- Do not use volatile liquids such as insecticide spray near the unit. Wiping with strong pressure may damage the surface. Do not leave rubber or plastic products in contact with the unit for a long period of time.
- Do not place the unit over the vehicle's air bag. When the air bag deploys, it may result in injury. Before using in the car, fix the unit.
- Do not use the handsfree function during driving a car.
- Do not leave the unit on an unstable place such as high shelves. It may fall down because of the vibration of the sound.

- Do not use high voltage products around this product. (ex. Electrical swatter) This product may malfunction due to electrical shock.







CAUTION when using this product in environments of low humidity.

- It may cause static electricity in environments of low humidity.
- To prevent static electricity, it is recommended to touch metal objects before using this product.

NOTICE: For safety marking information including product identification and supply ratings, please refer to the main label on the bottom or the other surface of the product.

CAUTION: Only use the AC adapter supplied with this device. Do not use a power supply from another device or another manufacturer. Using any other power cable or power supply may cause damage to the device. The LG limited warranty does not cover damage caused by the use of third party accessories.

Symbols

	Refers to alternating current (AC).
	Refers to direct current (DC).
	Refers to class II equipment.
	Refers to stand-by.
	Refers to "ON" (power).
	Refers to dangerous voltage.

For models using a built-in battery

Do not store or transport at pressures lower than 11.6 kPa and at above 15,000 m altitude.

- replacement of a battery with an incorrect type that can defeat a safeguard (for example, in the case of some lithium battery types);
- disposal of a battery into fire or a hot oven, or mechanically crushing or cutting of a battery, that can result in an explosion;
- leaving a battery in an extremely high temperature surrounding environment that can result in an explosion or the leakage of flammable liquid or gas; and

- a battery subjected to extremely low air pressure that may result in an explosion or the leakage of flammable liquid or gas.

For models using a battery

This device is equipped with a portable battery or accumulator.

CAUTION: Risk of fire or explosion if the battery is replaced by an incorrect type.

How to Safely remove the batteries or the battery pack from the equipment:

To Remove the old batteries or battery pack, follow the assembly steps in reverse order. To prevent contamination of the environment and bring on possible threat to human and/or animal health, the old batteries or the battery pack must be put in an appropriate container at designated collection points. Do not dispose of batteries or battery pack together with other waste. It is recommended that you use local, free reimbursement systems batteries or battery packs, (may not be available in your area). The batteries or the battery pack should not be exposed to excessive heat such as sunshine, fire or the like.





