

- Connect a smart device (smartphone, tablet, etc.) or laptop to the projector using the wired/ wireless connection to enjoy the smart device or laptop screen enlarged by the projector.

To connect a smart device (smartphone, tablet, etc.) or laptop to the projector using the wireless connection

Press the **INPUT** button on the projector remote control and select **SCREEN SHARE**. Launch the relevant **SCREEN SHARE** function* on the device you want to connect. Search for the projector on the smart device to connect. After the connection is made, the smart device screen will be displayed through the projector.

(For specific instructions regarding this function, refer to the owner's manual for the smart device.)


* SCREEN SHARE functions

- Android OS smart device: Miracast (LG Electronics, etc.), Screen Mirroring (Samsung Electronics, etc.), Wireless Mirroring, etc.
- Windows OS laptop: Intel WiDi, Miracast, etc.

NOTE

- Depending on the device you are using, the wireless connection may be weak or unstable. In this case, make changes in **Group** to improve the connection.
- Depending on the network's environment, the wireless connection may be weak or unstable. In this case, press the **SETTINGS** button on the remote control and change the channel settings in **WIRELESS** → **SCREEN SHARE** → **Channel** → **Manual**.
 - Using the 5.0 GHz band is recommended. (Only 5.0 GHz Supported model)

www.lg.com
P/No: MBM64557371 (1704-REV00)




To connect a smart device (smartphone, tablet, etc.) to the projector using the wired connection

Connect a smart device to the projector using a cable* and set the external input of the projector to HDMI. The smart device screen will then be displayed through the projector.

For model-specific instructions regarding use of the wired connection, please check with the smart device manufacturer.

Supported smart devices may change depending on the circumstances of each manufacturer.

* Examples of how to connect a cable to different smart devices (cable purchased separately).



* The picture may look different from the actual product.


To Connect a Bluetooth Audio Device (Speaker/Headset)

The Bluetooth feature of the projector searches for nearby Bluetooth audio devices and enables you to connect your desired Bluetooth device and your projector wirelessly, so you can hear the audio from your projector via your desired Bluetooth audio device. The following is how to connect a Bluetooth audio device:

* The menus in the images may differ in the actual product.

NOTE

- The Bluetooth function is to connect the product to Bluetooth speakers or Bluetooth headset. You cannot connect the product to a mobile phone through the Bluetooth function.



Search Device

- 1 Press the **SETTINGS** button on your remote control and set **AUDIO** → **Sound Out** → **Bluetooth**.
- 2 Set your desired Bluetooth audio device to Pairing mode.
(For information on how to set up the Pairing mode, see the manual of your Bluetooth audio device.)
- 3 Select the **Search Device** option to search for a device to connect to. (The total search time is about 15 seconds. When your desired device appears in the list, you can stop the search by selecting **Stop searching**. The time it takes to connect to a device may vary according to the signal strength and the number of devices.)




- 4 Select the device you want to connect to after the search is completed, and then the Bluetooth audio device will be connected and added to **List of registered devices** automatically.

List of registered devices

Bluetooth audio devices that have been connected to your product at least once are automatically added to **List of registered devices** so that you can select and connect your desired device without a search later on. The following is how to connect a Bluetooth audio device:

* The menus in the images may differ in the actual product.

- 1 Press the **SETTINGS** button on your remote control and set **AUDIO** → **Sound Out** → **Bluetooth**.
- 2 Select **AUDIO** → **Sound Out** → **List of registered devices**.
(Make sure that your desired Bluetooth audio device is turned on.)



- 3 Select the Bluetooth audio device you want to connect to, and then the device will be connected.

NOTE

- If Bluetooth is On when you turn on your projector, the most recently connected Bluetooth device will automatically be connected. Bluetooth audio devices, however, have a feature that automatically turns themselves off, so please make sure your Bluetooth audio device is turned on first. (For more information, see the manual of your Bluetooth audio device.)
- If the screen is out of sync with the sound of your Bluetooth audio device, adjust the synchronization with the **AV Sync. Adjust** option.
- It is recommended that you keep the distance between your projector and the connected Bluetooth device within 5 m.

- Hubungkan perangkat pintar (smartphone, tablet, dsb) atau laptop ke proyektor menggunakan koneksi kabel/nirkabel untuk menikmati layar perangkat pintar yang diperbesar oleh proyektor.

Untuk menghubungkan perangkat pintar (smartphone, tablet, dsb) atau laptop ke proyektor menggunakan koneksi nirkabel

Tekan tombol **INPUT** pada kontrol jarak jauh proyektor dan pilih **SCREEN SHARE**. Jalankan fungsi **SCREEN SHARE** yang relevan* pada perangkat yang ingin dihubungkan. Cari proyektor pada perangkat pintar untuk menghubungkan. Setelah koneksi dilakukan, layar perangkat pintar akan ditampilkan melalui proyektor.
(Untuk petunjuk spesifik mengenai fungsi ini, lihat manual pengguna untuk perangkat pintar.)
* Fungsi **SCREEN SHARE**
— Perangkat pintar OS Android: Miracast (LG Electronics, dsb.), Screen Mirroring (Pemantulan Layar) (Samsung Electronics, dsb.), Wireless Mirroring (Pemantulan Nirkabel), dsb.
— Laptop OS Windows: Intel WiDi, Miracast, dsb.


!

CATATAN

- Tergantung pada perangkat yang Anda gunakan, koneksi nirkabel mungkin lemah atau tidak stabil. Dalam hal ini, buat perubahan pada **Grup** untuk meningkatkan koneksi.
- Tergantung pada lingkungan jaringan, koneksi nirkabel mungkin lemah atau tidak stabil. Dalam hal ini, tekan tombol **SETTINGS** pada kontrol jarak jauh dan ubah pengaturan program di **NIRKABEL** → **SCREEN SHARE** → **Program** → **Manual**.
 - Disarankan menggunakan gelombang 5,0 GHz. (Hanya model yang Mendukung 5,0 GHz)

Untuk menghubungkan perangkat pintar (smartphone, tablet, dsb) ke proyektor menggunakan koneksi kabel

Hubungkan perangkat pintar ke proyektor menggunakan kabel* dan atur input eksternal proyektor ke HDMI. Layar perangkat pintar akan ditampilkan melalui proyektor.
Untuk petunjuk model yang spesifik mengenai penggunaan koneksi kabel, silakan tanyakan kepada pabrikan perangkat pintar.
Perangkat pintar yang didukung dapat berubah tergantung pada keadaan masing-masing pabrikan.
* Contoh tentang cara menghubungkan kabel ke perangkat pintar yang berbeda (kabel dibeli terpisah)



* Gambar mungkin tampak berbeda dari produk sesungguhnya.

Untuk Menghubungkan Perangkat Audio Bluetooth (Speaker/Headset)

Fitur Bluetooth di proyektor mencari perangkat audio Bluetooth terdekat dan memungkinkan Anda menghubungkan proyektor ke perangkat Bluetooth yang diinginkan secara nirkabel, jadi Anda dapat mendengar audio dari proyektor lewat perangkat audio Bluetooth yang Anda inginkan.
Berikut ini adalah cara menghubungkan perangkat audio Bluetooth:
* Menu dalam gambar mungkin berbeda dari produk sebenarnya.

!

CATATAN


- Fungsi Bluetooth adalah untuk menghubungkan produk ke speaker Bluetooth atau headset Bluetooth. Anda tidak dapat menghubungkan produk ke ponsel melalui fungsi Bluetooth.

Cari Perangkat

- 1 Tekan tombol **SETTINGS** pada remote control dan atur **AUDIO** → **Output Suara** → **Bluetooth**.
- 2 Atur perangkat audio Bluetooth pilihan ke Mode pasangan.
(Untuk informasi cara mengatur Mode pasangan, lihat manual perangkat audio Bluetooth Anda.)
- 3 Pilih opsi **Cari Perangkat** untuk mencari perangkat yang ingin dihubungkan. (Waktu pencarian total sekitar 15 detik. Ketika perangkat pilihan muncul dalam daftar, Anda dapat menghentikan pencarian dengan memilih **Stop Pencarian**. Waktu yang diperlukan untuk menyambung ke perangkat mungkin berbeda bergantung pada kekuatan sinyal dan jumlah perangkat.)

Daftar perangkat terdaftar


Perangkat audio Bluetooth yang sudah terhubung ke produk Anda setidaknya sekali otomatis ditambahkan ke **Daftar perangkat terdaftar** jadi Anda bisa memilih dan menghubungkan perangkat yang diinginkan tanpa perlu mencari lagi nantinya. Berikut ini adalah cara menghubungkan perangkat audio Bluetooth:
* Menu dalam gambar mungkin berbeda dari produk sebenarnya.
1 Tekan tombol **SETTINGS** pada remote control dan atur **AUDIO** → **Output Suara** → **Bluetooth**.
2 Pilih **AUDIO** → **Output Suara** → **Daftar perangkat terdaftar**.
(Pastikan perangkat audio Bluetooth pilihan sudah dihidupkan.)



!

CATATAN

- Apabila Bluetooth dalam posisi Aktif saat Anda menghidupkan proyektor, perangkat Bluetooth yang baru-baru ini terhubung akan otomatis dihubungkan. Meski begitu, perangkat audio Bluetooth memiliki fitur mati sendiri secara otomatis, jadi pastikan perangkat audio Bluetooth dihidupkan terlebih dahulu. (Untuk informasi lebih lanjut, lihat manual perangkat audio Bluetooth Anda.)
- Apabila layar tidak sinkron dengan suara perangkat audio Bluetooth, sesuaikan sinkronisasi dengan opsi **Sesuaikan Sinkronisasi AV**.
- Sebaiknya jaga jarak antara proyektor dengan perangkat Bluetooth yang tersambung sejauh 5 m.



- 4 Pilih perangkat yang ingin dihubungkan setelah pencarian selesai, lalu perangkat audio Bluetooth akan tersambung dan ditambahkan ke **Daftar perangkat terdaftar** secara otomatis.