

88BH7D

ENGLISH Easy Setup Guide







Please read this manual carefully before operating your set and retain it for future reference.

FRANÇAIS Guide de configuration rapide

Veuillez lire ce manuel attentivement avant d'utiliser l'appareil et conservez-le pour pouvoir vous y reporter ultérieurement.

ESPAÑOL Guía Rápida

Lea atentamente este manual antes de poner en marcha el equipo y consérvelo para futuras consultas.



* M F L 7 0 2 8 4 4 0 2 *

(1905-REV02)

**ENGLISH**

You can download the web manuals for this product at the following websites. (Keyword : BH7D)

FRANÇAIS

Vous pouvez télécharger les guides pour ce produit à partir des sites Web suivants. (Mot-clé : BH7D)

ESPAÑOL

Puede descargar los manuales web de este producto en los siguientes sitios web. (Palabra clave : BH7D)

- www.lg.com/id-manual



SuperSign : <http://partner.lge.com>



ENGLISH

Dimensions (Width x Height x Depth) / Weight	88BH7D	Head	2158.3 mm x 611.2 mm x 103.9 mm / 34.2 kg (84.9 inches x 24.0 inches x 4.0 inches / 75.3 lbs)
--	--------	------	--

FRANÇAIS

Dimensions (largeur x hauteur x profondeur) / Poids	88BH7D	Écran	2 158,3 mm x 611,2 mm x 103,9 mm / 34,2 kg (84,9 po x 24,0 po x 4,0 po / 75,3 lb)
---	--------	-------	--

ESPAÑOL

Dimensiones (ancho x alto x profundidad) / Peso	88BH7D	Cabezal	2 158,3 mm x 611,2 mm x 103,9 mm / 34,2 kg
Alimentación	88BH7D	AC 100-240 V~ 50/60 Hz 5,5 A	

