



SIMPLE MANUAL

# Sound Bar

To view the instructions of advanced features, visit <http://www.lg.com> and then download Owner's Manual. Some of the content in this manual may differ from your unit.


MODEL  
SH2



\* M F L 6 9 4 8 0 2 1 0 \*



## Front Panel




- F** ..... Selects Function
- +** ..... Adjusts Volume
- ⏻** ..... Power On/Off

## 1 Subwoofer Connection

Place the subwoofer near the sound bar and follow steps below.

- 1 Press each plastic finger pad to open subwoofer terminals on the unit.
- 2 Connect the black stripe wire to the terminal marked - (minus) and the other end to the terminal (red tube) marked + (plus).




## Controller App



Download the **Music Flow Bluetooth** App to your device.


## Rear Panel



- SUB WOOFER (4Ω)** ..... Connect to a Subwoofer
- OPT. IN** ..... Connect to an Optical device

## 2 TV Connection

- 1 Connect the sound bar to the TV using Optical cable.
- 2 Set up [External Speaker (Optical)] on your TV setting menu.



## LG Sound Sync (Wireless)



For more information, download the online owner's manual. <http://www.lg.com>

## Additional Information

### Specification

|                                       |  |
|---------------------------------------|--|
| Power requirements                    | Refer to the main label.   |
| Power consumption                     | Refer to the main label.   |
|                                       | Networked standby : 0.5 W<br>(If all network ports are activated.) |
| Dimensions<br>(W x H x D)             | Approx.<br>880 mm x 62 mm x 90 mm                                  |
| Net Weight                            | Approx. 1.8 kg   |
| Amplifier<br>(Total RMS Output power) | 100 W  |

Design and specifications are subject to change without notice.

### Remote control



**ASC** **CINEMA** **STANDARD** : Selects sound effect.

\*ASC : Adaptive Sound Control

**DRC ON** **DRC OFF** : Makes comfortable sound at Dolby Digital.

**WOOFER LEVEL** **WOOFER LEVEL** : Adjusts the volume level of subwoofer.

**AUTO POWER ON** **AUTO POWER OFF** : Automatically turns on by an input source : Optical, **Bluetooth**, LG TV

### How to disconnect the wireless network connection or the wireless device

Set up the AUTO POWER ON/OFF function to off and turn off the unit.

### Replacement of battery

