

ENGLISH

**Specification**

**Power requirements**

- Refer to the main label.

**Power consumption**

- Refer to the main label.

Dimensions (W x H x D): Approx. 1200.0 mm x 97.0 mm x 145.0 mm

Amplifier (Total RMS Output power): 800 W RMS

**Open Source Software Notice Information**

To obtain the source code that is contained in this product, under GPL, LGPL, MPL, and other open source licenses that have the obligation to disclose source code, and to access all referred license terms, copyright notices and other relevant documents, please visit <https://opensource.lge.com>.

LG Electronics will also provide open source code to you on CD-ROM for a charge covering the cost of performing such distribution (such as the cost of media, shipping, and handling) upon email request to [opensource@lge.com](mailto:opensource@lge.com).

This offer is valid to anyone in receipt of this information for a period of three years after our last shipment of this product.

**After Sales Service (Egypt Only)**

Shelf Life Time : 2 Years

*LG is committed to providing all spare parts of this device during the shelf life time.*

العربية

**المواصفة**

**مطالبات الطاقة**

- ارجع إلى الملصق الرئيسي.

**استهلاك الطاقة**

- ارجع إلى الملصق الرئيسي.

الأبعاد (العرض × الارتفاع × العمق): تقريرًا ١٢٠٠،٠ مم × ٩٧٠،٠ مم × ١٤٥،٠ مم

مكبر (أجمالي طاقة خرج RMS): ٨٠٠ وات

**معلومات حول أشعار البرامج مفتوحة المصدر**

للحصول على التعليمات البرمجية لل مصدر ضمن GPL، LGPL، MPL، وMPL، والحصول على التراخيص مفتوحة المصدر الأخرى التي لديها التزامات للكشف عن التعليمات البرمجية الخاصة بال مصدر، المضمنة في هذا المنتج، وللحصول إلى كل أحكام الترخيص المشار إليها، وإشعارات حقوق النشر وكل الوثائق ذات الصلة، يرجى زيارة <https://opensource.lge.com>.

توفر LG Electronics أيضًا التعليمات البرمجية المفتوحة المصدر على قرص CD-ROM مقابل رسوم يغطي بخلاف القيمة بهذا التوزيع (مثل تكلفة وسائل النقل والشحن والتوصيل) بناءً على طلب يرسل عبر البريد الإلكتروني إلى [opensource@lge.com](mailto:opensource@lge.com).

يسري هذا العرض لأي شخص يتسلم هذه المعلومات لمدة ثلاثة سنوات بعد آخر عملية شحن لهذا المنتج.

**خدمة ما بعد البيع (مصر فقط)**

العمر الافتراضي: سنتان

تلتزم شركة LG بتوفير جميع قطع الغيار الخاصة بهذه الأجهزة خلال فترة العمر الافتراضي.



Life's Good

الدليل البسيط

# ساوند بار لاسلكي

WIRELESS SOUND BAR

SH7Q



www.lg.com  
حقوق النشر والتأليف © لعام ٢٠٢٣ LG Electronics Inc. جميع الحقوق محفوظة.



MFL71894826  
2204\_Rev01

## ENGLISH Installing and Using the Product

Please read this manual carefully before operating your set and retain it for future reference. To view the instructions of advanced features, visit <http://www.lg.com> or scan QR code and then download Owner's Manual. Some of the content in this manual may differ from your product.



(A) Sound bar

(B) Status Display / Remote Control Receiver

(C) Wireless Subwoofer - Install it close to the sound bar.

**1** Connect the sound bar to your TV via an optical cable or an HDMI cable.

**2** Connect to power in the following order: wireless subwoofer → sound bar. Then, turn on the sound bar. When the connection is automatically established with the sound bar, the LED on the wireless subwoofer will light up green.

**3** Using the product with your TV

① Press the **Function** button repeatedly until "OPT/HDMI ARC" appears on the status display.

② On your TV's settings, set the output speaker to [HDMI ARC], [Optical], or [External Speaker].

③ When the TV is properly connected to the product, "OPT" or "ARC" will appear on the status display with a sound.

**4** Connecting the product to your smartphone via Bluetooth

① Tap the **Settings** button on your smartphone and select **Bluetooth**. Turn on the **Bluetooth** function. (Off > On)

② Press the **Bluetooth pair** button. After a moment, you will see "BT READY" on the status display.

③ Find and tap the product on your smartphone. The product appears as "LG SH7Q (XX)".

④ When the product is connected to your smartphone via **Bluetooth**, you can see the status display change from "PAIRED" → "Connected Bluetooth device name" → "BT".

**5** Connecting to the LG Sound Bar app

① Find and install the **LG Sound Bar** app on Google Play or App Store from your smartphone.

② You can get more information regarding its use by selecting [Help] in [Setting].



If you see a red LED on the front of the wireless subwoofer, it means that the sound bar is not connected to the subwoofer. If this is the case, connect them in the following order.

① Press the **Power** button on the sound bar to turn it off.

② Press the **PAIRING** button on the back of the disconnected wireless subwoofer. Check if LED blinks green.

- If you still see a red LED on the front of the wireless subwoofer, press and hold the button on the back of the subwoofer again.

③ Press the **Power** button on the sound bar to turn it on.

④ When the connection is established, you will see a green LED light on the front of the wireless subwoofer.

\* Keep the sound bar and the subwoofer away from the device (ex. wireless router, microwave oven, etc.) over 1 m to prevent wireless interference.


\* Some speakers may not make sound depend on the input source. Select CINEMA sound mode to listen through all speakers.

• Design and specifications are subject to change without notice.

• Google Play is a trademark of Google LLC.

## العربية تركيب المنتج واستخدامه

نُرجو قراءة هذا الدليل بعناية قبل تشغيل الجهاز، والاحتفاظ به للرجوع إليه فيما بعد. لعرض إرشادات الميزات المتقدمة، قم بزيارة <http://www.lg.com> أو قم بمسح رمز الاستجابة السريعة ضوئيًا ثم قم بتنزيل دليل المالك. قد تختلف بعض محتويات هذا الدليل عن منتجك.



(A) مكبر الصوت

(B) شاشة عرض الحالة / جهاز استقبال التحكم عن بعد

(C) مضخم صوت لا سلكي - قم بتركيبه بجوار مكبر الصوت.

**1** قم بتوسيع مكبر الصوت بجهاز التلفزيون عبر كبل بصري أو كبل HDMI.

**2** قم بتوسيع الطاقة بالترتيب التالي: مضخم الصوت اللاسلكي ← مكبر الصوت. عند إنشاء الاتصال بمكبر الصوت تلقائيًا، سيضيئ مصباح LED الموجود على مضخم الصوت اللاسلكي باللون الأخضر.

**3** استخدام المنتج مع التلفزيون

① اضغط على زر **وظيفة** (B) بشكل متكرر حتى يظهر «OPT/HDMI ARC» على شاشة عرض الحالة.

② من إعدادات التلفزيون، قم بضبط سماعة الآخراج على [HDMI ARC] أو [صاري] أو [السماعة الخارجية].

③ عند توصيل التلفاز بالمنفذ بالمنفذ صحيح، تظهر «OPT» أو «ARC» على شاشة عرض الحالة مع صوت.

**4** توصيل الوحدة بهاتف ذكي عبر Bluetooth

① انقر فوق زر **الإعدادات** (B) على هاتف ذكي وحدد **Bluetooth**. قم بتشغيل **Bluetooth** (B). (إيقاف تشغيل < تشتغل)

② انقر على زر **اقران** (B). بعد لحظة، سيظهر «BT READY» (B) على شاشة عرض الحالة.

③ أبحث عن المنتج وانقر عليه على هاتف ذكي. يظهر المنتج كـ «LG SH7Q (XX)».

④ عند توصيل المنتج بهاتف ذكي عبر Bluetooth، يمكنك مشاهدة شاشة عرض الحالة وهي تتغير من «PAIRED»

«BT».

**5** الاتصال بتطبيق LG Sound Bar

① ابحث عن تطبيق **LG Sound Bar** وثبتة في متجر Google Play أو App Store من هاتف ذكي.

② يمكنك الحصول على المزيد من المعلومات حول استخدامه من خلال تحديد [Help] (المساعدة) في [Setting] (الإعدادات).



إذا رأيت مؤشر LED الموجود في واجهة مضخم الصوت اللاسلكي يضيء باللون الأحمر، فيعني هذا أن مكبر الصوت غير متصل بالسماعات. في هذه الحالة، قم بتوسيعه بالترتيب التالي.

اضغط على زر **الطاقة** (B) في مكبر الصوت لإيقاف تشغيله.

② اضغط على زر **PAIRING** الموجود في الجزء الخلفي من مضخم الصوت اللاسلكي غير المتصل. تتحقق مما إذا كان مصباح LED يومض باللون الأخضر.

- إذا كنت لا تزال ترى مؤشر LED الموجود في واجهة مضخم الصوت اللاسلكي يضيء باللون الأحمر، فاضغط مطردًا على الزر الموجود في الجزء الخلفي من مضخم الصوت مجددًا.

③ اضغط على زر **الطاقة** (B) في مكبر الصوت لتشغيله.


④ عندما يتم إنشاء الاتصال، ستتجدد أن مؤشر LED الموجود في واجهة مضخم الصوت اللاسلكي يضيء باللون الأخضر.

\* أبعد مكبر الصوت ومضخم الصوت عن الجهاز (على سبيل المثال: الموجة أو قرن الميكرويف وما إلى ذلك) بمسافة تزيد على 1 متر لمنع التداخل اللاسلكي.


\* قد لا تجعل بعض المكبرات الصوت يعتمد على مصدر الإدخال. حدد وضع صوت CINEMA (السينما) لاستئناف عبر كل مكبرات الصوت.

• يخص تصميم والمواصفات للتغيير دون إشعار مسبق.

• Google Play هي العلامة التجارية لشركة Google LLC.



استبدال البطارية  
Replacement of Battery



HDMI™  
HIGH-DEFINITION MULTIMEDIA INTERFACE