



SIMPLE MANUAL

Wireless
Sound Bar


Please read this manual carefully before operating your set and retain it for future reference.
To view the instructions of advanced features, visit <http://www.lg.com> and then download Owner's Manual. Some of the content in this manual may differ from your unit.

MODEL
GX




www.lg.com
Copyright © 2020 LG Electronics Inc. All Rights Reserved.

ENGLISH




Front Panel



⏻ (Standby)Switches the unit ON or OFF.
F (Function)Selects function.
+/- (Volume) Adjusts volume.

Rear Panel



DC IN Connect to the AC adapter.
USB PortConnect to a USB device.
OPTICAL INConnect to an optical device.
HDMI INConnect to device with HDMI OUT.
HDMI OUT (TV eARC/ARC) Connect to a TV.

Make sure to properly align and connect the optical cable; improper alignment may cause damage to the jack.

Rear Speakers Ready
Ready for surround sound with Rear Speakers Kit sold separately. (SPK8-S)

Subwoofer Connection

Place the wireless subwoofer near the sound bar and follow steps below.

- 1 Connect the power cord of the sound bar and the wireless subwoofer to the outlet.
 - The sound bar and wireless subwoofer will be **automatically** connected. The subwoofer's green LED turns on.
- 2 Turn on the sound bar.

Manual Subwoofer Connection

If the subwoofer does not make sound, try to connect manually.

- 1 Press **PAIRING** on the rear of the wireless subwoofer.
 - The green LED on the rear of the wireless subwoofer blinks quickly. (If the green LED does not blink, press and hold the **PAIRING**.)
- 2 Turn on the sound bar.
 - Pairing is completed. The green LED on the rear of the wireless subwoofer turns on.


Keep the sound bar and the subwoofer away from the device (ex. wireless router, microwave oven, etc.) over 1 m to prevent wireless interference.

TV Connection

Connect the sound bar and TV using Optical (A) or HDMI ARC (B).


A Optical Connection

- 1 Connect the sound bar to the TV using Optical cable.
- 2 Set up [External Speaker (Optical)] on your TV setting menu.



B HDMI (ARC) Connection


- 1 Connect the sound bar to the TV using HDMI cable.
- 2 Set up [External Speaker (HDMI ARC)] on your TV setting menu.



- HDMI connection is unavailable if your TV does not support HDMI ARC.
- If this unit is connected by OPTICAL and ARC at the same time, the ARC signal has a higher priority.


Additional Device Connection

- 1 Connect to the external device like as follow.




- 2 Set the input source by pressing **F** repeatedly.

Remote control



Replacement of Battery



⏮/⏭: Skip/Search

⏸: Play/Pause

- **Bluetooth connection lock (BT LOCK):** Select the **Bluetooth** function by pressing **F** repeatedly. Long press **⏸** and press it again to limit Bluetooth connection to only BT and LG TV.

SOUND EFFECT: Selects a sound effect mode.

- **TV remote:** Long press **SOUND EFFECT** and press it again to use TV remote control.

FOLDER ^/∨: Searches a folder.

⌚: Displays the information of a file, an input source or connected **Bluetooth** device name.

- **Auto Power ON/OFF:** Long press ⌚ and press it again.

🔊: Adjusts sound level of each speaker.

- **Surround sound:** Long press 🔊 and press it again.

REPEAT: Listens to your files repeatedly or randomly.

This product provides screws and wall plugs to fix the wall bracket to the wall. Please check the installation method through Owner's manual on the website (www.lg.com).

Additional Information


Specification

Power consumption	Refer to the main label.
AC adapter	• Model : DA-50F25 • Manufacturer : Asian Power Devices Inc. • Input : 100 - 240 V ~ 50 - 60 Hz • Output : 25 V $\equiv$ 2 A
Dimensions (W x H x D)	Approx. 1446.0 mm x 150.0 mm x 32.5 mm
Bus Power Supply (USB)	5 V $\equiv$ 500 mA
Amplifier (Total RMS Output power)	420 W RMS

Design and specifications are subject to change without notice.

Installing the stand

Fix the hooks of the unit on the stands as shown below.



When installing the sound bar with a stand, install it so that it does not cover the TV's remote sensor or screen.

To enjoy content containing Dolby Atmos® and DTS:X®, the connected device and content must support Dolby Atmos® and DTS:X®.

OPEN SOURCE SOFTWARE NOTICE
INFORMATION

To obtain the source code under GPL, LGPL, MPL, and other open source licenses, that is contained in this product, please visit <http://opensource.lge.com>. In addition to the source code, all referred license terms, warranty disclaimers and copyright notices are available for download.

LG Electronics will also provide open source code to you on CD-ROM for a charge covering the cost of performing such distribution (such as the cost of media, shipping, and handling) upon email request to opensource@lge.com.

This offer is valid for a period of three years after our last shipment of this product. This offer is valid to anyone in receipt of this information.

Declaration of Conformity



Hereby, LG Electronics declares that the radio equipment type Wireless Sound Bar is in compliance with Directive 2014/53/EU. The full text of the EU declaration of conformity is available at the following internet address:

<http://www.lg.com/global/support/cedoc/cedoc#>

For consideration of the user, this device should be installed and operated with a minimum distance of 20 cm between the device and the body.

IMPORTANT SAFETY NOTICE

The cord grip for the plug fitted to this product is built into the existing power cord as supplied. If, for any reason you need to shorten the cord,

DO NOT RE-USE THE PLUG

A new plug must be used to ensure your continued safety by securing the plug to the power cord in accordance with Plug & Socket Regulations 1994.





簡易手冊

無線 Sound Bar


操作該裝置之前，請仔細閱讀此說明書。及保存此說明書作將來參考之用。
要查看進階功能的指示，請瀏覽 <http://www.lg.com> 並下載使用說明書。
此手冊中部份內容可能不適用於此器材上。

型號
GX




www.lg.com
版權所有 © 2020 LG Electronics Inc. 保留一切權利。

中文




前面板



⏻ (待命) 把機件啟動或關閉
F (功能) 選擇功能
+/- (音量) 調整音量

後面板



DC IN 連接 AC 電源轉接器。
USB 端口 連接至 USB 裝置。
OPTICAL IN 連接至光纖裝置。
HDMI IN 連接其他裝置的HDMI OUT。
HDMI OUT (TV eARC/ARC) 連接至電視。

❗ 如果光纖線沒有按照正確的方向連線，光纖接頭可能遭到損壞。

❗ **可連接後置揚聲器**
支援接駁另購後置揚聲器營造環迴音效。(SPK8-S)

無線超低音揚聲器連接

把無線超低音揚聲器放置在Sound Bar附近並按照以下步驟操作。


- ❶ 把Sound Bar及無線重低音揚聲器的電源線連接到電源插座。
 - Sound bar 與無線超低音揚聲器會自動連接。超低音揚聲器的綠燈亮起。

手動連接超低音揚聲器

若重低音擴音器不能發出聲響，嘗試手動連接。

- ❶ 按下無線低音炮後方 **PAIRING**。
 - 無線超低音揚聲器的後方之綠色LED燈會快速地閃爍。(如綠色 LED 燈無閃動，按下 **PAIRING** 並按住。)
- ❷ 開啓Sound Bar。
 - 配對完成。無線超低音揚聲器的後方之綠色LED燈就會啟動。

❗ 請勿把Sound Bar和超低音揚聲器放置於其他電子器材（如無線網絡路由器、微波爐等）的一米範圍內，以免出現無線訊號干擾。




電視連接

透過視像(A) 或 HDMI ARC (B) 纜線連接揚聲器和電視。


A 光纖連接

- ❶ 透過光纖線將Sound Bar連接至電視。
- ❷ 設定 [外置揚聲器 (光纖)]，可在您的電視設定功能表上找到。



B HDMI (ARC) 連接


- ❶ 透過 HDMI 纜線連接Sound Bar至電視。
- ❷ 設定 [External Speaker (HDMI ARC)]，可在您的電視設定功能表上找到。



- ❗ 如您的電視不支援 HDMI ARC，您將不能使用 HDMI 連接。
- 若裝置同時連接 OPTICAL 和 ARC，ARC訊號將更為優先。

連接至額外電子裝置


- ❶ 連接外置電子裝置的程序如下。



- ❷ 反覆按下 **F** 設定輸入資源。

遙控器

更換電池



⏮/⏭：跳過/搜索

⏸：播放/暫停

- **藍牙連接鎖 (BT LOCK)**: 重複按 **F** 可選擇藍牙功能。長時間按下 **⏸** 並再次按下，以限制藍牙連結 BT 與 LG TV。

SOUND EFFECT：選擇音效模式。

- **電視遙控**：長時間按下 **SOUND EFFECT** 並再次按下，以使用電視遙控。

FOLDER ^/∨：搜索資料夾。

Ⓜ：顯示文檔資訊、輸入資源或已連結藍牙設備名稱。

- **自動開機/關機**：長時間按下 **Ⓜ** 並再次按下。

🔊：調節每個揚聲器的音量。

- **環迴音效**：長時間按下 **🔊** 並再次按下。

REPEAT：重複或隨機播放你的文檔。

❗ 本產品提供螺絲及牆塞以便將掛牆架固定於牆上。請瀏覽網站 (www.lg.com) 的用戶手冊之安裝方法。

其他資訊


規格

電源耗用	請參閱主要標籤。
AC 轉接器	• 型號：DA-50F25 • 製造商：Asian Power Devices Inc. • 電源輸入：100 - 240 V ~ 50 - 60 Hz • 電源輸出：25 V $\equiv$ 2 A
尺寸 (闊 x 高 x 深)	大約 1446.0 毫米 X 150.0 毫米 X 32.5 毫米
匯流排電源供應 (USB)	5 V $\equiv$ 500 mA
擴音器 (總 RMS 輸出功率)	420 W RMS

如設計及規格有任何變更，恕不另行通告。

安裝支架

如下圖所示，將本機的鉤扣固定在支架上。



❗ 在安裝帶有支架的條形揚聲器時，不要擋住電視的遙控感應器或屏幕。

要享受包含 Dolby Atmos® 和 DTS:X® 的內容，所連線的裝置和內容必須支援 Dolby Atmos® 和 DTS:X®。

開放原始碼軟體注意事項

若要依據 GPL、LGPL、MPL 及其他開放原始碼授權取得對應的原始碼，請瀏覽 <http://opensource.lge.com>。
除了開放原始碼，所有涉及的授權條款、免責聲明和版權聲明均可供下載。
LG 電子也可應您要求，在由您支付相關費用（如媒體成本、運費及處理費）的條件下以 CD-ROM 方式提供開放原始程式碼，如有需要請寄送電子郵件至 opensource@lge.com。
此服務提供的有效期限為本產品最後裝運日起計算的三年。此服務提供的有效對象為收到此資訊的任何人。

符合性聲明



在此，LG電子聲明 無線條形音箱類型的無線電設備符合 2014/53/EU指令。你可以從以下互聯網地址獲得歐盟符合性聲明的全文：

<http://www.lg.com/global/support/cedoc/cedoc#>

為了使用者的考慮，安裝和使用設備時，設備需和身體之間保持最少20厘米距離。

安全注意事項

本機的插頭握柄是專為本產品所設計，且與附贈的電源線結合為一體，若您因為任何理由而需截短此電源線時

請勿再使用該插頭

應使用全新的插頭以確保連續使用之安全性。請依據1994年之插頭及插座規範的規定，將插頭確實地與電源線結合。

