





MFL71179904










(1903-REV00)





















*UM7300PWA

www.lg.com



- 繁體中文
- 簡易設定指南
 - 操作電視機之前，請先詳細閱讀本手冊，並妥善保管手冊以供日後參考。
 - 請閱讀安全與相關資訊





型號		70UM7300PWA	65UM7300PWA
尺寸 (寬 x 高 x 深)	含底座 (公釐)	1,578 x 984 x 299	1,463 x 914 x 269
	不含底座 (公釐)	1,578 x 913 x 91.1	1,463 x 850 x 87.8
重量	含底座 (公斤)	31.4	21.6
	不含底座 (公斤)	30.7	21.3
電源需求		AC 110 V ~ 60 Hz	
型號		55UM7300PWA	49UM7300PWA
尺寸 (寬 x 高 x 深)	含底座 (公釐)	1,244 x 786 x 231	1,110 x 709 x 231
	不含底座 (公釐)	1,244 x 726 x 87.1	1,110 x 650 x 81.1
重量	含底座 (公斤)	14.5	11.3
	不含底座 (公斤)	14.3	11.1
電源需求		AC 110 V ~ 60 Hz	