



SIMPLE MANUAL

Multimedia
Speaker System

Please read this manual carefully before operating your set and retain it for future reference.
To view the instructions of advanced features, visit <http://www.lg.com> and then download Owner's Manual. Some of the content in this manual may differ from your unit.

MODEL
LK72B



www.lg.com
Copyright © 2019 LG Electronics Inc. All Rights Reserved.
1805_Rev01

ENGLISH



CAUTION
RISK OF ELECTRIC SHOCK
DO NOT OPEN



CAUTION: TO REDUCE THE RISK OF ELECTRIC SHOCK DO NOT REMOVE COVER (OR BACK) NO USER-SERVICEABLE PARTS INSIDE. REFER SERVICING TO QUALIFIED SERVICE PERSONNEL.



This lightning flash with arrowhead symbol within an equilateral triangle is intended to alert the user to the presence of uninsulated dangerous voltage within the product's enclosure that may be of sufficient magnitude to constitute a risk of electric shock to persons.



The exclamation point within an equilateral triangle is intended to alert the user to the presence of important operating and maintenance (servicing) instructions in the literature accompanying the product.

WARNING: TO PREVENT FIRE OR ELECTRIC SHOCK HAZARD, DO NOT EXPOSE THIS PRODUCT TO RAIN OR MOISTURE.

WARNING: Do not install this equipment in a confined space such as a book case or similar unit.

CAUTION: Do not use high voltage products around this product. (ex. Electrical swatter) This product may malfunction due to electrical shock.

CAUTION: Do not block any ventilation openings. Install in accordance with the manufacturer's instructions.
Slots and openings in the cabinet are provided for ventilation and to ensure reliable operation of the product and to protect it from over heating. The openings should never be blocked by placing the product on a bed, sofa, rug or other similar surface. This product shall not be placed in a built-in installation such as a bookcase or rack unless proper ventilation is provided or the manufacturer's instruction has been adhered to.

CAUTION concerning the Power Cord
The Power Plug is the disconnecting device. In case of an emergency, the Power Plug must remain readily accessible.

CAUTION: The apparatus should not be exposed to water (dripping or splashing) and no objects filled with liquids, such as vases, should be placed on the apparatus.

NOTICE: For safety marking information including product identification and supply ratings, please refer to the main label on the bottom or the other surface of the product.

CAUTION: No naked flame sources, such as lighted candles, should be placed on the apparatus.

- The appliance is not intended for use by young children or infirm persons without supervision.
- Young Children should be supervised to ensure that they do not play with appliance.
- If the appliance is supplied from a cord extension set or an electrical portable outlet device, the cord extension set on electrical portable outlet device must be positioned so that it is not subject to splashing (of water or any form of liquid) or ingress of moisture.



RF Radiation Exposure Statement

This equipment shall be installed and used at a minimum distance of 20 cm from the human body.


Symbols

~	Refers to alternating current (AC).
≡	Refers to direct current (DC).
⊞	Refers to class II equipment.
⏻	Refers to stand-by.
I	Refers to "ON" (power).
⚡	Refers to dangerous voltage.





Front Panel



- 1

Remote sensor
- 2

SD card slot

You can play sound files by connecting the SD card.
- 3

(Standby)

Turns the power on or off.

F (Function)

Selects the function and input source.
- 4

VOL (Volume) **-/+**

Adjusts speaker volume.

⏮ / ⏭ (Skip/Search)

- Skips backward or forwards.

- Searches for a section within a file.

- Selects the radio stations.

⏮ (Play/Pause)

Starts or pauses playback.

BASS **-/+**


Adjusts bass level.
- 5

USB port

You can play sound files by connecting the USB device.
- 6

Display window

Rear Panel



- 1

AUX IN (L/R)


Connect an auxiliary device.
- 2

FRONT SPEAKERS (FL/FR) connector
- 3

POWER IN
- 4

FM ANTENNA

Speaker Connection



Additional information

LED Display table

LED displays and descriptions are as belows.

LED Display	Description
HELLO	HELLO
bye	BYE
USB	USB
Sd	SD
AUX AUDIO	AUX
PORTABLE AUDIO	PORTABLE
BT	BT
87.50	FM (Displays current radio frequency)
READ	
PAUSE	PAUSE
ONE	ONE
ALL	ALL
RAND	RANDOM
DEL ALL	DEL ALL
DELETED ALL	DELETED ALL
NO USB	NO USB
NO Sd	NO SD
NO SONG	NO SONG
NOT SUPPORT	NOT SUPPORT

Specifications

Power Requirements	Refer to the main label on the unit.
Power Consumption	Refer to the main label on the unit.
Dimensions (W x H x D)	Approx. 196.0 mm x 239.0 mm x 205.0 mm
Bus Power Supply (USB)	5 V 500 mA
Amplifier (Total RMS output power)	40 W RMS

Design and specifications are subject to change without notice.

Replacement of battery

